



Fibre Labelling

Polypropylene/polyamide bicomponent - Aquafil

FINAL REPORT
Administrative Arrangement N. 2007-30291
Analysis conducted on behalf of DG ENTERPRISE

P. Piccinini, R. Álvarez-Sarandes, M. de Sertorio, M. Trantallidi



EUR 24574 EN - 2010

The mission of the JRC-IHCP is to protect the interests and health of the consumer in the framework of EU legislation on chemicals, food, and consumer products by providing scientific and technical support including risk-benefit assessment and analysis of traceability.

European Commission
Joint Research Centre
Institute for Health and Consumer Protection

Contact information

Address: Paola Piccinini, T.P. 260, via E. Fermi 1, Ispra (VA), 21020, Italy
E-mail: paola.piccinini@jrc.it
Tel.: 0039-0332-789124
Fax: 0039-0332-785707

<http://ihcp.jrc.ec.europa.eu/>
<http://www.jrc.ec.europa.eu/>

Legal Notice

Neither the European Commission nor any person acting on behalf of the Commission is responsible for the use which might be made of this publication.

***Europe Direct is a service to help you find answers
to your questions about the European Union***

Freephone number (*):

00 800 6 7 8 9 10 11

(*) Certain mobile telephone operators do not allow access to 00 800 numbers or these calls may be billed.

A great deal of additional information on the European Union is available on the Internet.
It can be accessed through the Europa server <http://europa.eu/>

JRC 61247

EUR 24574 EN
ISBN 978-92-79-17456-8
ISSN 1018-5593
doi:10.2788/36853

Luxembourg: Publications Office of the European Union

© European Union, 2010

Reproduction is authorised provided the source is acknowledged

Printed in Italy

TABLE OF CONTENTS

| | |
|--|-----------|
| 1. EXECUTIVE SUMMARY | 1 |
| 2. INTRODUCTION | 5 |
| 3. BACKGROUND INFORMATION | 9 |
| 4. TEST METHODS FOR IDENTIFICATION OF THE NEW FIBRE | 13 |
| 4.1 Microscopy | 13 |
| 4.2 Fourier Transform Infrared Spectroscopy | 16 |
| 4.3 Differential Scanning Calorimetry | 21 |
| 5. TEST METHODS FOR QUANTIFICATION OF THE NEW FIBRE | 25 |
| 5.1 Influence of drying conditions on PAC | 25 |
| 5.2 Pre-treatment | 29 |
| 5.3 Agreed allowance | 31 |
| 5.4 Solubility properties | 32 |
| 5.4.1 Influence of drying conditions on solubility properties of PAC | 38 |
| 5.5 Quantification of PA6 in PAC | 42 |
| 5.5.1 Elemental analysis | 43 |
| 5.5.2 Hydrolysis method | 44 |
| 5.5.3 DSC method | 45 |
| 5.5.4 FT-IR method | 49 |
| 5.5.5 Chemical methods | 53 |
| 5.6 Quantification of binary mixtures PA6/PAC and PP/PAC | 55 |
| 5.6.1 Manual separation | 55 |
| 5.6.2 DSC method | 58 |
| 5.6.3 Chemical analysis | 62 |
| 5.6.3.1. Method 11 of Directive 96/73/EC | 62 |
| 5.6.3.2. Method 16 of Directive 96/73/EC | 63 |
| 5.6.4. Densitometric method combined with method 16 of Dir. 96/73/EC | 65 |
| 6. COLLABORATIVE TRIAL | 69 |
| 6.1 Design of the collaborative trial | 70 |
| 6.2 Homogeneity study | 70 |
| 6.3 Results of the collaborative trial | 71 |
| 7. 11th ENNETL MEETING | 75 |
| 8. FURTHER EXPERIMENTAL WORK | 77 |
| 9. CONCLUSIONS | 79 |
| 10. REFERENCES | 83 |

| | |
|---|------------|
| 11. ANNEX I – Analytical methods proposed by the applicant | 85 |
| 12. ANNEX II – Microscopic analysis | 135 |
| 13. ANNEX III – Spectroscopic analysis | 143 |
| 14. ANNEX IV – DSC analysis | 151 |
| 15. ANNEX V – Analysis of composition | 159 |
| Influence of drying conditions on PAC | 160 |
| Pre-treatment with petroleum ether in Soxhtec | 161 |
| Agreed allowance | 164 |
| Influence of drying conditions on solubility properties of PAC | 168 |
| Solubility properties – <i>d</i> correction factors | 176 |
| Quantification of PA6 in PAC | 199 |
| Manual separation | 212 |
| Quantification of binary mixtures and carpet samples | 220 |

1. Executive Summary

In November 2005, the European Commission received a petition, presented by Aquafil S.p.A, for the establishment of a new generic fibre name, in accordance with Directive 96/74/EC (currently substituted by Directive 2008/121/EC). The proposed name was propylamidecomposite (PAC) and the suggested definition was the following: “a composite fibre composed of between 10 % and 45 % by mass of polyamide fibrils embedded in polypropylene matrix”. On 6th February 2006, the European Commission convened a meeting of the technical expert working group on Textile Labelling, comprised of governmental experts representing each member state. The application was considered justified and therefore, an amendment to the European legislation on textile names (Directive 2008/121/EC) and quantification of binary textile fibre mixtures (Directive 96/73/EC) would subsequently be prepared.

In August 2007, the European Commission’s Joint Research Centre (JRC) was entrusted by DG Enterprise (DG ENTR) to conduct experimental work regarding the validity and applicability of the testing methods proposed by the petitioner for the identification and quantification of the new fibre. Results of this study were presented and discussed during the 9th, 10th and 11th technical meetings of the European network of national experts on Textile Labelling (ENNETL), held in Ispra on 20th October 2008, 10th December 2009 and 15th July 2010.

Name and definition

Based on discussions held during the 11th ENNETL meeting and on written consultation with national experts, the name “*polypropylene/polyamide bicomponent*” was chosen for the new fibre, as it fulfils the criteria set up in 2002 by the Commission and the technical experts working group on Textile Labelling. According to these criteria, a generic name should not link the fibre to a specific manufacturer, it should be free of rights and it should inform consumers about the characteristics of the fibre. On the basis of the experimental results and the written opinion of experts, the definition agreed and proposed for the new fibre was: “*a bicomponent fibre composed of between 10 % and 25 % by mass of polyamide fibrils embedded in polypropylene matrix*”.

Identification methods

The experiments performed by the JRC and described in this report confirmed that test methods are available for the identification of the new fibre. Identification of PAC can be achieved using Scanning Electronic Microscope (SEM) analysis, after dissolving the polyamide fibrils with formic acid. In order to be able to distinguish PAC from binary mixtures polypropylene (PP) – polyamide (PA), Fourier Transform Infrared Spectroscopy (FT-IR) and Differential Scanning Calorimetry (DSC) can be used.

Parameters for quantification

For quantification purposes, ventilated oven can be used, instead of the vacuum one proposed by the applicant, as statistical evaluation showed that results could be considered equivalent in the two cases. The pre-treatment described in Directive 96/73/EC was proved to be applicable to the new fibre and its established mass loss due to pre-treatment (*b* correction factor) was 0 %. Experts decided to establish the value of 1.00 % for the *agreed allowance* of the new fibre, based on the experimental average value of 0.40 %. PAC was found to be insoluble in methods 1, 2, 5-11 and 14 and the following *d* correction factors were established: 1.00 for methods 1, 2, 5, 6, 8-10, 1.005 for method 11 and 1.01 for methods 7 and 14. Three of these correction factors (for methods 2, 8 and 11) were validated through a collaborative trial at European level on PAC 20 %. PP was proved to be insoluble in methods 1, 3, 5-11, 14 and 16 (*d* factor values 1.00 in all cases) and soluble in method 15. Polyamide 6 (PA6) was shown to be insoluble in methods 5 and 10 (*d* factor values 1.00 and 1.01, respectively) and soluble in methods 3, 7, 11 and 16. Experts agreed that all these parameters shall be inserted in Directive 96/73/EC, apart from the *d* correction factors for PA which were measured just on PA6.

Quantification methods (PA in PAC)

For the quantification of PA in PAC, three methods were proposed by the applicant: the first one was based on hydrolysis of the sample with hydrochloric acid solution, the second one on DSC analysis and the third one on FT-IR analysis. In addition, a series of chemical dissolution methods were tested. The PA content of PAC samples was determined *via* elemental analysis and these results were used as reference values to judge the accuracy of all the other methods.

The hydrolysis method was considered not accurate and very time-consuming. The DSC and FT-IR methods gave results in good agreement with the reference values,

but showed the disadvantage of requiring the availability of standards of PAC of various PA contents. For these reasons, none of the aforementioned methods was considered by the JRC and the network of national experts suitable to quantify PA in PAC. Among the tested chemical methods, method 16 of Directive 96/73/EC was proved to be the most accurate and non time-consuming. It was, therefore, proposed by the JRC and agreed by experts as the suitable method to quantify PA in PAC.

Quantification methods (binary mixtures)

For the quantification of PAC in binary mixtures, manual separation is an adequate technique, whenever applicable. In the case of binary mixtures of PAC with PA or PP, several alternative methods were studied. In order to judge their accuracy, results were compared to the ones obtained *via* manual separation. The DSC method did not provide accurate quantification of these binary mixtures.

In the case of binary mixtures PP/PAC, method 16 of Directive 96/73/EC was proved to be accurate. PA inside PAC could be solubilised by 90 % formic acid solution under the conditions of this method. However, the quantification of binary mixtures can be achieved only if the PA content of PAC is known. In an attempt to try to overcome this problem, a densitometric approach was used to separate PAC from PP/PAC binary mixtures, to allow the quantification of PA content in it; however, several problems were experienced leading to lack of repeatability.

Concerning binary mixtures PA/PAC, method 11 of Directive 96/73/EC was considered very accurate and was proposed by the JRC for quantification purposes. Under the conditions of this method, only the PA fibres in the binary mixture were solubilised by 75 % sulphuric acid and not the PA fibrils inside PAC. As agreed during the 10th ENNETL meeting, the JRC organised a collaborative trial to validate method 11, in accordance with the rules laid down in ISO 5725 (1994). Loop twisted carpet samples of three levels of concentration were used and 17 European laboratories took part in the exercise. On the basis of successful results, experts agreed that the field of application of method 11 in Directive 96/73/EC shall be extended to the quantification of the binary mixtures PA/PAC, with the addition of PAC as an insoluble fibre. Moreover, the modified washing procedure, needed to achieve a correct quantification of binary mixtures with high percentages of PA fibres, shall be added in the method's description together with the established precision of the analytical method, expressed as reproducibility limit (2 %).

2. Introduction

In November 2005, the company Aquafil S.p.A requested to the European Commission the establishment of a new generic fibre name under Directive 96/74/EC on textile names [1], now substituted by Directive 2008/121/EC [2], as they claimed the novelty of their new fibre. The new fibre was specifically designed for carpet applications, for which durability and high appearance retention is needed. The request was submitted on the basis of several aspects suggested by the petitioner, such as the fact that the new fibre presents high permanent stain resistance; the use of polluting solvents and staining resistance products could, therefore, be avoided. Moreover, dyeability, intrinsic bleach resistance and good mechanical performances are considered to be advantages of the new fibre. The applicant considered that no existing fibre definitions could be used due to the new chemical composition of the fibre; therefore, requested a new name with the following definition: “a composite fibre composed of between 10 % and 45 % by mass of polyamide fibrils embedded in polypropylene matrix”. The proposed name was propylamidecomposite (PAC).

PAC is made by a combination of two different incompatible polymers, polypropylene (hydrophobic properties) and polyamide (hydrophilic properties). It is produced *via* a blend reactive spinning process, which gives a characteristic microstructure of “islands-in-the-sea” type. The fibre is composed of short fibrils of polyamide (PA), embedded inside a polypropylene (PP) matrix. The fibrils have a length of up to 1 mm and a diameter of up to 0.5 μm . Each filament contains millions of reinforcing fibrils. During the reactive spinning process, by means of special additives (compatibiliser) and of specific temperatures in the melting zones, copolymers are produced at the boundaries, so that the strong chemical links avoid fibrillation of the two incompatible materials. PAC currently in production contains around 20 % of polyamide 6 (PA6).



“Islands-in-the-sea” structure (cross-section and longitudinal view).

According to the producer, the physical and chemical interaction of the components leads to the creation of a mix of properties that is not possible to achieve by using physical mixtures of the components. In fact, on the one hand, polypropylene fibres are characterised by high chemical inertia and very low moisture absorption, presenting, however, poor mechanical properties. On the other hand, polyamide fibres provide excellent mechanical properties and very good viscoelastic properties; however, their yarns are easily stained. The petitioner suggested that the uniqueness of the new fibre is that it combines the best properties of each polymer (very high stain resistance together with good mechanical performances), making it different from the existing fibres and interesting for the end-consumer. In addition, tests carried out at the ITCF Institute of Denkendorf (D) demonstrated that the fibre is characterised by good dyeability properties. It can be dyed using commercially available dyestuffs, with the resulting colour presenting good light and water fastness. Although the fibre is dyeable, at the same time it is claimed to be intrinsically inert against all common staining products. Its stain resistance remains even after washing, cleaning, abrasion or heating. It is, therefore, considered suitable to solve the major problem currently affecting the textile floor-covering market, i.e. hygiene and easy maintenance. Moreover, the inert polyolefin shield protects polyamide fibrils from chemical attack, such as bleach containing solutions.

The application was discussed for the first time on 6th February 2006 during a meeting of the technical expert working group on Textile Labelling, composed of member states' governmental experts associated with the Committee for Directives relating to Textile Names and Labelling. Based on the following agreed set of criteria, the group of experts considered that the petition was justified:

1. the new fibre should be radically different from other fibres by chemical composition and/or by manufacturing route and production process;
2. fibre characteristics can be taken into account, but need to be examined on a case by case basis;
3. the new fibre should be detectable and distinguishable from other fibres by standardised test methods;
4. consumer relevance should be shown by active commercial use of the fibre;
5. a new name is justified only if the fibre cannot be classified into existing groups.

The group judged that experimental work was needed to verify the applicability of the proposed analytical methods for identifying and quantifying PAC in blends. In fact,

validated test methods, enabling market surveillance authorities in member states to determine the composition of textile products containing the new fibre, should be established at European level. An amendment to the European legislation on textile names (Directive 2008/121/EC) and quantification of binary textile fibre mixtures (Directive 96/73/EC [3]) would subsequently be prepared.

In August 2007, the European Commission's Joint Research Centre (JRC) was entrusted by DG Enterprise (DG ENTR) to conduct experimental work to verify the validity and applicability of the testing methods proposed by the applicant for the identification and quantification of the new fibre (Administrative Arrangement between JRC and DG ENTR, JRC Ref. Contract n. 30291).

3. Background information

The work plan included the verification of the applicability of the pre-treatment described in Directive 96/73/EC to the new fibre, the determination of the percentage mass loss due to pre-treatment (*b*), the *agreed allowance* and the solubility properties of PAC with the determination of its correction factors *d*. The most important issue concerned the verification of identification and quantification methods proposed by Aquafil (based on microscopic and FT-IR analysis, chemical dissolution methods and Differential Scanning Calorimetry).

The JRC collaborated with Aquafil to identify relevant samples for the experimental phase, taking into consideration possible range of compositions in blends. In view of the foreseen use of PAC in carpet applications, binary and ternary mixtures with PA and PP were judged as the most interesting ones. Aquafil was asked to provide various samples of pure PAC with different PA6 content, together with binary and ternary mixtures with PA6 and PP. Table 1 lists all samples received from Aquafil, while Table 2 shows the samples' composition according to the petitioner, based on linear density measurements (dtex¹). The samples used in this project were both yarns and carpets, received by the JRC from February 2007 until March 2010. Samples **160**, **162** – **167** were used only for preliminary testing. Sample **160** was not included in the final experimental study, as it was proved to be non-resistant to the experimental conditions. Samples **234** – **257** were carpets prepared by Aquafil for testing purposes in a small pilot plant, using both the loop and cut structure. Apart from samples listed in Table 1, sample **113** was also used in this project; it is composed of 100 % PP (yarn from bobbin), has a linear density of 121 dtex and was received by the JRC in the frame of a previous project. Samples **280**, **282** – **284** were used for the collaborative trial organised by the JRC at European level for the validation of the method to quantify binary mixtures PA/PAC and of three correction factors *d* for PAC.

¹ **dtex** is a unit to express linear density, numerically equal to the weight in grams of 10 000 meters of yarn, fibre or other textile strand.

Table 1: Samples received from Aquafil.

| JRC code | composition | nominal PA6 % | sample type | manufacturing type | colour | arrival date | TiO ₂ |
|----------|-------------|---------------|--------------|--------------------|-------------|--------------|------------------|
| 160 | 100 % PAC | 20 % | bobbin | interlaced | white | 5/2/07 | Yes |
| 162 | 100 % PAC | 7 % DU* | carpet - cut | twisted | grey | 5/2/07 | Yes |
| 163 | 100 % PAC | 15 % DU | carpet - cut | twisted | light green | 5/2/07 | Yes |
| 164 | 100 % PAC | 20 % BT** | carpet - cut | twisted | green | 5/2/07 | No |
| 165 | 100 % PAC | 20 % DU | carpet - cut | twisted | light green | 5/2/07 | Yes |
| 166 | 100 % PAC | 20 % 2-DU | carpet - cut | twisted | grey | 5/2/07 | Yes |
| 167 | 100 % PAC | 30 % DU | carpet - cut | twisted | green | 5/2/07 | Yes |
| 184 | 100 % PA6 | - | granules | - | white | 12/6/07 | No |
| 185 | 100 % PP | - | granules | - | white | 12/6/07 | No |
| 186 | 100 % PP | - | bobbin | interlaced | white | 27/7/07 | No |
| 187 | 100 % PP | - | bobbin | interlaced | dark yellow | 27/7/07 | No |
| 188 | 100 % PA6 | - | bobbin | interlaced | grey | 27/7/07 | Yes |
| 189 | 100 % PA6 | - | bobbin | interlaced | white | 27/7/07 | Yes |
| 192 | 100 % PP | - | bobbin | interlaced | white | 28/11/07 | No |
| 193 | 100 % PA6 | - | bobbin | interlaced | white | 28/11/07 | Yes |
| 194 | 100 % PA66 | - | bobbin | interlaced | white | 28/11/07 | Yes |
| 195 | 100 % PAC | 5 % | bobbin | interlaced | white | 28/11/07 | No |
| 196 | 100 % PAC | 10 % | bobbin | interlaced | white | 28/11/07 | No |
| 197 | 100 % PAC | 20 % | bobbin | interlaced | white | 28/11/07 | No |
| 198 | 100 % PAC | 30 % | bobbin | interlaced | white | 28/11/07 | No |
| 199 | 100 % PAC | 40 % | bobbin | interlaced | white | 28/11/07 | No |
| 200 | PA6/PAC | 10 % | bobbin | interlaced | white | 28/11/07 | Yes / No |
| 201 | PA6/PAC | 10 % | bobbin | twisted | white | 28/11/07 | Yes / No |
| 202 | PA6/PAC | 20 % | bobbin | interlaced | white | 28/11/07 | Yes / No |
| 203 | PA6/PAC | 20 % | bobbin | twisted | white | 28/11/07 | Yes / No |
| 204 | PA6/PAC | 30 % | bobbin | interlaced | white | 28/11/07 | Yes / No |
| 205 | PA6/PAC | 30 % | bobbin | twisted | white | 28/11/07 | Yes / No |
| 206 | PA6/PAC | 40 % | bobbin | twisted | white | 28/11/07 | Yes / No |
| 207 | PP/PAC | 10 % | bobbin | interlaced | white | 28/11/07 | No / No |
| 208 | PP/PAC | 10 % | bobbin | twisted | white | 28/11/07 | No / No |
| 209 | PP/PAC | 20 % | bobbin | interlaced | white | 28/11/07 | No / No |
| 210 | PP/PAC | 20 % | bobbin | twisted | white | 28/11/07 | No / No |
| 211 | PP/PAC | 30 % | bobbin | interlaced | white | 28/11/07 | No / No |
| 212 | PP/PAC | 30 % | bobbin | twisted | white | 28/11/07 | No / No |
| 213 | PP/PAC | 40 % | bobbin | twisted | white | 28/11/07 | No / No |
| 214 | PA6/PAC/PP | 10 % | bobbin | interlaced | white | 28/11/07 | Yes / No / No |
| 215 | PA6/PAC/PP | 10 % | bobbin | twisted | white | 28/11/07 | Yes / No / No |
| 216 | PA6/PAC/PP | 20 % | bobbin | interlaced | white | 28/11/07 | Yes / No / No |
| 217 | PA6/PAC/PP | 20 % | bobbin | twisted | white | 28/11/07 | Yes / No / No |
| 218 | PA6/PAC/PP | 30 % | bobbin | interlaced | white | 28/11/07 | Yes / No / No |
| 219 | PA6/PAC/PP | 30 % | bobbin | twisted | white | 28/11/07 | Yes / No / No |
| 220 | PA6/PAC/PP | 40 % | bobbin | twisted | white | 28/11/07 | Yes / No / No |
| 233 | 100% PAC | 20 % | bobbin | interlaced | white | 25/11/08 | Yes |

* DU dull (with TiO₂)** BT bright (without TiO₂)

| JRC code | composition | nominal PA6 % | sample type | manufacturing type | colour | arrival date | TiO ₂ |
|----------|-------------|---------------|--------------------|--------------------|---------------|--------------|------------------|
| 234 | PA6/PAC | 30 % | carpet - 1/10 loop | twisted | beige + white | 24/2/09 | Yes / No |
| 235 | PA6/PAC | 20 % | carpet - 1/10 loop | twisted | beige + white | 24/2/09 | Yes / No |
| 236 | PA6/PAC | 10 % | carpet - 1/10 loop | twisted | beige + white | 24/2/09 | Yes / No |
| 237 | PA6/PAC | 30 % | carpet - 1/10 loop | interlaced | beige + white | 24/2/09 | Yes / No |
| 238 | PA6/PAC | 20 % | carpet - 1/10 loop | interlaced | beige + white | 24/2/09 | Yes / No |
| 239 | PA6/PAC | 10 % | carpet - 1/10 loop | interlaced | beige + white | 24/2/09 | Yes / No |
| 240 | PA6/PAC | 30 % | carpet - 1/10 cut | twisted | beige + white | 24/2/09 | Yes / No |
| 241 | PA6/PAC | 20 % | carpet - 1/10 cut | twisted | beige + white | 24/2/09 | Yes / No |
| 242 | PA6/PAC | 10 % | carpet - 1/10 cut | twisted | beige + white | 24/2/09 | Yes / No |
| 243 | PA6/PAC | 30 % | carpet - 1/10 cut | interlaced | beige + white | 24/2/09 | Yes / No |
| 244 | PA6/PAC | 20 % | carpet - 1/10 cut | interlaced | beige + white | 24/2/09 | Yes / No |
| 245 | PA6/PAC | 10 % | carpet - 1/10 cut | interlaced | beige + white | 24/2/09 | Yes / No |
| 246 | PP/PAC | 30 % | carpet - 1/10 loop | twisted | black + white | 24/2/09 | Yes / No |
| 247 | PP/PAC | 20 % | carpet - 1/10 loop | twisted | black + white | 24/2/09 | Yes / No |
| 248 | PP/PAC | 10 % | carpet - 1/10 loop | twisted | black + white | 24/2/09 | Yes / No |
| 249 | PP/PAC | 30 % | carpet - 1/10 loop | interlaced | black + white | 24/2/09 | Yes / No |
| 250 | PP/PAC | 20 % | carpet - 1/10 loop | interlaced | black + white | 24/2/09 | Yes / No |
| 251 | PP/PAC | 10 % | carpet - 1/10 loop | interlaced | black + white | 24/2/09 | Yes / No |
| 252 | PP/PAC | 30 % | carpet - 1/10 cut | twisted | black + white | 24/2/09 | Yes / No |
| 253 | PP/PAC | 20 % | carpet - 1/10 cut | twisted | black + white | 24/2/09 | Yes / No |
| 254 | PP/PAC | 10 % | carpet - 1/10 cut | twisted | black + white | 24/2/09 | Yes / No |
| 255 | PP/PAC | 30 % | carpet - 1/10 cut | interlaced | black + white | 24/2/09 | Yes / No |
| 256 | PP/PAC | 20 % | carpet - 1/10 cut | interlaced | black + white | 24/2/09 | Yes / No |
| 257 | PP/PAC | 10 % | carpet - 1/10 cut | interlaced | black + white | 24/2/09 | Yes / No |
| 258 | 100 % PA6 | - | bobbin | interlaced | white | 16/3/09 | Yes |
| 259 | 100 % PP | - | bobbin | interlaced | black | 16/3/09 | Yes |
| 260 | 100 % PP | - | bobbin | interlaced | white | 19/11/09 | Yes |
| 261 | 100 % PP | - | bobbin | interlaced | white | 19/11/09 | Yes |
| 262 | 100 % PA6 | - | bobbin | interlaced | white | 19/11/09 | Yes |
| 263 | 100 % PA6 | - | bobbin | interlaced | white | 19/11/09 | Yes |
| 264 | 100 % PA6 | - | bobbin | interlaced | white | 19/11/09 | Yes |
| 265 | PAC | 20 % | bobbin | interlaced | white | 19/11/09 | Yes |
| 266 | PAC | 40 % | bobbin | interlaced | white | 19/11/09 | Yes |
| 267 | PA6/PAC | 20 % | carpet - loop | twisted | white | 19/11/09 | Yes / Yes |
| 268 | PA6/PAC | 20 % | carpet - loop | twisted | white | 19/11/09 | Yes / Yes |
| 269 | PA6/PAC | 20 % | carpet - loop | twisted | white | 19/11/09 | Yes / Yes |
| 270 | PA6/PAC | 40 % | carpet - loop | twisted | white | 19/11/09 | Yes / Yes |
| 271 | PP/PAC | 20 % | carpet - loop | twisted | white | 19/11/09 | Yes / Yes |
| 272 | PP/PAC | 20 % | carpet - loop | twisted | white | 19/11/09 | Yes / Yes |
| 273 | PP/PAC | 20 % | carpet - loop | twisted | white | 19/11/09 | Yes / Yes |
| 274 | PP/PAC | 40 % | carpet - loop | twisted | white | 19/11/09 | Yes / Yes |
| 275 | 100 % PP | - | bobbin | interlaced | white | 19/03/10 | No |
| 276 | 100 % PP | - | bobbin | interlaced | white | 19/03/10 | No |
| 277 | 100 % PA6 | - | bobbin | interlaced | white | 19/03/10 | Yes |
| 278 | 100 % PA6 | - | bobbin | interlaced | white | 19/03/10 | Yes |
| 279 | 100 % PA6 | - | bobbin | interlaced | white | 19/03/10 | Yes |
| 280 | PAC | 20 % | bobbin | interlaced | white | 19/03/10 | Yes |
| 281 | PAC | 40 % | bobbin | interlaced | white | 19/03/10 | Yes |
| 282 | PA6/PAC | 20 % | carpet - loop | twisted | white | 19/03/10 | Yes / Yes |
| 283 | PA6/PAC | 20 % | carpet - loop | twisted | white | 19/03/10 | Yes / Yes |

| JRC code | composition | nominal PA6 % | sample type | manufacturing type | colour | arrival date | TiO ₂ |
|----------|-------------|---------------|---------------|--------------------|--------|--------------|------------------|
| 284 | PA6/PAC | 20% | carpet - loop | twisted | white | 19/03/10 | Yes / Yes |
| 285 | PA6/PAC | 40% | carpet - loop | twisted | white | 19/03/10 | Yes / Yes |
| 286 | PP/PAC | 20% | carpet - loop | twisted | white | 19/03/10 | No / Yes |
| 287 | PP/PAC | 20% | carpet - loop | twisted | white | 19/03/10 | No / Yes |
| 288 | PP/PAC | 20% | carpet - loop | twisted | white | 19/03/10 | No / Yes |
| 289 | PP/PAC | 40% | carpet - loop | twisted | white | 19/03/10 | No / Yes |

Table 2: Samples' composition based on linear density measured by Aquafil.

| JRC code | composition | nominal PA6 % | filament number | linear density (dtex) | PA6/PP/PAC % * | linear density (dtex) | PA6/PP/PAC % ** |
|----------|-------------|---------------|-----------------|-----------------------|---------------------|-----------------------|--------------------|
| | | | | theoretical values | experimental values | | |
| 160 | 100 % PAC | 20 % | 60 | 1150 | - | - | - |
| 186 | 100 % PP | - | 42 | 900 | - | - | - |
| 187 | 100 % PP | - | 42 | 650 | - | - | - |
| 188 | 100 % PA6 | - | 42 | 700 | - | - | - |
| 189 | 100 % PA6 | - | 42 | 700 | - | - | - |
| 192 | 100 % PP | - | 60 | 1178 | - | 1183.9 | - |
| 193 | 100 % PA6 | - | 64 | 1331 | - | 1335.5 | - |
| 195 | 100 % PAC | 5 % | 60 | 1187 | - | 1150 | - |
| 196 | 100 % PAC | 10 % | 60 | 1168 | - | 1186.9 | - |
| 197 | 100 % PAC | 20 % | 60 | 1178 | - | 1201.1 | - |
| 198 | 100 % PAC | 30 % | 60 | 1203 | - | 1218.7 | - |
| 199 | 100 % PAC | 40 % | 60 | 1206 | - | 1220.3 | - |
| 200 | PA6/PAC | 10 % | - | 2545 | 50.2 / 49.8 | 2553.3 | 52.9 / 47.1 |
| 201 | PA6/PAC | 10 % | - | 2590 | 53.3 / 46.7 | 2586.6 | 52.9 / 47.1 |
| 202 | PA6/PAC | 20 % | - | 2598 | 50.0 / 50.0 | 2588.1 | 52.6 / 47.4 |
| 203 | PA6/PAC | 20 % | - | 2653 | 52.9 / 47.1 | 2595.4 | 52.6 / 47.4 |
| 204 | PA6/PAC | 30 % | - | 2605 | 49.5 / 50.5 | 2578.4 | 52.3 / 47.7 |
| 205 | PA6/PAC | 30 % | - | 2655 | 51.9 / 48.1 | 2627.5 | 52.3 / 47.7 |
| 206 | PA6/PAC | 40 % | - | 2659 | 51.7 / 48.3 | 2534.3 | 52.3 / 47.7 |
| 207 | PP/PAC | 10 % | - | 2400 | 50.2 / 49.8 | 2348.7 | 49.9 / 50.1 |
| 208 | PP/PAC | 10 % | - | 2412 | 50.2 / 49.8 | 2432.1 | 49.9 / 50.1 |
| 209 | PP/PAC | 20 % | - | 2427 | 50.0 / 50.0 | 2379.9 | 49.6 / 50.4 |
| 210 | PP/PAC | 20 % | - | 2461 | 50.0 / 50.0 | 2403.3 | 49.6 / 50.4 |
| 211 | PP/PAC | 30 % | - | 2482 | 49.5 / 50.5 | 2431.5 | 49.3 / 50.7 |
| 212 | PP/PAC | 30 % | - | 2466 | 49.5 / 50.5 | 2497.0 | 49.3 / 50.7 |
| 213 | PP/PAC | 40 % | - | 2508 | 49.4 / 50.6 | 2394.6 | 49.2 / 50.8 |
| 214 | PA6/PAC/PP | 10 % | - | 3768 | 36.2 / 31.8 / 32.0 | 3752.9 | 36.0 / 31.9 / 32.0 |
| 215 | PA6/PAC/PP | 10 % | - | 3912 | 36.2 / 31.8 / 32.0 | 3821.1 | 36.0 / 31.9 / 32.0 |
| 216 | PA6/PAC/PP | 20 % | - | 3773 | 36.1 / 32.0 / 32.0 | 3734.6 | 35.9 / 31.8 / 32.3 |
| 217 | PA6/PAC/PP | 20 % | - | 3807 | 36.1 / 32.0 / 32.0 | 3818.1 | 35.9 / 31.8 / 32.3 |
| 218 | PA6/PAC/PP | 30 % | - | 3767 | 35.9 / 32.4 / 31.7 | 3799.9 | 35.7 / 31.7 / 32.6 |
| 219 | PA6/PAC/PP | 30 % | - | 3895 | 35.9 / 32.4 / 31.7 | 3904.5 | 35.7 / 31.7 / 32.6 |
| 220 | PA6/PAC/PP | 40 % | - | 3756 | 35.8 / 32.5 / 31.7 | 3778.4 | 35.7 / 31.7 / 32.6 |

* Percentages calculated on the basis of theoretical values of linear density of pure PA6, PP and PAC used to prepare the mixtures

** Percentages calculated on the basis of experimental values of linear density of pure PA6, PP and PAC used to prepare the mixtures

4. Test methods for identification of the new fibre

The methods proposed by the applicant for identifying PAC were based on Scanning Electronic Microscope (SEM) analysis, Fourier Transform Infrared Spectroscopy (FT-IR) and Differential Scanning Calorimetry (DSC) (see Annex I). In this section results obtained with these techniques, plus optical microscopic analysis, are reported. Complete results are shown in Annexes II, III and IV. It has to be highlighted that, due to its composition, the new fibre has to be distinguishable not only from all the other fibres, but also from binary mixtures PP - PA. In the following, these mixtures will be referred to as “physical mixtures” PP - PA to stress the difference with the new fibre, which contains polyamide fibrils in polypropylene matrix with “islands-in-the-sea” structure.

4.1 Microscopy

The optical microscopic analysis of pure PP, PA6 and PAC 20 % are shown in Fig. 1. A Zeiss microscope model Axioskop 2 Mat was used and analyses were performed using transmitted light. Glyceryl triacetate (refractive index: 1.158) was used as mounting medium. Photos of samples received from Aquafil, analysed by microscopy for a preliminary characterisation, are reported in Annex II.






Fig. 1: Longitudinal and cross section analysis of PP, PA6 and PAC (20x).

As evident from the photos reported as an example in Fig. 1, it can be concluded that PAC cannot be identified by optical microscopy since it has the same appearance as polypropylene fibres.


The bicomponent nature of the new fibre and its microstructure of “islands-in-the-sea” type can be identified by Scanning Electron Microscope (SEM) analysis. In fact, after dissolving PA6 inside the new fibre with 98-100 % formic acid at room temperature for 15 minutes, the cross-section analysis showed several holes where fibrils of PA6 were present (Fig. 2).



(a)



(b)



(c)

Fig. 2: SEM cross-section of PAC containing:
a) 5 % PA6 (sample **195**); b) 20 % PA6 (sample **197**); c) 40 % PA6 (sample **199**).

It can be clearly observed that the number of holes increased with the increasing content of PA6 inside PAC. SEM analyses were performed by the Italian National Research Council (Consiglio Nazionale delle Ricerche, CNR), Biella, Italy.

4.2 Fourier transform infrared spectroscopy

The nature of the new fibre can be proved by means of Fourier transform infrared spectroscopy (FT-IR). All spectra were acquired using Attenuated Total Reflectance (ATR) mode with a Perkin Elmer instrument (FT-IR spectrometer spectrum 2000). Spectra were acquired in the scan range $4000.00 - 650.00 \text{ cm}^{-1}$, with a resolution of 4.00 cm^{-1} and a total of 4 scans. The FT-IR spectra of pure PA6, PP and PAC 20 % are shown below (Figs. 3-5). Samples were analysed without any preparation. FT-IR spectra of Aquafil samples are reported in Annex III.




Fig. 3: FT-IR spectrum of PA6 (sample 193).




Fig. 4: FT-IR spectrum of PP (sample 192).




Fig 5: FT-IR spectrum of PAC 20 % (sample **197**).

Due to the chemical composition of the new fibre, PAC spectrum (Fig. 5) shows peaks attributed to its PA6 content (3302, 1641 and 1541 cm^{-1}), as well as peaks attributed to the PP matrix (1456 and 1376 cm^{-1}). The band at 3302 cm^{-1} can be attributed to N-H stretching vibration. The band at 1641 cm^{-1} corresponds to C=O vibrations of amide, whereas the bands at 1456 cm^{-1} and 1376 cm^{-1} can be attributed to asymmetric deformation vibration of CH_2 and bending vibration of CH_3 , respectively.

A single spectrum is not sufficient to identify unequivocally the new fibre, because a similar spectrum would be obtained analysing a “physical mixture” of pure PP and PA6 fibres. To achieve the identification, two spectra are necessary: the first one on the sample as it is and the second one on the sample after dissolution of PA. In the case of PAC, subtracting the two spectra before and after dissolution of PA will result in a spectrum which still shows two small peaks (1542 and 1642 cm^{-1}), most probably related to the part of PA that is chemically linked to the microstructure of PAC through the compatibiliser (Figs. 6-7); vice versa, in the case of “physical mixture” PP – PA, the subtracted spectrum will just consist in the spectrum of pure PA (Fig. 8).




Fig. 6: FT-IR spectra of PAC 20 % (sample 197) before and after method 16.




Fig. 7: FT-IR spectra of PAC 20 % (sample **197**) before and after hydrolysis method.




Fig. 8: FT-IR spectra of "physical mixture" PP – PA6 (PA6 content about 20 %) before and after method 16.

In particular, Fig. 6 shows the FT-IR spectra of PAC 20 %, before and after an acid attack, able to dissolve the PA6 fibrils. The method used was method 16 of Directive 96/73/EC, which treats the sample with 90 % formic acid solution in a water bath at 90 °C for 1 hour as contact time. Additionally, Fig. 7 reports the FT-IR spectra of PAC 20 %, before and after a different acid attack, using a method proposed by the

petitioner for the quantification of the content of PA6 in PAC (hydrolysis method, see Annex I). The dissolution of PA6 is achieved by the use of a hydrochloric acid 18.5 % w/w aqueous solution at 75 ± 5 °C for 24 hours in a silicon bath.

In the case of a “physical mixture” PP – PA6 (containing 20 % PA6), the subtraction of spectra, before and after the application of method 16, shows a different result than in the case of PAC. Comparing the subtracted spectra reported in Figs. 6-7 with the one in Fig. 8, it can be clearly stated that the FT-IR technique is an efficient way to distinguish between PAC and “physical mixtures” of pure PP and PA fibres.

4.3 Differential scanning calorimetry

Differential Scanning Calorimetry (DSC) can also be used to identify PAC as a fibre, which is distinguishable from “physical mixtures” PP – PA6, as well as from binary mixtures PP/PAC and PA6/PAC. The equipment used for the analyses was a DSC model Q100 by TA Instruments. A temperature program of 10 °C/min, starting from 0 °C up to 260 °C, with a nitrogen gas flow of 50 ml/min was employed. The experimental method used consisted of a heating - cooling - heating cycle. Sample weight was in the range 6 - 10 mg. Fig. 9 shows the crystallisation and melting peaks of pure PP and PA6.

The crystallisation peaks of pure PP and PA6 are observed at 118 °C and 189 °C respectively, whereas their melting peaks (second heating) are found at 163 °C and 221 °C respectively. In Fig. 10, the DSC analyses of pure PAC 40 % and a “physical mixture” of PP – PA6 (containing 40.4 % PA6) can be compared.




Fig. 9: DSC analysis of PP (sample 192) and PA6 (sample 193).




Fig. 10: DSC analysis of PAC 40 % (sample 199) and a “physical mixture” PP - PA6 (40.4 %).

Observing the cooling cycle for the “physical mixture” PP - PA6, the crystallisation peak for PA6 was measured at 188 °C, as in the analysis of pure PA6. On the contrary, the crystallisation peak due to the PA6 fibrils in pure PAC was split in two: the first shoulder was measured at 190 °C (close to the one of pure PA6) and the second peak was recorded in the range of 180 °C, showing the tendency of moving towards the crystallisation peak of pure PP. Analogously, the crystallisation peak of PP in the physical mixture PP - PA6 was observed at about 116 °C (similar to the analysis of pure PP), whereas the crystallisation peak of PP in pure PAC (around

124 °C) was shifted towards the crystallisation peak of pure PA6. The differences in temperature for crystallisation peaks of PA6 and PP in the “physical mixture” and in the new fibre were about 8 °C.

Based on these data, it can be concluded that PAC is not a “physical mixture” of PP and PA6, as in the new fibre the crystallisation peaks of PA6 and PP move towards each other, possibly due to the formation of copolymers.

As shown in Fig. 11, the content of PA6 in PAC has an influence on the temperature of the crystallisation peak of PP. In fact, the lower the content of PA6 in PAC the smaller the difference between the temperature of PP crystallisation peak in PAC and the one of the crystallisation peak of pure PP. This phenomenon is coherent with the fact that PAC is more similar to pure PP when the content of PA6 decreases.




Fig. 11: Influence of PA6 content in pure PAC on PP crystallisation peak.

In Fig. 12, the cooling cycle for PAC 40 %, binary mixtures PP/PAC 40 % and PA6/PAC 40 % can be compared. In the region of the PA6 crystallisation peak of the sample made by PA6/PAC 40 %, a major peak (187 °C) and a secondary one (176 °C) can be observed. The first peak is probably due to the PA6 fibres in the mixture and to the “free” part of PA6 in PAC; the second one is most likely due to the part of PA6 embedded in PAC, which possibly formed copolymers with PP through the compatibiliser. Analogously, in the binary mixture PP/PAC 40%, two peaks can be seen in the PP peak region, one at 117 °C, due to the “free” PP fibres and another one at 124 °C, due to the PP content of PAC. Therefore, PAC and binary mixtures of PA6/PAC and PP/PAC can be clearly differentiated through DSC analysis.




Fig. 12: DSC crystallisation cycle for PAC 40 % (sample **199**), a binary mixture PA6/PAC 40 % (sample **206**) and PP/PAC 40 % (sample **213**).

5. Test methods for quantification of the new fibre

Initially, the JRC verified the applicability of the usual pre-treatment to the new fibre and determined both the mass loss due to pre-treatment and the *agreed allowance*. Secondly, the behaviour of the new fibre was studied with all the methods described in Directive 96/73/EC. The behaviour of pure PA6 and pure PP was studied as well, in order to verify which methods were able to differentiate them. Thirdly, the methods proposed by the applicant (see Annex I) for the quantification of PA6 in PAC were evaluated together with other possible less time-consuming methods. Finally, all the samples made by binary mixtures received from Aquafil (**200 – 213**) were analysed by manual separation, chemical analysis and DSC analysis. Based on the evaluation of results on binary mixtures, methods 11 and 16 of Directive 96/73/EC were considered accurate enough to be tested with carpet samples (samples **234 – 257**). These carpet samples were also analysed *via* manual separation in order to have the reference values needed to evaluate the accuracy of the aforementioned chemical methods for quantification purposes.

Detailed results regarding mass loss due to pre-treatment, *agreed allowance*, solubility properties, manual separation and chemical methods are reported in Annex V.

5.1 Influence of drying conditions on PAC

The petitioner suggested that drying steps should always be conducted in vacuum oven (~ 40 mbar) in order to avoid degradation of PAC (in particular the polyamide part). Based on Aquafil's experiments, PAC seemed to be damaged when dried in a ventilated oven at 105 °C for longer than 6 h, probably due to thermo-oxidative processes. At the beginning of the experimental work, the JRC studied the influence of the use of ventilated oven during the drying step. Tests were performed on sample **160** (PAC 20 %), the only yarn sample of PAC available at that time. From a total of twelve replicates, weighed under repeatability conditions, six of them were dried in a vacuum oven and six in a ventilated one for 2, 4, 6, 8, 12 and 16 hours. The percentage of mass loss during the drying step is shown in Fig. 13. Although the mass loss remained constant during 16 hours when vacuum oven was used, a decrease of

around 50 % was observed after 6 h, when ventilated oven was employed. This fact could be attributed to an oxidation of the new fibre, which could result in an increase of its weight and a decrease of mass loss. After 12 hours in the ventilated oven, the mass loss almost returned to its initial value, possibly due to a loss of volatile compounds from the oxidised sample. Moreover, using ventilated oven, the longer the drying step of samples the more serious the observed damages to the fibre. The fibre changed colour over the time from white to yellow (Fig. 14) and became more and more fragile. After 12 hours, the fibre could be disintegrated into dust when touched. Based on these experiments, a major part of the subsequent investigations were conducted drying samples in vacuum oven.




Fig. 13: Mass loss of sample **160** (PAC 20 %) dried in a vacuum or ventilated oven.




Fig. 14: Gradual change in colour of sample **160** (PAC 20 %) when dried in a ventilated oven.

Vacuum oven is not foreseen in any of the methods in Directive 96/73/EC and costs more than a conventional ventilated one. For this reason, when more samples were sent by Aquafil later on, the influence of drying conditions was checked again on samples **197** and **233**, which have the same composition as sample **160** (PAC 20 %). Surprisingly, no differences in mass loss were recorded independently of the type of drying conditions used (vacuum vs. ventilated) (Figs. 15-16). Mass loss values were in the same range (0.7 - 0.8 %) for both samples.




Fig. 15: Mass loss (%) of sample **197** (PAC 20 %) when dried in vacuum and ventilated oven.




Fig. 16: Mass loss (%) of sample **233** (PAC 20 %) when dried in vacuum and ventilated oven.

In the case of vacuum oven, results were also comparable to the ones observed for sample **160**, whereas in the case of ventilated oven they were completely different. Samples **197** and **233** did not change to yellow even after 12 h in ventilated oven and,

what is more important, these samples did not become fragile after the drying step in air (Figs. 17-18).




Fig. 17: Comparison of mass loss (%) of samples **160**, **197** and **233** (PAC 20 %) when dried in ventilated oven.




Fig. 18: Comparison of mass loss (%) of samples **160**, **197** and **233** (PAC 20 %) when dried in vacuum oven.

The JRC contacted immediately the company requesting information about possible differences in the production of samples **160**, **197** and **233**. Towards the end of the experimental investigation Aquafil confirmed that sample **160** was the only one showing degradation effect in ventilated oven. They communicated that sample **160** was very old and attributed its poor resistance to the inappropriate storage conditions under which it was kept before being sent to the JRC.

In conclusion, it was verified that ventilated oven can be safely applied since it does not cause any damage to the fibre. A further confirmation, that vacuum and ventilated

oven give equivalent results, was obtained when the solubility properties of the new fibre and the correction factors d were evaluated. In that case, samples with nominal content of PA6 equal to 20 and 40 % were analysed and results were statistically compared (see par. 5.4.1).

5.2 Pre-treatment

Before quantification, samples should be pre-treated in order to eliminate non-fibrous matter. Directive 96/73/EC suggests extracting non-fibrous matter with light petroleum ether and water. The procedure foresees one-hour extraction in Soxhlet with light petroleum ether (boiling range 40 - 60 °C), followed by one-hour extraction in water at room temperature and one-hour extraction in water at 65 ± 5 °C, using a liquor/specimen ratio of 100/1. An automatic hot-extractor (Soxhtec) instead of traditional Soxhlet was mostly employed for the pre-treatment, as no differences in terms of mass loss were noticed during the conduction of preliminary experiments.

In order to evaluate the b coefficient for the new fibre (mass loss due to pre-treatment), three consecutive complete pre-treatments were carried out on five replicates, five grams each, of PAC 20 %. Results (Table 3) showed a mass loss of 0.95 ± 0.03 % during the first pre-treatment, value in line with the content of finishing agents declared by Aquafil (1.00 ± 0.25 %). The second and third ones did not reveal any further significant mass loss. These evidences confirm that the new fibre is insoluble under the conditions of the pre-treatment. Therefore, in agreement with experts from member states, the usual pre-treatment was considered applicable and the b coefficient value for PAC was established to be 0 %.

Table 3: Mass loss due to pre-treatment.


| JRC code | 1 st pre-treatment | | 2 nd pre-treatment | | 3 rd pre-treatment | |
|-------------|-------------------------------|-----------------------|-------------------------------|-----------------------|-------------------------------|-----------------------|
| | loss of mass % | conf. limit (95 %) | loss of mass % | conf. limit (95 %) | loss of mass % | conf. limit (95 %) |
| 233 | 0.95 | 0.03 | 0.15 | 0.01 | 0.12 | 0.02 |

Results on samples of PAC with various content of PA6 showed mass loss in the same range with an average value of 1 % (Table 4).

Table 4: Mass loss of PAC, PP and PA6 due to pre-treatment.

| JRC code | composition | nominal PA6 % | replicates | mass loss % | conf. limit (95 %) |
|----------------------|-------------|---------------|------------|-------------|--------------------|
| 192 | 100 % PP | --- | 5 | 1.09 | 0.03 |
| 193 | 100 % PA6 | --- | 5 | 1.04 | 0.11 |
| 195 | 100 % PAC | 5 | 5 | 1.09 | 0.04 |
| 196 | 100 % PAC | 10 | 5 | 1.05 | 0.03 |
| 197 | 100 % PAC | 20 | 5 | 1.06 | 0.04 |
| 198 | 100 % PAC | 30 | 4 | 1.07 | 0.04 |
| 199 | 100 % PAC | 40 | 5 | 0.94 | 0.03 |
| average (PAC) | | | | 1.04 | |

Fig. 19 shows the comparison of FTIR spectra of PAC 40 % (sample **199**) as received and after pre-treatment.

**Fig. 19:** Comparison of FT-IR spectra of untreated (---) and pre-treated (---) PAC 40 % (sample **199**).

5.3 Agreed allowance

The *agreed allowance* was considered equal to the moisture regain in standard atmosphere according to the definition stated in ISO 6348:1980 [4].

A number of experiments were performed on samples of PAC with different PA6 content (**195 – 199**), in order to evaluate the *agreed allowance* of the new fibre. This parameter was calculated both for untreated and pre-treated samples. The procedure described in the following was applied. Weighing bottles were dried for 5 h at 105 °C, then cooled in a dessicator and weighed. A sample of about 2 g of PAC was placed in each weighing bottle and dried for 16 h at 105 °C, then cooled in a dessicator and weighed. Samples were then conditioned for 72 hours at 20 ± 1 °C and 65 ± 2 % relative humidity and weighed immediately after the conditioning period. The following formulas were used to calculate the *agreed allowance*:

$$\text{water mass} = \text{wet sample mass} - \text{dried sample mass} \quad 5.3.1$$

$$\text{agreed allowance} = 100 (\text{water mass} / \text{dried sample mass}) \quad 5.3.2$$

Ten replicates per each sample were analysed (Table 5). Results were similar for untreated and pre-treated samples, showing a tendency to increase with the increase of PA6 content (Fig. 20). This fact can be justified by the larger moisture regain in standard atmosphere of the PA component compared to the PP one. Results showed values in the range of 0.09 - 1.15 %, depending on PA6 content, the average being 0.6 %.

Table 5: *Agreed allowance* (AA) for PAC.

| JRC code | composition | replicates | untreated sample | | pre-treated sample | |
|------------------------|-------------|------------|------------------|-------------------|--------------------|-------------------|
| | | | AA % | conf. limit (95%) | AA % | conf. limit (95%) |
| 195 | PAC 5 % | 10 | 0.15 | 0.01 | 0.09 | 0.03 |
| 196 | PAC 10 % | 10 | 0.29 | 0.01 | 0.22 | 0.05 |
| 197 | PAC 20 % | 10 | 0.56 | 0.02 | 0.52 | 0.04 |
| 198 | PAC 30 % | 10 | 0.88 | 0.03 | 0.79 | 0.06 |
| 199 | PAC 40 % | 10 | 1.15 | 0.03 | 1.14 | 0.03 |
| average | | | 0.61 | | 0.55 | |
| overall average | | | | 0.58 | | |




Fig. 20: *Agreed allowance* values for pre-treated and untreated samples of PAC vs. % PA6 content.

Based on experimental results and after discussions with experts from member states, even though the value proposed by Aquafil was 1.6 %, it was agreed to establish a value of 1.00 % for the *agreed allowance* of PAC.

5.4 Solubility properties

The solubility properties of PP, PA6 and the new fibre were studied and correction factors d for mass loss of the insoluble component in the reagents during analysis were evaluated. The correction factors d were calculated using the following formula:

$$d = \frac{m}{r} \quad 5.4.1$$

where:

m is the dry mass of the specimen after pre-treatment

r is the dry mass of the residue

All weighing operations were performed using an analytical balance of weighing capacity of 0.01 mg. The percentages of insoluble component on a clean, dry mass basis, disregarding loss of fibre mass during pre-treatment, were calculated using the following formula:

$$P_1 \% = \frac{100 \ r \ d}{m} \quad 5.4.2$$

where:

- P_1 is the percentage of clean, dry insoluble component
- m is the dry mass of the specimen after pre-treatment
- r is the dry mass of the residue
- d is the correction factor for loss of mass of the insoluble component in the reagent during analysis

In the case of binary mixtures, calculations of percentage of insoluble component on clean, dry mass basis, with adjustment by conventional factors (*agreed allowances*) and, where appropriate, correction factors b for loss of mass during pre-treatment, were performed using the following formula:

$$P_{1A} \% = \frac{100 P_1 \left(1 + \frac{a_1 + b_1}{100}\right)}{P_1 \left(1 + \frac{a_1 + b_1}{100}\right) + (100 - P_1) \left(1 + \frac{a_2 + b_2}{100}\right)} \quad 5.4.3$$

where:

- P_{1A} is the percentage of insoluble component, adjusted by *agreed allowances* and for loss of mass during pre-treatment
- P_1 is the percentage of clean, dry insoluble component as calculated from equation 5.4.2
- a_1 is the *agreed allowance* for the insoluble component (listed in Annex V to the Directive 2008/121/EC on textile names)
- a_2 is the *agreed allowance* for the soluble component (listed in Annex V to the Directive 2008/121/EC on textile names)
- b_1 is the percentage loss of insoluble component caused by the pre-treatment
- b_2 is the percentage loss of soluble component caused by the pre-treatment

The percentage of the soluble component ($P_{2A} \%$) was obtained by difference.

The coefficients b used in the calculations were: 1 % for PP, 0 % for PA6 (as pointed out in Directive 96/73/EC) and 0 % for PAC. The *agreed allowances* used in the calculations were: 1.00 % for PAC, 2.00 % for PP and 6.25 % (in case of discontinuous fibre) or 5.75 % (in case of filament) for PA6.

The solubility properties of PP and PA were studied in the case that they were not known from Directive 96/73/EC, with the aim to find methods which could

differentiate PP from PA in order to try to dissolve only one of the two polymers in PAC. In addition, pre-treated specimens of about 1 g of PAC were analysed with all the chemical methods (apart from method 12 for nitrogen content) described in Directive 96/73/EC.

For each sample 10 - 20 replicates were analysed. The data were collected and subjected to statistical evaluation. The results were first examined for evidence of outliers using Grubbs' statistical test, as laid down in ISO 5725 [5]. Only few outliers were found out of all measurements and they were eliminated. The valid results were then subjected to a further statistical evaluation. The average and standard deviation (SD) of each set of data were calculated, as well as the relative standard deviation (RSD). The RSD was used to measure the dispersion of the distribution of test results in one laboratory: the lower the value of RSD, the better the repeatability of the method. The confidence intervals were calculated at 95 % probability, using the following formula:

$$\mu = x_m \pm \frac{t s}{\sqrt{n}} \quad 5.4.4$$

where:

- t is the value listed in the Student's t -distribution for a certain number of degrees of freedom and level of probability
- s is the estimated standard deviation
- μ is the true value
- x_m is the average of experimental results
- n is the number of measurements

Annex V reports all results regarding the evaluation of correction factors d and the composition analyses. An overview of results regarding the solubility properties of PP, PA6 and PAC is shown in the following tables. Table 6 shows the solubility properties of PP, whereas Table 7 shows the ones of PA for the quantitative methods of Directive 96/73/EC. Only the methods in which PP and/or PA were not included in the field of application were tested.

Table 6: Solubility properties of PP.

| JRC code | method | replicates | PP % | conf. limit (95%) | <i>d</i> | conf. limit (95%) |
|-------------|--------|------------|---------|----------------------|----------|----------------------|
| 186-187-192 | 1 | 20 | 99.75 | 0.04 | 1.003 | 0.0004 |
| 192 | 3 | 20 | 99.90 | 0.04 | 1.001 | 0.0005 |
| 192 | 5 | 19 | 99.87 | 0.05 | 1.001 | 0.0005 |
| 186-187-192 | 6 | 20 | 99.78 | 0.06 | 1.002 | 0.001 |
| 192 | 7 | 20 | 100.19 | 0.18 | 0.998 | 0.002 |
| 192 | 8 | 20 | 99.92 | 0.03 | 1.001 | 0.0004 |
| 192 | 9 | 20 | 99.64 | 0.07 | 1.004 | 0.001 |
| 192 | 10 | 20 | 99.86 | 0.05 | 1.001 | 0.001 |
| 192 | 11 | 20 | 100.01 | 0.09 | 1.000 | 0.001 |
| 192 | 14 | 18 | 100.01 | 0.12 | 1.000 | 0.001 |
| 113 | 15 | 10 | 100.00 | 0.03 | soluble | - |
| 192 | 16 | 20 | 99.77 | 0.04 | 1.002 | 0.0004 |

Table 7: Solubility properties of PA6.

| JRC code | method | replicates | PA6 % | conf. limit (95%) | <i>d</i> | conf. limit (95%) |
|----------|--------|------------|----------|----------------------|----------|----------------------|
| 193 | 3 | 10 | 99.88 | 0.04 | soluble | - |
| 193 | 5 | 10 | 99.76 | 0.07 | 1.003 | 0.001 |
| 193 | 7 | 10 | 99.87 | 0.04 | soluble | - |
| 193 | 10 | 10 | 98.91 | 0.06 | 1.012 | 0.001 |
| 193 | 11 | 10 | 99.88 | 0.01 | soluble | - |
| 193 | 16 | 10 | 99.93 | 0.02 | soluble | - |

Results showed that PP is insoluble in all the tested methods ($d = 1.00$), apart from method 15 (cyclohexanone) which solubilised completely this fibre. On the contrary, PA6 is soluble in methods 3, 7, 11 and 16, whereas it is insoluble in methods 5 and 10 ($d = 1.00$ and 1.01 respectively).

The solubility properties of PA6 and PP are compared in Table 8. Methods 3, 4, 7, 11, 13, 14, 15 and 16 were shown to be able to differentiate among PP and PA. Therefore, these methods were further taken into consideration in order to verify if they could be used to quantify PA6 in PAC. It has to be noted that no solvent used in the methods of Directive 96/73/EC can dissolve both PP and PA.

Table 8: Comparison of solubility properties of PP and PA6.

| method | PP <i>d</i> factor | PA6 <i>d</i> factor |
|--------|-----------------------|------------------------|
| 1 | 1.00 | 1.00 |
| 2 | 1.00 | 1.00 |
| 3 | 1.00 | soluble |
| 4 | 1.00 | soluble |
| 5 | 1.00 | 1.00 |
| 6 | 1.00 | 1.00 |
| 7 | 1.00 | soluble |
| 8 | 1.00 | 1.00 |
| 9 | 1.00 | 1.00 |
| 10 | 1.00 | 1.01 |
| 11 | 1.00 | soluble |
| 13 | soluble | 1.00 |
| 14 | 1.00 | soluble |
| 15 | soluble | 1.00 |
| 16 | 1.00 | soluble |

At first, the solubility properties of the new fibre were evaluated on PAC 40 % (sample **199**), using vacuum oven due to the difficulties mentioned in par. 5.1. The intention was to start considering the sample with the highest probability to be partially dissolved, in the case solubility properties would depend on the content of PA6 in PAC. An overview of results is shown in Table 9.

Table 9: Solubility properties of PAC 40 % (sample **199**).

| JRC code | method | replicates | insoluble comp. % | conf.limit (95%) | <i>d</i> | conf.limit (95%) |
|----------|--------|------------|----------------------|---------------------|-------------------|---------------------|
| 199 | 1 | 10 | 99.54 | 0.10 | 1.005 | 0.001 |
| 199 | 2 | 10 | 100.07 | 0.07 | 0.999 | 0.001 |
| 199 | 3 | 9 | 65.85 | 0.33 | partially soluble | - |
| 199 | 4 | 14 | 66.98 | 0.15 | partially soluble | - |
| 199 | 5 | 10 | 100.02 | 0.03 | 1.000 | 0.0003 |
| 199 | 6 | 10 | 99.65 | 0.05 | 1.004 | 0.0005 |
| 199 | 7 | 10 | 68.57 | 0.21 | partially soluble | - |
| 199 | 8 | 19 | 99.86 | 0.57 | 1.002 | 0.006 |
| 199 | 9 | 9 | 99.56 | 0.13 | 1.004 | 0.001 |
| 199 | 10 | 10 | 99.91 | 0.04 | 1.001 | 0.0004 |
| 199 | 11 | 9 | 97.82 | 0.04 | 1.023 | 0.0004 |
| 199 | 13 | 8 | 40.22 | 0.23 | partially soluble | - |
| 199 | 14 | 8 | 66.60 | 0.18 | partially soluble | - |
| 199 | 15 | 9 | 40.35 | 1.38 | partially soluble | - |
| 199 | 16 | 25 | 64.82 | 0.10 | partially soluble | - |

PAC 40 % was proved to be insoluble in methods 1, 2, 5, 6, 8-11. The *d* values observed were 1.00 for methods 1, 2, 5, 6, 8-10 and 1.02 for method 11. On the contrary, PAC 40 % was partially soluble using methods 3, 4, 7, and 13-16.

Interestingly, comparing results in Tables 7 and 9, it appears evident that even if polyamide is soluble in method 11, the PA component of PAC is not. This is probably due to the inert shield of the polypropylene matrix and to the difficulty of the reagent to penetrate the fibre structure.

In order to verify the possible influence of the content of PA6 in PAC on its solubility properties, some of the methods were also applied to sample **233** (PAC 20 %). All methods where PAC 40 % was insoluble (1, 2, 5, 6, 8-11), as well as selected methods where the same sample was partially soluble (14 and 16), were tested. An overview of results is shown in Table 10.

Table 10: Solubility properties of PAC 20 % (sample **233**).

| JRC code | method | replicates | insoluble comp. % | conf. limit (95%) | <i>d</i> | conf. limit (95%) |
|------------|-----------|------------|----------------------|----------------------|-------------------|----------------------|
| 233 | 1 | 5 | 100.26 | 0.56 | 0.997 | 0.006 |
| 233 | 2 | 5 | 99.99 | 0.21 | 1.000 | 0.002 |
| 233 | 5 | 5 | 100.47 | 0.58 | 0.995 | 0.006 |
| 233 | 6 | 5 | 100.00 | 0.28 | 1.000 | 0.003 |
| 233 | 8 | 5 | 99.95 | 0.15 | 1.001 | 0.001 |
| 233 | 9 | 5 | 99.92 | 0.20 | 1.001 | 0.002 |
| 233 | 10 | 5 | 100.17 | 0.27 | 0.998 | 0.003 |
| 233 | 11 | 5 | 99.60 | 0.06 | 1.004 | 0.001 |
| 233 | 14 | 5 | 99.40 | 0.06 | 1.006 | 0.001 |
| 233 | 16 | 5 | 81.17 | 0.17 | partially soluble | - |

Table 11: Comparison of *d* correction factors of PAC 20 % (sample **233**) and PAC 40 % (sample **199**).

| Method | <i>d</i> factor | |
|-----------|-------------------|-------------------|
| | 233 (20 %) | 199 (40 %) |
| 1 | 1.00 | 1.00 |
| 2 | 1.00 | 1.00 |
| 5 | 1.00 | 1.00 |
| 6 | 1.00 | 1.00 |
| 8 | 1.00 | 1.00 |
| 9 | 1.00 | 1.00 |
| 10 | 1.00 | 1.00 |
| 11 | 1.00 | 1.02 |
| 14 | 1.01 | partially soluble |
| 16 | partially soluble | partially soluble |

A comparison of the *d* correction factors for the methods tested with the two PAC samples of different PA6 content is shown in Table 11. The content of PA6 greatly influenced the solubility properties of PAC when method 14 was applied; although PAC 40 % (sample **199**) was partially soluble in this method, PAC 20 % (sample **233**) was proved to be insoluble. On the contrary, the content of PA6 in PAC did not at all affect the solubility properties of the new fibre when methods 1, 2, 5, 6, 8, 9 and 10

were applied; PAC samples **233** and **199** presented the same d correction factors for these methods (1.00 in all cases). Regarding method 16, the solubility of PAC was much greater in the case of sample **199** (Tabs. 9-10) than in the case of sample **233**, fact that could be easily attributed to the higher content of the soluble component (PA6) in these specimens. In the case of method 11, a difference of 0.2 % was observed between PAC 20 % and 40 % (d factors 1.00 and 1.02 respectively).

Since the d correction factor for method 11 depended on PA6 content, its value was evaluated in the range of PAC's composition available (10 – 40 %), which covered the range in the definition initially proposed (10 – 45 %). As expected, the correction factor d for method 11 slightly increased with PA6 content, the average value being 1.01 (Table 12).

Table 12: Correction factors d for PAC (method 11).

| JRC code | nominal PA6 % | n | PAC % | conf. limit (95 %) | d | conf. limit (95 %) |
|------------------------------|---------------|----|-------|--------------------|--------------|--------------------|
| 195 | 5 | 10 | 99.86 | 0.03 | 1.001 | 0.0003 |
| 196 | 10 | 10 | 99.63 | 0.12 | 1.004 | 0.0013 |
| 197 | 20 | 10 | 99.48 | 0.14 | 1.005 | 0.0014 |
| 198 | 30 | 10 | 99.03 | 0.05 | 1.010 | 0.0005 |
| 199 | 40 | 9 | 97.82 | 0.04 | 1.023 | 0.0004 |
| average (196 - 199) : | | | | | 1.010 | |

5.4.1 Influence of drying conditions on solubility properties of PAC

A further confirmation that a ventilated oven can be used, instead of a vacuum one, without damaging the fibre was obtained comparing results regarding the solubility properties of PAC in a variety of methods. The sample selected for this study was sample **233** (PAC 20 %), as it was in production at the time of the study. All methods of Directive 96/73/EC where both PAC 40 % and 20 % (samples **199** and **233**) were proved to be insoluble were tested. The influence of drying conditions was also studied in the case of method 16, as this method could be used for quantification purposes, such as PA6 content in PAC (see par. 5.5.5). Method 14, where only sample **233** was insoluble, was investigated as well.

For each tested method ten replicates were analysed, with the drying conditions as fixed parameter; five of them were dried in a ventilated oven and the other five in a

vacuum one. The null hypothesis was that the two methods would give the same result (i.e., the difference between the two averages could be attributed to random errors).

First of all, the standard deviations of the two independent sets of measurements (s_1 and s_2 , with the number of replicates $n_1 = n_2 = 5$) were analysed with the F -test (two-sided test) to determine if the two experimental procedures had standard deviations which differed significantly [6].

To check the variances, the statistic F was calculated:

$$F = \frac{s_1^2}{s_2^2} \quad 5.4.1.1$$

where s_1^2 is the bigger variance, as F must be higher than 1.

Taking into consideration the degrees of freedom for each set of measurements (4 in both cases) and the confidence level required (95 % probability), F values were compared with the critical value $F_{4,4}$ ($P=0.05$) reported in tables. If F value was higher than F critical, it was assumed that there was a statistically significant difference between the two variances.

To judge if the averages of two independent sets of measurements differed significantly, in the case of non significant difference between variances, the statistic t was calculated as follows:

$$t = \frac{(\bar{x}_1 - \bar{x}_2)}{s \sqrt{\frac{1}{n_1} + \frac{1}{n_2}}} \quad 5.4.1.2$$

where \bar{x}_1 and \bar{x}_2 are the sample means and n_1 and n_2 the number of replicates for the two sets of measurements. The degrees of freedom of t are $n_1 + n_2 - 2$.

The standard deviation was calculated with the following formula:

$$s^2 = \frac{(n_1 - 1)s_1^2 + (n_2 - 1)s_2^2}{(n_1 + n_2 - 2)} \quad 5.4.1.3$$

If the difference between variances was significant, then the statistic t was calculated as follows:

$$t = \frac{(\bar{x}_1 - \bar{x}_2)}{\sqrt{\frac{s_1^2}{n_1} + \frac{s_2^2}{n_2}}} \quad 5.4.1.4$$

with the degrees of freedom estimated using the Welch-Satterthwaiteu approximation:

$$\nu = \frac{\left(\frac{s_1^2}{n_1} + \frac{s_2^2}{n_2} \right)^2}{\left(\frac{s_1^4}{n_1^2(n_1-1)} + \frac{s_2^4}{n_2^2(n_2-1)} \right)} \quad 5.4.1.5$$

When necessary, the calculated value of ν was rounded down to the nearest integer. Finally, t values were compared with the critical value t ($P=0.05$) reported in the Student's t -distribution tables. According to the t -test, the difference between the two averages could be considered not significant when the calculated $|t|$ value did not exceed the critical one.

The overview of results is shown in Tables 13 and 14. In all cases, the statistical analyses showed that results obtained with vacuum and ventilated oven could be considered equivalent at 95 % probability.

Table 13: Comparison of d factors obtained using vacuum vs. ventilated oven (sample 233).

| Method | Vacuum oven | | | Ventilated oven | | | F | F_{crit} | SD | t | t_{crit} | average |
|--------|-------------|--------|---|-----------------|--------|---|--------|------------|----|-------|------------|---------|
| | d factor | SD | n | d factor | SD | n | | | | | | |
| 1 | 0.997 | 0.0045 | 5 | 1.003 | 0.0011 | 5 | 17.60 | 9.60 | ≠ | 2.762 | 2.776 | = |
| 2 | 1.000 | 0.0017 | 5 | 1.002 | 0.0012 | 4 | 2.13 | 15.10 | = | 1.990 | 2.365 | = |
| 5 | 0.995 | 0.0046 | 5 | 0.992 | 0.0063 | 5 | 1.84 | 9.60 | = | 0.958 | 2.306 | = |
| 6 | 1.000 | 0.0023 | 5 | 1.003 | 0.0002 | 5 | 93.91 | 9.60 | ≠ | 2.542 | 2.776 | = |
| 8 | 1.001 | 0.0012 | 5 | 1.001 | 0.0010 | 5 | 1.30 | 9.60 | = | 0.053 | 2.306 | = |
| 9 | 1.001 | 0.0016 | 5 | 1.003 | 0.0001 | 5 | 281.65 | 9.60 | ≠ | 2.618 | 2.776 | = |
| 10 | 0.998 | 0.0022 | 5 | 1.001 | 0.0018 | 5 | 1.43 | 9.60 | = | 2.220 | 2.306 | = |
| 11 | 1.004 | 0.0005 | 5 | 1.005 | 0.0004 | 5 | 1.97 | 9.60 | = | 2.195 | 2.306 | = |
| 14 | 1.006 | 0.0005 | 5 | 1.006 | 0.0034 | 5 | 41.23 | 9.60 | ≠ | 0.150 | 2.776 | = |

Table 14: Comparison of soluble component obtained using vacuum vs. ventilated oven (sample **233**).

| Method | Vacuum oven | | | Ventilated oven | | | <i>F</i> | <i>F crit</i> | SD | <i>t</i> | <i>t crit</i> | average |
|--------|-----------------|--------|---|-----------------|--------|---|----------|---------------|----|----------|---------------|---------|
| | soluble comp. % | SD | n | soluble comp. % | SD | n | | | | | | |
| 16 | 18.828 | 0.1397 | 5 | 18.878 | 0.0083 | 5 | 283.43 | 9.60 | ≠ | 0.788 | 2.776 | = |

To verify that the drying conditions have no influence on the solubility properties of PAC, even in the case of higher PA6 content, a variety of methods were tested on sample **199** (PAC 40 %). A number of methods which partially solubilised PAC 40 % (4, 7 and 16), as well as some methods in which PAC 40 % was insoluble (10 and 11) were tested. Results were subjected to statistical evaluation and are presented in Tables 15 and 16.

Table 15: Comparison of soluble component obtained using vacuum vs. ventilated oven (sample **199**).

| Method | Vacuum oven | | | Ventilated oven | | | <i>F</i> | <i>F crit</i> | SD | <i>t</i> | <i>t crit</i> | average |
|--------|-----------------|--------|----|-----------------|--------|----|----------|---------------|----|----------|---------------|---------|
| | soluble comp. % | SD | n | soluble comp. % | SD | n | | | | | | |
| 4 | 33.016 | 0.2613 | 14 | 33.173 | 0.1906 | 10 | 1.88 | 3.83 | = | 1.618 | 2.074 | = |
| 7 | 31.433 | 0.2932 | 10 | 31.501 | 0.3543 | 10 | 1.46 | 4.03 | = | 0.470 | 2.101 | = |
| 16 | 35.177 | 0.2409 | 25 | 35.259 | 0.0828 | 10 | 8.47 | 3.61 | ≠ | 1.500 | 2.035 | = |

Table 16: Comparison of *d* factors obtained using vacuum vs. ventilated oven (sample **199**).

| Method | Vacuum oven | | | Ventilated oven | | | <i>F</i> | <i>F crit</i> | SD | <i>t</i> | <i>T crit</i> | average |
|--------|-----------------|--------|----|-----------------|--------|----|----------|---------------|----|----------|---------------|---------|
| | <i>d</i> factor | SD | n | <i>d</i> factor | SD | n | | | | | | |
| 10 | 1.001 | 0.0006 | 10 | 1.001 | 0.0009 | 4 | 2.37 | 5.08 | = | 1.352 | 2.179 | = |
| 11 | 1.023 | 0.0005 | 9 | 1.032 | 0.0016 | 10 | 10.19 | 4.36 | ≠ | 17.698 | 2.201 | ≠ |

Examining Tables 15 and 16 it can be concluded that, in the case of PAC 40 %, an influence of drying conditions was observed only applying method 11. The mass loss of PAC 40 % obtained using ventilated oven was slightly higher than the one evaluated using vacuum oven. Therefore, all available compositions of PAC were analysed with method 11, performing all the drying steps in a ventilated oven (Table 17). The aim was to obtain an average *d* factor value under these conditions in the range of interest (PAC 10 – 40 %) and to compare it with the one obtained in the case of vacuum oven (1.01).

Table 17: Correction factors d for PAC (method 11, ventilated oven).

| JRC code | nominal PA6 % | n | PAC % | conf. limit (95 %) | d | conf. limit (95 %) |
|-----------------------|---------------|----|--------|--------------------|-------|--------------------|
| 195 | 5 | 10 | 99.95 | 0.37 | 1.001 | 0.0037 |
| 196 | 10 | 10 | 100.34 | 0.33 | 0.997 | 0.0033 |
| 197 | 20 | 9 | 99.52 | 0.02 | 1.005 | 0.0003 |
| 198 | 30 | 10 | 99.27 | 0.09 | 1.007 | 0.0009 |
| 199 | 40 | 10 | 96.93 | 0.11 | 1.032 | 0.0011 |
| average (196 - 199) : | | | | | 1.010 | |

Comparing Tables 12 and 17 it can be seen that the d factor, expressed with two decimals, changed only in the case of PAC 40 %, when ventilated oven was used instead of the vacuum one. However, it should be highlighted that, although the d value was increased from 1.02 to 1.03 for sample **199** when ventilated oven was used, the average d factor value remained constant (1.01). This fact proved an overall non-significant influence of the drying conditions on the solubility properties of PAC, also in the case of method 11.

5.5 Quantification of PA6 in PAC

Nowadays, the production of PAC is restricted to a percentage of PA6 around 20 %; however, since the definition proposed by Aquafil foresees a wide range of composition (10 – 45 %), a method to quantify the content of PA6 in PAC should be available.

The methods proposed by the petitioner for this purpose were three: the first one was based on hydrolysis, the second one on DSC analysis and the third one on FT-IR analysis (see Annex I). In addition, a series of chemical dissolution methods were investigated in the attempt to find alternative less time-consuming methods for this quantification.

The JRC examined the applicability and tried to evaluate the accuracy of all these methods. Elemental analysis was used with the intention to quantify PA6 in PAC on the basis of the nitrogen content of PAC samples, which is only due to the polyamide component. Results obtained with this method were considered reference values against which all other results were compared.

5.5.1 Elemental analysis

Due to the composition of the new fibre (polypropylene and polyamide, plus a nitrogen-free compatibiliser), elemental analysis was carried out to evaluate the per cent of nitrogen in the fibre and from this value the content of PA6 in PAC. Results were calculated based on the value of per cent nitrogen obtained for PA6 (sample **193**). The analyses were performed in duplicate at the University of Camerino, Department of Chemical Sciences, Camerino (MC), Italy.

The principle of elemental analysis is based on the burning of samples and on the evaluation of the elements' content. The fibre is completely burnt during the analysis, consequently both the polyamide linked through the compatibiliser to polypropylene and the “free” polyamide are taken into consideration.

This technique is generally considered accurate and usually provides reproducible results; for these reasons, the results obtained with this method were considered as reference values and used to evaluate the performance of the other proposed methods.

Table 18: Quantification of PA6 in PAC (elemental analysis).

| JRC code | composition | nitrogen % | SD | PA6 % | difference vs. nominal |
|------------|-------------|------------|-------|--------------|------------------------|
| 195 | PAC 5 % | 0.850 | 0.342 | 7.11 | 2.11 |
| 196 | PAC 10 % | 1.280 | 0.011 | 10.72 | 0.72 |
| 197 | PAC 20 % | 2.368 | 0.005 | 19.83 | -0.17 |
| 233 | PAC 20 % | 2.371 | 0.004 | 19.85 | -0.15 |
| 198 | PAC 30 % | 3.398 | 0.006 | 28.45 | -1.55 |
| 199 | PAC 40 % | 4.368 | 0.001 | 36.57 | -3.43 |
| 193 | PA6 100 % | 11.944 | 0.001 | | |

As shown in Table 18, standard deviations were usually very low with the exception of sample **195**. The content of PA6 measured *via* elemental analysis was in good agreement with the nominal content in the case of samples **196**, **197** and **233** (10 %, 20 % and 20 % respectively), whereas differences in the range of 1-3.5 % were obtained in the rest of concentrations. It has to be highlighted, however, that the production process was optimised by Aquafil only for the actual production (PAC 20 %).

5.5.2 Hydrolysis method

Hydrolysis was proposed by the petitioner as a method to quantify PA6 inside the new fibre. The procedure foresees that 1 g of cut sample (dried for 16 h at 105 °C) is put in a round-bottom flask which contains an aqueous solution with hydrochloric acid 18.5 % w/w (100 ml/g of sample). The flask is connected to a condenser and placed in a silicon bath at 75 ± 5 °C. The reaction must be continued for 24 hours. In the end, the sample has to be filtered through a filter crucible (porosity 1) and washed with plenty of water until the washing liquor shows a neutral pH. The sample is then dried again (16 h at 105 °C) and weighed.

This method is meant to hydrolyse all the amidic bonds present in the polyamide component, both “free” and linked through the compatibiliser to the other component and is, therefore, supposed to give results comparable to the ones obtained with elemental analysis.

Table 19: Quantification of PA6 in pure PAC (hydrolysis method).

| JRC code | nominal PA6 % | elemental analysis PA6 % | hydrolysis Aquafil PA6 % | hydrolysis (JRC) | | | difference vs. elemental analysis | difference vs. hydrolysis Aquafil |
|------------|---------------|--------------------------|--------------------------|------------------|-------------------|------------|-----------------------------------|-----------------------------------|
| | | | | PA6 % | conf. limit (95%) | replicates | | |
| 195 | 5 | 7.11 | 4.81 | 3.24 | 0.62 | 5 | -3.87 | -1.57 |
| 196 | 10 | 10.72 | 9.59 | 7.97 | 0.33 | 5 | -2.75 | -1.62 |
| 197 | 20 | 19.83 | 18.60 | 18.25 | 0.51 | 4 | -1.58 | -0.35 |
| 198 | 30 | 28.45 | 27.46 | 25.65 | 0.61 | 5 | -2.80 | -1.81 |
| 199 | 40 | 36.57 | 35.74 | 36.05 | 0.35 | 5 | -0.52 | 0.31 |
| 233 | 20 | 19.85 | not provided | 18.72 | 0.31 | 4 | -1.13 | - |

As shown in Table 19, results obtained with hydrolysis were not in good agreement with the reference values and were always much lower than them; differences ranged from 0.5 % to almost 4 % depending on the sample. JRC and Aquafil’s results were similar only in the case of samples **197** and **199** (PA6 content 20 % and 40 % respectively). Consequently, the hydrolysis method was not considered accurate enough for the quantification of PA6 in PAC. In addition, the method was very time consuming and did not show high repeatability.

5.5.3 DSC method

DSC was proposed by the petitioner in order to quantify PA6 inside the new fibre. The experimental procedure was the same as the one reported for the identification of PAC (heating-cooling-heating cycle, from 0 to 260 °C at 10 °C/min, nitrogen flow 50 ml/min, samples of about 10 mg). For comparison purposes, several calibration curves were built up.

At first, both melting peaks due to PP and PA6 on the first and second heating cycles were integrated, together with the crystallisation peaks of PP and PA6 on the cooling cycle. Comparison showed that best results were obtained integrating the melting peaks on the second heating cycles and all the results presented in this section were calculated in this way. At first analyses were performed both on untreated and pre-treated samples, however, as no differences were observed, all the subsequent analyses were performed on untreated samples. Area results in this section represent the average of three replicates. The detailed results are reported in Annex IV.

Calibration curves were built up both for PP and PA6 melting peaks, using either samples of PAC containing different PA6 content as standards, or “physical mixtures” PP - PA6 prepared in the laboratory by weighing the pure fibres. Finally, quantification based just on the comparison between enthalpies of samples and of pure PP or PA6 was also performed.

The two calibration curves prepared by using samples of PAC with different PA6 content were built up taking into account the PA6 content evaluated with elemental analysis (Fig. 21, Table 20). The blue line shows the calibration curve referring to the PP content in PAC (correlation factor 0.9971), whereas the red line shows the PA6 one (correlation factor 0.9862).




Fig. 21: Calibration curves built with PAC (samples 195 - 199).

Table 20: Calibration curve data obtained with PAC (samples **195 - 199**).

| % PA6* | Average area (J/g) | |
|------------------|--------------------|--------|
| | PP | PA6 |
| 7.11 | 104.07 | 3.56 |
| 10.72 | 98.60 | 6.67 |
| 19.83 | 88.65 | 12.15 |
| 28.45 | 77.32 | 15.28 |
| 36.57 | 65.29 | 19.44 |
| y=mx+n | | |
| m = | -1.2884 | 0.5206 |
| n = | 113.24 | 0.7283 |
| R ² = | 0.9971 | 0.9862 |

* elemental analysis

Tables 21 and 22 compare quantitative results obtained *via* elemental analysis and DSC, using the calibration curves reported in Table 20. Results showed that the PA6 content of PAC samples can be well quantified by using this approach, only when the melting peak of PP is integrated.

Table 21: Quantification of PA6 in PAC (DSC method).
(calibration curve based on PAC samples, integration of PP melting peak)

| JRC code | nominal PA6 % | elemental analysis PA6 % | area J/g | DSC PA6 % | difference vs. elemental analysis |
|------------|---------------|--------------------------|----------|--------------|-----------------------------------|
| 195 | 5 | 7.11 | 104.07 | 7.12 | 0.01 |
| 196 | 10 | 10.72 | 98.6 | 11.37 | 0.65 |
| 197 | 20 | 19.83 | 88.65 | 19.09 | -0.74 |
| 198 | 30 | 28.45 | 77.32 | 27.89 | -0.56 |
| 199 | 40 | 36.57 | 65.29 | 37.23 | 0.66 |

Table 22: Quantification of PA6 in PAC (DSC method).
(calibration curve based on PAC samples, integration of PA6 melting peak)

| JRC code | nominal PA6 % | elemental analysis PA6 % | area J/g | DSC PA6 % | difference vs. elemental analysis |
|------------|---------------|--------------------------|----------|--------------|-----------------------------------|
| 195 | 5 | 7.11 | 3.56 | 3.31 | -3.80 |
| 196 | 10 | 10.72 | 6.67 | 10.32 | -0.40 |
| 197 | 20 | 19.83 | 12.15 | 22.66 | 2.83 |
| 198 | 30 | 28.45 | 15.28 | 29.71 | 1.26 |
| 199 | 40 | 36.57 | 19.44 | 39.08 | 2.51 |

As the availability of PAC standards with various PA6 concentrations could be problematic for enforcement laboratories (only PAC 20 % is produced nowadays), two other calibration curves (Fig. 22, Table 23) were built up using samples prepared

gravimetrically by mixing pure fibres of PP and PA6. The blue line shows the decrease of the PP peak area with the increase of the PA6 content in the binary mixtures (correlation factor 0.9996), whereas the red line shows the increase of the PA6 peak area with the increase of the PA6 content (correlation factor 0.9976).




Fig. 22: Calibration curves built up with “physical mixtures” PP – PA6.

Table 23: Calibration curve data obtained with “physical mixtures” PP – PA6.

| % PA6* | Area (J/g) | |
|-----------------|------------|--------|
| | PP | PA6 |
| 0 | 108.80 | 0.00 |
| 14.22 | 92.72 | 6.74 |
| 20.88 | 85.13 | 10.69 |
| 27.79 | 78.57 | 16.07 |
| 40.39 | 64.77 | 21.27 |
| 49.67 | 55.41 | 27.88 |
| 59.55 | 43.76 | 33.71 |
| 70.23 | 31.12 | 41.31 |
| 78.82 | 21.77 | 45.15 |
| 87.74 | 11.15 | 51.90 |
| 100 | 0.00 | 56.66 |
| y = mx+n | | |
| m = | -1.097 | 0.587 |
| n = | 108.72 | -1.02 |
| R² = | 0.9996 | 0.9976 |

* calculated from weighed mixtures PP - PA6

Table 24: Quantification of PA6 in PAC (DSC method).
(calibration curve based on “physical mixtures” PP - PA6, integration of PP melting peak)

| JRC code | nominal PA6 % | elemental analysis PA6 % | area J/g | DSC PA6 % | difference vs. elemental analysis |
|----------|---------------------|-----------------------------------|----------|-----------------|--|
| 195 | 5 | 7.11 | 104.07 | 4.24 | -2.87 |
| 196 | 10 | 10.72 | 98.60 | 9.23 | -1.49 |
| 197 | 20 | 19.83 | 88.65 | 18.30 | -1.53 |
| 198 | 30 | 28.45 | 77.32 | 28.62 | 0.17 |
| 199 | 40 | 36.57 | 65.29 | 39.58 | 3.01 |

Table 25: Quantification of PA6 in PAC (DSC method).
(calibration curve based on “physical mixtures” PP - PA6, integration of PA6 melting peak)

| JRC code | nominal PA6 % | elemental analysis PA6 % | area J/g | DSC PA6 % | difference vs. elemental analysis |
|----------|---------------------|-----------------------------------|----------|-----------------|--|
| 195 | 5 | 7.11 | 3.56 | 7.79 | 0.68 |
| 196 | 10 | 10.72 | 6.67 | 13.10 | 2.38 |
| 197 | 20 | 19.83 | 12.15 | 22.42 | 2.59 |
| 198 | 30 | 28.45 | 15.28 | 27.76 | -0.69 |
| 199 | 40 | 36.57 | 19.44 | 34.83 | -1.74 |

As seen in Table 24, DSC results were not in good agreement with the ones obtained *via* elemental analysis, independently of the integrated melting peak, and differences up to 3 % were noticed.

Alternatively, a third approach was considered for the quantification of PA6 in PAC, taking into account the enthalpies of the pure fibres polypropylene and polyamide. In this case, the areas of PP or PA6 melting peaks in pure fibres were compared with the areas of PP or PA6 melting peaks in PAC samples. Results are shown in Tables 26 and 27.

Table 26: Quantification of PA6 in PAC based on enthalpy value of pure PP fibres (sample 192).

| JRC code | nominal PA6 % | elemental analysis PA6 % | area J/g | DSC | | difference vs. elemental analysis |
|----------|---------------------|-----------------------------------|-------------|---------|----------|--|
| | | | | PP % | PA6 % | |
| 195 | 5 | 7.11 | 104.07 | 95.65 | 4.35 | -2.76 |
| 196 | 10 | 10.72 | 98.60 | 90.63 | 9.38 | -1.34 |
| 197 | 20 | 19.83 | 88.65 | 81.48 | 18.52 | -1.31 |
| 198 | 30 | 28.45 | 77.32 | 71.06 | 28.94 | 0.49 |
| 199 | 40 | 36.57 | 65.29 | 60.01 | 39.99 | 3.42 |
| 192 | 0 | - | 108.80 | - | - | - |

Table 27: Quantification of PA6 in PAC based on enthalpy value of pure PA6 fibres (sample **193**).

| JRC code | nominal | elemental analysis | area | DSC | | difference vs. elemental analysis |
|------------|---------|--------------------|--------------|-------|--------------|-----------------------------------|
| | PA6 % | PA6 % | J/g | PP % | PA6 % | |
| 195 | 5 | 7.11 | 3.56 | 93.72 | 6.28 | -0.83 |
| 196 | 10 | 10.72 | 6.67 | 88.22 | 11.78 | 1.06 |
| 197 | 20 | 19.83 | 12.15 | 78.56 | 21.44 | 1.61 |
| 198 | 30 | 28.45 | 15.28 | 73.03 | 26.97 | -1.48 |
| 199 | 40 | 36.57 | 19.44 | 65.70 | 34.30 | -2.27 |
| 193 | 100 | - | 56.66 | - | - | - |

Also in this case high differences were observed comparing to reference values.

Concluding, only the first approach based on the integration of the PP melting peak and calibration curve built up with PAC samples provided good quantification results. However, the difficulty of having access to PAC samples of various PA6 content represents a serious drawback of this approach.

5.5.4 FT-IR method

FT-IR was proposed by the petitioner as a method for the quantification of PA6 inside PAC. As described in the section regarding the identification of the new fibre (par. 4.2), FT-IR spectra of all samples were acquired using Attenuated Total Reflectance (ATR) mode with a Perkin Elmer instrument (FT-IR spectrometer spectrum 2000). Spectra were acquired in the scan range of 4000.00-650.00 cm^{-1} at a resolution of 4.00 cm^{-1} with a total of 4 scans. Samples were analysed as received. All measurements of absorbance refer to the PA6 peak at 1650 cm^{-1} .

For the quantification of PA6 in PAC, a calibration curve was prepared using the absorbance values of samples of PAC with different PA6 content and the percentage of PA6 obtained by elemental analysis. Five replicates of each sample were analysed and results are shown in Table 28. All spectra were normalised in the entire scan range to the ordinate limit of 0.2 A (63.1 % of transmittance), so that spectra of different ordinate amplitudes could be compared. Spectra of samples analysed by FT-IR are reported in Annex III.

Table 28: Absorbance values of PA6 peak at 1650 cm⁻¹ of PAC (samples **195 – 199**).

| JRC code | 195 | 196 | 197 | 198 | 199 |
|-------------------|---------------|---------------|---------------|---------------|---------------|
| % PA6* | 7.11 | 10.72 | 19.83 | 28.45 | 36.57 |
| Absorbance | 0.0484 | 0.0778 | 0.1276 | 0.1585 | 0.2000 |
| | 0.0485 | 0.0752 | 0.1298 | 0.1746 | 0.2000 |
| | 0.0514 | 0.0780 | 0.1299 | 0.1477 | 0.2000 |
| | 0.0546 | 0.0693 | 0.1350 | 0.1807 | 0.2000 |
| | 0.0445 | 0.0649 | 0.1260 | 0.1774 | 0.2000 |
| average | 0.0495 | 0.0731 | 0.1297 | 0.1678 | 0.2000 |
| SD | 0.004 | 0.006 | 0.003 | 0.014 | - |
| RSD % | 7.66 | 7.88 | 2.62 | 8.39 | - |

* quantification based on elemental analysis

The above data were used to build up the linear calibration curve shown in Fig. 23.

The y-residuals were calculated (Table 29) and their plot is presented in Fig. 24.




Fig 23: Linear calibration curve built-up with PAC (samples **195 – 199**).

Table 29: Y-residual values calculated based on the linear calibration curve.

| JRC code | Linear calibration: $y = ax + b$ | | | | |
|-------------------|----------------------------------|--------------|--------------|--------------|--------------|
| | 195 | 196 | 197 | 198 | 199 |
| % PA6* | 7.11 | 10.72 | 19.83 | 28.45 | 36.57 |
| estimated % PA6 | 6.01 | 10.60 | 21.65 | 29.07 | 35.35 |
| y-residual | -1.10 | -0.12 | 1.82 | 0.62 | -1.22 |

* quantification based on elemental analysis




Fig 24: Y-residuals plot based on the linear calibration curve.

The y-residuals showed a trend in the signs and magnitudes; at first they were negative at low x-values, then they reached a positive maximum and, finally, they became again negative. This fact suggested that a quadratic calibration curve should be plotted (Fig. 25). According to this curve, the y-residuals were calculated (Table 30) and their plot is presented in Fig. 26.




Fig 25: Quadratic calibration curve built-up with PAC (samples **195 – 199**).

Table 30: Y-residual values calculated based on the quadratic calibration curve.

| | Quadratic calibration: $y = ax^2 + bx + c$ | | | | |
|-----------------|--|-------|-------|-------|-------|
| JRC code | 195 | 196 | 197 | 198 | 199 |
| % PA6* | 7.11 | 10.72 | 19.83 | 28.45 | 36.57 |
| estimated % PA6 | 7.13 | 10.61 | 20.14 | 28.07 | 36.74 |
| y-residual | 0.02 | -0.11 | 0.31 | -0.38 | 0.17 |

* quantification based on elemental analysis




Fig 26: Y-residuals plot based on the quadratic calibration curve.

The distribution of y-residuals in the case of the quadratic calibration curve could be considered satisfactory. In order to check the accuracy of FT-IR as a technique to quantify PA6 in PAC, five replicates of sample **233** (PAC 20 %) were analysed using both the linear (Fig. 23) and the quadratic (Fig. 25) calibration curves. Results were compared to the ones obtained by elemental analysis (Tables 31 and 32).

Table 31: Absorbance values of PA6 peak at 1650 cm^{-1} of PAC (sample **233**).

| JRC code | 233 |
|------------|---------------|
| Absorbance | 0.1304 |
| | 0.1266 |
| | 0.1354 |
| | 0.1270 |
| | 0.1255 |
| average | 0.1290 |
| SD | 0.004 |
| RSD % | 3.12 |

Table 32: Quantification of PAC (sample **233**) using linear and quadratic calibration curves.

| JRC code | linear | quadratic |
|-------------------|--------------|--------------|
| % PA6* | 19.85 | 19.85 |
| estimated % PA6 | 21.51 | 20.01 |
| difference | 1.66 | 0.16 |

* quantification based on elemental analysis

The FT-IR technique presented results very similar to the ones obtained by elemental analysis, especially when the quadratic calibration curve was used. Nevertheless, the

disadvantage of the need to possess standards of PAC of various concentrations to build-up the calibration curve cannot be neglected.

5.5.5 Chemical methods

Chemical dissolution methods were applied by the JRC in order to find alternative methods for the quantification of PA6 in PAC, which do not require the availability of PAC standards. With the intention to dissolve the polyamide component of the fibre, the tested chemical methods were based on formic acid solutions of different concentration, applying various conditions of time and temperature. Results were compared with the ones obtained by elemental analysis (Table 33).

From the theoretical point of view, any chemical method able to dissolve polyamide but not polypropylene, will most probably not be capable to dissolve the part of PA6 chemically linked to polypropylene through the compatibiliser. For this reason, results were expected to be lower than the reference values obtained *via* elemental analysis.

Table 33: Quantification of PA6 in PAC (comparison of chemical methods).

| JRC Code | % PA6 * | | Method | | | | | |
|----------|---------|-------------------|--------|-------|-------|-------|-------|-------|
| | | | A | B | C | D | E | F |
| 199 | 36.57 % | n | 25 | 2 | 5 | 3 | 3 | 14 |
| | | PA6 % | 35.18 | 34.68 | 34.68 | 33.10 | 33.15 | 33.02 |
| | | conf. limit (95%) | 0.10 | 0.68 | 0.48 | 0.39 | 0.42 | 0.15 |
| 198 | 28.45 % | n | 20 | 5 | 3 | - | - | 10 |
| | | PA6 % | 27.61 | 27.20 | 26.89 | - | - | 18.58 |
| | | conf. limit (95%) | 0.05 | 0.46 | 0.05 | - | - | 0.77 |
| 197 | 19.83 % | n | 20 | 5 | 5 | - | - | 9 |
| | | PA6 % | 18.78 | 18.27 | 17.69 | - | - | 1.24 |
| | | conf. limit (95%) | 0.11 | 0.33 | 0.40 | - | - | 0.24 |
| 196 | 10.72 % | n | 19 | 3 | 6 | - | - | 9 |
| | | PA6 % | 8.94 | 8.89 | 5.26 | - | - | 0.40 |
| | | conf. limit (95%) | 0.02 | 0.70 | 1.46 | - | - | 0.10 |
| 195 | 7.11 % | n | 20 | 8 | 2 | - | - | 10 |
| | | PA6 % | 4.20 | 2.19 | 2.28 | - | - | 0.26 |
| | | conf. limit (95%) | 0.02 | 0.41 | 16.15 | - | - | 0.09 |

* % PA6 based on elemental analysis

| | Conditions | | | | | |
|--------------|------------|----------|----------|------|------|--------|
| | A | B | C | D | E | F |
| HCOOH | 90 % | 98-100 % | 98-100 % | 80 % | 80 % | 80 % |
| Time | 1 h | 3 h | 15 min | 7 h | 1 h | 15 min |
| T | 90 °C | RT* | RT | RT | RT | RT |

Note 1: Method A is method 16 of Directive 96/73/EC.

Note 2: Method F is method 4 of Directive 96/73/EC.

* RT: room temperature

Among all the tested methods, method 16 of Directive 96/73/EC (condition A) gave the most similar results to the reference values. This evidence suggested that a combination of high concentration of formic acid and high temperature is needed to reach and dissolve the PA6 fibrils shielded by polypropylene in PAC. Method 16 showed differences always negative, as expected, and not higher than 2 %. The only exception was in the case of sample **195**, but the reference value for this sample was most probably affected by errors; in fact, it was the only one showing high differences between the results for the two replicates (see Table 18).

Table 34: Quantification of PA6 in PAC (method 16).

| JRC code | nominal PA6 % | elemental analysis PA6 % | hot formic acid method | | | difference vs. elemental analysis |
|------------|---------------|--------------------------|------------------------|-------------------|------------|-----------------------------------|
| | | | PA6 % | conf. limit (95%) | replicates | |
| 195 | 5 | 7.11 | 4.20 | 0.02 | 20 | -2.91 |
| 196 | 10 | 10.72 | 8.94 | 0.02 | 19 | -1.78 |
| 197 | 20 | 19.83 | 18.78 | 0.11 | 20 | -1.05 |
| 198 | 30 | 28.45 | 27.61 | 0.05 | 20 | -0.84 |
| 199 | 40 | 36.57 | 35.18 | 0.10 | 25 | -1.39 |
| 233 | 20 | 19.85 | 18.83 | 0.17 | 5 | -1.02 |

Additionally, PAC samples were analysed with method 13 of Directive 96/73/EC, in an attempt to dissolve the PP component of PAC, instead of the PA6 one (Table 35). Even though filters were warmed in the oven before use, strong difficulties were experienced principally to avoid the reprecipitation of the dissolved PP component while filtering. In some cases, filtration was not possible at all, due to the occlusion of the filter, most probably not only due to the reprecipitation of PP, but also to the PA component that had the appearance of a thin plastic film. Problems were also noticed because of the lack of repeatability.

Table 35: Quantification of PA6 in PAC (method 13).

| JRC code | nominal PA6 % | elemental analysis PA6 % | method 13 | | | difference vs. elemental analysis |
|----------|---------------------|-----------------------------------|-----------|----------------------|------------|--|
| | | | PA6 % | conf. limit (95%) | replicates | |
| 195 | 5 | 7.11 | 5.11 | 0.25 | 5 | -2.00 |
| 196 | 10 | 10.72 | 11.29 | 0.35 | 5 | 0.57 |
| 197 | 20 | 19.83 | 20.04 | 0.59 | 5 | 0.21 |
| 198 | 30 | 28.45 | 29.99 | 0.22 | 5 | 1.54 |
| 199 | 40 | 36.57 | 40.22 | 0.23 | 8 | 3.65 |

In Table 35 only the best results are reported. They showed to be always higher than the reference values, except for sample **195**, confirming the idea that it was not possible to avoid completely the reprecipitation of PP on the filter. In the case of sample **199**, the difference was as high as 3.6 %. As a result, method 13 was excluded as a possible chemical quantitative method, due to the risk of overestimating the PA6 content in PAC.

Concluding, among the tested chemical methods, method 16 resulted to be the one with the highest accuracy, when compared with the results obtained *via* elemental analysis, and it was proposed by the JRC for the quantification of PA6 in PAC.

5.6 Quantification of binary mixtures PA6/PAC and PP/PAC

5.6.1 Manual separation

Binary mixtures made with twisted yarns were quantified *via* manual separation. Manual separation of binary mixtures made with interlaced yarns was not feasible, because the two fibres had the same colour (white).

The values of *agreed allowance* used for the calculation of results were 1.00 % for PAC, 2.00 % for PP and 5.75 % for PA6 (as the PA6 fibres of the binary mixture PA6/PAC were considered filaments). Results are listed in Table 36 and compared with the theoretical contents of PAC calculated based on linear density measurements, performed by Aquafil, on the pure fibres.

Table 36: Quantification of binary mixtures (manual separation).

| JRC code | composition | manufacturing type | theoretical (Aquafil) PAC % | manual separation | | | |
|------------|----------------|--------------------|-----------------------------|-------------------|--------------|--------------------|----------------------------|
| | | | | n | PAC % | conf. limit (95 %) | difference vs. theoretical |
| 201 | PA6/PAC (10 %) | twisted | 47.1 | 10 | 46.03 | 0.29 | -1.07 |
| 203 | PA6/PAC (20 %) | twisted | 47.4 | 10 | 46.37 | 0.44 | -1.03 |
| 205 | PA6/PAC (30 %) | twisted | 47.7 | 10 | 46.81 | 0.50 | -0.89 |
| 206 | PA6/PAC (40 %) | twisted | 47.7 | 9 | 46.47 | 0.56 | -1.23 |
| 208 | PP/PAC (10 %) | twisted | 50.1 | 10 | 49.50 | 0.40 | -0.60 |
| 210 | PP/PAC (20 %) | twisted | 50.4 | 10 | 49.73 | 0.32 | -0.67 |
| 212 | PP/PAC (30 %) | twisted | 50.7 | 10 | 49.87 | 0.47 | -0.83 |
| 213 | PP/PAC (40 %) | twisted | 50.8 | 10 | 50.45 | 0.49 | -0.35 |

Quantification results based on manual separation were in very good agreement with the theoretical ones. Whenever possible, manual separation is recommended as it is considered more precise and accurate than other analyses, such as the chemical ones. For this reason, PAC contents estimated through manual separation were considered as reference values against which results obtained with alternative methods were compared. For comparison purposes, the interlaced binary mixtures (samples **200**, **202**, **204**, **207**, **209** and **211**) were considered to be of the same composition as the respective twisted ones.

Carpet samples sent by Aquafil containing PA6 (beige) and PAC (white) were both loop type (samples **234** – **239**) and cut type (samples **240** – **245**). Similarly, carpet samples containing PP (black) and PAC (white) were loop type (samples **246** – **251**) and cut type (samples **252** – **257**). Half of the samples were manufactured containing twisted yarns and the other half interlaced ones. An example of carpet samples can be seen in Fig. 27.




Fig. 27: Cut carpet samples PP/PAC (samples 252 – 257) and PA6/PAC (samples 240 – 245).

Carpet samples were manually separated in order to obtain reference values against which compare other quantitative results (Tabs. 37-38). All loop carpet samples containing both twisted and interlaced yarns were analysed *via* manual separation. Manual separation of cut samples was not possible in the case of interlaced yarns. In the case of twisted yarns, this technique has the disadvantage to be very time-consuming and applicable only in the case of mixtures containing fibres of different colour.

Table 37: Quantification of carpet samples PA6/PAC (manual separation).

| | JRC code | nominal PA6 in PAC % | | manual separation | | | | |
|----------|----------|----------------------------|----------------------|-------------------|----------|-----------------------|-------|------|
| | | | | n | PAC % | conf. limit (95 %) | | |
| Carpet 1 | 234 | 30 | PA beige + PAC white | LOOP | twisted | 10 | 47.74 | 0.36 |
| | 235 | 20 | | | | 10 | 46.53 | 0.30 |
| | 236 | 10 | | | | 10 | 46.35 | 0.35 |
| | 237 | 30 | | Interl. | 10 | 46.66 | 0.39 | |
| | 238 | 20 | | | 10 | 46.54 | 0.45 | |
| | 239 | 10 | | | 10 | 46.50 | 0.53 | |
| Carpet 2 | 240 | 30 | CUT | twisted | - | - | - | |
| | 241 | 20 | | | - | - | - | |
| | 242 | 10 | | | - | - | - | |
| | 243 | 30 | | Interl. | - | - | - | |
| | 244 | 20 | | | - | - | - | |
| | 245 | 10 | | | - | - | - | |

PA beige + PAC white

Table 38: Quantification of carpet samples PP/PAC (manual separation).

| | JRC code | nominal PA6 in PAC % | | | manual separation | | | |
|----------|----------|----------------------------|----------------------|---------|-------------------|----------|-----------------------|------|
| | | | | | n | PAC % | conf. limit (95 %) | |
| Carpet 1 | 246 | 30 | PP black + PAC white | LOOP | twisted | 10 | 56.64 | 0.37 |
| | 247 | 20 | | | twisted | 10 | 56.94 | 0.48 |
| | 248 | 10 | | | twisted | 10 | 56.53 | 0.18 |
| | 249 | 30 | | Interl. | 10 | 56.36 | 0.34 | |
| | 250 | 20 | | | 10 | 56.24 | 0.38 | |
| | 251 | 10 | | | 10 | 55.72 | 0.60 | |
| Carpet 2 | 252 | 30 | | CUT | twisted | 8 | 56.41 | 0.14 |
| | 253 | 20 | | | | 8 | 56.42 | 0.31 |
| | 254 | 10 | | | | 8 | 56.15 | 0.10 |
| | 255 | 30 | | | Interl. | - | - | - |
| | 256 | 20 | | | | - | - | - |
| | 257 | 10 | | | | - | - | - |

5.6.2 DSC method

The DSC technique was proposed by the petitioner for the quantification of binary mixtures of PAC with PP or PA6. Using the same experimental procedure and the same approach as in the quantification of PA6 in PAC, two calibration curves were built up: the first one made with PAC samples (see Fig. 21) and the second one made with “physical mixtures” of pure PP and PA6 fibres (see Fig. 22). The areas (J/g) of PP and PA6 melting peaks were averaged on the basis of three replicates. Detailed results are reported in Annex IV.

If the percentage of PA6 in PAC is known, binary mixtures PP/PAC or PA6/PAC can be quantified using the value of total percentage of PA6 in the sample, measured with DSC. The percentage of PAC is calculated back in the following way.

For binary mixtures PA6/PAC:

$$\%PAC = 100 \frac{\%PP_t}{\%PP_i} = 100 \frac{100 - \%PA6_t}{100 - \%PA6_i} \quad 5.6.2.1$$

and for binary mixtures PP/PAC:

$$\%PAC = 100 \frac{\%PA6_t}{\%PA6_i} \quad 5.6.2.2$$

where

% PAC is the percentage of PAC in the binary mixture,
 % PP_i is the percentage of PP in PAC,
 % PP_t is the total percentage of PP in the binary mixture,
 % PA6_i is the percentage of PA6 in PAC,
 % PA6_t is the total percentage of PA6 in the binary mixture.

The quantification results obtained using the calibration curve built up with “physical mixtures” of PP and PA6 (see Fig. 22) are shown in Tables 39 and 40. The % PA6_i values, obtained by elemental analysis, were used as input in the calculations. It has to be reminded that manual separation could be performed only on twisted samples (**201**, **203**, **205**, **206**, **208**, **210**, **212** and **213**) and that, for comparison purposes, the interlaced samples were supposed to be of equal composition to the respective twisted ones.

Table 39: Quantification of binary mixtures PA6/PAC.
 (calibration curve based on “physical mixtures” PP - PA6)

| JRC code | elem. analysis PA6 % | man sep PAC % | PP J/g | PA6 J/g | based on PP area | | diff. vs. man sep | based on PA6 area | | diff. vs. man sep |
|------------|----------------------|---------------|--------|---------|------------------|--------------|-------------------|-------------------|--------------|-------------------|
| | | | | | PA6 tot % | PAC % | | PA6 tot % | PAC % | |
| 200 | 10.72 | - | 39.22 | 31.36 | 63.34 | 41.07 | -4.96 | 55.14 | 50.25 | 4.22 |
| 201 | 10.72 | 46.03 | 38.65 | 32.71 | 63.86 | 40.48 | -5.55 | 57.43 | 47.68 | 1.65 |
| 202 | 19.83 | - | 37.45 | 33.37 | 64.95 | 43.72 | -2.65 | 58.55 | 51.70 | 5.33 |
| 203 | 19.83 | 46.37 | 37.10 | 34.67 | 65.27 | 43.32 | -3.05 | 60.77 | 48.94 | 2.57 |
| 204 | 28.45 | - | 31.32 | 35.25 | 70.54 | 41.18 | -5.63 | 61.76 | 53.45 | 6.64 |
| 205 | 28.45 | 46.81 | 31.35 | 35.84 | 70.51 | 41.22 | -5.59 | 62.76 | 52.05 | 5.24 |
| 206 | 36.57 | 46.47 | 28.72 | 37.69 | 72.91 | 42.71 | -3.76 | 65.91 | 53.74 | 7.27 |

Table 40: Quantification of binary mixtures PP/PAC.
 (calibration curve based on “physical mixtures” PP - PA6)

| JRC code | elem. analysis PA6 % | man sep PAC % | PP J/g | PA6 J/g | based on PP area | | diff. vs. man sep | based on PA6 area | | diff. vs. man sep |
|------------|----------------------|---------------|--------|---------|------------------|--------------|-------------------|-------------------|--------------|-------------------|
| | | | | | PA6 tot % | PAC % | | PA6 tot % | PAC % | |
| 207 | 10.72 | - | 99.91 | 3.16 | 8.04 | 74.96 | 25.46 | 7.12 | 66.41 | 16.91 |
| 208 | 10.72 | 49.50 | 97.65 | 3.17 | 10.09 | 94.11 | 44.61 | 7.14 | 66.57 | 17.07 |
| 209 | 19.83 | - | 93.45 | 5.44 | 13.92 | 70.19 | 20.46 | 10.99 | 55.41 | 5.68 |
| 210 | 19.83 | 49.73 | 94.41 | 5.28 | 13.04 | 65.76 | 16.03 | 10.72 | 54.05 | 4.32 |
| 211 | 28.45 | - | 94.87 | 7.49 | 12.63 | 44.39 | -5.48 | 14.49 | 50.93 | 1.06 |
| 212 | 28.45 | 49.87 | 94.72 | 7.41 | 12.76 | 44.85 | -5.02 | 14.35 | 50.44 | 0.57 |
| 213 | 36.57 | 50.45 | 89.48 | 9.95 | 17.54 | 47.97 | -2.48 | 18.68 | 51.08 | 0.63 |

Apart from few exceptions, quantification results were not accurate. Both for binary mixtures with PA6 and PP, high differences were calculated comparing with the reference values, independently of the melting peak integrated.

Using the same approach for the calculation of results, the quantification results of binary mixtures PA6/PAC and PP/PAC, using the calibration curve built up with PAC samples (see Fig. 21), are shown in Tables 41 and 42.

Table 41: Quantification of binary mixtures of PA6/PAC.
(calibration curve based on PAC samples)

| JRC code | elem. analysis PA6 % | man sep PAC % | PP J/g | PA6 J/g | based on PP area | | diff. vs. man sep | based on PA6 area | | diff. vs. man sep |
|----------|-------------------------|------------------|-----------|------------|------------------|-------|-------------------------|-------------------|-------|-------------------------|
| | | | | | PA6 total % | PAC % | | PA6 total % | PAC % | |
| 200 | 10.72 | - | 39.22 | 31.36 | 57.45 | 47.66 | 1.63 | 58.84 | 46.10 | 0.07 |
| 201 | 10.72 | 46.03 | 38.65 | 32.71 | 57.90 | 47.16 | 1.13 | 61.42 | 43.21 | -2.82 |
| 202 | 19.83 | - | 37.45 | 33.37 | 58.82 | 51.36 | 4.99 | 62.69 | 46.54 | 0.17 |
| 203 | 19.83 | 46.37 | 37.10 | 34.67 | 59.10 | 51.02 | 4.65 | 65.19 | 43.42 | -2.95 |
| 204 | 28.45 | - | 31.32 | 35.25 | 63.58 | 50.90 | 4.09 | 66.31 | 47.09 | 0.28 |
| 205 | 28.45 | 46.81 | 31.35 | 35.84 | 63.56 | 50.93 | 4.12 | 67.43 | 45.51 | -1.30 |
| 206 | 36.57 | 46.47 | 28.72 | 37.69 | 65.60 | 54.23 | 7.76 | 70.99 | 45.73 | -0.74 |

Table 42: Quantification of binary mixtures of PP/PAC.
(calibration curve based on PAC samples)

| JRC code | elem. analysis PA6 % | man sep PAC % | PP J/g | PA6 J/g | based on PP area | | diff. vs. man sep | based on PA6 area | | diff. vs. man sep |
|----------|-------------------------|------------------|-----------|------------|------------------|--------|-------------------------|-------------------|-------|-------------------------|
| | | | | | PA6 total 5 | PAC % | | PA6 total % | PAC % | |
| 207 | 10.72 | - | 99.91 | 3.16 | 10.35 | 96.56 | 47.06 | 4.68 | 43.64 | -5.86 |
| 208 | 10.72 | 49.50 | 97.65 | 3.17 | 12.10 | 112.86 | 63.36 | 4.70 | 43.81 | -5.69 |
| 209 | 19.83 | - | 93.45 | 5.44 | 15.36 | 77.47 | 27.74 | 9.04 | 45.60 | -4.13 |
| 210 | 19.83 | 49.73 | 94.41 | 5.28 | 14.61 | 73.70 | 23.97 | 8.74 | 44.06 | -5.67 |
| 211 | 28.45 | - | 94.87 | 7.49 | 14.26 | 50.13 | 0.26 | 12.99 | 45.67 | -4.20 |
| 212 | 28.45 | 49.87 | 94.72 | 7.41 | 14.38 | 50.53 | 0.66 | 12.83 | 45.11 | -4.76 |
| 213 | 36.57 | 50.45 | 89.48 | 9.95 | 18.45 | 50.44 | -0.01 | 17.72 | 48.45 | -2.00 |

In the case of binary mixtures PA6/PAC, best results were obtained with the integration of the PA6 peak. Generally, good quantification could be achieved with the exception of two samples (**201** and **203**, PAC 10 % and 20 % respectively).

In the case of binary mixtures PP/PAC, differences obtained between DSC and manual separation results were very high, apart from samples with high PA6 content integrating the PP melting peak.

Alternatively, a third approach was performed for the quantification of binary mixtures PP/PAC and PA6/PAC, taking into account the enthalpies of the pure fibres PP and PA6, as in the case of the quantification of PA6 in PAC. For the calculation of results, formulas 5.6.2.1 and 5.6.2.2 were used, where:

$$\%PA6_i = 100 \frac{PA6_{(J/g)}}{PA6_{100\%}} \quad 5.6.2.3$$

in the case of integration based on the PA6 peak and

$$\%PA6_t = 100 - \%PP_t = 100 - \left[100 \frac{PP_{(J/g)}}{PP_{100\%}} \right] \quad 5.6.2.4$$

in the case of integration based on the PP peak.

Table 43: Quantification of binary mixtures PA6/ PAC, based on enthalpy values of pure PP (sample **192**) and PA6 (sample **193**).

| JRC code | elem. analysis PA6 % | man sep PAC % | PP J/g | PA6 J/g | based on PP area | | | diff. vs. man sep | based on PA6 area | | diff. vs. man sep |
|------------|----------------------|---------------|--------|---------|------------------|-------------|--------------|-------------------|-------------------|--------------|-------------------|
| | | | | | PP total % | PA6 total % | PAC % | | PA6 total % | PAC % | |
| 200 | 10.72 | - | 39.22 | 31.36 | 36.05 | 63.95 | 40.38 | -5.65 | 55.35 | 50.01 | 3.98 |
| 201 | 10.72 | 46.03 | 38.65 | 32.71 | 35.52 | 64.48 | 39.79 | -6.24 | 57.72 | 47.35 | 1.32 |
| 202 | 19.83 | - | 37.45 | 33.37 | 34.42 | 65.58 | 42.94 | -3.43 | 58.89 | 51.28 | 4.91 |
| 203 | 19.83 | 46.37 | 37.10 | 34.67 | 34.10 | 65.90 | 42.53 | -3.84 | 61.18 | 48.42 | 2.05 |
| 204 | 28.45 | - | 31.32 | 35.25 | 28.79 | 71.21 | 40.23 | -6.58 | 62.21 | 52.81 | 6.00 |
| 205 | 28.45 | 46.81 | 31.35 | 35.84 | 28.82 | 71.18 | 40.28 | -6.53 | 63.25 | 51.36 | 4.55 |
| 206 | 36.57 | 46.47 | 28.72 | 37.69 | 26.40 | 73.60 | 41.62 | -4.85 | 66.52 | 52.78 | 6.31 |

Table 44: Quantification of binary mixtures PP/ PAC, based on enthalpy values of pure PP (sample **192**) and PA6 (sample **193**).

| JRC code | elem. analysis PA6 % | man sep PAC % | PP J/g | PA6 J/g | based on PP area | | | diff. vs. man sep | based on PA6 area | | diff. vs. man sep |
|------------|----------------------|---------------|--------|---------|------------------|-------------|--------------|-------------------|-------------------|--------------|-------------------|
| | | | | | PP total % | PA6 total % | PAC % | | PA6 total % | PAC % | |
| 207 | 10.72 | - | 99.91 | 3.16 | 91.82 | 8.18 | 76.26 | 26.76 | 5.58 | 52.09 | 2.59 |
| 208 | 10.72 | 49.50 | 97.65 | 3.17 | 89.75 | 10.25 | 95.57 | 46.07 | 5.60 | 52.25 | 2.75 |
| 209 | 19.83 | - | 93.45 | 5.44 | 85.89 | 14.11 | 71.15 | 21.42 | 9.59 | 48.38 | -1.35 |
| 210 | 19.83 | 49.73 | 94.41 | 5.28 | 86.78 | 13.22 | 66.68 | 16.95 | 9.31 | 46.96 | -2.77 |
| 211 | 28.45 | - | 94.87 | 7.49 | 87.19 | 12.81 | 45.01 | -4.86 | 13.22 | 46.48 | -3.39 |
| 212 | 28.45 | 49.87 | 94.72 | 7.41 | 87.06 | 12.94 | 45.49 | -4.38 | 13.08 | 45.97 | -3.90 |
| 213 | 36.57 | 50.45 | 89.48 | 9.95 | 82.24 | 17.76 | 48.57 | -1.88 | 17.57 | 48.03 | -2.42 |

As presented in Table 23 (see par. 5.5.3), the enthalpies of pure PA6 ($PA6_{100\%}$) and pure PP ($PP_{100\%}$) were 56.66 J/g and 108.8 J/g, respectively. Results regarding the quantification of binary mixtures PA6/PAC and PP/PAC based on the comparison of the enthalpies of the binary mixtures and those of pure PA6 and PP are shown in Tables 43 and 44. Neither with the third approach good quantitative results could be obtained.

Based on all these experimental data, it can be concluded that the DSC method is not accurate enough to quantify binary mixtures PA6/PAC and PP/PAC. In fact, results were far different from the reference values obtained *via* manual separation.

5.6.3 Chemical analysis

5.6.3.1 *Method 11 of Directive 96/73/EC*

Binary mixtures of PA6/PAC were analysed with method 11 of Directive 96/73/EC, as PA6 fibrils inside the new fibre are not soluble with 75 % sulphuric acid at room temperature, whereas PA6 fibres in mixture with PAC are. The values of *agreed allowance* used for the calculation of results were 1.00 % for PAC and 5.75 % for PA6 (filament). According to the analysis performed on PAC samples (Tabs. 12 and 17), the *d* factor used for the calculation of results regarding binary mixtures was 1.01.

Table 45: Quantification of PAC in binary mixtures PA6/PAC (method 11).

| JRC code | nominal PA6 in PAC % | manuf. type | manual separation PAC % | method 11 | | | |
|----------|----------------------------|----------------|----------------------------------|-----------|----------|-------------------------|---|
| | | | | n | PAC % | conf. limit (95%) | difference vs. manual separation |
| 200 | 10 | interlaced | - | 9 | 46.87 | 0.24 | 0.84 |
| 201 | 10 | twisted | 46.03 | 10 | 46.16 | 0.30 | 0.13 |
| 202 | 20 | interlaced | - | 10 | 47.78 | 0.33 | 1.41 |
| 203 | 20 | twisted | 46.37 | 10 | 47.15 | 0.23 | 0.78 |
| 204 | 30 | interlaced | - | 10 | 47.29 | 0.79 | 0.48 |
| 205 | 30 | twisted | 46.81 | 10 | 47.28 | 0.26 | 0.47 |
| 206 | 40 | twisted | 46.47 | 9 | 46.91 | 1.27 | 0.44 |

Table 45 contains the quantitative results of binary mixtures PA6/PAC, as well as their comparison with the reference values. It has to be reminded that manual separation could be performed only on twisted samples (201, 203, 205 and 206) and that the respective interlaced samples were supposed to be of equal composition for comparison purposes. Results were similar to the ones obtained *via* manual separation, showing a difference of less than 1 % in most cases.

Carpet samples PA6/PAC were also quantified and results (Table 46) were in very good agreement with the ones obtained *via* manual separation, showing differences of less than 1 %. Therefore, it was concluded that method 11 is an accurate method for the quantification of PAC in binary mixtures PA6/PAC, both yarns and carpets.

Table 46: Quantification of carpets samples PA6/PAC (method 11).

| | JRC code | nominal PA6 in PAC % | | | manual separation PAC % | method 11 | | | difference vs. manual separation |
|----------|----------|----------------------|----------|------|-------------------------|-----------|-------|--------------------|----------------------------------|
| | | | | | | n | PAC % | conf. limit (95 %) | |
| Carpet 1 | 234 | 30 | PA / PAC | LOOP | 47.74 | 5 | 47.74 | 0.51 | 0.00 |
| | 235 | 20 | | | 46.53 | 5 | 46.80 | 0.65 | 0.27 |
| | 236 | 10 | | | 46.35 | 5 | 47.10 | 1.88 | 0.75 |
| | 237 | 30 | | | 46.66 | 4 | 47.37 | 0.39 | 0.71 |
| | 238 | 20 | | | 46.54 | 5 | 46.68 | 0.94 | 0.14 |
| | 239 | 10 | | | 46.50 | 5 | 46.77 | 0.60 | 0.27 |

5.6.3.2 Method 16 of Directive 96/73/EC

Binary mixtures of PP/PAC were analysed with method 16 of Directive 96/73/EC, which is able to solubilise PA6 fibrils inside PAC. If the percentage of PA6 in PAC is known, binary mixtures PP/PAC can be quantified by calculating the total percentage of PA6 in the binary mixture obtained with method 16. Then, the percentage of PAC in the binary mixture is calculated back using the formula 5.6.2.2. In the case of this experimental study, as Aquafil had provided the JRC with the PAC yarns used in the production of the binary mixtures, the percentage of PA6 in PAC, needed as input data in the above formula, was obtained applying method 16 to the PAC samples **195** – **199**. The values of *agreed allowance* used for the calculation of results with this method were 2.00 % for PP and 6.25 % for PA6 inside PAC (considered as discontinuous fibre).

Table 47: Quantification of PAC in binary mixtures PP/PAC (method 16).

| JRC code | nominal PA6 in PAC % | manuf. type | manual separation PAC % | method 16 | | | | | difference vs. manual separation |
|-------------|----------------------------|----------------|----------------------------------|-----------|-----------------------------------|-------------------------|-----------------------|----------|---|
| | | | | n | PA6 in binary mixtures % | conf. limit (95%) | PA6 in PAC % | PAC % | |
| 207 | 10 | interlaced | - | 9 | 4.56 | 0.17 | 8.94 | 50.97 | 1.47 |
| 208 | 10 | twisted | 49.50 | 10 | 4.41 | 0.05 | | 49.36 | -0.14 |
| 209 | 20 | interlaced | - | 10 | 9.51 | 0.10 | 18.78 | 50.66 | 0.93 |
| 210 | 20 | twisted | 49.73 | 10 | 9.44 | 0.14 | | 50.28 | 0.55 |
| 211 | 30 | interlaced | - | 9 | 14.03 | 0.05 | 27.61 | 50.82 | 0.95 |
| 212 | 30 | twisted | 49.87 | 9 | 14.09 | 0.05 | | 51.04 | 1.17 |
| 213 | 40 | twisted | 50.45 | 10 | 18.15 | 0.32 | 35.18 | 51.60 | 1.15 |

Table 47 contains the results of the quantification of PAC in binary mixtures PP/PAC, as well as their comparison with the reference values. Attention must be paid to the fact that manual separation could be performed only on twisted samples (**208**, **210**, **212** and **213**) and that the respective interlaced samples were supposed to be of equal composition for comparison purposes. Results appeared to be in good agreement with the quantification performed *via* manual separation. Differences were less than 1.5 % in all cases.

For the quantification of carpets PP/PAC, samples were firstly manually separated; then, the PAC part was analysed with method 16 in order to obtain the percentage of PA6 inside PAC (% $PA6_i$). The total % PA6 in the carpet samples (% $PA6_t$) was also measured by method 16 and these two percentages of PA6 were used for the quantification of PAC in the carpet samples using the formula 5.6.2.2.

Table 48: Quantification of carpets samples PP/PAC (method 16).

| | JRC code | nominal PA6 in PAC % | | manual separation PAC % | method 16 | | | | | | | | | |
|----------|----------|-------------------------------|----------|----------------------------------|-----------|-----------------------|-----------------------------|-------|--------------------------|--------------------------|----------|---|-------|------|
| | | | | | n | PA6 in PAC % | conf. limit (95 %) | n | PA6 in carpet % | conf. limit (95 %) | PAC % | difference vs. manual separation | | |
| Carpet 1 | 246 | 30 | PP / PAC | LOOP | twisted | 56.64 | 5 | 27.79 | 0.11 | 5 | 16.07 | 0.15 | 57.83 | 1.19 |
| | 247 | 20 | | | | 56.94 | 5 | 18.89 | 0.12 | 5 | 10.94 | 0.07 | 57.90 | 0.96 |
| | 248 | 10 | | | | 56.53 | 5 | 8.84 | 0.07 | 5 | 5.07 | 0.13 | 57.39 | 0.86 |
| | 249 | 30 | | | Interl. | 56.36 | 5 | 27.58 | 0.05 | 5 | 15.97 | 0.29 | 57.91 | 1.55 |
| | 250 | 20 | | | | 56.24 | 5 | 18.52 | 0.09 | 5 | 10.54 | 0.24 | 56.91 | 0.67 |
| | 251 | 10 | | | | 55.72 | 5 | 8.86 | 0.07 | 5 | 5.00 | 0.19 | 56.40 | 0.68 |
| Carpet 2 | 252 | 30 | | CUT | twisted | 56.41 | 3 | 27.76 | 0.05 | 2 | 16.09 | 0.55 | 57.95 | 1.54 |
| | 253 | 20 | | | | 56.42 | 3 | 18.68 | 0.03 | 2 | 10.79 | 0.19 | 57.76 | 1.34 |
| | 254 | 10 | | | | 56.15 | 3 | 8.85 | 1.08 | 2 | 4.99 | 1.36 | 56.35 | 0.20 |
| | 255 | 30 | | | Interl. | - | - | - | - | 6 | 15.77 | 0.05 | - | - |
| | 256 | 20 | | | | - | - | - | - | 5 | 10.67 | 0.08 | - | - |
| | 257 | 10 | | | | - | - | - | - | 6 | 5.15 | 0.05 | - | - |

In general, results obtained with method 16 were in line with the ones obtained *via* manual separation, showing differences of up to 1.55 %.

Concluding, method 16 was proved to be a method sufficiently accurate for the quantification of binary mixtures PP/PAC, including real carpet samples, provided that the PA6 content of PAC is known or a quantity of PAC can be separated from the mixture and analysed to obtain this value.

5.6.4 Densitometric method combined with method 16 of Dir. 96/73/EC

In an attempt to find a way to separate PAC from mixtures PP/PAC, when manual separation is not feasible, in order to be able to quantify its PA6 content applying method 16 on it, a variation of a densitometric method proposed by industry (see Annex I) was investigated. The physical separation of PAC from the binary mixture was based on the difference of densities between PAC (0.93-0.98 g/cm³) and PP (0.89-0.905 g/cm³). Using an ethanol/water solution of density 0.92 g/cm³, the less dense fibre PP would float on the surface of the liquid, whereas the densest fibre PAC would go to the bottom.

The yarns of the binary mixture were cut into pieces not longer than 5 mm; entangling knots were removed and single filaments were physically separated. 50 mg of cut yarns were placed in a bottle of 500 ml and then 400 ml of the ethanol/water solution (0.92 g/cm³), prepared at least two days before, were added. Mixing was performed until all fibres were wet and separated one from the other. The floating fibres were removed after 24 h and the solution was filtered to collect the fibres of the bottom. The filter with the residue was dried overnight (14-16 h) in a vacuum oven, left in dessicator for 2 h and then weighed.

Due to the fact that the densitometric method requires big quantities of ethanol, the ratio (sample size)/(volume of solution needed) had to be optimised; experimental tests proved that the optimal ratio was 100 mg of binary mixture PP/PAC per 200 ml of solution ethanol/water (90:130 v/v). Since the densitometric method was very time-consuming and several separations were needed in order to collect one gram of PAC, experiments were performed applying method 16 of Directive 96/73/EC to evaluate the minimum quantity of PAC sample needed for an accurate determination of PA6 in PAC. Sample sizes were decreased from one gram (reference value) to one hundred

milligrams; in parallel also the reagent volume was adjusted. First results showed that accuracy was worsened lowering sample size. This effect could be avoided using small and light glassware. As shown in Table 49, using small filters and weighing bottles, 100 mg of pure PAC in 50 ml of formic acid solution are sufficient in order to obtain results enough accurate.

Table 49: Quantification of PA6 in PAC, influence of sample size (method 16).

| JRC code | method 16 PA6 % | sample mass g | volume reagent ml | weighing bottle mass g | weighing filter mass g | n | PA6 % | conf. limit (95 %) | diff. |
|----------|-----------------|---------------|-------------------|------------------------|------------------------|----|-------|--------------------|-------|
| 199 | 35.18 | 0.500 | 100 | 68 | 32 | 3 | 35.36 | 0.48 | -0.18 |
| 199 | 35.18 | 0.250 | 50 | 68 | 32 | 3 | 35.52 | 0.36 | -0.34 |
| 199 | 35.18 | 0.200 | 40 | 68 | 32 | 3 | 35.59 | 0.20 | -0.41 |
| 199 | 35.18 | 0.150 | 30 | 68 | 32 | 3 | 36.51 | 1.18 | -1.33 |
| 199 | 35.18 | 0.100 | 20 | 68 | 32 | 3 | 35.98 | 0.11 | -0.80 |
| 199 | 35.18 | 0.100 | 50 | 68 | 32 | 9 | 36.39 | 0.07 | -1.21 |
| 199 | 35.18 | 0.250 | 50 | 20 | 19 | 9 | 35.18 | 0.05 | 0.00 |
| 199 | 35.18 | 0.100 | 50 | 20 | 19 | 10 | 35.37 | 0.05 | -0.19 |

In the case of a binary mixture PP/PAC about 50/50, the densitometric method would need to be applied five times, using the optimised ratio mg of sample per ml of solution, in order to collect about 200 mg of PAC, so that two replicates (100 mg each) could be analysed with method 16.

Unfortunately, from the experimental point of view, several problems were observed in particular due to lack of repeatability. Firstly, the fibres were prone to stay together, despite careful sample preparation; secondly, the same ethanol/water solution worked differently on different specimens of the same sample; thirdly, bubbles were evident in the solution and disturbed the process. Last but not least, the removal of the floating fibres had to be repeated twice with an interval of six hours, as the removal of the fibres caused perturbation of the solution and, thus, problems in separation.

The densitometric method was applied to the black/white carpet sample **255** (PP/PAC 30 %) to separate a quantity of PAC from the binary mixture. Subsequently, method 16 was performed on the separated PAC fibres (sample **255***) and results are shown in Table 50.

Table 50: Quantification of PA6 in PAC (method 16).

PAC separated from sample **255** (densitometric method).

| JRC code | reference value PA6 (HFA) % | sample mass g | volume reagent ml | n | PA6 % | conf. limit (95 %) | difference |
|----------|-----------------------------|---------------|-------------------|---|-------|--------------------|------------|
| 255* | 27.61 | 0.150 | 50 | 5 | 27.52 | 0.16 | 0.09 |

The quantification of PA6 in PAC in sample **255*** was very good; however, several major disadvantages were observed. First of all the entire procedure was very time-consuming; in fact, apart from the 24 plus 6 h contact time, five separations were needed in order to obtain the minimum quantity needed for the subsequent execution of method 16. Moreover, a perfect separation between PAC and PP could not be achieved, as evident due to the different colours of the fibres. Last but not least, there was an evident lack of repeatability in the experimental procedure. Therefore, the densitometric method was judged not adequate to separate PAC sample from binary mixtures PP/PAC as a first step towards the quantification of binary mixtures PP/PAC with method 16.

6. Collaborative trial

As agreed on 10th December 2010, during the 10th meeting of the European network of national experts on Textile Labelling (ENNETL), the JRC organised a collaborative trial at European level with the participation of 17 European laboratories. The validation exercise was conducted and evaluated according to ISO 5725:1994 (parts 1, 2 and 6). The first aim of the study was the validation of the *d* correction factors for PAC using methods 2, 8 and 11 of Directive 96/73/EC. The second aim was the validation of method 11 as quantitative method for binary mixtures PA/PAC, including the determination of the method's accuracy in terms of trueness and precision.

The initial plan was to use samples of both PAC 20 % and 40 % in the validation exercise; however, PAC 40 % (samples **266** and **281**) newly produced by Aquafil showed solubility properties completely different from the ones of sample **199** (Table 51). In fact, the producer was unable to reproduce PAC 40 % which remains insoluble when treated with method 11, as it was the case for sample **199**. For this reason PAC 40 % was finally not included in the collaborative study.

Table 51: Solubility properties of PAC 40 % (method 11).

| JRC code | replicates | insoluble component % | conf. limit (95%) | <i>d</i> | conf. limit (95%) |
|------------|------------|-----------------------------|----------------------|--------------|----------------------|
| 199 | 10 | 96.93 | 0.15 | 1.032 | 0.16 |
| 266 | 5 | 65.51 | 1.14 | 1.518 | 1.11 |
| 281 | 3 | 82.52 | 6.92 | 1.230 | 6.95 |

For the validation of the *d* values, yarns of PAC 20 % (sample **280**), provided by the petitioner, were used. For the validation of method 11, a balanced uniform level test was performed. Carpet samples made of binary mixtures PA/PAC 20 % of three levels of concentration (PA content about 25, 50 and 75 %) were sent to participants (samples **282 - 284**). Loop twisted carpets were chosen in order to be able to obtain reference values through quantification done *via* manual separation. Each laboratory analysed five replicates for every sample under repeatability conditions.

6.1 Design of the collaborative trial

Seventeen laboratories from fifteen EU member states (BE, CZ, FI, FR, DE, EL, HU, IT, LT, PL, PT, RO, SK, ES and UK), members of the ENNETL, participated in the validation study. The participants were provided with test samples, instruction guidelines and an electronic reporting sheet containing formulas to collect results. They were requested to strictly follow the protocols of methods 2 and 8, as described in Directive 96/73/EC. On the contrary, in the case of method 11 a slight modification in the procedure was adopted. Work conducted by the JRC had shown that, in case method 11 would have to be used for binary mixtures containing the new fibre and polyamide in concentration higher than 60 %, accurate quantification could only be achieved modifying the washing procedure. For this reason, participants were asked to apply the modified version of method 11. The modification foresaw the addition of two new washing steps of PAC residue with 75 % sulfuric acid solution before applying the normal washing procedure.

6.2 Homogeneity study

For the validation study, in the case of yarns, the fibre had to be homogenised before being sent to participants. Homogenisation was performed using a glass round-bottom balloon of 50 l capacity. Due to the big quantity of homogenised sample needed, the yarn sample was divided into five batches of about 70 g each, for every method. Fibres of every batch were cut into pieces of about 10 mm and inserted into the balloon. The balloon was tapped with an elastic porous tissue, through which compressed air was applied for 5 minutes to mix the fibres, using an air blow gun. From each homogenised batch a testing specimen of about 2.6 g was packed in a plastic package. Half of the quantity of each testing specimen (about 1.3 g) had to be analysed under repeatability conditions for the determination of the d correction factor. The second halves had to be considered as spare samples, to be analysed only in case of errors during the quantification of one or more testing specimens. In that case, all five spare specimens had to be quantified together under repeatability conditions.

In the case of carpets, five batches were selected longitudinally from each of the three carpet samples. Every batch was sub-divided into 24 testing specimens of 2.6 g each.

Each testing specimen was split in two pieces of 1.3 g each, placed together in the same aluminium foil package. Again, only one piece of each specimen (1.3 g) had to be quantified in repeatability conditions and the rest had to be considered as a spare sample.

Homogeneity tests were performed according to the accepted procedure of the test for ‘sufficient homogeneity’ [7]. For yarn sample **280**, two testing specimens of 2.6 g each were randomly selected from the homogenised batches (five for every method) and analysed in duplicate with methods 2, 8 and 11. The 20 replicates (for each method) were analysed under randomised repeatability conditions. All results were checked for outliers according to Cochran’s test and were retained as there was no evidence for analytical outliers. The statistical evaluation of results showed that the yarn sample was ‘sufficiently homogeneous’ when tested with methods 2, 8 and 11 and that there was no evidence for significant differences among the five batches.

For every carpet (samples **282 - 284**), two testing specimens of 2.6 g each were randomly selected from each of the five batches and analysed in duplicate with method 11. Analyses on the 20 replicates, carried out under randomised repeatability conditions, showed that there was no evidence for analytical outliers according to Cochran’s test. As in the case of yarn sample, the statistical evaluation of results showed that carpet samples could be considered ‘sufficiently homogeneous’ when tested with method 11 and that there was no evidence for significant differences among the five batches.

Consequently, both yarn and carpet samples were considered suitable to be sent to participants for the purposes of the validation study. For each sample and method, five testing specimens were randomly provided to every laboratory participant, one from each batch.

6.3 Results of collaborative trial

All participant laboratories reported results. At first, data were investigated for outliers according to Mandel’s h parameters to detect laboratories with high or low extreme mean values and according to Mandel’s k parameters to detect laboratories with poor repeatability. No decision about possible elimination of suspect data was taken on the basis of Mandel’s statistics. Secondly, Cochran’s and Grubbs’ tests were carried out to identify numerical outliers. Based on these tests, data considered

outliers were eliminated, whereas data considered stragglers were retained. Repeatability and reproducibility standard deviations were calculated according to ISO 5725-2 in order to obtain the repeatability and reproducibility limits (r and R , respectively).

In the case of the evaluation of d correction factors, for the calculation of the precision parameters, according to Cochran's test one outlier was rejected for method 2 and two for method 11. Final results were:

| | | | |
|-----------|-------------|--------------|--------------|
| Method 2 | $d = 1.001$ | $r = 0.0031$ | $R = 0.0077$ |
| Method 8 | $d = 1.004$ | $r = 0.0047$ | $R = 0.0146$ |
| Method 11 | $d = 1.005$ | $r = 0.0039$ | $R = 0.0089$ |

In the case of the validation of method 11 for the quantification of binary mixtures PA/PAC, for the calculation of the precision parameters, two outliers were eliminated according to Grubbs for the carpet sample **284** (approximate concentration of PAC 75 %).

The trueness of the method (expressed as bias) was calculated, for the three levels of concentration, as the difference between the content of PAC (%), obtained by method 11, and its reference value, obtained by manual separation. Manual separation was performed on ten replicates, two from each of the five batches from which testing specimens were sent to participants. The bias of the method, calculated using a d factor value equal to 1.005, was in the range 0.06 – 0.48 %, increasing with the content of polyamide. Using four levels of concentration (the three carpet samples plus the PAC 20 % yarn analysed to establish d), a linear relationship was found between bias and % PAC.

The d value for PAC in method 11, determined through the collaborative trial, was 1.005; however, d correction factors in Directive 96/73/EC are usually reported with two decimals. For this reason, the influence of the d factor on trueness was evaluated using the three values 1.00, 1.005 and 1.01. Following ISO 5725-6, critical differences were calculated using these three values. Best results were obtained in the case of $d = 1.005$, where the bias could be considered acceptable in three out of four levels of concentration. Therefore, this value was proposed by the JRC.

Results regarding precision parameters, calculated using d factor equal to 1.005, were:

| | | | |
|---------------|--------------|--------------|-----------------|
| PAC % = 76.96 | r (%) = 0.69 | R (%) = 0.97 | bias (%) = 0.06 |
| PAC % = 48.43 | r (%) = 1.04 | R (%) = 1.87 | bias (%) = 0.28 |
| PAC % = 27.35 | r (%) = 0.95 | R (%) = 1.68 | bias (%) = 0.48 |

On this basis, the JRC proposed the value of 2 %, as the reproducibility limit of method 11, to be inserted in Directive 96/73/EC.

7. 11th ENNETL meeting

As discussed during the 9th and 10th ENNETL meetings, experts confirmed that, in their point of view, the term “composite” should not be part neither of the name nor of the definition of the new fibre. They were, instead, in favour of the term “bicomponent” fibre. Moreover, they were of the opinion that the term “propylamide”, proposed by the petitioner, could mislead giving wrong idea about the chemical composition of the fibre. “Bi-polypropylene/polyamide” and “polypropylene/polyamide bicomponent” were considered good proposals for the following reasons: first of all, the names of constituents are stated and secondly, both bi- and bicomponent introduce the idea of a multicomponent fibre. A written consultation of national experts was organised by the JRC and the name preferred by the majority was “*polypropylene/polyamide bicomponent*”.

Regarding the definition, as far as the range of composition is concerned, experts decided to change the proposed range 10 % - 45 %, due to the problems experienced with PAC 40 %. In fact, solubility properties of different samples of PAC 40 % were proved to be substantially different, thus strongly influencing their behaviour when method 11 was applied (see chapter 6). The group of experts judged that an analytical method to quantify binary mixtures PA/PAC is needed to allow market surveillance and, for this reason, they agreed to restrict the range of composition to 10 % – 25 %. Some experts were of the opinion that the structure “islands-in-the-sea” should be mentioned in the definition and questioned the term “fibrils”. On the basis of a written consultation regarding the new definition in its various possible forms, the majority of experts chose the following: “*a bicomponent fibre composed of between 10 % and 25 % by mass of polyamide fibrils embedded in polypropylene matrix*”.

Experts agreed on the adoption of 1.00 %, as the value of *agreed allowance* for the new fibre (see par. 5.3), based on the restriction of composition’s range for PAC (10 % – 25 %) and on the average result (about 0.40 %). According to experimental results, experts agreed on the value of 0 % as the *b* correction factor for mass loss due to pre-treatment (see par. 5.2).

The group agreed that, according to the results of the validation study, the field of application of method 11 shall be extended to binary mixtures PA/PAC and the following *d* factor values for PAC should be inserted in Directive 96/73/EC: 1.00 for

methods 2 and 8 and 1.005 for method 11. They also considered necessary to be specified that, in the description of method 11 for binary mixtures PA/PAC, the modified washing procedure has to be followed and the reproducibility limit is 2 %. In addition, they were of the opinion that all the other *d* correction factors evaluated by the JRC both for PAC and PP shall be trusted and inserted in Directive 96/73/EC on the basis of 20 replicates.

8. Further experimental work

As the experimental work performed on solubility properties had been essentially done on PAC 40 % and due to the decision of restricting the composition's range for the new fibre (10 % – 25 %), further experimental work was conducted by the JRC on PAC 20 %. Twenty replicates were analysed in case PAC resulted to be insoluble, in order to establish the d correction factors. Analyses on ten replicates were performed in case PAC was partially soluble.

Table 52: Solubility properties of PAC 20 %.

| JRC code | method | replicates | insoluble component % | conf.limit (95%) | d | conf.limit (95%) |
|----------|--------|------------|-----------------------|------------------|-------------------|------------------|
| 233 | 1 | 19 | 99.83 | 0.094 | 1.002 | 0.001 |
| 233 | 3 | 10 | 82.23 | 0.148 | partially soluble | - |
| 233 | 4 | 10 | 94.60 | 0.301 | partially soluble | - |
| 233 | 5 | 20 | 100.25 | 0.258 | 0.997 | 0.003 |
| 233 | 6 | 20 | 99.84 | 0.082 | 1.002 | 0.001 |
| 233 | 7 | 20 | 99.38 | 0.048 | 1.006 | 0.001 |
| 233 | 9 | 19 | 99.90 | 0.106 | 1.001 | 0.001 |
| 233 | 10 | 20 | 99.92 | 0.093 | 1.001 | 0.001 |
| 233 | 14 | 20 | 99.30 | 0.095 | 1.007 | 0.001 |

As shown in Table 52, PAC 20 % was proven to be partially soluble under the conditions of methods 3 and 4 and insoluble in methods 1, 5-7, 9, 10 and 14. The d correction factor values were 1.00 for methods 1, 5, 6, 9 and 10, whereas methods 7 and 14 showed d values equal to 1.01.

9. Conclusions

On the basis of experimental results, discussions during the 9th, 10th and 11th ENNETL meetings (20th October 2008, 10th December 2009 and 15th July 2010) and written consultation with national experts, the name and definition agreed and proposed for the new fibre are “*polypropylene/polyamide bicomponent: a bicomponent fibre composed of between 10 % and 25 % by mass of polyamide fibrils embedded in polypropylene matrix*”.

Experimental work conducted at the JRC confirmed that test methods are available for the identification and quantification of the new fibre PAC.

As far as the identification methods are concerned, experts agreed with the JRC that Scanning Electronic Microscope (SEM) analysis is an adequate method, whereas optical microscopy is not. Additionally, Fourier Transform Infrared Spectroscopy (FT-IR) and Differential Scanning Calorimetry (DSC) can be used as techniques to differentiate PAC from binary mixtures PP - PA.

For quantification purposes, the normal pre-treatment described in Directive 96/73/EC, was proved to be applicable to the new fibre. Ventilated oven can be used, instead of the vacuum one proposed by the applicant, as statistical evaluation showed that results could be considered equivalent in the two cases. The *agreed allowance* of the new fibre and the correction factor *b* for mass loss during pre-treatment were experimentally evaluated. The resulting values, adopted by the network of national experts from member states, were 1.00 % and 0 % respectively. Additionally, the solubility properties of the new fibre were evaluated with all methods described in Directive 96/73/EC. The solubility behaviour of PA6 and PP was studied as well, in case the information is not included in Directive 96/73/EC.

The new fibre was proved to be insoluble in methods 1, 2, 5-11 and 14. The *d* correction factors were established on the basis of the experimental work carried out by the JRC and, in the case of methods 2, 8 and 11, checked through a collaborative trial at European level. For the determination of the *d* correction values, yarns of pure PAC 20 % were used. The resulting values were: 1.00 for methods 1, 2, 5, 6, 8-10, 1.005 for method 11 and 1.01 for methods 7 and 14.

Polypropylene was insoluble in methods 1, 3, 5-11, 14 and 16; the average *d* factor values were 1.00 in all cases. Polyamide 6 was shown to be insoluble in methods 5

and 10 and the average d factor values were 1.00 and 1.01, respectively. Experts agreed that only the correction factors d for PAC and PP shall be inserted in Directive 96/73/EC, as the ones for polyamide were measured just on PA6.

The JRC examined the applicability and evaluated the accuracy of the three methods (hydrolysis, DSC and FTIR) proposed by the petitioner to quantify the content of PA in PAC. In addition, a series of chemical dissolution methods were investigated in the attempt to find accurate and less time-consuming alternative methods for this quantification. PA6 in PAC was quantified *via* elemental analysis on the basis of the nitrogen content of PAC samples, which is only due to the polyamide component. Results obtained with this technique were considered reference values against which all other results were compared.

The DSC and FT-IR methods quantified accurately PA6 in PAC, but showed the disadvantage to require the availability of standards of PAC of various PA contents in order to build up calibration curves. The hydrolysis method, apart from the fact that it was very time-consuming, did not present results similar to the reference values. Among the chemical dissolution methods tested, method 16 of Directive 96/73/EC was proved to be in good agreement with elemental analysis. Therefore, it was proposed by the JRC and agreed by national experts as the most suitable method for the quantification of the PA6 content of the new fibre.

For the quantification of PAC in binary mixtures with PA and PP, manual separation is an adequate technique whenever feasible. Alternatively, several methods were investigated not only on yarns but also on real carpet samples. The accuracy of these methods was evaluated by comparing quantification results to the ones obtained *via* manual separation on twisted yarns. The DSC method, proposed by the petitioner, resulted to be not accurate, neither in the case of mixtures PA/PAC nor of PP/PAC.

For the quantification of binary mixtures PA/PAC, method 11 of Directive 96/73/EC was judged very accurate, as results were in very good agreement with the reference values. In fact, 75 % sulphuric acid solution at room temperature (1 h contact time) was able to solubilise only the PA fibres in the binary mixture and not the PA fibrils inside PAC. For the quantification of binary mixtures PP/PAC, method 16 of Directive 96/73/EC was proved to be accurate when compared to the reference values. PA inside PAC could be solubilised using 90 % formic acid at 90 °C (1 h contact time). However, the great disadvantage that the PA content of PAC should be known for the calculation of results cannot be neglected. In an attempt to overcome this

problem, a densitometric approach was used to separate PAC from PP/PAC binary mixtures, to allow the quantification of PA content in it; however, several problems were experienced leading to lack of repeatability.

On the basis of experimental results obtained also on real carpet samples, the JRC proposed method 11 as the adequate one for quantifying mixtures PA/PAC. During the 10th ENNETL meeting, a consensus was reached on the need to validate method 11 to extend the field of application to this binary mixture. Consequently, the JRC organised a successful collaborative trial with the participation of 17 European laboratories, in accordance with the rules laid down in ISO 5725:1994. For the validation of method 11, a balanced uniform level test was performed. Loop twisted carpet samples made of binary mixtures PA/PAC 20 % of three levels of concentration (PA content around 25, 50 and 75 %) were tested for sufficient homogeneity and sent to participants. Carpet samples were quantified also *via* manual separation in order to obtain reference values against which compare results.

Based on the outcome of the validation study, experts agreed that the field of application of method 11 shall be extended to the quantification of binary mixtures PA/PAC. The JRC and experts were of the opinion that, in the description of method 11, the reproducibility limit of 2 % shall be specified in the case of binary mixtures PA/PAC. Furthermore, it was decided that the modified washing procedure, used in the collaborative study and needed to obtain correct quantification of mixtures PA/PAC with high percentages of PA fibres, must be inserted in Directive 96/73/EC.

10. References

- [1] Directive 96/74/EC of the European Parliament and of the Council of 16 December 1996 on textile names (*Official Journal L032 of 3.2.1997 p. 0038-0055*).
- [2] Directive 2008/121/EC of the European Parliament and of the Council of 14 January 2009 on textile names (recast) (*Official Journal L019 of 23.1.2009 p. 0029-0048*).
- [3] Directive 96/73/EC of the European Parliament and of the Council of 16 December 1996 on certain methods for the quantitative analysis of binary textile fibre mixtures (*Official Journal L032 of 3.2.1997 p. 0001-0037*).
- [4] ISO 6348 (1980). Textiles. Determination of mass. Vocabulary. International Organization for Standardization, Geneva, Switzerland
- [5] ISO 5725 (1994). Accuracy (trueness and precision) of measurement methods and results. International Organization for Standardization, Geneva, Switzerland.
- [6] Miller, J. N., Miller, J. C., Statistics and Chemometrics for Analytical Chemistry. Pearson Education Limited, .5th Ed, 2005.
- [7] Thompson, M., Ellison, S. L. R., Wood, R., The international harmonized protocol for the proficiency testing of analytical chemistry laboratories (IUPAC Technical Report), *Pure Appl. Chem.*, 2006, **78** (1), 145.

Annex I

Analytical methods proposed by the applicant

Development of Experimental Methodologies for the Identification of the PAC fibre in commercial fibre blends.

Summary.

Aquafil applied for a New Generic Name on November the 8th 2005 and presented the new fibre to the Commission of the Member States Technical Experts W.G. on Textile Labelling on the 6th of February 2006. The new fibre is based on a chemical blend of PA and PP, whereas the PA is shaped in a nanofibrils form inside the PP matrix.

The proposed Fibre definition was: 'A composite fibre composed of between 10% and 45% by mass of polyamide fibrils embedded in polypropylene matrix' and the proposed Generic Name was Propylamidecomposite (PAC). In this report this will be used.

Following the positive discussion and decision made by the EU Commission W.G., a request was issued by the same Commission to Aquafil to propose specific methodologies for the quantitative identification of the new fibre inside fibres blends.

Activities done by Aquafil, also in collaboration with the University of Trento, were concentrated on the PA/PP/PAC blends, as, in case of other blends other known and simple analysis, will provide the information.

Results indicate that it is possible to discriminate and measure the quantity of the new fibre inside a fibre blends, both binary and ternary. In particular the chemical elimination of the PA part seems to be particularly useful in case of mixtures with PA fibres, while the fibre differentiation through density separation can be proposed as a general method for any type of fibre blend.

Sample preparation.

Fibre blends were prepared by air-entangling of different BCF yarns, as listed in Tab.1. This reprocessing technology is characterised by the physical intimate mixing of the singles filaments of each yarn and physical knots are created. The actual Wt% for each fibre was calculated from original yarn's denier. It must be remarked that the error in the dtex measurement is about $\pm 1,5\%$ and therefore the minimum wt% error in the real quantity of fibre present can be estimated to be about $\pm 1\%$.

Tab.1 – List of fibre blends prepared for the methodology evaluation.

| | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
|-----|-------|-------|-------|-------|-------|-------|-------|
| | wt. % | wt. % | wt. % | wt. % | wt. % | wt. % | wt. % |
| PAC | 48,5 | 55 | 35 | | | 77 | 38 |
| PA | 50,5 | | 37 | 74 | | | 30 |
| PP | | 45 | 28 | | 65 | | 22 |
| PES | | | | 26 | 35 | 23 | 12 |

Qualitative and Quantitative fibre determination inside fibre blends

A) Colorimetric Fibre Identification.

This method is based on the fact that the different polymers do have a different chemical behaviour towards dyestuffs. In particular: PA 6 and 66 shows a chemical reaction against acid and/or cationic dyestuffs, while PAC or PES does not.

Methodology description

1. Fibre preparation with spin finish removal using petrol ether or methyl alcohol and drying for 2 h at 100°C.
2. Fibre weighing.
3. Liquor preparation using following dyestuff types and concentrations:
 - a. 1% acid + 1% cationic for PA/PAC blends
 - b. 1% disperse for PAC/PP blends
4. Dyeing conditions: 60°C for 5 min, pH 6, liquor ratio: 40 g bath each g of fibre
5. Fibre washing: 50°C for 5 min and drying at 100°C for 2 h.
6. Fibre separation by hand
7. Fibre weighing.

Methodology application

Fig.1 shows the colour differentiation evident in the case of the PA/PAC (acid dyestuff Tectilon Blue+ cationic Maxilon Blu) blend, for the PP/PA/PAC blend (acid Tectilon Blue+ cationic Maxilon Blu + disperse dyestuff Dianix Red) and for the PP/PAC blend (disperse dyestuff Dianix Red) in case of rope dyeing). Results are given in Tab.2.



Fig.1 – Colour differentiation for PAC fibre blended with PP and PA fibres.

Tab.2 – PAC quantity measurement achieved using the colorimetric method

| | PAC wt% content | PAC wt% measured |
|-------------|--------------------|---------------------|
| PAC + PP | 55 | 53 |
| PAC +PA6 | 48,5 | 49 |
| PAC +PA6+PP | 35 | 33,5 |

Comments on the methodology proposed.

The proposed method is very easy in case of PAC / PA blends . Hand separation could be more difficult in case of dark dyed fibres (less colour contrast) and very short fibres.

The precision of the method is linked to the precision of fibre separation.

In the case of carpets, dying can be done directly on it before pile cutting.

This method could be used un conjunction with other methods, e.g. with the physical separation by density, to have a cross-check the nature of the fibre.

B) Chemical dissolution of PA

This method is valid for PA/PAC fibres or PA/PP/PAC. It is based on the different chemical reaction of the fibres towards chemicals. In particular, PA fibres are dissolved by acids, like formic acid, while PAC does not.

Methodology Description.

1. Preparation of 1 g of yarn inside a bottle of 150 ml
2. Spin finish removal using petrol ether or methyl alcohol and drying for 2 h at 100°C
3. Introduction of 100 ml of formic acid solution with 70% concentration at 25°C for 10 min.
4. Removal of the formic acid and fibre washing using distilled water
5. Fibre drying at 100°C for 5 h
6. Fibre weighing and ratio calculation

Methodology application and testing

PAC/PA6 (sample n.1), PAC/PP (sample n.2) and PAC/PA6/PP (sample n.3) fibres were tested using different acid formic concentrations. Moreover, to understand the possible error of the methodology proposed, the same was applied on 100% PA6 fibre, 100% PP fibres

Finally also 100% PAC fibre, produced with a PA6 nano-fibrils content in the range 10 - 35%, and different 100%PAC fibres engineered with a 20% PA6 nano-fibrils, were tested to evaluate the error induced by the different fibre engineering, using the best formic acid solution.

Table 3 compare the results achieved, i.e. the quantity of PA removed, with real PA content.

Tab.3 – Results of chemical removal of PA fibre in various blend using different formic acid solution concentrations

| | PA% content | PA% measured | | |
|-------------|-------------|---------------------------|------|------|
| | | Formic Acid concentration | | |
| | | 50% | 70% | 80% |
| PP | 0 | 0 | 0 | 0,0 |
| PA6 | 100 | 2,47 | 100 | 100 |
| PAC | 0 | 0,34 | 0,42 | 1,21 |
| PAC + PP | 0 | 0,7 | 0,4 | 0,9 |
| PAC +PA6 | 51,1 | 1 | 51,8 | 52,5 |
| PAC +PA6+PP | 38,9 | 1 | 37,2 | 38,1 |




Fig.2 – Results of chemical removal of PA fibre in various blend using different formic acid solution concentrations

Results on pure PAC fibre indicate that a systematic error of about 0,4 can be present with concentration of 70% formic acid, while using 50% concentration time is not sufficient even to solve the pure PA6 fibre.

The effect of the concentration of PA6 nano-fibrils inside the PAC fibre on data reliability, tested using the 70% of formic acid solution concentration, is listed in Tab.4, that shows that the systematic error is increased by increasing the amount of PA6 nanofibrils concentration, up to a 1,2% value.

Tab.4 – Effect of the PP/PA ratio of the PAC fibre on test precision.

| Fibre Type | % PA6 |
|-------------------|-------|
| PAC - 10% PA6 | 0,2 |
| PAC - 15% PA6 | 0,25 |
| PAC - 20% PA6 - A | 0,42 |
| PAC - 20% PA6 - B | 0,4 |
| PAC - 20% PA6 - C | 0,55 |
| PAC - 35% PA6 | 1,29 |

Comments on the methodology proposed.

The methodology, seems to be useful to discriminate the presence of PA from the one of PAC. It can be easily used on carpet, as carpet pile can be cut with a razor blade and do not have the problem of fibre hand-separation. Do not require complicated instrumentations.

The systematic error, the overestimation of the PA fibre content, is proportional to the PAC wt% present. Therefore, supposing that an error of 1,2wt% of weight loss is measured on 100% PAC fibre, an error of 0,6wt% will result of blends 50wt%PAC / 50wt%PA6 (0,3% difference in the real PA6 quantity present), which seems to be tolerable.

C) Physical separation of the fibres.

The method proposed is valid for the most part of synthetic fibres. Is based on the fact that different polymers do have a different density. Tab.5 lists the most common polymers together with their density range, while Fig.3 shows the measured density range for different types of the PAC fibre family.




Fig.3 – Density range for the PAC fibre as a function of the nanofibrils content.

Tab.5 – Density range for different synthetic fibres.

| | density (g/cm ³) | |
|-----|------------------------------|-------|
| | min | max |
| PET | 1,36 | 1,38 |
| PA | 1,12 | 1,14 |
| PAC | 0,93 | 0,98 |
| PP | 0,89 | 0,905 |

Density separation can be easily done using specific water solutions:

- if the fibre density is higher than the one of the solution she will sink down,
- if her density is lower, she will remain on the solution surface.

To separate to fibres having a different density a solution characterised by an intermediate density must be chosen. Following water solutions are proposed:

The solutions proposed and tested are the following:

- i. Distilled water – 1 g/cm³
- ii. Distilled water saturated with NaCl – 1,19 g/cm³
- iii. Distilled water with 50% of Ethylic Alcohol – 0,93 g/cm³

A) Distilled Water

The density of pure, distilled water is around 1 g/cm³, as indicated by Tab.6

Tab.6 – Density values of distilled water as a function of temperature.

| 19°C | 20°C | 21°C | 22°C | 23°C | 24°C |
|--------------------------|--------------------------|--------------------------|--------------------------|--------------------------|--------------------------|
| 0,9984 g/cm ³ | 0,9982 g/cm ³ | 0,9980 g/cm ³ | 0,9978 g/cm ³ | 0,9975 g/cm ³ | 0,9973 g/cm ³ |
| 25°C | 26°C | 27°C | 28°C | 29°C | 30°C |
| 0,9970 g/cm ³ | 0,9968 g/cm ³ | 0,9965 g/cm ³ | 0,9962 g/cm ³ | 0,9959 g/cm ³ | 0,9956 g/cm ³ |

B) Saturated NaCl water solution

NaCl maximum solubility limit is about 26wt% (358g/l). Under those stable conditions (an excess of NaCl will precipitate), the solution density is around 1,19, as predicted from Tab.7:

Tab.7 – Density values of saturated NaCl water solution as a function of temperature.

| 19°C | 20°C | 21°C | 22°C | 23°C | 24°C |
|--------------------------|--------------------------|--------------------------|--------------------------|--------------------------|--------------------------|
| 1,1952 g/cm ³ | 1,1946 g/cm ³ | 1,194 g/cm ³ | 1,1934 g/cm ³ | 1,1928 g/cm ³ | 1,1922 g/cm ³ |
| 25°C | 26°C | 27°C | 28°C | 29°C | 30°C |
| 1,192 g/cm ³ | 1,1911 g/cm ³ | 1,1906 g/cm ³ | 1,1899 g/cm ³ | 1,1893 g/cm ³ | 1,1888 g/cm ³ |

C) Ethanol - water solution

Fig.4 shows the density of ethanol-water solutions: to achieve a density of about 0,926 g/cm³, required to separate the PP from the PAC fibres, a solution of water with 50wt% of Ethylic Alcohol (commercial product with 95% concentration) is needed. Tab.8 shows also the correction factor as a function of temperature.




Fig.4 – Density values of ethanol - water solution

Tab.8 – Ethanol quantity correction required as function of the temperature to achieve a density value of 0,926 g/cm³

| 19°C | 20°C | 21°C | 22°C | 23°C | 24°C |
|-------|-------|-------|-------|-------|-------|
| 50,9% | 50,6% | 50,3% | 50% | 49,8% | 49,5% |
| 25°C | 26°C | 27°C | 28°C | 29°C | 30°C |
| 49,2% | 48,9% | 48,6% | 48,4% | 48,1% | 47,8% |

To evaluate a possible effect of alcohol evaporation on density, the stability of the solution in time was analysed. Results as a function of time are reported in following Fig.5. Results are consistent with literature (Perry's Chemical Engineers' Hand Book – Seventh Edition- Robert H.Perry, Don W. Green – pag. 2-112).

It is important to remark that an exothermic reaction is occurring during the first 1-2 days, as the peak is showing, with the formation of air bubbles. Those air bubbles can be trapped by the single filaments and drive then towards the surface of the bottle, therefore introducing an error in the quantitative measurement. It must be concluded that the solution has to be prepared at least 2 days before the measurement. Moreover the use of some surfactant (e.g. some droplets of liquid soap) can be beneficial and are suggested in removing the air bubbles from single filament's surface.




Fig.5 – Experimental time dependent of the density of Ethanol – Water solution. The first peak seems to be related to an exothermic reaction whereas the formation of air bubbles was visible

Methodology Description.

1. Yarn cut – single filaments must be no longer than 5mm, entangling knots or other bonding points must be removed, single filaments must be physically separated
2. Preparation of 50 g of yarn inside a bottle of 500 ml
3. Spin finish removal using petrol ether or methyl alcohol and drying for 2 h at 100°C
4. Introduction of the water solution, prepared at least 2 days before, selected as a function of the fibre mixture to be analysed:
 - o distilled water for PAC/PES or PAC/PA;
 - o NaCl saturated water for PAC/PES
 - o water/ethylic alcohol for PAC/PP mixtures.
5. Mixing of the fibre inside the solution until all have been are wetted and have been separated one from the other. If some bundle of fibres are formed, they have to be removed and their weight subtracted from the total sample weight.

6. After more than 24 h, separation of the fibres that are emerging from the one that are sunk down using a filter or other separation methods
7. Fibres rinsing with distilled water and drying at 100°C for 1 h
8. Fibre weight measurement

The selection of the right solution for the separation of the single fibres is indicated in Tab.9.

Tab.9 – Solution selection for each binary and ternary fibre mixture used in this study and fibre behaviour - W=Distilled Water; SW=NaCl Salt Water; W/EA=Ethanol/ Water

| ----- | PET | PA6 | PAC | PP | PET + PA6 | PAC + PP |
|------------------|------------------------------|------------------------------|-----------------------------|--------------------------------|----------------------------------|----------------------------------|
| PET | ----- PET down PA6 up | SW PET down PA6 up | W PET down MTX up | W PET down PP up | ----- | W PET down MTX+PP gup. |
| PA6 | W/S PET down PA6 up | ----- PA6 down MTX up | W PA6 down MTX up | W PA6 down PP up | ----- | W PA6 down MTX+PP gup. |
| PAC | W PET down MTX up | W PA6 down MTX up | ----- MTX down PP up | W/EA MTX down PP up | W PET-PA6 down MTX up | ----- |
| PP | W PET down PP up | W PA6 down PP up | W/EA MTX down PP up | ----- PET-PA6 down PP up | W PET-PA6 down PP up | ----- |
| PET + PA6 | ----- PET down MTX up | ----- PA6 down MTX up | W PET-PA6 down MTX up | W PET-PA6 down PP up | ----- | W PET-PA6 down MTX+PP gup. |
| MTX + PP | W PET down MTX+PP gup. | W PA6 down MTX+PP gup. | ----- MTX down PP up | ----- PET-PA6 down PP up | W PET-PA6 down MTX+PP gup. | ----- |

Methodology application and testing

This methodology was applied on all samples listed in Tab.1, i.e. on binary and ternary PAC blends with PP, PA, PES. In Fig. 6 the fibre preparation is shown, while Fig.7 shows the fibre separation inside the bottle.

Experimental results are summarised in Tab.10, together with the set fibre quantity.



Fig.6 – Fibre preparation for the physical separation



Fig.7 – PAC / PP fibre separation inside the bottle

Tab.10 – Results of quantitative measurement of different fibre blends by means of the physical fibre separation using the proposed methodology on all sample. The set value is also indicated for comparison purposes.

| | 1 | | 2 | | 3 | | 4 | | 5 | | 6 | | 7 | |
|-----|-------|--------|-------|--------|-------|----------|-------|--------|-------|--------|-------|--------|-------|--------|
| | set | result | set | result | set | measured | set | result | set | result | set | result | set | result |
| | wt. % | | wt. % | | wt. % | | wt. % | | wt. % | | wt. % | | wt. % | |
| PAC | 48,5 | 47,8 | 55 | 54,2 | 35 | 34,8 | | | | | 77 | 76,8 | 36 | 36,9 |
| PA | 50,5 | 52,2 | | | 37 | 35,7 | 74 | 73,4 | | | | | 30 | 29,7 |
| PP | | | 45 | 45,8 | 28 | 29,5 | | | 65 | 64,1 | | | 22 | 22,6 |
| PES | | | | | | | 26 | 26,5 | 35 | 35,9 | 23 | 23,2 | 12 | 10,8 |

MISURA DELLA % DI NYLON NELLA FIBRA PAC TRAMITE FTIR CON ACCESSORIO ATR

1. SCOPO

Scopo di questo metodo è la determinazione della quantità di nylon presente nella fibra di PAC

2. PRINCIPIO DEL METODO

La metodologia utilizzata prevede l'analisi della trasmittanza % a determinate lunghezze d'onda specifiche del nylon e del polipropilene nella fibra PAC

3. REAGENTI OCCORRENTI

- Alcool Metilico RP

4. MATERIALE OCCORRENTE

- Pallone da 250 ml

5. APPARECCHIATURA OCCORRENTE

- Stufa sotto vuoto
- Spettrofotometro FTIR Spectrum 100 Perkin Elmer con modulo ATR

6. PROCEDIMENTO

- Lavare a freddo una matassina da 2 g circa con alcool metilico
- Asciugare in stufa sotto vuoto a 50°C per almeno 1 ora e comunque fino a peso costante
- Acquisire uno spettro FTIR del campione eseguendo una scansione nel range 4000 a 650 cm⁻¹, risoluzione 4cm⁻¹ e 16 accumulazioni.

7. ANALISI DELLO SPETTRO OTTENUTO

Procedura manuale:

Diagrammare lo spettro in assorbanza

- Identificare i picchi caratteristici delle fasi PA6 e PP nella fibra PAC:

Picco 1 presso 1650 cm⁻¹ assegnato alla poliammide (ammide I)

Picco 2 presso 1450 cm⁻¹ assegnato al polipropilene (CH₃ bending)

- Integrare i picchi identificati al punto precedente utilizzando i seguenti estremi di integrazione e le base-line lineari corrispondenti

Picco 1: da 1700 a 1595 cm⁻¹ con base-line da 1700 a 1595 cm⁻¹

Picco 2: da 1500 a 1400 cm⁻¹ con base-line da 1500 a 1400 cm⁻¹

- Calcolare il rapporto delle aree dei picchi 1 e 2 precedentemente ottenuti: $R_{exp} = A_{picco1} / A_{picco2}$

- Utilizzare la seguente formula per il calcolo della percentuale di PA6 totale nella fibra PAC:

$$PA6\% = 0.312 + 10.146 \cdot R_{exp}$$

Procedura automatica (software Perkin Elmer)

- Dopo aver acquisito lo spettro sottrarre una base-line rettilinea che intersechi la curva di trasmittanza dello spettro a 2155 cm⁻¹.
- Applicare il metodo Quant®, richiamando il file di calibrazione PAC_1450, allo spettro così ottenuto.
- La percentuale di PA6 totale nella fibra PAC analizzata è fornita dal report automatico generato dal metodo.

8. COSTRUZIONE CURVA DI TARATURA

DATA: 22/11/07 PREPARATO : ...Paralovo..... APPROVATO :
DESCRIZIONE MODIFICA :

IDROLISI NYLON NELLA FIBRA PAC**1. SCOPO**

Scopo di questo metodo è la determinazione della quantità di nylon presente nella fibra di PAC

2. PRINCIPIO DEL METODO

Una piccola quantità di campione viene idrolizzata a caldo a refluxo per 16 ore con acido cloridrico al 37% diluito 1:1, in questo modo si idrolizza completamente la componente nylon della fibra, quindi sottraendo al peso iniziale, la fibra rimasta dopo l'idrolisi, posso risalire alla composizione in % di nylon.

3. REAGENTI OCCORRENTI

- Acido Cloridrico al 37%
- Acido Cloridrico 1:1
- Etere di petrolio 40°-60° RP
- Alcool etilico RP
- Alcool metilico RP

4. MATERIALE OCCORRENTE

- Pallone da 250 ml
- refrigerante
- calotta riscaldante
- Soxhlet

5. APPARECCHIATURA OCCORRENTE

- Stufa
- Stufa sotto vuoto
- bilancia analitica precisione 0.0001

6. PROCEDIMENTO

- Pesare circa 1 grammo di campione in un pesafiltro di ppl
- Introdurlo in estrattore Soxhlet da 100 ml
- Aggiungere 150 ml di etere di petrolio
- Estrarre il tutto in Soxhlet per 1 ora o per 6 cicli per estrarre l'olio di ensimaggio dalla fibra
- Recuperare la fibra lavata con etere porla in un pesafiltro introducendo il tutto in stufa a 105°C per 5 ore e pesare infine la fibra a peso costante
- Introdurre la fibra lavata e asciugata in un pallone da 250 ml e aggiungere 100 ml di acido cloridrico 1:1
- Riscaldare il tutto al bollo a refluxo per 16 ore
- Recuperare la fibra dopo le 16 ore di idrolisi lavandola con acqua in un complesso filtrante sotto vuoto fino a che le acque di lavaggio non risultano completamente neutre PH 7-7.5
- Lavare infine la fibra con alcool metilico a caldo, circa 100 ml, e porla ad asciugare per quattro ore, comunque fino a completo asciugamento, in stufa a 105°C per almeno 5 ore in ogni caso fino a peso costante

7. CALCOLI

- Pesare la fibra lavata ed eseguire il seguente calcolo:

$$\% \text{ nylon} = (P1 - P2) / P1 \times 100$$

dove: P1= peso fibra dopo lavaggio con etere e asciugamento

P2= peso fibra dopo idrolisi lavaggio e asciugamento

DATA: 22/11/07 PREPARATO: ...Paralovo..... APPROVATO:
DESCRIZIONE MODIFICA:

Metodi di identificazione fibre PAC (PP/PA6)

Misura della percentuale di Nylon nelle fibre PAC

Misura della percentuale di PAC in fibre in mista

Arco (TN) 03/04/2007

Indice

1. Introduzione
2. Metodologie
 - 2.1. Misura della percentuale di Nylon nelle fibre PAC
 - 2.1.1. Idrolisi del Nylon
 - 2.1.2. Attacco acido del Nylon nella fibra PAC
 - 2.1.3. Spettroscopia infrarossa
 - 2.2. Misura della percentuale di PAC in fibre in mista
 - 2.2.1. Idrolisi del Nylon
 - 2.2.2. Densitometria
3. Risultati ottenuti
 - 3.1. Misura della percentuale di Nylon nelle fibre PAC
 - 3.1.1. Idrolisi del Nylon
 - 3.1.1.1. Idrolisi del Nylon in fibra PAC a diverse composizioni
 - 3.1.1.2. Idrolisi del Nylon in fibra PAC a differenti tempi di analisi
 - 3.1.2. Attacco acido del Nylon nella fibra PAC
 - 3.1.3. Spettroscopia infrarossa
 - 3.2. Misura della percentuale di PAC in fibre in mista
 - 3.2.1. Idrolisi del Nylon
 - 3.2.1.1. Idrolisi del Nylon in miste PAC/PP
 - 3.2.1.2. Idrolisi del Nylon in miste PAC/PA6
 - 3.2.2. Densitometria
 - 3.2.2.1. Ripetibilità statistica per miste PAC-PP
 - 3.2.2.2. Ripetibilità statistica per miste PAC-PP con quantità elevate di fibra in soluzione
4. Conclusioni

1. Introduzione

Nelle precedenti relazioni si era cercato di mettere a punto delle metodologie adatte per l'identificazione della percentuale di Nylon in fibre PAC e della percentuale di fibra PAC in miste. In particolare si era visto che per l'individuazione della percentuale di Nylon in fibre PAC possono essere utilizzate le seguenti analisi:

- Idrolisi del Nylon in acido cloridrico;
- Attacco acido del Nylon in acido formico;
- Spettroscopia infrarossa.

Mentre per l'individuazione della percentuale di fibra PAC in miste si sono sviluppate le seguenti metodologie:

- Idrolisi del Nylon in acido cloridrico;
- Analisi densitometrica.

Nella presente relazione verranno illustrati i metodi utilizzati ed i risultati ottenuti nello sviluppo delle analisi sopraelencate al fine di individuare il sistema metodologico più adeguato per le misure richieste.

1.2 Metodologie

2.1 Misura della percentuale di Nylon nelle fibre PAC

Nel presente capitolo verranno illustrate alcune differenti metodologie per l'individuazione della percentuale di Nylon presente nelle fibre PAC.

2.1.1 Idrolisi del Nylon

La metodologia di idrolisi del Nylon con riflusso di acido cloridrico è stata eseguita dopo prelavaggio con etere di petrolio.

PRINCIPIO

Una piccola quantità di campione viene idrolizzata a caldo a riflusso per 24 ore con acido cloridrico al 18,5 %, in questo modo si idrolizza completamente la componente Nylon della fibra, quindi sottraendo al peso iniziale la fibra rimasta dopo l'idrolisi, è possibile risalire alla composizione in % di Nylon.

PROCEDURA

- Pesare circa 1 grammo di campione in un pesafiltro di ppl
- Introdurlo in un pallone da 250 ml
- Aggiungere 100 ml di etere di petrolio
- Riscaldare il tutto a riflusso per 1 ora per estrarre l'olio di ensimaggio dalla fibra
- Recuperare la fibra lavata con etere porla in un pesafiltro introducendo il tutto in stufa a 50°C sotto vuoto per 1 ora
- Pesare circa 1 grammo di fibra lavata e asciugata porla in un pallone da 250 ml e aggiungere 100 ml di acido cloridrico al 18,5 %.
- Riscaldare il tutto a circa 70°-80° a riflusso per 24 ore
- Recuperare la fibra dopo le 24 ore di idrolisi lavandola con acqua in un complesso filtrante sotto vuoto fino a che le acque di lavaggio non risultano completamente alcaline PH 7-7.5
- Lavare infine la fibra con alcool metilico a caldo ,circa 100 ml, e porla ad asciugare per quattro ore ,comunque fino a completo asciugamento,in stufa a 100°C

- Pesare la fibra lavata ed eseguire il seguente calcolo:

$$\% \text{ Nylon} = (P1 - P2) / P1 \times 100$$

P1= peso fibra dopo il lavaggio con etere ed essiccamento

P2= peso fibra dopo il lavaggio con alcol metilico ed essiccamento

2.1.2 Attacco acido del Nylon nella fibra PAC

Non si riporta per intero la procedura di tale processo di analisi vista la similitudine che essa presenta con quanto già illustrato per l'idrolisi. L'unica differenza è infatti rappresentata dall'utilizzo dell'acido formico (concentrazione 80 %) al posto dell'acido cloridrico.

2.1.3 Spettroscopia infrarossa

Tramite uno strumento Spectrum 100 Series della PerkinElmer sono state eseguite delle misure di spettroscopia infrarossa su fibre di PAC. Scopo di tale analisi è esclusivamente quello di rendere più rapida la metodologia per l'individuazione della % di PA6: le misure ad infrarosso richiedono infatti pochi minuti a differenza dei lunghi tempi richiesti dall'idrolisi con acido cloridrico.

La metodologia utilizzata prevede l'analisi della trasmittanza % del picco compreso tra 1645 e 1635 cm^{-1} e può essere sintetizzata nei seguenti passaggi:

- eseguire una misura tramite spettrometro in maniera tale che il picco a maggiore assorbimento mostri una trasmittanza di $60 \pm 3 \%T$
- normalizzare la curva lasciando in automatico la scelta della BaseLine
- identificare il minimo nella trasmittanza del picco compreso tra 1645 e 1635 cm^{-1}
- inserire il valore (che indicheremo con T) nell'equazione logaritmica presentata in seguito.


Si fa presente esclusivamente che tale ipotesi di normalizzazione del picco porta a standardizzare la curva sul picco massimo del polipropilene e quindi la calibrazione della curva è stata eseguita sulla % di PA6 normalizzata, calcolata come:

$$\% \text{ PA6 normalizzata} = \frac{\% \text{ PA6}}{(\% \text{ PA6} + 100)} \times 100$$

Analogamente il valore ottenuto dall'equazione logaritmica andrà riportato alle condizioni originali e quindi il calcolo diverrà:

$$\% \text{ PA6 normalizzata} = - 8,903 \cdot \ln (T) + 39,281$$

$$\% \text{ PA6} = \frac{\% \text{ PA6 normalizzata}}{(100 - \% \text{ PA6 normalizzata})} \cdot 100$$



La metodologia può ulteriormente essere semplificata utilizzando il programma Beers Law, nel qual caso una volta generata la curva di taratura la misura della percentuale di Nylon viene eseguita in automatico.

La metodologia utilizzata prevede l'utilizzo del programma Beer's Law 2.2.0 for Spectrum v.6 la cui retta di calibrazione è stata eseguita utilizzando dei campioni di PAC pretrattati con lavaggio a freddo in etere di petrolio ed asciugatura in forno a contenuto nominale di PA6 pari al 7, 15, 20 e 30%.

Come metodo di calcolo si è utilizzato il rapporto di intensità massima tra picchi dove:

- Picco 1 nella regione 1600-1700 cm^{-1} assegnato alla PA6
- Picco 2 nella regione 1300-1400 cm^{-1} assegnato al PP

Per le misure eseguite i campioni sono sempre stati pretrattati con lavaggio a freddo in etere di petrolio ed asciugatura in forno.

2.2 Misura della percentuale di PAC in fibre in mista

Nel presente capitolo verranno illustrate alcune differenti metodologie per l'individuazione della percentuale di PAC presente in fibre in mista, concentrandosi in particolare sulle miste PAC-PA e PAC-PP poiché maggiormente complesse da identificare.

2.2.1 Idrolisi del Nylon

Per la procedura utilizzata nella misura della percentuale di PAC in fibre in mista tramite idrolisi si faccia riferimento a quanto presentato nel capitolo 2.1.1. Premesso che tale metodologia richiede di conoscere a priori la percentuale di Nylon presente nelle fibre PAC si può allora dire che:

$$\% \text{ Nylon estratto} = (P1 - P2) / P1 \times 100$$

P1= peso fibra dopo il lavaggio con etere ed essiccamento

P2= peso fibra dopo il lavaggio con alcol metilico ed essiccamento

e quindi per le miste PAC-PA:

$$\% \text{ PAC} = \frac{(100 - \% \text{Nylon estratto}) \times \% \text{Nylon in fibra PAC}}{100 - \% \text{Nylon in fibra PAC}} + (100 - \% \text{Nylon estratto})$$

mentre per le restanti miste:

$$\% \text{ PAC} = \frac{\% \text{Nylon estratto} \times 100}{\% \text{Nylon in fibra PAC}}$$

2.2.2 Densitometria

INTRODUZIONE

E' stata verificata la possibilità di identificare fibre di PAC (PP/PA6 - 80/20), PP, PET e PA6 tramite l'immersione di queste in soluzioni acquose a densità nota. Inoltre con questa procedura, è possibile stimare le composizioni percentuali di sistemi a più componenti valutando la quantità di fibra precipitata in una soluzione di densità compresa tra le densità dei due componenti.

Avendo disponibilità di uno Spettrometro IR è possibile identificare le fibre in modo più preciso ed inoltre stimare le composizioni percentuali di sistemi a più componenti.

L

IQUIDI PER L'IDENTIFICAZIONE E LA SEPARAZIONE

I liquidi utilizzati nella separazione delle fibre PET, PA6, PAC e PP sono:

- Acqua distillata e sale (Cloruro di Sodio), con una quantità di sale pari al suo limite di solubilità in acqua (358 g/l) corrispondente a circa il **26% in peso**. Si ottiene una densità della soluzione che varia con la temperatura nel seguente modo:

| 19°C | 20°C | 21°C | 22°C | 23°C | 24°C |
|--------------------------|--------------------------|-------------------------|--------------------------|--------------------------|--------------------------|
| 1,1952 g/cm ³ | 1,1946 g/cm ³ | 1,194 g/cm ³ | 1,1934 g/cm ³ | 1,1928 g/cm ³ | 1,1922 g/cm ³ |

| 25°C | 26°C | 27°C | 28°C | 29°C | 30°C |
|-------------------------|--------------------------|--------------------------|--------------------------|--------------------------|--------------------------|
| 1,192 g/cm ³ | 1,1911 g/cm ³ | 1,1905 g/cm ³ | 1,1899 g/cm ³ | 1,1893 g/cm ³ | 1,1888 g/cm ³ |

Questa soluzione permette di separare il PET (densità 1,37 g/cm³) dal PA6 (densità 1,15 g/cm³)

- Acqua distillata, con una densità prossima ad 1 g/cm³, si possono separare fibre di PET e PA6 da fibre PAC e PP. La densità dell'acqua distillata varia con la temperatura nel seguente modo:

| 19°C | 20°C | 21°C | 22°C | 23°C | 24°C |
|--------------------------|--------------------------|--------------------------|--------------------------|--------------------------|--------------------------|
| 0,9984 g/cm ³ | 0,9982 g/cm ³ | 0,9980 g/cm ³ | 0,9978 g/cm ³ | 0,9975 g/cm ³ | 0,9973 g/cm ³ |

| 25°C | 26°C | 27°C | 28°C | 29°C | 30°C |
|--------------------------|--------------------------|--------------------------|--------------------------|--------------------------|--------------------------|
| 0,9970 g/cm ³ | 0,9968 g/cm ³ | 0,9965 g/cm ³ | 0,9962 g/cm ³ | 0,9959 g/cm ³ | 0,9956 g/cm ³ |

- Acqua distillata e alcol etilico 95%: la percentuale volumetrica di alcol etilico è compresa tra 48% e 51%; valore che dipende dalla temperatura dei liquidi. Si riportano in tabella le percentuali volumetriche di alcol etilico, e le rispettive temperature, che permettono di ottenere una densità della soluzione di circa **0,926 g/cm³**.

| 19°C | 20°C | 21°C | 22°C | 23°C | 24°C |
|-------|-------|-------|------|-------|-------|
| 50,9% | 50,6% | 50,3% | 50% | 49,8% | 49,5% |

| 25°C | 26°C | 27°C | 28°C | 29°C | 30°C |
|-------|-------|-------|-------|-------|-------|
| 49,2% | 48,9% | 48,6% | 48,4% | 48,1% | 47,8% |

Questa soluzione permette di separare il PAC (densità 0,9497 g/cm³) dal PP (densità 0,9 g/cm³).

La variazione di densità rispetto al tempo di una soluzione acqua alcol a 25°C è rappresentata nel seguente grafico.



Come si può notare dal grafico si ha un aumento iniziale di densità dovuto ad una reazione di miscelazione leggermente esotermica che porta ad un aumento della temperatura di circa 7°C; successivamente la miscela si stabilizza ad un valore poco inferiore a 0,926 g/cm³. Valore confermato da Perry's Chemical Engineers' Hand Book – Seventh Edition (Robert H. Perry, Don W. Green) – pagina 2-112, che da una densità di 0,92649 g/cm³.

E' necessario quindi lasciar riposare la miscela almeno un giorno al fine di evitare che bolle di gas si attacchino alle fibre rendendo la prova inesatta. E' consigliabile inoltre miscelare nella soluzione del sapone (indicativamente 30 gocce per litro di miscela) che abbassa la tensione superficiale rendendo più facile il distacco delle bolle e non modifica la densità.

Nella tabella seguente sono stati riassunti tutti i liquidi utilizzati nei processi di separazione.

| ----- | PET | PA6 | PAC | PP | PET + PA6 | PAC + PP |
|-----------|--|--|--|--|---|---|
| PET | ----- PET affonda PA6 galleggia | ACQUA/SALE PET affonda PA6 galleggia | ACQUA PET affonda PAC galleggia | ACQUA PET affonda PP galleggia | ----- | ACQUA PET affonda PAC+PP galleg. |
| PA6 | ACQUA/SALE PET affonda PA6 galleggia | ----- PA6 affonda PAC galleggia | ACQUA PA6 affonda PAC galleggia | ACQUA PA6 affonda PP galleggia | ----- | ACQUA PA6 affonda PAC+PP galleg. |
| PAC | ACQUA PET affonda PAC galleggia | ACQUA PA6 affonda PAC galleggia | ----- PAC affonda PP galleggia | ACQUA/ALCOL PAC affonda PP galleggia | ACQUA PET+PA6 affond PAC galleggia | ----- |
| PP | ACQUA PET affonda PP galleggia | ACQUA PA6 affonda PP galleggia | ACQUA/ALCOL PAC affonda PP galleggia | ----- PET+PA6 affond PP galleggia | ACQUA PET+PA6 affond PP galleggia | ----- |
| PET + PA6 | ----- | ----- | ACQUA PET+PA6 affond PAC galleggia | ACQUA PET+PA6 affond PP galleggia | ----- | ACQUA PET+PA6 affond PAC+PP galleg. |
| PAC + PP | ACQUA PET affonda PAC+PP galleg. | ACQUA PA6 affonda PAC+PP galleg. | ----- | ----- | ACQUA PET+PA6 affond PAC+PP galleg. | ----- |

PROCEDURA DI IDENTIFICAZIONE

1. Materiale necessario: acqua distillata, alcol 95%, sale (Cloruro di Sodio), recipiente in vetro.
2. Taglio del fascio di fibre: il fascio di fibre deve essere tagliato tra due punti di interlacciatura in modo che le singole fibre risultino divise e con una lunghezza di 5 millimetri; questo per evitare che bolle di aria rimangano intrappolate nei fasci interi di fibre sfalsando la misura.
3. Immersione delle fibre nelle soluzioni: immergere le fibre tagliate in un recipiente riempito con acqua distillata: se affondano sono costituite da PET o PA6 e per la definitiva identificazione, si deve procedere con l'immersione in acqua e sale. Se le fibre invece galleggiano sono costituite da PAC o PP e per la definitiva identificazione, si deve procedere con l'immersione in acqua e alcol.

PROCEDURA DI SEPARAZIONE

1. Materiale necessario: acqua distillata, alcol 95%, sale (Cloruro di Sodio), recipiente in vetro, sistema di aspirazione (siringa), filtro.
2. Taglio del fascio di fibre: il fascio di fibre deve essere tagliato in modo che le singole fibre risultino ben divise le une dalle altre e con una lunghezza di 5 millimetri. Il taglio va quindi

eseguito tra due punti di interlacciatura (figura 1) e le fibre, se non completamente separate, devono essere divise manualmente (figura 2). Indicativamente sono sufficienti 30 mg per i sistemi binari e 50 mg per i sistemi a più di due componenti.

3. Immersione delle fibre nella soluzione: immergere le fibre nella soluzione appropriate, seguendo le indicazioni date nella tabella riassuntiva, ed agitare bene in modo da distribuire le fibre nel liquido. Il tempo per la separazione dipende dal tipo di soluzione utilizzata:

- 2^h30^m / 3^h ore per la soluzione acqua e alcol;
- 30^m per le altre soluzioni (acqua ed acqua/sale).

Prestare attenzione che tutte le fibre si siano separate, in quanto capita che alcune fibre (di diverso materiale) si annodino tra di loro, figura 3, e rimangano in sospensione; in tal caso aiutare la separazione tramite l'utilizzo di pinze di lunghezza adeguata.

4. Aspirazione: aspirare le fibre in superficie con una siringa o con altri strumenti adatti.
5. Filtraggio: filtrare il contenuto della siringa e lasciare asciugare le fibre in modo da poter eseguire la misura del peso; si può accelerare l'asciugatura utilizzando un forno. In tal caso portare la temperatura a 75°C e se l'apparecchiatura lo permette, creare il vuoto all'interno del forno. Nel caso in cui si utilizzi acqua e sale è necessario lavare le fibre con acqua distillata, una volta estratte dalla miscela; questo perché il sale si deposita sulla fibra e modifica il peso della stessa.

SPETTROMETRO IR

Con un Spettrometro IR è possibile identificare una fibra in modo molto preciso tramite un'analisi ed una comparazione con i dati in letteratura. Per il calcolo delle percentuali di un sistema a più componenti, il metodo consta in una separazione manuale dei diversi fasci di fibra, in una analisi degli stessi al fine di verificarne la natura e la corretta separazione ed infine, in una misura del peso dei singoli fasci attraverso una bilancia analogica. E' così possibile calcolare le percentuali ponderali e volumetriche dei vari componenti.

3 Risultati ottenuti

3.1 Misura della percentuale di Nylon nelle fibre PAC

3.1.1 Idrolisi del Nylon

Nei capitoli a seguire verranno presentati i risultati di misura della percentuale di Nylon nelle fibre PAC tramite idrolisi in acido cloridrico. Si è dapprima verificata la capacità di estrarre tutto il Nylon in fibre contenenti diverse percentuali dello stesso e successivamente si è analizzato il tempo minimo richiesto per tale analisi.

3.1.1.1 Idrolisi del Nylon in fibra PAC a diverse composizioni

Vengono di seguito presentati i risultati inerenti all'idrolisi del Nylon in fibre PAC a differenti concentrazioni nominali di PA con fibre prelevate da tappeto. Per tali misure si è utilizzato un tempo di estrazione di 24 ore.

| % di PA6 misurata dopo idrolisi con acido cloridrico al 18,5% | | | |
|--|-----------------------|------------------------|-----------------------|
| Campione | % PA6 nominale | TiO₂ | % PA6 (24 ore) |
| 7% PAC DU | 7 | si | 6,6 |
| 15% PAC DU | 15 | si | 14,3 |
| 20% PAC BT | 20 | no | 18,9 |
| 20% PAC DU | 20 | si | 18,9 |
| 20% PAC 2DU | 20 | doppio | 18,5 |
| 30% PAC DU | 30 | si | 28,1 |

Al termine di tutte le prove di idrolisi è stata eseguita una misura di spettroscopia infrarossa, la quale ha verificato che non erano più presenti tracce di polipropilene nel residuo. Per tale ragione si ritiene che la percentuale di Nylon misurata, possa essere ritenuta la percentuale reale di PA6 contenuta nelle fibre di Matrix.

3.1.1.2 Idrolisi del Nylon in fibra PAC a differenti tempi di analisi

Verificata la buona capacità dell'acido cloridrico di idrolizzare il Nylon presente in fibre PAC si sono eseguite differenti prove al fine di valutare il tempo minimo necessario di estrazione per una corretta misura. Per tale analisi si è utilizzata della fibra PAC a concentrazione nominale del 20 % (concentrazione reale stimata attraverso l'analisi dei parametri di processo pari al 20,2 %).

| Idrolisi in HCL al 17,5 % | | | |
|---------------------------|---------|----------|-------------|
| tempo [ore] | PAC | | PAC |
| | p iniz. | p idrol. | % Nylon |
| 2 | 1.0453 | 0.8479 | 18.9 |
| | 1.0818 | 0.8750 | 19.1 |
| MEDIA | 1.0636 | 0.8615 | 19.0 |
| 4 | 1.0881 | 0.8755 | 19.5 |
| | 1.0804 | 0.8696 | 19.5 |
| MEDIA | 1.0843 | 0.8726 | 19.5 |
| 6 | 1.1481 | 0.9298 | 19.0 |
| | 1.0156 | 0.8189 | 19.4 |
| | 1.1003 | 0.8845 | 19.6 |
| | 1.0881 | 0.8790 | 19.2 |
| | 1.0249 | 0.8289 | 19.1 |
| | 1.0791 | 0.8663 | 19.7 |
| | 1.0745 | 0.8686 | 19.2 |
| MEDIA | 1.0758 | 0.8680 | 19.3 |
| 8 | 1.0218 | 0.8230 | 19.5 |
| | 1.0275 | 0.8270 | 19.5 |
| MEDIA | 1.0247 | 0.8250 | 19.5 |
| 16 | 1.0317 | 0.8203 | 20.5 |
| | 1.0040 | 0.8047 | 19.9 |
| MEDIA | 1.0179 | 0.8125 | 20.2 |
| 24 | 1.0145 | 0.8094 | 20.2 |
| | 1.0265 | 0.8188 | 20.2 |
| MEDIA | 1.0205 | 0.8141 | 20.2 |

3.1.2 Attacco acido del Nylon nella fibra PAC

Per le analisi di trattamento delle fibre di PAC con acido formico e solforico si è utilizzata una bava contenente una percentuale nominale di Nylon del 20%. Nelle seguenti tabelle vengono presentati i risultati di perdita in peso ottenuta dopo lavaggio in etere e dopo il successivo attacco con acido formico 80%. I risultati mostrano che l'etere di petrolio rimuove l'olio di ensimaggio in modo

completo (teorico 1,4%), mentre la perdita in peso successiva è stimabile in circa 0,56% con una deviazione standard di 0,06% .

| Perdita di peso dopo lavaggio in Etere di Petrolio | | | |
|--|---------------|-------------|------------------------|
| campione | peso iniziale | peso finale | % di estratto in etere |
| 1 | 1,2428 | 1,2246 | 1,46 |
| 2 | 1,1224 | 1,1058 | 1,48 |
| 3 | 1,1590 | 1,1419 | 1,48 |
| 4 | 1,2223 | 1,2047 | 1,44 |
| 5 | 1,2575 | 1,2396 | 1,42 |
| 6 | 1,1661 | 1,1491 | 1,46 |
| 7 | 1,1929 | 1,1759 | 1,43 |
| 8 | 1,2234 | 1,2046 | 1,54 |
| 9 | 1,1739 | 1,1554 | 1,58 |
| 10 | 1,1553 | 1,1380 | 1,50 |
| media | | | 1,48 |
| dev.st | | | 0,05 |


| Perdita di peso dopo trattamento con acido formico all'80% | | | |
|--|---------------|-------------|------------------|
| campione | peso iniziale | peso finale | % Nylon solubile |
| 1 | 1,2246 | 1,2171 | 0,61 |
| 2 | 1,1058 | 1,0989 | 0,62 |
| 3 | 1,1419 | 1,1356 | 0,55 |
| 4 | 1,2047 | 1,1976 | 0,59 |
| 5 | 1,2396 | 1,2320 | 0,61 |
| 6 | 1,1491 | 1,1423 | 0,59 |
| 7 | 1,1759 | 1,1707 | 0,44 |
| 8 | 1,2046 | 1,1986 | 0,50 |
| 9 | 1,1554 | 1,1494 | 0,52 |
| 10 | 1,1380 | 1,1322 | 0,51 |
| media | | | 0,56 |
| dev.st | | | 0,06 |

3.1.3 Spettroscopia infrarossa

Vengono di seguito presentati i risultati inerenti all'analisi del Nylon in fibre PAC a differenti concentrazioni nominali di PA con fibre prelevate da tappeto tramite spettroscopia infrarossa. I risultati ottenuti mostrano come sei misure di spettroscopia possano essere sufficienti per valutare la percentuale di poliammide media contenuta nelle fibre di PAC con ottima approssimazione. Poiché l'analisi è puntuale e la concentrazione di Nylon non è uniforme nella fibra la deviazione standard risulta piuttosto elevata.

Per tale analisi si sono utilizzate le medesime fibre provenienti da tappeto utilizzate per l'analisi: idrolisi del Nylon in fibra PAC a diverse composizioni.

| % di PA6 misurata tramite spettroscopia infrarossa | | | | | | |
|--|--------------|---------------|---------------|---------------|----------------|---------------|
| | 7% PAC DU | 15% PAC DU | 20% PAC BT | 20% PAC DU | 20% PAC 2DU | 30% PAC DU |
| % PA6 idrolisi | 6,6 | 14,3 | 18,9 | 18,9 | 18,5 | 28,1 |
| | 6,1 | 13,9 | 17,8 | 18,0 | 18,9 | 29,6 |
| | 6,5 | 15,2 | 19,0 | 19,2 | 19,9 | 28,8 |
| | 6,8 | 14,5 | 19,9 | 17,5 | 18,4 | 27,4 |
| | 6,6 | 14,7 | 18,5 | 19,5 | 19,2 | 27,2 |
| | 6,4 | 14,6 | 18,6 | 20,8 | 18,1 | 25,5 |
| | 6,3 | 15,6 | 20,9 | 18,0 | 17,8 | 30,5 |
| media | 6,5 | 14,8 | 19,1 | 18,8 | 18,7 | 28,0 |
| dev.st | 0,3 | 0,6 | 1,1 | 1,2 | 0,8 | 1,8 |



I risultati ottenuti su filo di PAC a contenuto nominale di PA del 20% prelevato da una bobina in mista di PAC – PP sono i seguenti attraverso la metodica che prevede l'utilizzo del software Beers Law sono i seguenti:

| FTIR – PAC a 20% di contenuto nominale | | | | | | | | |
|--|------|------|------|------|------|------|--------------|------------|
| Campione | 1 | 2 | 3 | 4 | 5 | 6 | media | DS |
| % PA6 | 20,5 | 19,6 | 20,6 | 19,7 | 20,1 | 19,6 | 20,0 | 0,5 |

3.2 Misura della percentuale di PAC in fibre in mista

3.2.1 Idrolisi del Nylon

Nei capitoli a seguire verranno presentati i risultati relativi all'idrolisi del Nylon in fibre in mista PAC-PP e PAC-PA6 a differenti tempi di analisi.

Per il calcolo della percentuale di PAC presente nella mista si è utilizzata la % di Nylon estratta dalla fibra PAC nel medesimo tempo di idrolisi.

La verifica della bontà della misura è stata eseguita misurando il titolo della fibra PAC e delle fibre in mista e calcolando quindi il rapporto percentuale tra le fibre componenti la mista:

$$\% \text{ PAC} = \frac{\text{Titolo PAC} \cdot 100}{\text{Titolo mista}}$$

Si è infine stimata la percentuale teorica di Nylon estraibile dalla mista assumendo che la fibra PAC contenesse una % di Nylon pari al 20,2%.

3.2.1.1 Idrolisi del Nylon in miste PAC/PP

I risultati ottenuti a differenti tempi di analisi per l'idrolisi del Nylon in miste PAC/PP vengono presentati nella seguente tabella:

| Idrolisi in HCL al 17,5 % | | | | | | |
|---------------------------|----------|----------|---------|----------|-------|------|
| tempo [ore] | PAC + PP | | PAC | PAC + PP | | |
| | p iniz. | p idrol. | % Nylon | % Nylon | % PAC | % PP |
| 2 | 1.0764 | 0.9580 | 19.0 | 11.0 | 57.9 | 42.1 |
| 4 | 1.0568 | 0.9384 | 19.5 | 11.2 | 57.4 | 42.6 |
| 6 | 1.1325 | 1.0045 | 19.3 | 11.3 | 58.5 | 41.5 |
| 8 | 1.0239 | 0.9072 | 19.5 | 11.4 | 58.5 | 41.5 |
| 16 | 1.1153 | 0.9915 | 20.2 | 11.1 | 55.0 | 45.0 |
| 24 | 1.0985 | 0.9755 | 20.2 | 11.2 | 55.4 | 44.6 |
| Misura dei titoli | | | | | | |
| | PAC | PAC + PP | PAC | PAC + PP | | |
| | dTex | | % Nylon | % Nylon | % PAC | % PP |
| | 1181 | 2154 | | | | |
| | 1215 | 2149 | | | | |
| | 1180 | 2113 | | | | |
| MEDIA | 1192 | 2139 | 20.2 | 11.3 | 55.7 | 44.3 |

Come si può osservare per fibre in mista PAC/PP 6 ore di idrolisi sono sufficienti ad ottenere un valore della % di Nylon confrontabile con il valore teorico.

3.2.1.2 Idrolisi del Nylon in miste PAC/PA6

I risultati ottenuti a differenti tempi di analisi per l'idrolisi del Nylon in miste PAC/PA6 vengono presentati nella seguente tabella:

| Idrolisi in HCL al 17,5 % | | | | | | |
|---------------------------|-----------|-----------|---------|-----------|-------|-------|
| tempo [ore] | PAC + PA6 | | PAC | PAC + PA6 | | |
| | p iniz. | p idrol. | % Nylon | % Nylon | % PAC | % PA6 |
| 2 | 1.1067 | 0.4839 | 19.0 | 56.3 | 54.0 | 46.0 |
| 4 | 1.0234 | 0.4459 | 19.5 | 56.4 | 54.1 | 45.9 |
| 6 | 1.0463 | 0.4538 | 19.3 | 56.6 | 53.8 | 46.2 |
| 8 | 1.0032 | 0.4348 | 19.5 | 56.7 | 53.8 | 46.2 |
| 16 | 1.1398 | 0.4958 | 20.2 | 56.5 | 54.5 | 45.5 |
| 24 | 1.0247 | 0.4439 | 20.2 | 56.7 | 54.3 | 45.7 |
| Misura dei titoli | | | | | | |
| | PAC | PAC + PA6 | PAC | PAC + PA6 | | |
| | dTex | | % Nylon | % Nylon | % PAC | % PA6 |
| | 1181 | 2222 | | | | |
| | 1215 | 2212 | | | | |
| | 1180 | 2204 | | | | |
| MEDIA | 1192 | 2213 | 20.2 | 57.0 | 53.9 | 46.1 |

Analogamente a quanto osservato per miste PAC/PP anche per fibre in mista PAC/PA6 6 ore di idrolisi sono sufficienti ad ottenere un valore della % di Nylon confrontabile con il valore teorico.

3.2.2 Densitometria


E' stata verificata la possibilità di identificare fibre di PAC (PP/PA6 - 80/20), PP, PET e PA6 tramite l'immersione di queste in soluzioni acquose a densità nota. Inoltre con questa procedura, è possibile stimare le composizioni percentuali di sistemi a più componenti valutando la quantità di fibra precipitata in una soluzione di densità compresa tra le densità dei due componenti.

Avendo disponibilità di uno Spettrometro IR è possibile identificare le fibre in modo più preciso ed inoltre stimare le composizioni percentuali di sistemi a più componenti.

3.2.2.1 Ripetibilità statistica per miste PAC-PP

L'attività condotta è mirata alla valutazione dell'affidabilità della metodica di separazione tramite densimetria sulle miste PP/PAC, che risulta essere, a causa della ridotta differenza di densità, la più difficile da analizzare.

I risultati ottenuti e la relativa analisi statistica vengono riportati in figura. I risultati indicano una buona corrispondenza tra i dati ottenuti tramite separazione manuale e la misura ottenuta per separazione densitometrica.




3.2.2.2 Ripetibilità statistica per miste PAC-PP con quantità elevate di fibra in soluzione

Le prove, rispetto a quanto fatto in precedenza, sono state condotte utilizzando un litro di soluzione ed aumentando progressivamente il quantitativo di fibra introdotta.

Prove con l'utilizzo di 0.1 g di fibra: i risultati ottenuti in una prima sessione di prova vengono riportati nella pagina seguente. Come si può osservare i risultati sono confrontabili con quelli ottenuti con 30 mg di fibra introdotta sia come valore medio che come deviazione standard.

Si fa presente che una seconda sessione di misure non ha prodotto alcun risultato, l'elevato quantitativo di soluzione e la relativa necessità di aumentare le dimensioni del contenitore comportano un minore controllo nell'evaporazione dell'alcool durante i tre giorni di stazionamento. Sebbene le condizioni ambientali fossero immutate così come la tipologia di soluzione rispetto alla prima prova, una verifica della densità ha mostrato come la soluzione fosse eccessivamente densa per riuscire a separare le fibre che hanno raggiunto il galleggiamento in maniera quasi totalitaria.

| Prima sessione di prove con quantitativo superiore a 100 mg | | | | | | |
|---|-------|------|----------|-------|-------------|-------------|
| Campione | PP | PAC | PP + PAC | % PP | % PAC | |
| | [mg] | [mg] | [mg] | [%] | [%] | |
| 1 | 116,8 | 55,4 | 61,6 | 116,9 | 47,4 | 52,6 |
| 2 | 114,8 | 50,1 | 64,6 | 114,7 | 43,7 | 56,3 |
| 3 | 116,0 | 52,4 | 63,6 | 116,1 | 45,2 | 54,8 |
| 4 | 113,8 | 45,8 | 67,9 | 113,7 | 40,3 | 59,7 |
| 5 | 114,3 | 48,0 | 66,4 | 114,3 | 42,0 | 58,0 |
| 6 | 115,3 | 51,0 | 64,5 | 115,4 | 44,2 | 55,8 |
| MEDIA | | | | | 43,8 | 56,2 |
| DS | | | | | 2,5 | 2,5 |



Dati misurati e loro analisi statistica

Prove con l'utilizzo di 0.5 g di fibra: anche in questo caso sono state eseguite due differenti sessioni di prova. In entrambi i casi si è misurata la densità della soluzione e verificato che rientrasse nei parametri richiesti.

Nella prima sessione le fibre sono state tagliate con lunghezza approssimativa di 5 mm e l'interazione tra le fibre ha fatto sì che le bave di PP trasportassero con loro anche quelle di PAC rendendo la misura decisamente poco significativa.

Per ovviare a tale problema si è deciso di ridurre la dimensione delle fibre in una seconda sessione a 1 – 2 mm, tuttavia ciò non ha comportato alcun miglioramento.

4 Conclusioni

Alla luce dei risultati presentati è possibile trarre le seguenti conclusioni:

Misura della percentuale di Nylon nelle fibre PAC

Idrolisi del Nylon

L'idrolisi del Nylon a diverse composizioni ha mostrato come 24 ore di analisi consentano di misurare la percentuale di PA6 presente nella fibra PAC con ottima precisione. In seguito lo studio di un filo a percentuale nominale del 20% a differenti tempi di idrolisi ha evidenziato come l'analisi su sei ore presenti una discreta stabilità della misura e sebbene essa tenda ad essere leggermente sottostimante consente di individuare con certezza il contenuto nominale di Nylon presente in fibra.

Attacco acido del Nylon nella fibra PAC

L'utilizzo di acido formico all'80% consente di sviluppare una metodologia che non è in grado di fornire una misura quantitativa tuttavia essa garantisce un riconoscimento immediato della fibra PAC rispetto alle fibre in Nylon le quali subiscono una perdita di peso decisamente superiore o rispetto a fibre di PP le quali non subiscono alcuna perdita di peso.

Spettroscopia infrarossa

L'utilizzo di uno spettroscopio ad infrarosso consente il riconoscimento immediato delle fibre di PAC senza bisogno di alcun pretrattamento ed è sufficiente avere a disposizione una singola bava. Per ottenere dei valori quantitativi significativi sono necessarie differenti misure poiché l'analisi è puntuale e le bave presentano un'elevata variabilità nella percentuale di PA6 presente a livello microscopico; variabilità dovuta al processo produttivo stesso. Ciò nonostante il metodo risulta decisamente il più rapido e sufficientemente preciso in particolar modo se le fibre vengono precedentemente lavate in etere di petrolio al fine di rimuovere l'olio di ensimaggio. Il metodo presenta come unico difetto la necessità di disporre a priori di campioni a percentuale di PA6 nota al fine di generare una curva di taratura specifica per lo strumento utilizzato.

Misura della percentuale di PAC in fibre in mista

Idrolisi del Nylon

I risultati ottenuti per miste PAC-PP e PAC-PA6 evidenziano come tale metodologia sia molto precisa per misure quantitative, essa richiede tuttavia di conoscere a priori la percentuale di Nylon presente nella fibra PAC. Nello specifico l'analisi dei tempi ha evidenziato come 6 ore di idrolisi siano sufficienti ad ottenere dei valori con una precisione sufficiente.

Sebbene il metodo sia stato applicato esclusivamente alle miste PAC-PP e PAC-PA6 essa è applicabile anche a miste PAC con poliestere il quale non subisce perdite di peso significative in acido cloridrico al 17,5%.

Densitometria

Le prove condotte si sono concentrate su miste PAC-PP essendo il caso con la minore differenza di densità e quindi il più complesso. Tali misure hanno evidenziato che la metodologia migliore è quella con quantità di fibra ridotte (30 mg) la quale porta ad una buona corrispondenza tra i dati ottenuti tramite separazione manuale e la misura ottenuta per separazione densitometrica.

Oltre alla buona precisione la metodologia offre il vantaggio di essere applicabile a qualunque mista; di contro tuttavia si riescono ad analizzare solo piccole quantità, è estremamente laboriosa e necessità di tempi lunghi e ottima manualità e accuratezza dell'operatore. Tale metodo diventa indispensabile in presenza di miste triple (es: PAC-PP-PET) poiché consente di ricondursi a sistemi binari e poter quindi procedere con la metodologia di idrolisi o eseguire una nuova misura densitometrica.

Metodologie combinate per la misura della percentuale di PAC in fibre in mista

In conclusione in presenza di miste di tipo ternario è sicuramente necessario l'utilizzo della metodologia densitometrica al fine di ricondursi a sistemi misti PAC-PP o PAC-PA6. Per l'analisi di tali miste può essere utilizzata nuovamente l'analisi densitometrica oppure si può utilizzare la metodologia ad idrolisi la quale garantisce una maggiore precisione nei risultati e tempi inferiori visto che 6 ore di idrolisi sono sufficienti per ottenere buone misure quantitative. Tale metodologia di analisi necessita tuttavia di conoscere la percentuale di Nylon presente nella fibra PAC. Sebbene l'idrolisi della sola fibra PAC conduca a buoni risultati essa appare molto difficile in presenza di



fibre in mista poiché sarebbe necessario disporre di quantitativi notevoli di fibra e difficilmente ricavabili tramite analisi densitometrica. Con tali premesse si può dedurre come l'analisi di spettroscopia infrarossa sia la maggiormente adeguata a tale scopo poiché consente di distinguere in maniera immediata le fibre PAC dalle restanti, necessita di piccoli quantitativi e sebbene siano necessarie almeno 6 misure differenti è molto rapida.

Il sistema metodologico che pare quindi maggiormente idoneo è il seguente:

| | | | | |
|------------------------|----|------------------------------|----|------------------------------------|
| Miste ternarie | | Miste PAC/PP; PAC/PA6 | | Nylon presente in fibra PAC |
| Analisi densitometrica | => | Idrolisi in 6 ore | => | Spettroscopia infrarossa |

IDENTIFICATION METHODOLOGIES FOR PROPYLAMIDECOMPOSITE FIBER.

INTRODUCTION

Following the research developed by Aquafil spa (Arco, Trento-Italy) on the production of a new composite-like fiber, in the Laboratory of Polymers and Composite of the University of Trento various methodologies have been optimised and used for the characterization of the products.

Propylamidecomposite fibers are produced by a Reactive Spinning of polymeric blends based on polypropylene (PP) and polyamide (PA). Significant mechanical properties improvements can be achieved as reported (1).

Reactive Blending of PA and PP will allow and induce the creation of a see-in-the-island type structure, whereas polyamide islands, are formed and are sheeted by the inert polyolefin see. Scientific evidences do exist that, as PA content increases, the size of islands will increase up to a point, where 'bridges' will start connect islands and create a more complex microstructure. Experimental evidences (2) suggests that an extruded 50 wt % PP / 50 wt% PA, can still maintain this island-in-the-see microstructure. Also (3) provide experimental evidences that an extruded 50wt% PP/50wt% PA blend is characterized by a dispersed microstructure of PA inside a PP matrix.

In the case of Reactive Spinning, PA is shaped in form of fibrils elongated in the direction of the fiber axis and surrounded by the polyolefin polymer. However, due to the novelty of the new fiber, it is more difficult to have scientific information about the upper limit of the Polyamide content in the Propylamidecomposite fiber. Therefore, we prudently suggest to consider a maximum limit of PA of 45wt%.

1) Fiber Composition determination: the main procedures used by the present Laboratory are:

- Differential Scanning Calorimetry (DSC)
- Infrared Spectroscopy in ATR configuration (FTIR-ATR)
- Density Measurement

Also XR analysis is interesting, but it requires a more specific equipment, not always available in common analytical labs.

2) Fiber Microstructure determination: the main procedure used by the present Laboratory is:

- Scanning Electronic Microscope (SEM)

METHODOLOGIES DESCRIPTION

DSC

1. About 15-20 mg of continuous filament are loaded in an aluminium DSC pan. It is recommended to use a large pan of about 160 microliter.
2. Thermal scan is performed between 0°C and 260°C by using a heating rate of 10°C/min flushing nitrogen at 100ml/min. A single heating scan will provide a standard information on the fiber characteristics, whereas more details can be achieved by using a cycle of heating-cooling-heating:
 - a) During the first heating scan, the melting peak of both the PP and PA phase are registered at about 170 and 220°C respectively.
 - b) The second heating scan evidences the melting peak of PP at about 165°C, whereas the melting peak of PA is located at about 220°C. The integration of these two peaks is more representative of the real composition, because the processing effects and the orientation phenomena have been delayed after the first scan. The melting enthalpy is related to the percentage of crystalline phase of the two components, that could approximately evaluated by referring to the melting enthalpy of the pure components $E_{PP-100\%}$ and $E_{PA-100\%}$ according to the equations (1) and (2) where E_{P-MTX} and E_{PA-MTX} are the melting enthalpy of the two polymer in the MTX filament.
$$P_{PP} \% = 100 \times E_{P-MTX} / E_{PP-100\%} \quad (1)$$
$$P_{PA} \% = 100 \times E_{PA-MTX} / E_{PA-100\%} \quad (2)$$
 - c) Further information can be obtained during a controlled cooling stage in same interval of 260-0°C with a cooling rate of -10°C/min. The crystallization peak of polypropylene is always detectable at about 120°C. The crystallization peak of PA is typically a large peak between 190 and 160°C. In the case of the Propylamidecomposite Fiber family it is strongly reduced and tends to disappears in dependence of the chemical reaction between the two polymers during reactive blending. This phenomena is called 'co-crystallisation', as reported by the literature, and differentiate this fiber family from the commonly used physical fiber blends (fiber mixtures).

FTIR

The FTIR (infrared spectroscopy in solid phase) is a complementary technique. The BCF product is directly tested in the range 4000-650 cm^{-1} (sensitivity 4 cm^{-1}). The typical PA peaks are located at about 3300, 3080, (2930 and 2860), 1640 and 1535 cm^{-1} , whereas PP shows peaks at about 2950, 2920, (2870 and 2940), 1455 and 1375 cm^{-1} . The presence of the main peak will qualitatively identified the MTX filament. In the range 3000-2800 cm^{-1} , the peaks are partially overlapped.

A quantitative analysis can be obtained by comparing the intensity of the peak at 1640 cm^{-1} or 3300 cm^{-1} (I_{PA-MTX}) and 1455 cm^{-1} (I_{P-MTX}) in MTX filament and in the pure PP or PA filament according to the equations 3 and 4:

$$P_{PP} \% = 100 \times I_{P-MTX} / I_{PP-100\%} \quad (3)$$

$$P_{PA} \% = 100 \times I_{PA-MTX} / I_{PA-100\%} \quad (4)$$

For a good quantitative analysis, the operator should take care to use the same amount of fiber and to apply the same contact pressure on the crystal. A more sophisticated evaluation will consider an internal standard in order to normalize the relative intensities of the three spectra (PP, PA and MTX), for instance the peaks at about 2950-2920 cm^{-1} .

DENSITY

Blend density can be measured by the Archimedean methodology following the norm ASTM D792. For the specific case the Propylamidecomposite yarn, sample is prepared as follows:

1. is gently scoured in warm water to remove sin finish;
2. is dried at 100°C for at least 15 min and than cooled to room temperature;
3. yarns weight is measured in air w_{air} ;
4. yarns weight is measured in ethyl alcohol having a purity of 95%, w_{Et} ; ethanol temperature is also measured to compensate its density ρ_{Et} as a function of temperature;
5. Density ρ is calculated according to ASTM D792 norms with equation (5):


$$\rho_{\text{Et}} = \rho_{\text{Et}} w_{\text{air}} / (w_{\text{air}} - w_{\text{Et}}) \quad (5)$$

The experimental error is ± 0.001 .

SEM

Analysis of the microstructure, i.e. of the presence, size and distribution of the PA microfibrils embedded inside the polyolefin matrix, is carried out on yarns cross-section after a proper sample preparation.

1. The yarn is wrapped around a metal square-shaped metal sample-holder typically made in AISI 304 steel, as in (1) of sample-holder sketch (where red lines indicates the wrapped yarn), with typical dimensions of 45x10x5 mm. Sample-holder edges must be as sharp as possible. A second bar having the same size is joined to the first, using two screws, as in (2) of sample-holder sketch.



1. **Wrapping of the yarn around the metal bar**
2. **Side view after positioning of the second square bar and yarn cut**

2. The sample-holder with the wrapped yarn and a sharp razor blades are placed inside a liquid nitrogen bath for at least 5 minutes.
3. Immediately after removal from the liquid nitrogen bath, the yarn is carefully cut using the razor blade at the edges were the two bars are joining. Cutting is done by a rapid sliding of the razor blade on the sample-holder surface. An appropriate pressure must be exerted on the sample-holder surface while sliding and an appropriate cut speed must be used in order

to have a proper plain cut surface of the yarn. After cutting, only the yarn clipped inside the two metal bars remains, as in (2) (red line) of sample-holder sketch. A visual inspection using an Optical Microscope with a minimum magnification of 50x allows to verify the quality of the cut surface. Eventually, when this is not properly done, the procedure must be repeated.

4. The sample-holder is then placed inside a formic acid bath at room temperature for at least 60 minutes, in order to remove the nylon fibrils by chemical dissolution.
5. The sample is then coated by a conductive layer using the standard metallographic SEM procedure, such as through a silver metallization in a vacuum chamber.
6. A morphological SEM analysis is then carried out in order to evidence the location of the nylon fibrils inside fiber cross-section, now visible in form of holes.
7. When necessary, e.g. to verify the existence of hole previously present (e.g. hollow fibers) the surface analysis can also be repeated without the chemical attack in the formic acid bath.

EXPERIMENTAL APPLICATION OF TESTING METHODOLOGIES

Three different industrial BCF Propylamidecomposite yarns were produced by Aquafil having a composition range from 15wt% to 25wt% of PA6.

DSC, FITR-ATR, density and SEM analysis were performed on the three types of yarns.

- Results of DSC analysis are reported in Fig.1 to 4. Fig.1 present the first Heating Cycle, Fig.2 the Cooling Cycle, showing the co-crystallisation, Fig.3 the second heating Cycle. Fig.4 plots the relationships between the nominal PA6 wt% content and the Melting Heat or the Melting Enthalpy.
- Results of FITR are reported in Fig.5.
- A comparison between nominal composition, DSC and FITR results is reported in Fig.6.
- The correlation between the nominal composition and density is reported in Fig.7; a slight deviation from the linear relationship is evidenced.
- SEM metallographic analysis are reported in Fig.8 (15wt% PA6), 9 (20wt%PA6) and 10 (25wt%PA6).

LIST OF FIGURES

Fig.1 – DSC analysis of Propylamidecomposite fibers – Ist Heating Cycle.

Fig.2 – DSC analysis of Propylamidecomposite fibers – Cooling Cycle

Fig.3 – DSC analysis of Propylamidecomposite fibers – IInd Heating Cycle

Fig.4 – DSC analysis of Propylamidecomposite fibers – Melting Enthalpy as a function of PA6wt%

Fig.5 – FITR analysis of Propylamidecomposite fibers

Fig.6 – Comparison between Nominal PA6wt% content and results of DSC and FITR analysis of Propylamidecomposite fibers

Fig.7 – Correlation between yarn density and nominal PA6 wt% content in Propylamidecomposite

Fig.8 – Distribution of PA6 fibrils in the Propylamidecomposite fiber with 15wt% of PA6

Fig.9 – Distribution of PA6 fibrils in the Propylamidecomposite fiber with 20wt% of PA6.

Fig.10 – Distribution of PA6 fibrils in the Propylamidecomposite fiber with 25wt% of PA6.

REFERENCES.

- (1) I.Grof, M.Sain, O.Drcova, Structure-Properties Relationship of Modified Polypropylene-Polycaprolactamide Fiber, J.of Applied Polymer Science, vol.44 1061-1068 (1992).
 - (2) J.E. Bidaux, G.D.Smith, J.E.manson, C.Plummer, J.Hilborn, Fusion Bonding of maleic anhydride grafted Polypropylene-Polyamide 6 blends to polyamide 6, Polymer, Vol.39, n.24, pp.5939-5948, 1998.
 - (3) G.Pompe, P.Ploetschke, J.Pionteck, Reactive Melt Blending of Modified Polyamide and Polypropylene: Assessment of Compatibilisation by Fractionated Crystallisation and Blend Morphology, Journal of Applied Polymer Science, Vol.86, pp.3445-3453, 2002.
 - (4) J. Teng1, J.U. Otaigbe, E. P. Taylor, Reactive Blending of Functionalized Polypropylene and Polyamide 6: In situ Polymerization and In situ Compatibilization, Polymer Engineering And Science, , Vol. 44, No. 4, pp.648-659, April 2004.
-




Grafico 5-3: Propylamidecomposite Fibre, I SCAN (riscaldamento -30°C ? 260°C)

Fig.1 – DSC analysis of Propylamidecomposite fibers – Ist Heating Cycle.




Grafico 5-4: Propylamidecomposite Fibre, II SCAN (raffreddamento 260°C ? 0°C)

Fig.2 – DSC analysis of Propylamidecomposite fibers – Cooling Cycle




Grafico 5-5: Propylamidecomposite Fibre, III SCAN (riscaldamento 10°C / 260°C)

Fig.3 – DSC analysis of Propylamidecomposite fibers – IInd Heating Cycle




Fig.4 – DSC analysis of Propylamidecomposite fibers – Melting Enthalpy as a function of PA6wt%




Figura 5.1: spettri IR

Fig.5 – FITR analysis of Propylamidecomposite fibers.




Grafico 6-6: confronto delle percentuali dichiarate di PA6 con le due tecniche di analisi

Fig.6 – Comparison between Nominal PA6wt% content and results of DSC and FITR analysis of Propylamidecomposite fibers.




Fig.7 – Correlation between yarn density and nominal PA6 wt% content in Propylamidecomposite fibers. Dotted line represent a linear relationship.




Fig.8 – Distribution of PA6 fibrils in the Propylamide composite fiber with 15wt% of PA6.




Fig.9 – Distribution of PA6 fibrils in the Propylamide composite fiber with 20wt% of PA6.




Fig.10 – Distribution of PA6 fibrils in the Propylamide composite fiber with 25wt% of PA6.

Annex II

Microscopic analysis

polypropylene (sample 192)




Fig. 1: Sample **192**, longitudinal view, 20X.




Fig. 2: Sample **192**, cross-section, 20X.



Fig. 3: Sample **192**, longitudinal view, 40X.




Fig. 4: Sample **192**, cross-section, 40X.

polyamide (sample 193)



Fig. 5: Sample **193**, longitudinal view, 10X.



Fig. 6: Sample **193**, cross-section, 10X.



Fig. 7: Sample **193**, longitudinal view, 20X.



Fig. 8: Sample **193**, cross-section, 20X.




Fig.9: Sample **193**, longitudinal view, 40X.



Fig. 10: Sample **193**, cross-section, 40X.

PAC 40 % (sample 199)




Fig.11: Sample 199, longitudinal view, 10X.




Fig. 12: Sample 199, cross-section, 10X.




Fig.13: Sample 199, longitudinal view, 20X.




Fig. 14: Sample 199, cross-section, 20X.




Fig.15: Sample 199, longitudinal view, 40X.




Fig. 16: Sample 199, cross-section, 40X.

PA6/PAC 10% interlaced (sample 200)




Fig.17: Sample 200, longitudinal view, 10X.




Fig. 18: Sample 200, cross-section, 10X.




Fig.19: Sample 200, longitudinal view, 20X.



Fig. 20: Sample 200, cross-section, 20X.




Fig.21: Sample 200, longitudinal view, 40X.




Fig. 22: Sample 200, cross-section, 40X.

PP/PAC 20% twisted (sample 210)




Fig.23: Sample 210, longitudinal view, 10X.



Fig. 24: Sample 210, cross-section, 20X.




Fig. 25: Sample 210, cross-section, 20X.




Fig. 26: Sample 210, cross-section, 40X.

PP/PAC 20% twisted (sample 210)



Fig.27: Sample 210, longitudinal view, 10X.




Fig. 28: Sample 210, cross-section, 10X.



Fig.29: Sample 210, longitudinal view, 20X.




Fig. 30: Sample 210, cross-section, 20X.




Fig.31: Sample 210, longitudinal view, 40X.




Fig. 32: Sample 210, cross-section, 40X.

Annex III

Spectroscopic analysis FT-IR




Fig. 1: FT-IR spectrum of polypropylene (sample 192).




Fig. 2: FT-IR spectrum of polyamide 6 (sample 193).




Fig. 3: FT-IR spectrum of PAC 20 % (sample 197).




Fig. 4: FT-IR spectrum of PAC 40 % (sample 199).




Fig. 5: FT-IR spectrum of PAC 20 % (sample 233).




Fig. 6: Comparison of FT-IR spectra of PAC 5 % (---), 10 % (---), 20 % (---), 30 % (---), 40 % (---) (samples 195 - 199).




Fig. 7: Comparison of FT-IR spectra of untreated (---) and pre-treated (---) PAC 40 % (sample **199**).




Fig. 8: Comparison of FT-IR spectra of PAC 20 % (sample **197**) as received (---) and after hydrolysis method (---).




Fig. 9: Comparison of FT-IR spectra of PAC 20 % (sample **197**) as received (---) and after method 16 of Dir. 96/73/EC (---).




Fig. 10: FT-IR spectrum of "physical mixture" of PP and PA6 (PA6 content 20 %).

Annex IV

DSC analysis

Quantification of PA6 in PAC

PAC 5 %- 40 % (samples 195 - 199)

| JRC code | PP peak area J/g | PA6 peak area J/g |
|-------------------------|---------------------|----------------------|
| 195-1 | 104.60 | 3.60 |
| 195-2 | 104.30 | 3.52 |
| 195-3 | 103.30 | 3.56 |
| average | 104.07 | 3.56 |
| confidence limit | 1.69 | 0.09 |
| SD | 0.68 | 0.04 |
| RSD % | 0.65 | 1.01 |

| JRC code | PP peak area J/g | PA6 peak area J/g |
|-------------------------|---------------------|----------------------|
| 196-1 | 97.86 | 6.74 |
| 196-2 | 99.97 | 6.48 |
| 196-3 | 97.97 | 6.81 |
| average | 98.60 | 6.67 |
| confidence limit | 2.95 | 0.43 |
| SD | 1.19 | 0.17 |
| RSD % | 1.20 | 2.62 |

| JRC code | PP peak area J/g | PA6 peak area J/g |
|-------------------------|---------------------|----------------------|
| 197-1 | 90.61 | 12.27 |
| 197-2 | 88.02 | 12.21 |
| 197-3 | 87.31 | 11.96 |
| average | 88.65 | 12.15 |
| confidence limit | 4.31 | 0.41 |
| SD | 1.74 | 0.16 |
| RSD % | 1.96 | 1.35 |

| JRC code | PP peak area J/g | PA6 peak area J/g |
|-------------------------|---------------------|----------------------|
| 198-1 | 78.99 | 15.74 |
| 198-2 | 75.82 | 14.58 |
| 198-3 | 77.14 | 15.53 |
| average | 77.32 | 15.28 |
| confidence limit | 3.96 | 1.54 |
| SD | 1.59 | 0.62 |
| RSD % | 2.06 | 4.04 |

| JRC code | PP peak area J/g | PA6 peak area J/g |
|-------------------------|---------------------|----------------------|
| 199-1 | 65.71 | 20.91 |
| 199-2 | 65.91 | 19.18 |
| 199-3 | 64.24 | 18.22 |
| average | 65.29 | 19.44 |
| confidence limit | 2.27 | 3.39 |
| SD | 0.91 | 1.36 |
| RSD % | 1.40 | 7.01 |

Quantification of binary mixtures PA6/PAC

Binary mixtures PA6/PAC (samples 200 - 206)

| JRC code | PP peak area J/g | PA6 peak area J/g |
|------------------|---------------------|----------------------|
| 200-1 | 38.79 | 31.92 |
| 200-2 | 39.74 | 31.86 |
| 200-3 | 39.14 | 30.31 |
| average | 39.22 | 31.36 |
| confidence limit | 1.19 | 2.27 |
| SD | 0.48 | 0.91 |
| RSD % | 1.22 | 2.91 |

| JRC code | PP peak area J/g | PA6 peak area J/g |
|------------------|---------------------|----------------------|
| 201-1 | 38.22 | 33.14 |
| 201-2 | 38.79 | 32.26 |
| 201-3 | 38.93 | 32.72 |
| average | 38.65 | 32.71 |
| confidence limit | 0.93 | 1.09 |
| SD | 0.38 | 0.44 |
| RSD % | 0.97 | 1.35 |

| JRC code | PP peak area J/g | PA6 peak area J/g |
|------------------|---------------------|----------------------|
| 202-1 | 37.34 | 33.82 |
| 202-2 | 37.37 | 32.92 |
| 202-3 | 37.65 | 33.36 |
| average | 37.45 | 33.37 |
| confidence limit | 0.42 | 1.12 |
| SD | 0.17 | 0.45 |
| RSD % | 0.46 | 1.35 |

| JRC code | PP peak area J/g | PA6 peak area J/g |
|------------------|---------------------|----------------------|
| 203-1 | 37.38 | 34.51 |
| 203-2 | 37.07 | 34.76 |
| 203-3 | 36.85 | 34.73 |
| average | 37.10 | 34.67 |
| confidence limit | 0.66 | 0.34 |
| SD | 0.27 | 0.14 |
| RSD % | 0.72 | 0.39 |

| JRC code | PP peak area J/g | PA6 peak area J/g |
|------------------|---------------------|----------------------|
| 204-1 | 31.74 | 35.70 |
| 204-2 | 31.97 | 34.70 |
| 204-3 | 30.25 | 35.35 |
| average | 31.32 | 35.25 |
| confidence limit | 2.32 | 1.26 |
| SD | 0.93 | 0.51 |
| RSD % | 2.98 | 1.44 |

| JRC code | PP peak area J/g | PA6 peak area J/g |
|------------------|---------------------|----------------------|
| 205-1 | 31.87 | 36.71 |
| 205-2 | 30.18 | 34.59 |
| 205-3 | 32.01 | 36.21 |
| average | 31.35 | 35.84 |
| confidence limit | 2.53 | 2.75 |
| SD | 1.02 | 1.11 |
| RSD % | 3.25 | 3.09 |

| JRC code | PP peak area J/g | PA6 peak area J/g |
|------------------|---------------------|----------------------|
| 206-1 | 30.09 | 37.91 |
| 206-2 | 28.12 | 37.10 |
| 206-3 | 27.95 | 38.06 |
| average | 28.72 | 37.69 |
| confidence limit | 2.95 | 1.28 |
| SD | 1.19 | 0.52 |
| RSD % | 4.14 | 1.37 |

Quantification of binary mixtures PP/PAC

Binary mixtures PP/PAC (samples 207 - 213)

| JRC code | PP peak area J/g | PA6 peak area J/g |
|------------------|---------------------|----------------------|
| 207-1 | 100.1 | 3.15 |
| 207-2 | 99.71 | 3.18 |
| average | 99.91 | 3.16 |
| confidence limit | 2.48 | 0.14 |
| SD | 0.28 | 0.02 |
| RSD % | 0.28 | 0.49 |

| JRC code | PP peak area J/g | PA6 peak area J/g |
|------------------|---------------------|----------------------|
| 208-1 | 97.92 | 3.17 |
| 208-2 | 98.13 | 3.25 |
| 208-3 | 96.91 | 3.10 |
| average | 97.65 | 3.17 |
| confidence limit | 1.62 | 0.18 |
| SD | 0.65 | 0.07 |
| RSD % | 0.67 | 2.32 |

| JRC code | PP peak area J/g | PA6 peak area J/g |
|------------------|---------------------|----------------------|
| 209-1 | 92.15 | 5.36 |
| 209-2 | 93.46 | 5.29 |
| 209-3 | 94.74 | 5.66 |
| average | 93.45 | 5.44 |
| confidence limit | 3.22 | 0.50 |
| SD | 1.30 | 0.20 |
| RSD % | 1.39 | 3.67 |

| JRC code | PP peak area J/g | PA6 peak area J/g |
|------------------|---------------------|----------------------|
| 210-1 | 94.74 | 5.42 |
| 210-2 | 94.72 | 5.29 |
| 210-3 | 93.78 | 5.12 |
| average | 94.41 | 5.28 |
| confidence limit | 1.36 | 0.37 |
| SD | 0.55 | 0.15 |
| RSD % | 0.58 | 2.79 |

| JRC code | PP peak area J/g | PA6 peak area J/g |
|------------------|---------------------|----------------------|
| 211-1 | 94.56 | 7.63 |
| 211-2 | 94.78 | 7.32 |
| 211-3 | 95.26 | 7.53 |
| average | 94.87 | 7.49 |
| confidence limit | 0.89 | 0.40 |
| SD | 0.36 | 0.16 |
| RSD % | 0.38 | 2.15 |

| JRC code | PP peak area J/g | PA6 peak area J/g |
|------------------|---------------------|----------------------|
| 212-1 | 93.55 | 7.52 |
| 212-2 | 94.74 | 7.13 |
| 212-3 | 95.87 | 7.58 |
| average | 94.72 | 7.41 |
| confidence limit | 2.88 | 0.60 |
| SD | 1.16 | 0.24 |
| RSD % | 1.22 | 3.28 |

| JRC code | PP peak area J/g | PA6 peak area J/g |
|------------------|---------------------|----------------------|
| 213-1 | 88.07 | 9.36 |
| 213-2 | 90.88 | 10.97 |
| 213-3 | | 9.53 |
| average | 89.48 | 9.95 |
| confidence limit | 17.85 | 2.20 |
| SD | 1.99 | 0.88 |
| RSD % | 2.22 | 8.89 |

Annex V

Analysis of composition

Influence of drying conditions on PAC

PAC 20 % (samples 160, 197, 233)

- Vacuum oven

| JRC code | time h | wet sample mass g | dried sample mass g | water mass g | loss of mass % |
|----------|-----------|----------------------|------------------------|-----------------|-------------------|
| 160-1 | 2 | 6.0344 | 5.9888 | 0.0456 | 0.756 |
| 160-2 | 4 | 6.0652 | 6.0183 | 0.0469 | 0.773 |
| 160-3 | 6 | 6.0312 | 5.9874 | 0.0438 | 0.726 |
| 160-4 | 8 | 6.0622 | 6.0199 | 0.0423 | 0.698 |
| 160-5 | 12 | 6.0593 | 6.0139 | 0.0454 | 0.749 |
| 160-6 | 16 | 5.9671 | 5.9269 | 0.0402 | 0.674 |

| JRC code | time h | wet sample mass g | dried sample mass g | water mass g | loss of mass % |
|----------|-----------|----------------------|------------------------|-----------------|-------------------|
| 197-1 | 2 | 6.2282 | 6.1795 | 0.0487 | 0.782 |
| 197-2 | 4 | 6.2273 | 6.1776 | 0.0497 | 0.798 |
| 197-3 | 6 | 6.2449 | 6.1980 | 0.0469 | 0.751 |
| 197-4 | 8 | 6.2196 | 6.1770 | 0.0426 | 0.685 |
| 197-5 | 12 | 6.2647 | 6.2180 | 0.0467 | 0.745 |
| 197-6 | 16 | 6.2667 | 6.2258 | 0.0409 | 0.653 |

| JRC code | time h | wet sample mass g | dried sample mass g | water mass g | loss of mass % |
|----------|-----------|----------------------|------------------------|-----------------|-------------------|
| 233-1 | 2 | 6.1383 | 6.0893 | 0.0490 | 0.798 |
| 233-2 | 4 | 6.1913 | 6.1414 | 0.0499 | 0.806 |
| 233-3 | 6 | 6.2964 | 6.2502 | 0.0462 | 0.734 |
| 233-4 | 8 | 6.2040 | 6.1598 | 0.0442 | 0.712 |
| 233-5 | 12 | 6.1510 | 6.1055 | 0.0455 | 0.740 |
| 233-6 | 16 | 6.2927 | 6.2494 | 0.0433 | 0.688 |

- Ventilated oven

| JRC code | time h | wet sample mass g | dried sample mass g | water mass g | loss of mass % |
|----------|-----------|----------------------|------------------------|-----------------|-------------------|
| 160-1 | 2 | 6.0376 | 5.9923 | 0.0453 | 0.750 |
| 160-2 | 4 | 6.1139 | 6.0662 | 0.0477 | 0.780 |
| 160-3 | 6 | 6.1657 | 6.1397 | 0.0260 | 0.422 |
| 160-4 | 8 | 6.0477 | 6.0274 | 0.0203 | 0.336 |
| 160-5 | 12 | 6.0327 | 5.9930 | 0.0397 | 0.658 |
| 160-6 | 16 | 6.0460 | 6.0012 | 0.0448 | 0.741 |

| JRC code | time h | wet sample mass g | dried sample mass g | water mass g | loss of mass % |
|----------|-----------|----------------------|------------------------|-----------------|-------------------|
| 197-1 | 2 | 6.1665 | 6.1185 | 0.0480 | 0.778 |
| 197-2 | 4 | 6.1669 | 6.1171 | 0.0498 | 0.808 |
| 197-3 | 6 | 6.1758 | 6.1305 | 0.0453 | 0.734 |
| 197-4 | 8 | 6.2624 | 6.2159 | 0.0465 | 0.743 |
| 197-5 | 12 | 6.2312 | 6.1843 | 0.0469 | 0.753 |
| 197-6 | 16 | 6.2221 | 6.1799 | 0.0422 | 0.678 |

| JRC code | time h | wet sample mass g | dried sample mass g | water mass g | loss of mass % |
|----------|-----------|----------------------|------------------------|-----------------|-------------------|
| 233-1 | 2 | 6.2140 | 6.1673 | 0.0467 | 0.752 |
| 233-2 | 4 | 6.2281 | 6.1801 | 0.0480 | 0.771 |
| 233-3 | 6 | 6.1681 | 6.1234 | 0.0447 | 0.725 |
| 233-4 | 8 | 6.1876 | 6.1425 | 0.0451 | 0.729 |
| 233-5 | 12 | 6.2630 | 6.2138 | 0.0492 | 0.786 |
| 233-6 | 16 | 6.1941 | 6.1494 | 0.0447 | 0.722 |

Pre-treatment with petroleum ether in Soxhtec

polypropylene (sample 192)

| JRC code | untreated sample mass | pre-treated sample mass | mass loss | mass loss |
|----------|--------------------------|----------------------------|------------------|-----------|
| | g | g | g | % |
| 192-1 | 5.3461 | 5.2875 | 0.0586 | 1.10 |
| 192-2 | 5.4132 | 5.3560 | 0.0572 | 1.06 |
| 192-3 | 5.3385 | 5.2795 | 0.0590 | 1.11 |
| 192-4 | 5.4301 | 5.3715 | 0.0586 | 1.08 |
| 192-5 | 5.4412 | 5.3812 | 0.0600 | 1.10 |
| | | | average | 1.09 |
| | | | confidence limit | 0.03 |
| | | | SD | 0.02 |
| | | | RSD % | 1.86 |

polyamide 6 (sample 193)

| JRC code | untreated sample mass | pre-treated sample mass | mass loss | mass loss |
|----------|--------------------------|----------------------------|------------------|-----------|
| | g | g | g | % |
| 193-1 | 5.4018 | 5.3505 | 0.0513 | 0.95 |
| 193-2 | 5.5224 | 5.4651 | 0.0573 | 1.04 |
| 193-3 | 5.4091 | 5.3565 | 0.0526 | 0.97 |
| 193-4 | 5.4931 | 5.4294 | 0.0637 | 1.16 |
| 193-5 | 5.4590 | 5.3999 | 0.0591 | 1.08 |
| | | | average | 1.04 |
| | | | confidence limit | 0.11 |
| | | | SD | 0.08 |
| | | | RSD % | 8.16 |

PAC (samples 195 - 199, 233)

| JRC code | untreated sample mass | pre-treated sample mass | mass loss | mass loss |
|----------|--------------------------|----------------------------|------------------|-----------|
| | g | g | g | % |
| 195-1 | 5.2184 | 5.1623 | 0.0561 | 1.08 |
| 195-2 | 5.2198 | 5.1608 | 0.0590 | 1.13 |
| 195-3 | 5.1947 | 5.1363 | 0.0584 | 1.12 |
| 195-4 | 5.2911 | 5.2336 | 0.0575 | 1.09 |
| 195-5 | 5.2066 | 5.1520 | 0.0546 | 1.05 |
| | | | average | 1.09 |
| | | | confidence limit | 0.04 |
| | | | SD | 0.03 |
| | | | RSD % | 3.13 |

| JRC code | untreated sample mass | pre-treated sample mass | mass loss | mass loss |
|----------|--------------------------|----------------------------|------------------|-----------|
| | g | g | g | % |
| 196-1 | 5.2086 | 5.1531 | 0.0555 | 1.07 |
| 196-2 | 5.1682 | 5.1136 | 0.0546 | 1.06 |
| 196-3 | 5.1901 | 5.1359 | 0.0542 | 1.04 |
| 196-4 | 5.1947 | 5.1387 | 0.0560 | 1.08 |
| 196-5 | 5.2093 | 5.1565 | 0.0528 | 1.01 |
| | | | average | 1.05 |
| | | | confidence limit | 0.03 |
| | | | SD | 0.02 |
| | | | RSD % | 2.34 |

| JRC code | untreated sample mass | pre-treated sample mass | mass loss | mass loss |
|----------|--------------------------|----------------------------|------------------|-----------|
| | g | g | g | % |
| 197-1 | 5.2394 | 5.1839 | 0.0555 | 1.06 |
| 197-2 | 5.2509 | 5.1970 | 0.0539 | 1.03 |
| 197-3 | 5.1916 | 5.1343 | 0.0573 | 1.10 |
| 197-4 | 5.2236 | 5.1692 | 0.0544 | 1.04 |
| 197-5 | 5.2798 | 5.2235 | 0.0563 | 1.07 |
| | | | average | 1.06 |
| | | | confidence limit | 0.04 |
| | | | SD | 0.03 |
| | | | RSD % | 2.76 |

| JRC code | untreated sample mass | pre-treated sample mass | mass loss | mass loss |
|----------|--------------------------|----------------------------|------------------|-----------|
| | g | g | g | % |
| 198-1 | 5.3072 | 5.2494 | 0.0578 | 1.09 |
| 198-2 | 5.3004 | 5.2418 | 0.0586 | 1.11 |
| 198-3 | 5.3708 | 5.3151 | 0.0557 | 1.04 |
| 198-4 | 5.2525 | 5.1950 | 0.0575 | 1.09 |
| 198-5 | 5.3384 | 5.2829 | 0.0555 | 1.04 |
| | | | average | 1.07 |
| | | | confidence limit | 0.04 |
| | | | SD | 0.03 |
| | | | RSD % | 3.02 |

| JRC code | untreated sample mass | pre-treated sample mass | mass loss | mass loss |
|----------|--------------------------|----------------------------|------------------|-----------|
| | g | g | g | % |
| 199-1 | 5.2242 | 5.1772 | 0.0470 | 0.90 |
| 199-2 | 5.3317 | 5.2821 | 0.0496 | 0.93 |
| 199-3 | 5.2822 | 5.2327 | 0.0495 | 0.94 |
| 199-4 | 5.356 | 5.3047 | 0.0513 | 0.96 |
| 199-5 | 5.3517 | 5.3003 | 0.0514 | 0.96 |
| | | | average | 0.94 |
| | | | confidence limit | 0.03 |
| | | | SD | 0.02 |
| | | | RSD % | 2.63 |

1st pre-treatment

| JRC code | untreated sample mass g | pre-treated sample mass g | mass loss g | mass loss % |
|----------|-------------------------------|---------------------------------|------------------|----------------|
| 233-1 | 4.8803 | 4.8352 | 0.0451 | 0.92 |
| 233-2 | 4.9304 | 4.8815 | 0.0489 | 0.99 |
| 233-3 | 4.9396 | 4.8923 | 0.0473 | 0.96 |
| 233-4 | 5.3062 | 5.2558 | 0.0504 | 0.95 |
| 233-5 | 4.9809 | 4.9344 | 0.0465 | 0.93 |
| | | | average | 0.95 |
| | | | confidence limit | 0.03 |
| | | | SD | 0.03 |
| | | | RSD % | 2.75 |

2nd pre-treatment

| JRC code | untreated sample mass g | pre-treated sample mass g | mass loss g | mass loss % |
|----------|-------------------------------|---------------------------------|------------------|----------------|
| 233-1 | 4.8352 | 4.8281 | 0.0071 | 0.15 |
| 233-2 | 4.8815 | 4.8750 | 0.0065 | 0.13 |
| 233-3 | 4.8923 | 4.8855 | 0.0068 | 0.14 |
| 233-4 | 5.2558 | 5.2482 | 0.0076 | 0.14 |
| 233-5 | 4.9344 | 4.9264 | 0.0080 | 0.16 |
| | | | average | 0.15 |
| | | | confidence limit | 0.01 |
| | | | SD | 0.01 |
| | | | RSD % | 7.49 |

3rd pre-treatment

| JRC code | untreated sample mass g | pre-treated sample mass g | mass loss g | mass loss % |
|----------|-------------------------------|---------------------------------|------------------|----------------|
| 233-1 | 4.8281 | 4.8233 | 0.0048 | 0.10 |
| 233-2 | 4.8750 | 4.8689 | 0.0061 | 0.13 |
| 233-3 | 4.8855 | 4.8806 | 0.0049 | 0.10 |
| 233-4 | 5.2482 | 5.2425 | 0.0057 | 0.11 |
| 233-5 | 4.9264 | 4.9193 | 0.0071 | 0.14 |
| | | | average | 0.12 |
| | | | confidence limit | 0.02 |
| | | | SD | 0.02 |
| | | | RSD % | 16.48 |

Agreed allowance

untreated PAC 5 %– 40 % (samples 195 - 199)

| JRC code | dried sample mass g | wet sample mass g | water mass g | agreed allowance % |
|------------------|------------------------|----------------------|-----------------|-----------------------|
| 195-1 | 2.0641 | 2.0673 | 0.0032 | 0.16 |
| 195-2 | 2.0713 | 2.0744 | 0.0031 | 0.15 |
| 195-3 | 2.0732 | 2.0758 | 0.0026 | 0.13 |
| 195-4 | 2.045 | 2.0483 | 0.0033 | 0.16 |
| 195-5 | 2.0465 | 2.0491 | 0.0026 | 0.13 |
| 195-6 | 2.0499 | 2.0532 | 0.0033 | 0.16 |
| 195-7 | 2.0202 | 2.0225 | 0.0023 | 0.11 |
| 195-8 | 2.0135 | 2.0169 | 0.0034 | 0.17 |
| 195-9 | 2.0615 | 2.0648 | 0.0033 | 0.16 |
| 195-10 | 2.0446 | 2.0479 | 0.0033 | 0.16 |
| average | | | | 0.15 |
| confidence limit | | | | 0.01 |
| SD | | | | 0.02 |
| RSD % | | | | 12.86 |

| JRC code | dried sample mass g | wet sample mass g | water mass g | agreed allowance % |
|------------------|------------------------|----------------------|-----------------|-----------------------|
| 196-1 | 2.0885 | 2.0949 | 0.0064 | 0.31 |
| 196-2 | 2.0578 | 2.0637 | 0.0059 | 0.29 |
| 196-3 | 2.0608 | 2.0671 | 0.0063 | 0.31 |
| 196-4 | 2.0803 | 2.0862 | 0.0059 | 0.28 |
| 196-5 | 2.0821 | 2.0882 | 0.0061 | 0.29 |
| 196-6 | 2.0235 | 2.0297 | 0.0062 | 0.31 |
| 196-7 | 2.0587 | 2.0644 | 0.0057 | 0.28 |
| 196-8 | 1.7843 | 1.7891 | 0.0048 | 0.27 |
| 196-9 | 2.0284 | 2.0341 | 0.0057 | 0.28 |
| 196-10 | 2.0049 | 2.0108 | 0.0059 | 0.29 |
| average | | | | 0.29 |
| confidence limit | | | | 0.01 |
| SD | | | | 0.01 |
| RSD % | | | | 4.53 |

| JRC code | dried sample mass g | wet sample mass g | water mass g | agreed allowance % |
|------------------|------------------------|----------------------|-----------------|-----------------------|
| 197-1 | 2.0448 | 2.0568 | 0.0120 | 0.59 |
| 197-2 | 2.0718 | 2.0835 | 0.0117 | 0.56 |
| 197-3 | 2.025 | 2.0375 | 0.0125 | 0.62 |
| 197-4 | 2.0412 | 2.0517 | 0.0105 | 0.51 |
| 197-5 | 2.0372 | 2.0482 | 0.0110 | 0.54 |
| 197-6 | 2.0698 | 2.0814 | 0.0116 | 0.56 |
| 197-7 | 2.0175 | 2.0288 | 0.0113 | 0.56 |
| 197-8 | 2.019 | 2.0301 | 0.0111 | 0.55 |
| 197-9 | 2.0581 | 2.0696 | 0.0115 | 0.56 |
| 197-10 | 2.047 | 2.0583 | 0.0113 | 0.55 |
| average | | | | 0.56 |
| confidence limit | | | | 0.02 |
| SD | | | | 0.03 |
| RSD % | | | | 4.86 |

| JRC code | dried sample mass | wet sample mass | water mass | agreed allowance |
|----------|-------------------|-----------------|------------|------------------|
| | g | g | g | % |
| 198-1 | 2.0176 | 2.0362 | 0.0186 | 0.92 |
| 198-2 | 2.0105 | 2.0286 | 0.0181 | 0.90 |
| 198-3 | 2.0332 | 2.0505 | 0.0173 | 0.85 |
| 198-4 | 2.0107 | 2.0276 | 0.0169 | 0.84 |
| 198-5 | 2.0726 | 2.0903 | 0.0177 | 0.85 |
| 198-6 | 2.0145 | 2.0323 | 0.0178 | 0.88 |
| 198-7 | 2.031 | 2.0493 | 0.0183 | 0.90 |
| 198-8 | 2.0714 | 2.0910 | 0.0196 | 0.95 |
| 198-9 | 2.0453 | 2.0626 | 0.0173 | 0.85 |
| 198-10 | 2.0193 | 2.0362 | 0.0169 | 0.84 |

average **0.88**
confidence limit **0.03**
SD **0.04**
RSD % **4.34**

| JRC code | dried sample mass | wet sample mass | water mass | agreed allowance |
|----------|-------------------|-----------------|------------|------------------|
| | g | g | g | % |
| 199-1 | 2.0519 | 2.0765 | 0.0246 | 1.20 |
| 199-2 | 2.0368 | 2.0608 | 0.0240 | 1.18 |
| 199-3 | 2.0203 | 2.0450 | 0.0247 | 1.22 |
| 199-4 | 2.0719 | 2.0945 | 0.0226 | 1.09 |
| 199-5 | 2.0462 | 2.0691 | 0.0229 | 1.12 |
| 199-6 | 2.0279 | 2.0499 | 0.0220 | 1.08 |
| 199-7 | 2.0627 | 2.0858 | 0.0231 | 1.12 |
| 199-8 | 1.9965 | 2.0190 | 0.0225 | 1.13 |
| 199-9 | 2.0389 | 2.0623 | 0.0234 | 1.15 |
| 199-10 | 2.0564 | 2.0809 | 0.0245 | 1.19 |

average **1.15**
confidence limit **0.03**
SD **0.05**
RSD % **4.13**

pre-treated PAC 5 %– 40 % (samples 195 - 199)

| JRC code | dried sample mass | wet sample mass | water mass | agreed allowance |
|----------|-------------------|-----------------|------------|------------------|
| | g | g | g | % |
| 195-1 | 2.0139 | 2.0148 | 0.0009 | 0.04 |
| 195-2 | 2.0710 | 2.0719 | 0.0009 | 0.04 |
| 195-3 | 2.0517 | 2.0531 | 0.0014 | 0.07 |
| 195-4 | 2.0338 | 2.0358 | 0.0020 | 0.10 |
| 195-5 | 2.0219 | 2.0234 | 0.0015 | 0.07 |
| 195-6 | 2.0627 | 2.0637 | 0.0010 | 0.05 |
| 195-7 | 2.0300 | 2.0317 | 0.0017 | 0.08 |
| 195-8 | 2.0453 | 2.0478 | 0.0025 | 0.12 |
| 195-9 | 2.0200 | 2.0241 | 0.0041 | 0.20 |
| 195-10 | 2.0152 | 2.0168 | 0.0016 | 0.08 |

average **0.09**
confidence limit **0.03**
SD **0.05**
RSD % **55.22**

| JRC code | dried sample mass | wet sample mass | water mass | agreed allowance |
|----------|-------------------|-----------------|------------|------------------|
| | g | g | g | % |
| 196-1 | 2.0535 | 2.0586 | 0.0051 | 0.25 |
| 196-2 | 2.0557 | 2.0604 | 0.0047 | 0.23 |
| 196-3 | 2.0255 | 2.0305 | 0.0050 | 0.25 |
| 196-4 | 2.0175 | 2.0201 | 0.0026 | 0.13 |
| 196-5 | 2.0256 | 2.0309 | 0.0053 | 0.26 |
| 196-6 | 2.0458 | 2.0524 | 0.0066 | 0.32 |
| 196-7 | 2.0215 | 2.0260 | 0.0045 | 0.22 |
| 196-8 | 2.0309 | 2.0367 | 0.0058 | 0.29 |
| 196-9 | 2.0131 | 2.0177 | 0.0046 | 0.23 |
| 196-10 | 2.0704 | 2.0716 | 0.0012 | 0.06 |

average **0.22**
confidence limit **0.05**
SD **0.08**
RSD % **34.29**

| JRC code | dried sample mass | wet sample mass | water mass | agreed allowance |
|----------|-------------------|-----------------|------------|------------------|
| | g | g | g | % |
| 197-1 | 2.0375 | 2.0489 | 0.0114 | 0.56 |
| 197-2 | 2.0358 | 2.0478 | 0.0120 | 0.59 |
| 197-3 | 2.0196 | 2.0293 | 0.0097 | 0.48 |
| 197-4 | 2.0684 | 2.0796 | 0.0112 | 0.54 |
| 197-5 | 2.0256 | 2.0369 | 0.0113 | 0.56 |
| 197-6 | 2.0425 | 2.0526 | 0.0101 | 0.49 |
| 197-7 | 2.0760 | 2.0851 | 0.0091 | 0.44 |
| 197-8 | 2.0532 | 2.0653 | 0.0121 | 0.59 |
| 197-9 | 2.0054 | 2.0151 | 0.0097 | 0.48 |
| 197-10 | 2.0629 | 2.0734 | 0.0105 | 0.51 |

average **0.52**
confidence limit **0.04**
SD **0.05**
RSD % **9.69**

| JRC code | dried sample mass | wet sample mass | water mass | agreed allowance |
|----------|-------------------|-----------------|------------|------------------|
| | g | g | g | % |
| 198-1 | 2.0508 | 2.0673 | 0.0165 | 0.80 |
| 198-2 | 2.0504 | 2.0631 | 0.0127 | 0.62 |
| 198-3 | 2.0006 | 2.0179 | 0.0173 | 0.86 |
| 198-4 | 2.0101 | 2.0277 | 0.0176 | 0.88 |
| 198-5 | 2.0473 | 2.0644 | 0.0171 | 0.84 |
| 198-6 | 2.0045 | 2.0188 | 0.0143 | 0.71 |
| 198-7 | 2.0051 | 2.0206 | 0.0155 | 0.77 |
| 198-8 | 2.0162 | 2.0344 | 0.0182 | 0.90 |
| 198-9 | 2.0145 | 2.0298 | 0.0153 | 0.76 |
| 198-10 | 2.0184 | 2.0327 | 0.0143 | 0.71 |

average **0.79**
confidence limit **0.06**
SD **0.09**
RSD % **11.27**

| JRC code | dried sample mass | wet sample mass | water mass | agreed allowance |
|------------------|-------------------|-----------------|------------|------------------|
| | g | g | g | % |
| 199-1 | 2.0149 | 2.0391 | 0.0242 | 1.20 |
| 199-2 | 2.0292 | 2.0522 | 0.0230 | 1.13 |
| 199-3 | 2.0470 | 2.0702 | 0.0232 | 1.13 |
| 199-4 | 2.0279 | 2.0495 | 0.0216 | 1.07 |
| 199-5 | 2.0283 | 2.0505 | 0.0222 | 1.09 |
| 199-6 | 2.0313 | 2.0551 | 0.0238 | 1.17 |
| 199-7 | 2.0202 | 2.0438 | 0.0236 | 1.17 |
| 199-8 | 2.0206 | 2.0444 | 0.0238 | 1.18 |
| 199-9 | 2.0231 | 2.0461 | 0.0230 | 1.14 |
| 199-10 | 2.0122 | 2.0342 | 0.0220 | 1.09 |
| average | | | | 1.14 |
| confidence limit | | | | 0.03 |
| SD | | | | 0.04 |
| RSD % | | | | 3.80 |

Influence of drying conditions on solubility properties of PAC

PAC 20 % (sample 233)

- Vacuum oven

Method 1

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|-------|
| 233-1 | 1.0382 | 1.0401 | 100.18 | -0.18 | 0.998 |
| 233-2 | 1.1399 | 1.1411 | 100.10 | -0.10 | 0.999 |
| 233-3 | 1.1219 | 1.1250 | 100.27 | -0.27 | 0.997 |
| 233-4 | 1.0750 | 1.0723 | 99.75 | 0.25 | 1.003 |
| 233-5 | 1.1982 | 1.2100 | 100.97 | -0.97 | 0.990 |
| average | | | 100.26 | -0.26 | 0.997 |
| confidence limit | | | 0.56 | 0.56 | 0.006 |
| SD | | | 0.45 | 0.45 | 0.004 |
| RSD % | | | 0.45 | -174.03 | 0.449 |

Method 2

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|-------|
| 233-1 | 0.9978 | 0.9973 | 99.95 | 0.05 | 1.001 |
| 233-2 | 1.0178 | 1.0169 | 99.91 | 0.09 | 1.001 |
| 233-3 | 1.0466 | 1.0474 | 100.08 | -0.08 | 0.999 |
| 233-4 | 1.0005 | 1.0028 | 100.23 | -0.23 | 0.998 |
| 233-5 | 1.0350 | 1.0327 | 99.78 | 0.22 | 1.002 |
| average | | | 99.99 | 0.01 | 1.000 |
| confidence limit | | | 0.21 | 0.21 | 0.002 |
| SD | | | 0.17 | 0.17 | 0.002 |
| RSD % | | | 0.17 | 1576.00 | 0.172 |

Method 5

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|-------|
| 233-1 | 0.9736 | 0.9746 | 100.10 | -0.10 | 0.999 |
| 233-2 | 1.0043 | 1.0037 | 99.94 | 0.06 | 1.001 |
| 233-3 | 0.9967 | 1.0065 | 100.97 | -0.97 | 0.990 |
| 233-4 | 1.0482 | 1.0578 | 100.91 | -0.91 | 0.991 |
| 233-5 | 0.9977 | 1.0021 | 100.44 | -0.44 | 0.996 |
| average | | | 100.47 | -0.47 | 0.995 |
| confidence limit | | | 0.58 | 0.58 | 0.006 |
| SD | | | 0.46 | 0.46 | 0.005 |
| RSD % | | | 0.46 | -98.32 | 0.466 |

Method 6

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|-------|
| 233-1 | 1.0235 | 1.0195 | 99.61 | 0.39 | 1.004 |
| 233-2 | 1.0284 | 1.0298 | 100.13 | -0.13 | 0.999 |
| 233-3 | 1.0369 | 1.0373 | 100.04 | -0.04 | 1.000 |
| 233-4 | 1.0220 | 1.0220 | 100.00 | 0.00 | 1.000 |
| 233-5 | 1.0106 | 1.0126 | 100.20 | -0.20 | 0.998 |
| average | | | 100.00 | 0.00 | 1.000 |
| confidence limit | | | 0.28 | 0.28 | 0.003 |
| SD | | | 0.23 | 0.23 | 0.002 |
| RSD % | | | 0.23 | 6314.24 | 0.231 |

Method 8

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|-------|
| 233-1 | 1.0647 | 1.0631 | 99.85 | 0.15 | 1.002 |
| 233-2 | 1.0116 | 1.0128 | 100.12 | -0.12 | 0.999 |
| 233-3 | 1.0423 | 1.0423 | 100.00 | 0.00 | 1.000 |
| 233-4 | 1.0279 | 1.0261 | 99.83 | 0.17 | 1.002 |
| 233-5 | 1.0368 | 1.0361 | 99.93 | 0.07 | 1.001 |
| average | | | 99.95 | 0.05 | 1.001 |
| confidence limit | | | 0.15 | 0.15 | 0.001 |
| SD | | | 0.12 | 0.12 | 0.001 |
| RSD % | | | 0.12 | 217.28 | 0.119 |

Method 9

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|-------|
| 233-1 | 1.0538 | 1.0544 | 100.06 | -0.06 | 0.999 |
| 233-2 | 1.0664 | 1.0641 | 99.79 | 0.21 | 1.002 |
| 233-3 | 1.0342 | 1.0339 | 99.97 | 0.03 | 1.000 |
| 233-4 | 1.0666 | 1.0672 | 100.06 | -0.06 | 0.999 |
| 233-5 | 1.0260 | 1.0230 | 99.71 | 0.29 | 1.003 |
| average | | | 99.92 | 0.08 | 1.001 |
| confidence limit | | | 0.20 | 0.20 | 0.002 |
| SD | | | 0.16 | 0.16 | 0.002 |
| RSD % | | | 0.16 | 189.57 | 0.161 |

Method 10

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|-------|
| 233-1 | 1.0246 | 1.0262 | 100.15 | -0.15 | 0.998 |
| 233-2 | 1.0005 | 1.0040 | 100.35 | -0.35 | 0.997 |
| 233-3 | 1.0095 | 1.0076 | 99.81 | 0.19 | 1.002 |
| 233-4 | 1.0055 | 1.0087 | 100.32 | -0.32 | 0.997 |
| 233-5 | 0.9974 | 0.9998 | 100.24 | -0.24 | 0.998 |
| average | | | 100.17 | -0.17 | 0.998 |
| confidence limit | | | 0.27 | 0.27 | 0.003 |
| SD | | | 0.21 | 0.21 | 0.002 |
| RSD % | | | 0.21 | -123.54 | 0.217 |

Method 11

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|--------|
| 233-1 | 1.0177 | 1.0135 | 99.59 | 0.41 | 1.004 |
| 233-2 | 1.0287 | 1.0244 | 99.59 | 0.41 | 1.004 |
| 233-3 | 1.0248 | 1.0199 | 99.53 | 0.47 | 1.005 |
| 233-4 | 1.0169 | 1.0129 | 99.61 | 0.39 | 1.004 |
| 233-5 | 1.0247 | 1.0212 | 99.66 | 0.34 | 1.003 |
| average | | | 99.60 | 0.40 | 1.004 |
| confidence limit | | | 0.06 | 0.06 | 0.001 |
| SD | | | 0.05 | 0.05 | 0.0005 |
| RSD % | | | 0.05 | 12.03 | 0.049 |

Method 14

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|-------|
| 233-1 | 1.0124 | 1.0056 | 99.33 | 0.67 | 1.007 |
| 233-2 | 1.0421 | 1.0357 | 99.39 | 0.61 | 1.006 |
| 233-3 | 1.0267 | 1.0204 | 99.39 | 0.61 | 1.006 |
| 233-4 | 1.0281 | 1.0227 | 99.48 | 0.52 | 1.005 |
| 233-5 | 1.0449 | 1.0387 | 99.41 | 0.59 | 1.006 |
| average | | | 99.40 | 0.60 | 1.006 |
| confidence limit | | | 0.06 | 0.06 | 0.001 |
| SD | | | 0.05 | 0.05 | 0.001 |
| RSD % | | | 0.05 | 8.72 | 0.053 |

Method 16

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 233-1 | 1.0752 | 0.8779 | 81.18 | 18.82 |
| 233-2 | 1.0141 | 0.8303 | 81.41 | 18.59 |
| 233-3 | 1.0056 | 0.8201 | 81.08 | 18.92 |
| 233-4 | 1.0411 | 0.8494 | 81.12 | 18.88 |
| 233-5 | 0.9986 | 0.8143 | 81.07 | 18.93 |
| average | | | 81.17 | 18.83 |
| confidence limit | | | 0.17 | 0.17 |
| SD | | | 0.14 | 0.14 |
| RSD % | | | 0.17 | 0.74 |

- Ventilated oven**

Method 1

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|-------|
| 233-1 | 0.9855 | 0.9814 | 99.59 | 0.41 | 1.004 |
| 233-2 | 1.1205 | 1.1179 | 99.77 | 0.23 | 1.002 |
| 233-3 | 1.1177 | 1.1136 | 99.64 | 0.36 | 1.004 |
| 233-4 | 1.1427 | 1.1408 | 99.84 | 0.16 | 1.002 |
| 233-5 | 1.1537 | 1.1494 | 99.63 | 0.37 | 1.004 |
| average | | | 99.69 | 0.31 | 1.003 |
| confidence limit | | | 0.13 | 0.13 | 0.001 |
| SD | | | 0.11 | 0.11 | 0.001 |
| RSD % | | | 0.11 | 34.18 | 0.107 |

Method 2

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|-------|
| 233-1 | 1.0231 | 1.0221 | 99.90 | 0.10 | 1.001 |
| 233-2 | 1.0174 | 1.0155 | 99.82 | 0.18 | 1.002 |
| 233-3 | 1.0134 | 1.0115 | 99.81 | 0.19 | 1.002 |
| 233-4 | 1.0391 | 1.0352 | 99.63 | 0.37 | 1.004 |
| average | | | 99.79 | 0.21 | 1.002 |
| confidence limit | | | 0.18 | 0.18 | 0.002 |
| SD | | | 0.12 | 0.12 | 0.001 |
| RSD % | | | 0.12 | 55.17 | 0.117 |

Method 5

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|-------|
| 233-1 | 1.0977 | 1.0982 | 100.05 | -0.05 | 1.000 |
| 233-2 | 1.0908 | 1.1096 | 101.71 | -1.71 | 0.983 |
| 233-3 | 1.0718 | 1.0790 | 100.67 | -0.67 | 0.993 |
| 233-4 | 1.0051 | 1.0166 | 101.13 | -1.13 | 0.989 |
| 233-5 | 1.1545 | 1.1603 | 100.50 | -0.50 | 0.995 |
| average | | | 100.81 | -0.81 | 0.992 |
| confidence limit | | | 0.79 | 0.79 | 0.008 |
| SD | | | 0.63 | 0.63 | 0.006 |
| RSD % | | | 0.63 | -78.42 | 0.635 |

Method 6

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|--------|
| 233-1 | 1.0407 | 1.0380 | 99.74 | 0.26 | 1.003 |
| 233-2 | 1.0684 | 1.0653 | 99.71 | 0.29 | 1.003 |
| 233-3 | 1.0750 | 1.0722 | 99.74 | 0.26 | 1.003 |
| 233-4 | 1.0235 | 1.0211 | 99.77 | 0.23 | 1.002 |
| 233-5 | 1.0329 | 1.0299 | 99.71 | 0.29 | 1.003 |
| average | | | 99.74 | 0.26 | 1.003 |
| confidence limit | | | 0.03 | 0.03 | 0.0003 |
| SD | | | 0.02 | 0.02 | 0.0002 |
| RSD % | | | 0.02 | 8.87 | 0.024 |

Method 8

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|-------|
| 233-1 | 1.0417 | 1.0417 | 100.00 | 0.00 | 1.000 |
| 233-2 | 1.0295 | 1.0301 | 100.06 | -0.06 | 0.999 |
| 233-3 | 1.0374 | 1.0372 | 99.98 | 0.02 | 1.000 |
| 233-4 | 1.0215 | 1.0195 | 99.81 | 0.19 | 1.002 |
| 233-5 | 1.0261 | 1.0247 | 99.86 | 0.14 | 1.001 |
| average | | | 99.94 | 0.06 | 1.001 |
| confidence limit | | | 0.13 | 0.13 | 0.001 |
| SD | | | 0.10 | 0.10 | 0.001 |
| RSD % | | | 0.10 | 177.86 | 0.104 |

Method 9

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|--------|
| 233-1 | 1.0489 | 1.0459 | 99.72 | 0.28 | 1.003 |
| 233-2 | 1.0331 | 1.0302 | 99.72 | 0.28 | 1.003 |
| 233-3 | 1.0461 | 1.0433 | 99.73 | 0.27 | 1.003 |
| 233-4 | 1.0602 | 1.0574 | 99.74 | 0.26 | 1.003 |
| 233-5 | 1.0460 | 1.0432 | 99.73 | 0.27 | 1.003 |
| average | | | 99.73 | 0.27 | 1.003 |
| confidence limit | | | 0.01 | 0.01 | 0.0001 |
| SD | | | 0.01 | 0.01 | 0.0001 |
| RSD % | | | 0.01 | 3.49 | 0.010 |

Method 10

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|-------|
| 233-1 | 1.0136 | 1.0126 | 99.90 | 0.10 | 1.001 |
| 233-2 | 1.0082 | 1.0066 | 99.84 | 0.16 | 1.002 |
| 233-3 | 1.0139 | 1.0117 | 99.79 | 0.21 | 1.002 |
| 233-4 | 0.9950 | 0.9925 | 99.75 | 0.25 | 1.003 |
| 233-5 | 0.9436 | 0.9455 | 100.20 | -0.20 | 0.998 |
| average | | | 99.90 | 0.10 | 1.001 |
| confidence limit | | | 0.22 | 0.22 | 0.002 |
| SD | | | 0.18 | 0.18 | 0.002 |
| RSD % | | | 0.18 | 172.40 | 0.181 |

Method 11

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|--------|
| 233-1 | 1.0353 | 1.0304 | 99.53 | 0.47 | 1.005 |
| 233-2 | 1.026 | 1.021 | 99.52 | 0.48 | 1.005 |
| 233-3 | 1.0212 | 1.0164 | 99.53 | 0.47 | 1.005 |
| 233-4 | 1.0396 | 1.0344 | 99.50 | 0.50 | 1.005 |
| 233-5 | 1.0265 | 1.0223 | 99.59 | 0.41 | 1.004 |
| average | | | 99.54 | 0.46 | 1.005 |
| confidence limit | | | 0.04 | 0.04 | 0.0004 |
| SD | | | 0.03 | 0.03 | 0.0004 |
| RSD % | | | 0.03 | 7.48 | 0.035 |

Method 14

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|-------|
| 233-1 | 1.0502 | 1.045 | 99.51 | 0.49 | 1.005 |
| 233-2 | 1.0181 | 1.0118 | 99.39 | 0.61 | 1.006 |
| 233-3 | 1.0571 | 1.0505 | 99.38 | 0.62 | 1.006 |
| 233-4 | 1.0225 | 1.0214 | 99.89 | 0.11 | 1.001 |
| 233-5 | 1.0542 | 1.0431 | 98.96 | 1.04 | 1.011 |
| average | | | 99.43 | 0.57 | 1.006 |
| confidence limit | | | 0.42 | 0.42 | 0.004 |
| SD | | | 0.33 | 0.33 | 0.003 |
| RSD % | | | 0.34 | 58.34 | 0.340 |

Method 16

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 233-1 | 0.9822 | 0.8014 | 81.12 | 18.88 |
| 233-2 | 1.0237 | 0.8352 | 81.12 | 18.88 |
| 233-3 | 1.0526 | 0.8590 | 81.14 | 18.86 |
| 233-4 | 1.0445 | 0.8522 | 81.12 | 18.88 |
| 233-5 | 1.0273 | 0.8382 | 81.12 | 18.88 |
| average | | | 81.12 | 18.88 |
| confidence limit | | | 0.01 | 0.01 |
| SD | | | 0.01 | 0.01 |
| RSD % | | | 0.01 | 0.04 |

PAC 40 % (sample 199)• **Vacuum oven****Method 4**

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 199-1 | 1.0790 | 0.7298 | 66.95 | 33.05 |
| 199-2 | 1.0825 | 0.7293 | 66.69 | 33.31 |
| 199-3 | 1.0691 | 0.7191 | 66.57 | 33.43 |
| 199-4 | 1.0637 | 0.7158 | 66.61 | 33.39 |
| 199-5 | 1.0511 | 0.7103 | 66.89 | 33.11 |
| 199-6 | 1.0244 | 0.6944 | 67.10 | 32.90 |
| 199-7 | 1.0361 | 0.7049 | 67.35 | 32.65 |
| 199-8 | 0.9972 | 0.6781 | 67.32 | 32.68 |
| 199-9 | 1.0566 | 0.7131 | 66.80 | 33.20 |
| 199-10 | 1.0779 | 0.7313 | 67.16 | 32.84 |
| 199-11 | 1.0283 | 0.6968 | 67.08 | 32.92 |
| 199-12 | 1.2898 | 0.8762 | 67.25 | 32.75 |
| 199-13 | 1.1020 | 0.7438 | 66.81 | 33.19 |
| 199-14 | 1.1711 | 0.7947 | 67.18 | 32.82 |
| average | | | 66.98 | 33.02 |
| confidence limit | | | 0.19 | 0.19 |
| SD | | | 0.26 | 0.26 |
| RSD % | | | 0.39 | 0.79 |

Method 7

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 199-1 | 1.0279 | 0.7145 | 68.85 | 31.15 |
| 199-2 | 1.0370 | 0.7144 | 68.22 | 31.78 |
| 199-3 | 1.0268 | 0.7108 | 68.56 | 31.44 |
| 199-4 | 1.0722 | 0.7369 | 68.06 | 31.94 |
| 199-5 | 1.0474 | 0.7247 | 68.52 | 31.48 |
| 199-6 | 1.0465 | 0.7287 | 68.97 | 31.03 |
| 199-7 | 1.0648 | 0.7372 | 68.57 | 31.43 |
| 199-8 | 1.0529 | 0.7305 | 68.72 | 31.28 |
| 199-9 | 1.0645 | 0.7400 | 68.85 | 31.15 |
| 199-10 | 1.0592 | 0.7311 | 68.36 | 31.64 |
| average | | | 68.57 | 31.43 |
| confidence limit | | | 0.21 | 0.21 |
| SD | | | 0.29 | 0.29 |
| RSD % | | | 0.43 | 0.93 |

Method 10

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|--------|
| 199-1 | 1.0133 | 1.0133 | 100.00 | 0.00 | 1.000 |
| 199-2 | 1.0062 | 1.0057 | 99.95 | 0.05 | 1.000 |
| 199-3 | 1.0256 | 1.0248 | 99.92 | 0.08 | 1.001 |
| 199-4 | 1.0121 | 1.0101 | 99.81 | 0.19 | 1.002 |
| 199-5 | 1.0208 | 1.0194 | 99.87 | 0.13 | 1.001 |
| 199-6 | 1.0301 | 1.0294 | 99.93 | 0.07 | 1.001 |
| 199-7 | 0.9998 | 0.9988 | 99.90 | 0.10 | 1.001 |
| 199-8 | 1.0110 | 1.0099 | 99.89 | 0.11 | 1.001 |
| 199-9 | 1.0040 | 1.0024 | 99.84 | 0.16 | 1.002 |
| 199-10 | 1.0062 | 1.0057 | 99.95 | 0.05 | 1.000 |
| average | | | 99.91 | 0.09 | 1.001 |
| confidence limit | | | 0.04 | 0.04 | 0.0004 |
| SD | | | 0.06 | 0.06 | 0.001 |
| RSD % | | | 0.06 | 61.71 | 0.059 |

Method 11

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|--------|
| 199-1 | 1.0624 | 1.0387 | 97.81 | 2.19 | 1.023 |
| 199-2 | 1.1102 | 1.0863 | 97.89 | 2.11 | 1.022 |
| 199-3 | 1.0455 | 1.0228 | 97.87 | 2.13 | 1.022 |
| 199-4 | 1.1353 | 1.1099 | 97.81 | 2.19 | 1.023 |
| 199-5 | 1.0223 | 0.9992 | 97.78 | 2.22 | 1.023 |
| 199-6 | 0.9119 | 0.8917 | 97.83 | 2.17 | 1.023 |
| 199-7 | 0.8517 | 0.8325 | 97.79 | 2.21 | 1.023 |
| 199-8 | 0.9301 | 0.9096 | 97.84 | 2.16 | 1.023 |
| 199-9 | 1.0053 | 0.984 | 97.92 | 2.08 | 1.022 |
| average | | | 97.84 | 2.16 | 1.0225 |
| confidence limit | | | 0.04 | 0.04 | 0.0004 |
| SD | | | 0.05 | 0.05 | 0.001 |
| RSD % | | | 0.05 | 2.18 | 0.049 |

Method 16

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 199-1 | 1.1414 | 0.7490 | 64.92 | 35.08 |
| 199-2 | 1.1199 | 0.7375 | 65.15 | 34.85 |
| 199-3 | 1.1946 | 0.7832 | 64.86 | 35.14 |
| 199-4 | 1.2122 | 0.7867 | 64.19 | 35.81 |
| 199-5 | 1.1229 | 0.7319 | 64.47 | 35.53 |
| 199-6 | 1.1241 | 0.7385 | 64.99 | 35.01 |
| 199-7 | 1.1334 | 0.7461 | 65.13 | 34.87 |
| 199-8 | 1.2088 | 0.7974 | 65.27 | 34.73 |
| 199-9 | 1.0901 | 0.7154 | 64.92 | 35.08 |
| 199-10 | 1.1170 | 0.7346 | 65.06 | 34.94 |
| 199-11 | 1.1259 | 0.7386 | 64.90 | 35.10 |
| 199-12 | 1.1094 | 0.7278 | 64.90 | 35.10 |
| 199-13 | 1.1338 | 0.7420 | 64.74 | 35.26 |
| 199-14 | 1.0351 | 0.6782 | 64.82 | 35.18 |
| 199-15 | 1.1628 | 0.7624 | 64.86 | 35.14 |
| 199-16 | 1.0895 | 0.7128 | 64.72 | 35.28 |
| 199-17 | 1.1087 | 0.7264 | 64.81 | 35.19 |
| 199-18 | 1.0774 | 0.7063 | 64.85 | 35.15 |
| 199-19 | 1.1229 | 0.7349 | 64.74 | 35.26 |
| 199-20 | 1.1552 | 0.7505 | 64.26 | 35.74 |
| 199-21 | 1.0829 | 0.7098 | 64.84 | 35.16 |
| 199-22 | 1.0483 | 0.6867 | 64.80 | 35.20 |
| 199-23 | 1.0191 | 0.6674 | 64.78 | 35.22 |
| 199-24 | 1.0405 | 0.6815 | 64.79 | 35.21 |
| 199-25 | 1.0162 | 0.6659 | 64.82 | 35.18 |
| average | | | 64.82 | 35.18 |
| confidence limit | | | 0.10 | 0.10 |
| SD | | | 0.24 | 0.24 |
| RSD % | | | 0.37 | 0.68 |

- Ventilated oven

Method 4

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 199-1 | 1.1143 | 0.7551 | 67.08 | 32.92 |
| 199-2 | 1.0235 | 0.6920 | 66.93 | 33.07 |
| 199-3 | 1.0126 | 0.6857 | 67.03 | 32.97 |
| 199-4 | 1.0331 | 0.6991 | 66.99 | 33.01 |
| 199-5 | 1.0453 | 0.7065 | 66.90 | 33.10 |
| 199-6 | 1.0468 | 0.7051 | 66.67 | 33.33 |
| 199-7 | 1.0102 | 0.6821 | 66.84 | 33.16 |
| 199-8 | 0.9950 | 0.6704 | 66.69 | 33.31 |
| 199-9 | 1.0236 | 0.6883 | 66.56 | 33.44 |
| 199-10 | 1.0464 | 0.7039 | 66.58 | 33.42 |
| average | | | 66.83 | 33.17 |
| confidence limit | | | 0.14 | 0.14 |
| SD | | | 0.19 | 0.19 |
| RSD % | | | 0.29 | 0.57 |

Method 7

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 199-1 | 1.0121 | 0.6939 | 67.89 | 32.11 |
| 199-2 | 1.0216 | 0.7028 | 68.12 | 31.88 |
| 199-3 | 1.0421 | 0.7202 | 68.44 | 31.56 |
| 199-4 | 1.0316 | 0.7122 | 68.37 | 31.63 |
| 199-5 | 1.0093 | 0.6952 | 68.21 | 31.79 |
| 199-6 | 1.0117 | 0.7009 | 68.61 | 31.39 |
| 199-7 | 1.0612 | 0.7367 | 68.76 | 31.24 |
| 199-8 | 1.0577 | 0.7362 | 68.94 | 31.06 |
| 199-9 | 0.9897 | 0.6888 | 68.94 | 31.06 |
| 199-10 | 0.9481 | 0.6577 | 68.71 | 31.29 |
| average | | | 68.50 | 31.50 |
| confidence limit | | | 0.25 | 0.25 |
| SD | | | 0.35 | 0.35 |
| RSD % | | | 0.52 | 1.12 |

Method 10

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|-------|
| 199-1 | 1.0764 | 1.0754 | 99.91 | 0.09 | 1.001 |
| 199-2 | 1.0577 | 1.0565 | 99.89 | 0.11 | 1.001 |
| 199-3 | 1.0591 | 1.0561 | 99.72 | 0.28 | 1.003 |
| 199-4 | 1.0345 | 1.0334 | 99.90 | 0.10 | 1.001 |
| average | | | 99.85 | 0.15 | 1.001 |
| confidence limit | | | 0.14 | 0.14 | 0.001 |
| SD | | | 0.09 | 0.09 | 0.001 |
| RSD % | | | 0.09 | 60.36 | 0.090 |

Method 11

| JRC code | sample mass | residue mass | PAC | soluble | d |
|------------------|-------------|--------------|-------|---------|-------|
| | g | g | % | % | |
| 199-1 | 1.0049 | 0.9744 | 97.02 | 2.98 | 1.031 |
| 199-2 | 1.0328 | 1.0013 | 97.01 | 2.99 | 1.031 |
| 199-3 | 1.0367 | 1.0054 | 97.04 | 2.96 | 1.031 |
| 199-4 | 1.0196 | 0.9883 | 96.99 | 3.01 | 1.032 |
| 199-5 | 1.0117 | 0.9815 | 97.07 | 2.93 | 1.031 |
| 199-6 | 0.9934 | 0.9632 | 97.02 | 2.98 | 1.031 |
| 199-7 | 0.9973 | 0.9675 | 97.07 | 2.93 | 1.031 |
| 199-8 | 1.0178 | 0.9834 | 96.68 | 3.32 | 1.035 |
| 199-9 | 1.0084 | 0.9775 | 96.99 | 3.01 | 1.032 |
| 199-10 | 1.0106 | 0.9764 | 96.68 | 3.32 | 1.035 |
| average | | | 96.96 | 3.04 | 1.032 |
| confidence limit | | | 0.11 | 0.11 | 0.001 |
| SD | | | 0.15 | 0.15 | 0.002 |
| RSD % | | | 0.15 | 4.85 | 0.156 |

Method 16

| JRC code | sample mass | residue mass | insoluble | soluble |
|------------------|-------------|--------------|-----------|---------|
| | g | g | % | % |
| 199-1 | 1.0794 | 0.7070 | 64.79 | 35.21 |
| 199-2 | 1.0589 | 0.6935 | 64.79 | 35.21 |
| 199-3 | 1.0091 | 0.6613 | 64.83 | 35.17 |
| 199-4 | 1.0220 | 0.6690 | 64.75 | 35.25 |
| 199-5 | 1.0428 | 0.6831 | 64.80 | 35.20 |
| 199-6 | 1.0067 | 0.6579 | 64.65 | 35.35 |
| 199-7 | 1.0126 | 0.6637 | 64.84 | 35.16 |
| 199-8 | 1.0584 | 0.6923 | 64.70 | 35.30 |
| 199-9 | 1.0106 | 0.6602 | 64.62 | 35.38 |
| 199-10 | 1.0541 | 0.6888 | 64.64 | 35.36 |
| average | | | 64.74 | 35.26 |
| confidence limit | | | 0.06 | 0.06 |
| SD | | | 0.08 | 0.08 |
| RSD % | | | 0.13 | 0.23 |

Solubility properties – *d* correction factors

polypropylene (samples 113, 186, 187, 192)

Method 1

| JRC code | sample mass | residue mass | PP | soluble | d |
|------------------|-------------|--------------|-------|---------|--------|
| | g | g | % | % | |
| 186-1 | 1.1102 | 1.1090 | 99.90 | 0.10 | 1.001 |
| 186-2 | 1.0691 | 1.0662 | 99.74 | 0.26 | 1.003 |
| 186-3 | 1.0303 | 1.0270 | 99.69 | 0.31 | 1.003 |
| 186-4 | 0.9821 | 0.9794 | 99.73 | 0.27 | 1.003 |
| 186-5 | 0.9299 | 0.9282 | 99.82 | 0.18 | 1.002 |
| 187-6 | 1.0078 | 1.0048 | 99.71 | 0.29 | 1.003 |
| 187-7 | 0.9851 | 0.9845 | 99.94 | 0.06 | 1.001 |
| 187-8 | 1.0045 | 1.0020 | 99.76 | 0.24 | 1.002 |
| 187-9 | 1.0004 | 0.9993 | 99.89 | 0.11 | 1.001 |
| 187-10 | 0.8950 | 0.8920 | 99.67 | 0.33 | 1.003 |
| 192-11 | 1.0453 | 1.0418 | 99.67 | 0.33 | 1.003 |
| 192-12 | 1.0399 | 1.0367 | 99.70 | 0.30 | 1.003 |
| 192-13 | 1.0798 | 1.0759 | 99.65 | 0.35 | 1.004 |
| 192-14 | 1.0669 | 1.0639 | 99.73 | 0.27 | 1.003 |
| 192-15 | 1.0155 | 1.0122 | 99.68 | 0.32 | 1.003 |
| 192-16 | 1.0519 | 1.0491 | 99.74 | 0.26 | 1.003 |
| 192-17 | 1.0335 | 1.0308 | 99.75 | 0.25 | 1.003 |
| 192-18 | 1.0395 | 1.0364 | 99.71 | 0.29 | 1.003 |
| 192-19 | 1.0387 | 1.0363 | 99.78 | 0.22 | 1.002 |
| 192-20 | 1.0174 | 1.0148 | 99.75 | 0.25 | 1.003 |
| average | | | 99.75 | 0.25 | 1.003 |
| confidence limit | | | 0.04 | 0.04 | 0.0004 |
| SD | | | 0.08 | 0.08 | 0.001 |
| RSD % | | | 0.08 | 31.90 | 0.082 |

Method 3

| JRC code | sample mass | residue mass | PP | soluble | d |
|------------------|-------------|--------------|--------|---------|--------|
| | g | g | % | % | |
| 192-1 | 1.1342 | 1.1323 | 99.84 | 0.16 | 1.002 |
| 192-2 | 1.1944 | 1.1940 | 99.97 | 0.03 | 1.000 |
| 192-3 | 1.0948 | 1.0943 | 99.96 | 0.04 | 1.000 |
| 192-4 | 1.0051 | 1.0054 | 100.03 | -0.03 | 1.000 |
| 192-5 | 1.1128 | 1.1108 | 99.83 | 0.17 | 1.002 |
| 192-6 | 1.0070 | 1.0045 | 99.76 | 0.24 | 1.002 |
| 192-7 | 0.9898 | 0.9867 | 99.70 | 0.30 | 1.003 |
| 192-8 | 0.9961 | 0.9956 | 99.95 | 0.05 | 1.001 |
| 192-9 | 1.0016 | 1.0007 | 99.91 | 0.09 | 1.001 |
| 192-10 | 0.9904 | 0.9898 | 99.94 | 0.06 | 1.001 |
| 192-11 | 1.0626 | 1.0610 | 99.85 | 0.15 | 1.002 |
| 192-12 | 1.0352 | 1.0339 | 99.88 | 0.12 | 1.001 |
| 192-13 | 1.0240 | 1.0217 | 99.78 | 0.22 | 1.002 |
| 192-14 | 1.0284 | 1.0264 | 99.81 | 0.19 | 1.002 |
| 192-15 | 1.0156 | 1.0143 | 99.88 | 0.12 | 1.001 |
| 192-16 | 1.0202 | 1.0202 | 100.00 | 0.00 | 1.000 |
| 192-17 | 1.0108 | 1.0110 | 100.02 | -0.02 | 1.000 |
| 192-18 | 1.0201 | 1.0202 | 100.01 | -0.01 | 1.000 |
| 192-19 | 1.0217 | 1.0203 | 99.87 | 0.13 | 1.001 |
| 192-20 | 1.0206 | 1.0202 | 99.96 | 0.04 | 1.000 |
| average | | | 99.90 | 0.10 | 1.001 |
| confidence limit | | | 0.04 | 0.04 | 0.0005 |
| SD | | | 0.09 | 0.09 | 0.001 |
| RSD % | | | 0.09 | 90.39 | 0.096 |

Method 5

| JRC code | sample mass g | residue mass g | PP % | soluble % | d |
|------------------|------------------|-------------------|---------|--------------|--------|
| 192-1 | 1.0812 | 1.0812 | 100.00 | 0.00 | 1.000 |
| 192-2 | 1.1810 | 1.1789 | 99.83 | 0.17 | 1.002 |
| 192-3 | 1.0343 | 1.0347 | 100.04 | -0.04 | 1.000 |
| 192-4 | 0.9650 | 0.9648 | 99.98 | 0.02 | 1.000 |
| 192-5 | 1.0002 | 0.9997 | 99.95 | 0.05 | 1.001 |
| 192-6 | 0.9717 | 0.9715 | 99.98 | 0.02 | 1.000 |
| 192-7 | 0.9829 | 0.9811 | 99.82 | 0.18 | 1.002 |
| 192-8 | 1.0049 | 1.0045 | 99.96 | 0.04 | 1.000 |
| 192-9 | 0.9911 | 0.9914 | 100.03 | -0.03 | 1.000 |
| 192-10 | 1.0146 | 1.0128 | 99.83 | 0.17 | 1.002 |
| 192-11 | 1.0227 | 1.0206 | 99.80 | 0.20 | 1.002 |
| 192-12 | 1.0175 | 1.0155 | 99.81 | 0.19 | 1.002 |
| 192-13 | 1.0216 | 1.0194 | 99.79 | 0.21 | 1.002 |
| 192-14 | 1.0262 | 1.0238 | 99.77 | 0.23 | 1.002 |
| 192-15 | 1.0154 | 1.0132 | 99.79 | 0.21 | 1.002 |
| 192-16 | 1.0187 | 1.0164 | 99.78 | 0.22 | 1.002 |
| 192-17 | 1.0362 | 1.0340 | 99.79 | 0.21 | 1.002 |
| 192-18 | 1.0474 | 1.0449 | 99.77 | 0.23 | 1.002 |
| 192-19 | 1.0375 | 1.0356 | 99.82 | 0.18 | 1.002 |
| average | | | 99.87 | 0.13 | 1.001 |
| confidence limit | | | 0.05 | 0.05 | 0.0005 |
| SD | | | 0.10 | 0.10 | 0.001 |
| RSD % | | | 0.10 | 75.76 | 0.101 |

Method 6

| JRC code | sample mass g | residue mass g | PP % | soluble % | d |
|------------------|------------------|-------------------|---------|--------------|-------|
| 186-1 | 0.9458 | 0.9417 | 99.58 | 0.42 | 1.004 |
| 186-2 | 1.1322 | 1.1291 | 99.73 | 0.27 | 1.003 |
| 186-3 | 1.2013 | 1.1974 | 99.68 | 0.32 | 1.003 |
| 186-4 | 1.1845 | 1.1799 | 99.62 | 0.38 | 1.004 |
| 186-5 | 1.0465 | 1.0424 | 99.62 | 0.38 | 1.004 |
| 187-6 | 0.9995 | 0.9968 | 99.74 | 0.26 | 1.003 |
| 187-7 | 1.0007 | 0.9980 | 99.74 | 0.26 | 1.003 |
| 187-8 | 0.9978 | 0.9943 | 99.66 | 0.34 | 1.004 |
| 187-9 | 0.9969 | 0.9926 | 99.58 | 0.42 | 1.004 |
| 187-10 | 1.0168 | 1.0140 | 99.73 | 0.27 | 1.003 |
| 192-11 | 1.0474 | 1.0458 | 99.85 | 0.15 | 1.002 |
| 192-12 | 1.0616 | 1.0595 | 99.81 | 0.19 | 1.002 |
| 192-13 | 1.0318 | 1.0318 | 100.00 | 0.00 | 1.000 |
| 192-14 | 1.0394 | 1.0393 | 99.99 | 0.01 | 1.000 |
| 192-15 | 1.0247 | 1.0238 | 99.91 | 0.09 | 1.001 |
| 192-16 | 1.0393 | 1.0391 | 99.98 | 0.02 | 1.000 |
| 192-17 | 1.0319 | 1.0304 | 99.86 | 0.14 | 1.001 |
| 192-18 | 1.0128 | 1.0113 | 99.86 | 0.14 | 1.001 |
| 192-19 | 1.0509 | 1.0491 | 99.83 | 0.17 | 1.002 |
| 192-20 | 1.0645 | 1.0630 | 99.86 | 0.14 | 1.001 |
| average | | | 99.78 | 0.22 | 1.002 |
| confidence limit | | | 0.06 | 0.06 | 0.001 |
| SD | | | 0.13 | 0.13 | 0.001 |
| RSD % | | | 0.13 | 61.55 | 0.138 |

Method 7

| JRC code | sample mass g | residue mass g | PP % | soluble % | d |
|------------------|------------------|-------------------|---------|--------------|-------|
| 192-1 | 0.5410 | 0.5404 | 99.89 | 0.11 | 1.001 |
| 192-2 | 0.9873 | 0.9855 | 99.82 | 0.18 | 1.002 |
| 192-3 | 0.7601 | 0.7598 | 99.96 | 0.04 | 1.000 |
| 192-4 | 1.0655 | 1.0634 | 99.81 | 0.19 | 1.002 |
| 192-5 | 1.1154 | 1.1142 | 99.90 | 0.10 | 1.001 |
| 192-6 | 1.0072 | 1.0051 | 99.80 | 0.20 | 1.002 |
| 192-7 | 0.9940 | 0.9932 | 99.92 | 0.08 | 1.001 |
| 192-8 | 0.9879 | 0.9856 | 99.77 | 0.23 | 1.002 |
| 192-9 | 0.9391 | 0.9377 | 99.86 | 0.14 | 1.001 |
| 192-10 | 1.0139 | 1.0140 | 100.01 | -0.01 | 1.000 |
| 192-11 | 1.0274 | 1.0324 | 100.47 | -0.47 | 0.995 |
| 192-12 | 1.0218 | 1.0268 | 100.48 | -0.48 | 0.995 |
| 192-13 | 1.0174 | 1.0223 | 100.47 | -0.47 | 0.995 |
| 192-14 | 1.0325 | 1.0359 | 100.32 | -0.32 | 0.997 |
| 192-15 | 1.0160 | 1.0202 | 100.40 | -0.40 | 0.996 |
| 192-16 | 1.0660 | 1.0702 | 100.38 | -0.38 | 0.996 |
| 192-17 | 1.0316 | 1.0424 | 101.02 | -1.02 | 0.990 |
| 192-18 | 1.0393 | 1.0502 | 101.02 | -1.02 | 0.990 |
| 192-19 | 1.0207 | 1.0235 | 100.27 | -0.27 | 0.997 |
| 192-20 | 1.0232 | 1.0268 | 100.34 | -0.34 | 0.996 |
| average | | | 100.19 | -0.19 | 0.998 |
| confidence limit | | | 0.18 | 0.18 | 0.002 |
| SD | | | 0.38 | 0.38 | 0.004 |
| RSD % | | | 0.38 | -196.31 | 0.392 |

Method 8

| JRC code | sample mass g | residue mass g | PP % | soluble % | d |
|------------------|------------------|-------------------|---------|--------------|--------|
| 192-1 | 1.2085 | 1.2078 | 99.94 | 0.06 | 1.001 |
| 192-2 | 1.2337 | 1.2335 | 99.98 | 0.02 | 1.000 |
| 192-3 | 1.0034 | 1.0013 | 99.80 | 0.20 | 1.002 |
| 192-4 | 1.1167 | 1.1167 | 100.00 | 0.00 | 1.000 |
| 192-5 | 1.2237 | 1.2202 | 99.72 | 0.28 | 1.003 |
| 192-6 | 1.0036 | 1.0034 | 99.98 | 0.02 | 1.000 |
| 192-7 | 1.0057 | 1.0054 | 99.97 | 0.03 | 1.000 |
| 192-8 | 1.0153 | 1.0149 | 99.96 | 0.04 | 1.000 |
| 192-9 | 1.0943 | 1.0938 | 99.96 | 0.04 | 1.000 |
| 192-10 | 1.0076 | 1.0063 | 99.87 | 0.13 | 1.001 |
| 192-11 | 0.9651 | 0.9642 | 99.91 | 0.09 | 1.001 |
| 192-12 | 1.0419 | 1.0399 | 99.81 | 0.19 | 1.002 |
| 192-13 | 0.9167 | 0.9161 | 99.94 | 0.06 | 1.001 |
| 192-14 | 1.0354 | 1.0343 | 99.90 | 0.10 | 1.001 |
| 192-15 | 1.0288 | 1.0275 | 99.88 | 0.12 | 1.001 |
| 192-16 | 1.0355 | 1.0350 | 99.95 | 0.05 | 1.000 |
| 192-17 | 1.0349 | 1.0339 | 99.91 | 0.09 | 1.001 |
| 192-18 | 1.0452 | 1.0441 | 99.90 | 0.10 | 1.001 |
| 192-19 | 1.0313 | 1.0308 | 99.95 | 0.05 | 1.000 |
| 192-20 | 1.0200 | 1.0201 | 100.01 | -0.01 | 1.000 |
| average | | | 99.92 | 0.08 | 1.001 |
| confidence limit | | | 0.03 | 0.03 | 0.0004 |
| SD | | | 0.07 | 0.07 | 0.001 |
| RSD % | | | 0.07 | 88.28 | 0.075 |

Method 9

| JRC code | sample mass g | residue mass g | PP % | soluble % | d |
|------------------|------------------|-------------------|---------|--------------|--------|
| 192-1 | 0.9498 | 0.9447 | 99.48 | 0.52 | 1.005 |
| 192-2 | 0.9508 | 0.9470 | 99.61 | 0.39 | 1.004 |
| 192-3 | 1.4469 | 1.4395 | 99.50 | 0.50 | 1.005 |
| 192-4 | 1.1444 | 1.1386 | 99.51 | 0.49 | 1.005 |
| 192-5 | 1.0148 | 1.0101 | 99.55 | 0.45 | 1.005 |
| 192-6 | 0.9806 | 0.9757 | 99.51 | 0.49 | 1.005 |
| 192-7 | 1.0018 | 0.9980 | 99.63 | 0.37 | 1.004 |
| 192-8 | 0.9704 | 0.9674 | 99.70 | 0.30 | 1.003 |
| 192-9 | 1.0178 | 1.0140 | 99.64 | 0.36 | 1.004 |
| 192-10 | 1.0104 | 1.0063 | 99.61 | 0.39 | 1.004 |
| 192-11 | 1.0448 | 1.0421 | 99.75 | 0.25 | 1.003 |
| 192-12 | 1.0005 | 0.9995 | 99.90 | 0.10 | 1.001 |
| 192-13 | 1.0231 | 1.0218 | 99.88 | 0.12 | 1.001 |
| 192-14 | 1.0223 | 1.0171 | 99.50 | 0.50 | 1.005 |
| 192-15 | 1.0167 | 1.0114 | 99.49 | 0.51 | 1.005 |
| 192-16 | 1.0121 | 1.0104 | 99.84 | 0.16 | 1.002 |
| 192-17 | 1.0163 | 1.0143 | 99.81 | 0.19 | 1.002 |
| 192-18 | 1.0335 | 1.0285 | 99.53 | 0.47 | 1.005 |
| 192-19 | 1.0165 | 1.0152 | 99.87 | 0.13 | 1.001 |
| 192-20 | 1.0229 | 1.0178 | 99.51 | 0.49 | 1.005 |
| average | | | 99.64 | 0.36 | 1.004 |
| confidence limit | | | 0.07 | 0.07 | 0.0007 |
| SD | | | 0.15 | 0.15 | 0.002 |
| RSD % | | | 0.15 | 41.35 | 0.153 |

Method 10

| JRC code | sample mass g | residue mass g | PP % | soluble % | d |
|------------------|------------------|-------------------|---------|--------------|-------|
| 192-1 | 0.9304 | 0.9292 | 99.87 | 0.13 | 1.001 |
| 192-2 | 1.1085 | 1.1053 | 99.72 | 0.28 | 1.003 |
| 192-3 | 0.9109 | 0.9106 | 99.97 | 0.03 | 1.000 |
| 192-4 | 1.1011 | 1.0980 | 99.73 | 0.27 | 1.003 |
| 192-5 | 1.0792 | 1.0762 | 99.73 | 0.27 | 1.003 |
| 192-6 | 0.9956 | 0.9931 | 99.76 | 0.24 | 1.003 |
| 192-7 | 0.9773 | 0.9740 | 99.67 | 0.33 | 1.003 |
| 192-8 | 1.0152 | 1.0125 | 99.74 | 0.26 | 1.003 |
| 192-9 | 0.9971 | 0.9947 | 99.77 | 0.23 | 1.002 |
| 192-10 | 0.9911 | 0.9880 | 99.70 | 0.30 | 1.003 |
| 192-11 | 1.0408 | 1.0401 | 99.93 | 0.07 | 1.001 |
| 192-12 | 1.0337 | 1.0329 | 99.92 | 0.08 | 1.001 |
| 192-13 | 1.0228 | 1.0222 | 99.94 | 0.06 | 1.001 |
| 192-14 | 1.0188 | 1.0184 | 99.96 | 0.04 | 1.000 |
| 192-15 | 1.0213 | 1.0204 | 99.91 | 0.09 | 1.001 |
| 192-16 | 1.0314 | 1.0305 | 99.92 | 0.08 | 1.001 |
| 192-17 | 1.0401 | 1.0398 | 99.97 | 0.03 | 1.000 |
| 192-18 | 1.0553 | 1.0552 | 99.99 | 0.01 | 1.000 |
| 192-19 | 1.0519 | 1.0518 | 99.99 | 0.01 | 1.000 |
| 192-20 | 1.0175 | 1.0174 | 99.99 | 0.01 | 1.000 |
| average | | | 99.86 | 0.14 | 1.001 |
| confidence limit | | | 0.05 | 0.05 | 0.001 |
| SD | | | 0.12 | 0.12 | 0.001 |
| RSD % | | | 0.12 | 83.06 | 0.120 |

Method 11

| JRC code | sample mass g | residue mass g | PP % | soluble % | d |
|------------------|------------------|-------------------|---------|--------------|-------|
| 192-1 | 1.0715 | 1.0717 | 100.02 | -0.02 | 1.000 |
| 192-2 | 0.5793 | 0.5789 | 99.93 | 0.07 | 1.001 |
| 192-3 | 1.0011 | 1.0010 | 99.99 | 0.01 | 1.000 |
| 192-4 | 1.1259 | 1.1263 | 100.03 | -0.03 | 1.000 |
| 192-5 | 1.0961 | 1.0955 | 99.95 | 0.05 | 1.001 |
| 192-6 | 1.0055 | 1.0058 | 100.03 | -0.03 | 1.000 |
| 192-7 | 1.0060 | 1.0048 | 99.88 | 0.12 | 1.001 |
| 192-8 | 1.0010 | 1.0002 | 99.92 | 0.08 | 1.001 |
| 192-9 | 1.0017 | 1.0020 | 100.03 | -0.03 | 1.000 |
| 192-10 | 0.9900 | 0.9868 | 99.69 | 0.31 | 1.003 |
| 192-11 | 1.0545 | 1.0597 | 100.48 | -0.48 | 0.995 |
| 192-12 | 1.0745 | 1.0762 | 100.15 | -0.15 | 0.998 |
| 192-13 | 1.0194 | 1.0198 | 100.04 | -0.04 | 1.000 |
| 192-14 | 1.0296 | 1.0320 | 100.23 | -0.23 | 0.998 |
| 192-15 | 1.0171 | 1.0134 | 99.65 | 0.35 | 1.004 |
| 192-16 | 1.0184 | 1.0200 | 100.15 | -0.15 | 0.998 |
| 192-17 | 1.0226 | 1.0192 | 99.68 | 0.32 | 1.003 |
| 192-18 | 1.0393 | 1.0410 | 100.16 | -0.16 | 0.998 |
| 192-19 | 1.0107 | 1.0127 | 100.19 | -0.19 | 0.998 |
| 192-20 | 1.0112 | 1.0117 | 100.05 | -0.05 | 1.000 |
| average | | | 100.01 | -0.01 | 1.000 |
| confidence limit | | | 0.09 | 0.09 | 0.001 |
| SD | | | 0.20 | 0.20 | 0.002 |
| RSD % | | | 0.20 | -1615.43 | 0.204 |

Method 14

| JRC code | sample mass g | residue mass g | PP % | soluble % | d |
|------------------|------------------|-------------------|---------|--------------|-------|
| 192-1 | 0.5685 | 0.5683 | 99.97 | 0.03 | 1.000 |
| 192-2 | 0.7926 | 0.7926 | 100.00 | 0.00 | 1.000 |
| 192-3 | 0.8798 | 0.8784 | 99.85 | 0.15 | 1.002 |
| 192-4 | 0.9709 | 0.9701 | 99.92 | 0.08 | 1.001 |
| 192-5 | 0.6646 | 0.6633 | 99.81 | 0.19 | 1.002 |
| 192-6 | 0.9940 | 0.9940 | 100.00 | 0.00 | 1.000 |
| 192-7 | 1.0270 | 1.0262 | 99.92 | 0.08 | 1.001 |
| 192-8 | 0.9357 | 0.9339 | 99.81 | 0.19 | 1.002 |
| 192-9 | 1.0070 | 1.0041 | 99.72 | 0.28 | 1.003 |
| 192-10 | 1.0086 | 1.0070 | 99.85 | 0.15 | 1.002 |
| 192-11 | 1.0237 | 1.0290 | 100.50 | -0.50 | 0.995 |
| 192-12 | 1.0444 | 1.0435 | 99.92 | 0.08 | 1.001 |
| 192-13 | 1.0367 | 1.0378 | 100.10 | -0.10 | 0.999 |
| 192-14 | 1.0210 | 1.0209 | 99.99 | 0.01 | 1.000 |
| 192-15 | 1.0152 | 1.0209 | 100.55 | -0.55 | 0.994 |
| 192-16 | 1.0223 | 1.0210 | 99.88 | 0.12 | 1.001 |
| 192-17 | 1.0119 | 1.0112 | 99.93 | 0.07 | 1.001 |
| 192-18 | 1.0121 | 1.0166 | 100.43 | -0.43 | 0.996 |
| average | | | 100.01 | -0.01 | 1.000 |
| confidence limit | | | 0.12 | 0.12 | 0.001 |
| SD | | | 0.24 | 0.24 | 0.002 |
| RSD % | | | 0.24 | -3008.91 | 0.247 |

Method 15

| JRC code | sample mass g | residue mass g | soluble % | PP % |
|------------------|------------------|-------------------|--------------|---------|
| 113-1 | 0.2238 | 0.0001 | 0.04 | 99.96 |
| 113-2 | 0.5726 | -0.0006 | -0.10 | 100.10 |
| 113-3 | 0.3984 | 0.0001 | 0.02 | 99.98 |
| 113-4 | 0.3729 | -0.0001 | -0.03 | 100.03 |
| 113-5 | 0.3674 | 0.0001 | 0.03 | 99.97 |
| 113-6 | 0.4007 | 0.0002 | 0.05 | 99.95 |
| 113-7 | 0.3701 | -0.0001 | -0.03 | 100.03 |
| 113-8 | 0.4483 | 0.0001 | 0.02 | 99.98 |
| 113-9 | 0.5311 | 0.0001 | 0.02 | 99.98 |
| 113-10 | 0.4600 | 0.0001 | 0.02 | 99.98 |
| average | | | 0.005 | 100.00 |
| confidence limit | | | 0.03 | 0.03 |
| SD | | | 0.05 | 0.05 |
| RSD % | | | 906.12 | 0.05 |

Method 16

| JRC code | sample mass g | residue mass g | PP % | soluble % | d |
|------------------|------------------|-------------------|---------|--------------|--------|
| 192-1 | 1.1827 | 1.1805 | 99.82 | 0.18 | 1.002 |
| 192-2 | 0.9492 | 0.9474 | 99.82 | 0.18 | 1.002 |
| 192-3 | 1.2121 | 1.2091 | 99.76 | 0.24 | 1.002 |
| 192-4 | 1.0966 | 1.0948 | 99.84 | 0.16 | 1.002 |
| 192-5 | 1.0006 | 0.9967 | 99.62 | 0.38 | 1.004 |
| 192-6 | 1.0300 | 1.0256 | 99.59 | 0.41 | 1.004 |
| 192-7 | 1.0236 | 1.0209 | 99.74 | 0.26 | 1.003 |
| 192-8 | 0.9808 | 0.9768 | 99.60 | 0.40 | 1.004 |
| 192-9 | 0.8770 | 0.8750 | 99.78 | 0.22 | 1.002 |
| 192-10 | 1.0349 | 1.0335 | 99.87 | 0.13 | 1.001 |
| 192-11 | 1.0480 | 1.0459 | 99.81 | 0.19 | 1.002 |
| 192-12 | 1.0377 | 1.0356 | 99.80 | 0.20 | 1.002 |
| 192-13 | 1.0240 | 1.0219 | 99.80 | 0.20 | 1.002 |
| 192-14 | 1.0299 | 1.0277 | 99.79 | 0.21 | 1.002 |
| 192-15 | 1.0130 | 1.0110 | 99.81 | 0.19 | 1.002 |
| 192-16 | 1.0480 | 1.0459 | 99.81 | 0.19 | 1.002 |
| 192-17 | 1.0377 | 1.0356 | 99.80 | 0.20 | 1.002 |
| 192-18 | 1.0240 | 1.0219 | 99.80 | 0.20 | 1.002 |
| 192-19 | 1.0299 | 1.0277 | 99.79 | 0.21 | 1.002 |
| 192-20 | 1.0130 | 1.0110 | 99.81 | 0.19 | 1.002 |
| average | | | 99.77 | 0.23 | 1.002 |
| confidence limit | | | 0.04 | 0.04 | 0.0004 |
| SD | | | 0.08 | 0.08 | 0.001 |
| RSD % | | | 0.08 | 34.16 | 0.080 |

polyamide 6 (sample 193)**Method 3**

| JRC code | sample mass g | residue mass g | insoluble % | PA6 % |
|------------------|------------------|-------------------|----------------|----------|
| 193-1 | 0.9703 | 0.0017 | 0.17 | 99.83 |
| 193-2 | 0.9893 | 0.0023 | 0.22 | 99.78 |
| 193-3 | 1.1739 | 0.0012 | 0.10 | 99.90 |
| 193-4 | 1.0699 | 0.0008 | 0.07 | 99.93 |
| 193-5 | 0.9709 | 0.0016 | 0.16 | 99.84 |
| 193-6 | 0.9620 | 0.0018 | 0.18 | 99.82 |
| 193-7 | 1.0019 | 0.0009 | 0.08 | 99.92 |
| 193-8 | 1.0050 | 0.0008 | 0.08 | 99.92 |
| 193-9 | 1.0009 | 0.0011 | 0.10 | 99.90 |
| 193-10 | 1.0106 | 0.0007 | 0.07 | 99.93 |
| average | | | 0.12 | 99.88 |
| confidence limit | | | 0.04 | 0.04 |
| SD | | | 0.05 | 0.05 |
| RSD % | | | 44.22 | 0.05 |

Method 5

| JRC code | sample mass g | residue mass g | PA6 % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|-------|
| 193-1 | 1.0711 | 1.0688 | 99.80 | 0.20 | 1.002 |
| 193-2 | 1.0147 | 1.0103 | 99.59 | 0.41 | 1.004 |
| 193-3 | 1.0359 | 1.0350 | 99.92 | 0.08 | 1.001 |
| 193-4 | 0.9992 | 0.9970 | 99.79 | 0.21 | 1.002 |
| 193-5 | 1.1574 | 1.1542 | 99.74 | 0.26 | 1.003 |
| 193-6 | 1.0069 | 1.0057 | 99.89 | 0.11 | 1.001 |
| 193-7 | 0.9622 | 0.9589 | 99.68 | 0.32 | 1.003 |
| 193-8 | 1.0011 | 0.9988 | 99.78 | 0.22 | 1.002 |
| 193-9 | 1.0706 | 1.0673 | 99.71 | 0.29 | 1.003 |
| 193-10 | 0.9115 | 0.9086 | 99.70 | 0.30 | 1.003 |
| average | | | 99.76 | 0.24 | 1.003 |
| confidence limit | | | 0.07 | 0.07 | 0.001 |
| SD | | | 0.10 | 0.10 | 0.001 |
| RSD % | | | 0.10 | 40.74 | 0.104 |

Method 7

| JRC code | sample mass g | residue mass g | insoluble % | PA6 % |
|------------------|------------------|-------------------|----------------|----------|
| 193-1 | 0.9684 | 0.0026 | 0.25 | 99.75 |
| 193-2 | 0.7825 | 0.0009 | 0.11 | 99.89 |
| 193-3 | 1.1117 | 0.0013 | 0.11 | 99.89 |
| 193-4 | 0.8248 | 0.0017 | 0.19 | 99.81 |
| 193-5 | 1.0367 | 0.0010 | 0.09 | 99.91 |
| 193-6 | 0.9920 | 0.0009 | 0.09 | 99.91 |
| 193-7 | 1.0065 | 0.0014 | 0.13 | 99.87 |
| 193-8 | 1.0060 | 0.0012 | 0.11 | 99.89 |
| 193-9 | 0.9866 | 0.0010 | 0.10 | 99.90 |
| 193-10 | 0.9903 | 0.0013 | 0.12 | 99.88 |
| average | | | 0.13 | 99.87 |
| confidence limit | | | 0.04 | 0.04 |
| SD | | | 0.05 | 0.05 |
| RSD % | | | 40.52 | 0.05 |

Method 10

| JRC code | sample mass g | residue mass g | PA6 % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|-------|
| 193-1 | 0.9757 | 0.9632 | 98.79 | 1.21 | 1.013 |
| 193-2 | 1.0649 | 1.0522 | 98.87 | 1.13 | 1.012 |
| 193-3 | 0.9479 | 0.9368 | 98.89 | 1.11 | 1.012 |
| 193-4 | 0.9608 | 0.9496 | 98.90 | 1.10 | 1.012 |
| 193-5 | 0.8802 | 0.8710 | 99.01 | 0.99 | 1.011 |
| 193-6 | 1.0008 | 0.9888 | 98.87 | 1.13 | 1.012 |
| 193-7 | 0.9908 | 0.9793 | 98.90 | 1.10 | 1.012 |
| 193-8 | 1.0089 | 0.9976 | 98.94 | 1.06 | 1.011 |
| 193-9 | 0.9989 | 0.9870 | 98.87 | 1.13 | 1.012 |
| 193-10 | 0.9906 | 0.9810 | 99.08 | 0.92 | 1.010 |
| average | | | 98.91 | 1.09 | 1.012 |
| confidence limit | | | 0.06 | 0.06 | 0.001 |
| SD | | | 0.08 | 0.08 | 0.001 |
| RSD % | | | 0.08 | 7.59 | 0.088 |

Method 11

| JRC code | sample mass g | residue mass g | insoluble % | PA6 % |
|------------------|------------------|-------------------|----------------|----------|
| 193-1 | 1.0356 | 0.0012 | 0.11 | 99.89 |
| 193-2 | 1.0509 | 0.0011 | 0.10 | 99.90 |
| 193-3 | 1.0631 | 0.0012 | 0.11 | 99.89 |
| 193-4 | 1.0013 | 0.0014 | 0.13 | 99.87 |
| 193-5 | 0.9568 | 0.0015 | 0.15 | 99.85 |
| 193-6 | 0.9591 | 0.0010 | 0.10 | 99.90 |
| 193-7 | 0.9894 | 0.0015 | 0.14 | 99.86 |
| 193-8 | 1.0009 | 0.0016 | 0.15 | 99.85 |
| 193-9 | 0.9960 | 0.0013 | 0.12 | 99.88 |
| 193-10 | 1.0090 | 0.0012 | 0.11 | 99.89 |
| average | | | 0.12 | 99.88 |
| confidence limit | | | 0.01 | 0.01 |
| SD | | | 0.02 | 0.02 |
| RSD % | | | 16.46 | 0.02 |

Method 16

| JRC code | sample mass g | residue mass g | insoluble % | PA6 % |
|------------------|------------------|-------------------|----------------|----------|
| 193-1 | 1.0523 | 0.0010 | 0.09 | 99.91 |
| 193-2 | 0.8789 | 0.0005 | 0.05 | 99.95 |
| 193-3 | 0.9547 | 0.0002 | 0.02 | 99.98 |
| 193-4 | 1.0452 | 0.0010 | 0.09 | 99.91 |
| 193-5 | 1.1815 | 0.0010 | 0.08 | 99.92 |
| 193-6 | 1.0080 | 0.0011 | 0.10 | 99.90 |
| 193-7 | 0.9960 | 0.0006 | 0.06 | 99.94 |
| 193-8 | 1.0002 | 0.0006 | 0.06 | 99.94 |
| 193-9 | 0.9921 | 0.0007 | 0.07 | 99.93 |
| 193-10 | 1.0987 | 0.0012 | 0.10 | 99.90 |
| average | | | 0.07 | 99.93 |
| confidence limit | | | 0.02 | 0.02 |
| SD | | | 0.03 | 0.03 |
| RSD % | | | 36.47 | 0.03 |

PAC 5 % (sample 195)

- Vacuum oven

Method 11

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|--------|
| 195-1 | 1.0029 | 1.0020 | 99.91 | 0.09 | 1.001 |
| 195-2 | 1.0256 | 1.0245 | 99.89 | 0.11 | 1.001 |
| 195-3 | 1.0047 | 1.0037 | 99.90 | 0.10 | 1.001 |
| 195-4 | 1.0480 | 1.0467 | 99.88 | 0.12 | 1.001 |
| 195-5 | 1.0173 | 1.0160 | 99.87 | 0.13 | 1.001 |
| 195-6 | 1.0233 | 1.0219 | 99.86 | 0.14 | 1.001 |
| 195-7 | 1.0821 | 1.0803 | 99.84 | 0.16 | 1.002 |
| 195-8 | 1.0189 | 1.0174 | 99.85 | 0.15 | 1.001 |
| 195-9 | 1.0268 | 1.0252 | 99.85 | 0.15 | 1.002 |
| 195-10 | 1.0218 | 1.0196 | 99.79 | 0.21 | 1.002 |
| average | | | 99.86 | 0.14 | 1.001 |
| confidence limit | | | 0.03 | 0.03 | 0.0003 |
| SD | | | 0.04 | 0.04 | 0.0004 |
| RSD % | | | 0.04 | 26.91 | 0.037 |

- Ventilated oven

Method 11

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|-------|
| 195-1 | 1.0195 | 1.0200 | 100.05 | -0.05 | 1.000 |
| 195-2 | 1.0330 | 1.0236 | 99.10 | 0.90 | 1.009 |
| 195-3 | 1.0273 | 1.0305 | 100.31 | -0.31 | 0.997 |
| 195-4 | 1.0350 | 1.0258 | 99.12 | 0.88 | 1.009 |
| 195-5 | 1.0270 | 1.0301 | 100.30 | -0.30 | 0.997 |
| 195-6 | 1.0229 | 1.0273 | 100.43 | -0.43 | 0.996 |
| 195-7 | 1.0161 | 1.0210 | 100.48 | -0.48 | 0.995 |
| 195-8 | 1.0267 | 1.0280 | 100.13 | -0.13 | 0.999 |
| 195-9 | 1.0326 | 1.0325 | 99.99 | 0.01 | 1.000 |
| 195-10 | 1.0447 | 1.0403 | 99.58 | 0.42 | 1.004 |
| average | | | 99.95 | 0.05 | 1.001 |
| confidence limit | | | 0.37 | 0.37 | 0.004 |
| SD | | | 0.51 | 0.51 | 0.005 |
| RSD % | | | 0.51 | 975.38 | 0.518 |

PAC 10 % (sample 196)

- Vacuum oven

Method 11

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|-------|
| 196-1 | 1.0083 | 1.0060 | 99.77 | 0.23 | 1.002 |
| 196-2 | 0.9985 | 0.9957 | 99.72 | 0.28 | 1.003 |
| 196-3 | 1.0367 | 1.0309 | 99.45 | 0.55 | 1.006 |
| 196-4 | 1.0233 | 1.0206 | 99.74 | 0.26 | 1.003 |
| 196-5 | 1.0632 | 1.0563 | 99.36 | 0.64 | 1.007 |
| 196-6 | 1.0408 | 1.0345 | 99.40 | 0.60 | 1.006 |
| 196-7 | 1.0649 | 1.0621 | 99.74 | 0.26 | 1.003 |
| 196-8 | 0.9993 | 0.9946 | 99.53 | 0.47 | 1.005 |
| 196-9 | 1.0355 | 1.0332 | 99.78 | 0.22 | 1.002 |
| 196-10 | 1.0222 | 1.0199 | 99.78 | 0.22 | 1.002 |
| average | | | 99.63 | 0.37 | 1.004 |
| confidence limit | | | 0.12 | 0.12 | 0.001 |
| SD | | | 0.17 | 0.17 | 0.002 |
| RSD % | | | 0.17 | 46.20 | 0.175 |

- Ventilated oven

Method 11

| JRC code | sample mass | residue mass | PAC | soluble | d |
|------------------|-------------|--------------|--------|---------|-------|
| | g | g | % | % | |
| 196-1 | 1.0522 | 1.0602 | 100.75 | -0.75 | 0.992 |
| 196-2 | 1.0159 | 1.0134 | 99.76 | 0.24 | 1.002 |
| 196-3 | 1.0333 | 1.0275 | 99.44 | 0.56 | 1.006 |
| 196-4 | 1.0282 | 1.0373 | 100.88 | -0.88 | 0.991 |
| 196-5 | 1.0218 | 1.0305 | 100.84 | -0.84 | 0.992 |
| 196-6 | 1.0233 | 1.0267 | 100.33 | -0.33 | 0.997 |
| 196-7 | 1.0026 | 1.0046 | 100.20 | -0.20 | 0.998 |
| 196-8 | 1.0125 | 1.0174 | 100.48 | -0.48 | 0.995 |
| 196-9 | 1.0294 | 1.0321 | 100.26 | -0.26 | 0.997 |
| 196-10 | 1.0407 | 1.0452 | 100.43 | -0.43 | 0.996 |
| average | | | 100.34 | -0.34 | 0.997 |
| confidence limit | | | 0.33 | 0.33 | 0.003 |
| SD | | | 0.46 | 0.46 | 0.005 |
| RSD % | | | 0.46 | -136.79 | 0.465 |

PAC 20 % (sample 197)

- Vacuum oven

Method 11

| JRC code | sample mass | residue mass | PAC | soluble | d |
|------------------|-------------|--------------|-------|---------|-------|
| | g | g | % | % | |
| 197-1 | 1.0188 | 1.0165 | 99.78 | 0.22 | 1.002 |
| 197-2 | 1.0253 | 1.0212 | 99.60 | 0.40 | 1.004 |
| 197-3 | 1.0192 | 1.0127 | 99.37 | 0.63 | 1.006 |
| 197-4 | 1.0232 | 1.0184 | 99.54 | 0.46 | 1.005 |
| 197-5 | 1.0278 | 1.0190 | 99.15 | 0.85 | 1.009 |
| 197-6 | 1.0357 | 1.0317 | 99.62 | 0.38 | 1.004 |
| 197-7 | 1.0362 | 1.0284 | 99.25 | 0.75 | 1.008 |
| 197-8 | 1.0039 | 0.9975 | 99.37 | 0.63 | 1.006 |
| 197-9 | 1.0224 | 1.0180 | 99.57 | 0.43 | 1.004 |
| 197-10 | 1.0221 | 1.0174 | 99.54 | 0.46 | 1.005 |
| average | | | 99.48 | 0.52 | 1.005 |
| confidence limit | | | 0.14 | 0.14 | 0.001 |
| SD | | | 0.19 | 0.19 | 0.002 |
| RSD % | | | 0.19 | 36.31 | 0.192 |

- Ventilated oven

Method 11

| JRC code | sample mass | residue mass | PAC | soluble | d |
|------------------|-------------|--------------|-------|---------|--------|
| | g | g | % | % | |
| 197-1 | 1.2283 | 1.2223 | 99.52 | 0.48 | 1.005 |
| 197-2 | 1.1943 | 1.1878 | 99.46 | 0.54 | 1.005 |
| 197-3 | 1.2165 | 1.2111 | 99.56 | 0.44 | 1.004 |
| 197-4 | 1.2368 | 1.2308 | 99.52 | 0.48 | 1.005 |
| 197-5 | 1.2010 | 1.1955 | 99.55 | 0.45 | 1.005 |
| 197-6 | 1.1912 | 1.1856 | 99.53 | 0.47 | 1.005 |
| 197-7 | 1.1829 | 1.1775 | 99.55 | 0.45 | 1.005 |
| 197-8 | 1.1951 | 1.1896 | 99.54 | 0.46 | 1.005 |
| 197-9 | 1.2018 | 1.1956 | 99.49 | 0.51 | 1.005 |
| average | | | 99.52 | 0.48 | 1.005 |
| confidence limit | | | 0.02 | 0.02 | 0.0003 |
| SD | | | 0.03 | 0.03 | 0.0003 |
| RSD % | | | 0.03 | 6.73 | 0.032 |

PAC 30 % (sample 198)

- Vacuum oven

Method 11

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|--------|
| 198-1 | 1.0656 | 1.0541 | 98.93 | 1.07 | 1.011 |
| 198-2 | 1.0338 | 1.0229 | 98.96 | 1.04 | 1.011 |
| 198-3 | 0.9473 | 0.9387 | 99.10 | 0.90 | 1.009 |
| 198-4 | 1.0412 | 1.0310 | 99.03 | 0.97 | 1.010 |
| 198-5 | 1.2329 | 1.2202 | 98.98 | 1.02 | 1.010 |
| 198-6 | 1.0445 | 1.0351 | 99.11 | 0.89 | 1.009 |
| 198-7 | 0.9791 | 0.9695 | 99.03 | 0.97 | 1.010 |
| 198-8 | 0.9464 | 0.9379 | 99.11 | 0.89 | 1.009 |
| 198-9 | 0.9575 | 0.9478 | 99.00 | 1.00 | 1.010 |
| 198-10 | 0.9565 | 0.9478 | 99.10 | 0.90 | 1.009 |
| average | | | 99.03 | 0.97 | 1.010 |
| confidence limit | | | 0.05 | 0.05 | 0.0005 |
| SD | | | 0.07 | 0.07 | 0.001 |
| RSD % | | | 0.07 | 7.01 | 0.069 |

- Ventilated oven

Method 11

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|-------|
| 198-1 | 1.0258 | 1.0182 | 99.27 | 0.73 | 1.007 |
| 198-2 | 1.0090 | 1.0002 | 99.14 | 0.86 | 1.009 |
| 198-3 | 1.0166 | 1.0088 | 99.24 | 0.76 | 1.008 |
| 198-4 | 1.0257 | 1.0179 | 99.25 | 0.75 | 1.008 |
| 198-5 | 1.0416 | 1.0320 | 99.09 | 0.91 | 1.009 |
| 198-6 | 1.0311 | 1.0248 | 99.40 | 0.60 | 1.006 |
| 198-7 | 1.0337 | 1.0274 | 99.40 | 0.60 | 1.006 |
| 198-8 | 1.0397 | 1.0327 | 99.33 | 0.67 | 1.007 |
| 198-9 | 1.0165 | 1.0080 | 99.17 | 0.83 | 1.008 |
| 198-10 | 1.0107 | 1.0050 | 99.44 | 0.56 | 1.006 |
| average | | | 99.27 | 0.73 | 1.007 |
| confidence limit | | | 0.09 | 0.09 | 0.001 |
| SD | | | 0.12 | 0.12 | 0.001 |
| RSD % | | | 0.12 | 16.33 | 0.121 |

PAC 40 % (sample 199)

- Vacuum oven

Method 1

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|-------|
| 199-1 | 0.9697 | 0.9655 | 99.57 | 0.43 | 1.004 |
| 199-2 | 0.8080 | 0.8042 | 99.53 | 0.47 | 1.005 |
| 199-3 | 0.9684 | 0.9644 | 99.59 | 0.41 | 1.004 |
| 199-4 | 1.0545 | 1.0492 | 99.50 | 0.50 | 1.005 |
| 199-5 | 0.8873 | 0.8834 | 99.56 | 0.44 | 1.004 |
| 199-6 | 1.0198 | 1.0120 | 99.24 | 0.76 | 1.008 |
| 199-7 | 1.0593 | 1.0560 | 99.69 | 0.31 | 1.003 |
| 199-8 | 1.0056 | 1.0020 | 99.65 | 0.35 | 1.004 |
| 199-9 | 1.0741 | 1.0673 | 99.37 | 0.63 | 1.006 |
| 199-10 | 1.1646 | 1.1611 | 99.70 | 0.30 | 1.003 |
| average | | | 99.54 | 0.46 | 1.005 |
| confidence limit | | | 0.10 | 0.10 | 0.001 |
| SD | | | 0.14 | 0.14 | 0.001 |
| RSD % | | | 0.14 | 31.07 | 0.145 |

Method 2

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|-------|
| 199-1 | 1.0473 | 1.0484 | 100.10 | -0.10 | 0.999 |
| 199-2 | 1.0392 | 1.0402 | 100.10 | -0.10 | 0.999 |
| 199-3 | 1.0342 | 1.0354 | 100.11 | -0.11 | 0.999 |
| 199-4 | 1.0297 | 1.0286 | 99.89 | 0.11 | 1.001 |
| 199-5 | 1.0519 | 1.0535 | 100.15 | -0.15 | 0.998 |
| 199-6 | 1.0721 | 1.0722 | 100.01 | -0.01 | 1.000 |
| 199-7 | 1.06 | 1.0626 | 100.24 | -0.24 | 0.998 |
| 199-8 | 1.0427 | 1.0426 | 99.99 | 0.01 | 1.000 |
| 199-9 | 1.0174 | 1.0184 | 100.10 | -0.10 | 0.999 |
| 199-10 | 1.0227 | 1.0229 | 100.02 | -0.02 | 1.000 |
| average | | | 100.07 | -0.07 | 0.999 |
| confidence limit | | | 0.07 | 0.07 | 0.001 |
| SD | | | 0.10 | 0.10 | 0.001 |
| RSD % | | | 0.10 | -134.80 | 0.098 |

Method 3

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 199-1 | 1.0307 | 0.6890 | 66.16 | 33.84 |
| 199-2 | 1.0524 | 0.7015 | 65.96 | 34.04 |
| 199-3 | 1.0302 | 0.6886 | 66.15 | 33.85 |
| 199-4 | 1.0196 | 0.6760 | 65.60 | 34.40 |
| 199-5 | 1.0363 | 0.6896 | 65.85 | 34.15 |
| 199-6 | 1.0457 | 0.7011 | 66.36 | 33.64 |
| 199-7 | 1.0451 | 0.6932 | 65.63 | 34.37 |
| 199-8 | 1.0245 | 0.6833 | 66.00 | 34.00 |
| 199-9 | 1.0501 | 0.6891 | 64.92 | 35.08 |
| average | | | 65.85 | 34.15 |
| confidence limit | | | 0.33 | 0.33 |
| SD | | | 0.43 | 0.43 |
| RSD % | | | 0.65 | 1.25 |

Method 4

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 199-1 | 1.079 | 0.7298 | 66.95 | 33.05 |
| 199-2 | 1.0825 | 0.7293 | 66.69 | 33.31 |
| 199-3 | 1.0691 | 0.7191 | 66.57 | 33.43 |
| 199-4 | 1.0637 | 0.7158 | 66.61 | 33.39 |
| 199-5 | 1.0511 | 0.7103 | 66.89 | 33.11 |
| 199-6 | 1.0244 | 0.6944 | 67.10 | 32.90 |
| 199-7 | 1.0361 | 0.7049 | 67.35 | 32.65 |
| 199-8 | 0.9972 | 0.6781 | 67.32 | 32.68 |
| 199-9 | 1.0566 | 0.7131 | 66.80 | 33.20 |
| 199-10 | 1.0779 | 0.7313 | 67.16 | 32.84 |
| 199-11 | 1.0283 | 0.6968 | 67.08 | 32.92 |
| 199-12 | 1.2898 | 0.8762 | 67.25 | 32.75 |
| 199-13 | 1.102 | 0.7438 | 66.81 | 33.19 |
| 199-14 | 1.1711 | 0.7947 | 67.18 | 32.82 |
| average | | | 66.98 | 33.02 |
| confidence limit | | | 0.15 | 0.15 |
| SD | | | 0.26 | 0.26 |
| RSD % | | | 0.39 | 0.79 |

Method 5

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|--------|
| 199-1 | 1.0529 | 1.0541 | 100.11 | -0.11 | 0.999 |
| 199-2 | 1.0129 | 1.0134 | 100.05 | -0.05 | 1.000 |
| 199-3 | 1.0310 | 1.0317 | 100.07 | -0.07 | 0.999 |
| 199-4 | 1.0250 | 1.0250 | 100.00 | 0.00 | 1.000 |
| 199-5 | 1.0409 | 1.0410 | 100.01 | -0.01 | 1.000 |
| 199-6 | 1.0373 | 1.0377 | 100.04 | -0.04 | 1.000 |
| 199-7 | 1.0829 | 1.0827 | 99.98 | 0.02 | 1.000 |
| 199-8 | 1.0499 | 1.0494 | 99.95 | 0.05 | 1.000 |
| 199-9 | 1.0154 | 1.0152 | 99.98 | 0.02 | 1.000 |
| 199-10 | 1.0571 | 1.0574 | 100.03 | -0.03 | 1.000 |
| average | | | 100.02 | -0.02 | 1.000 |
| confidence limit | | | 0.03 | 0.03 | 0.0003 |
| SD | | | 0.05 | 0.05 | 0.0005 |
| RSD % | | | 0.05 | -214.94 | 0.048 |

Method 6

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|--------|
| 199-1 | 1.0304 | 1.0261 | 99.59 | 0.41 | 1.004 |
| 199-2 | 1.0239 | 1.0202 | 99.64 | 0.36 | 1.004 |
| 199-3 | 1.0381 | 1.0345 | 99.66 | 0.34 | 1.003 |
| 199-4 | 1.0216 | 1.0178 | 99.63 | 0.37 | 1.004 |
| 199-5 | 1.0367 | 1.0323 | 99.58 | 0.42 | 1.004 |
| 199-6 | 1.0227 | 1.0198 | 99.72 | 0.28 | 1.003 |
| 199-7 | 1.0197 | 1.0164 | 99.68 | 0.32 | 1.003 |
| 199-8 | 1.0325 | 1.0283 | 99.60 | 0.40 | 1.004 |
| 199-9 | 1.0506 | 1.0483 | 99.78 | 0.22 | 1.002 |
| 199-10 | 1.0245 | 1.0202 | 99.58 | 0.42 | 1.004 |
| average | | | 99.65 | 0.35 | 1.004 |
| confidence limit | | | 0.05 | 0.05 | 0.0005 |
| SD | | | 0.07 | 0.07 | 0.001 |
| RSD % | | | 0.07 | 18.77 | 0.067 |

Method 7

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 199-1 | 1.0279 | 0.7145 | 68.85 | 31.15 |
| 199-2 | 1.037 | 0.7144 | 68.22 | 31.78 |
| 199-3 | 1.0268 | 0.7108 | 68.56 | 31.44 |
| 199-4 | 1.0722 | 0.7369 | 68.06 | 31.94 |
| 199-5 | 1.0474 | 0.7247 | 68.52 | 31.48 |
| 199-6 | 1.0465 | 0.7287 | 68.97 | 31.03 |
| 199-7 | 1.0648 | 0.7372 | 68.57 | 31.43 |
| 199-8 | 1.0529 | 0.7305 | 68.72 | 31.28 |
| 199-9 | 1.0645 | 0.74 | 68.85 | 31.15 |
| 199-10 | 1.0592 | 0.7311 | 68.36 | 31.64 |
| average | | | 68.57 | 31.43 |
| confidence limit | | | 0.21 | 0.21 |
| SD | | | 0.29 | 0.29 |
| RSD % | | | 0.43 | 0.93 |

Method 8

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|-------|
| 199-1 | 1.0526 | 1.0456 | 99.34 | 0.66 | 1.007 |
| 199-2 | 1.0409 | 1.0581 | 101.64 | -1.64 | 0.984 |
| 199-3 | 1.033 | 1.0447 | 101.12 | -1.12 | 0.989 |
| 199-4 | 1.0536 | 1.0453 | 99.22 | 0.78 | 1.008 |
| 199-5 | 1.0417 | 1.0361 | 99.47 | 0.53 | 1.005 |
| 199-6 | 1.0667 | 1.0718 | 100.47 | -0.47 | 0.995 |
| 199-7 | 1.0234 | 1.0221 | 99.87 | 0.13 | 1.001 |
| 199-8 | 1.0284 | 1.0528 | 102.35 | -2.35 | 0.977 |
| 199-9 | 1.058 | 1.0232 | 96.74 | 3.26 | 1.034 |
| 199-10 | 1.0269 | 1.0093 | 98.30 | 1.70 | 1.017 |
| 199-11 | 1.1764 | 1.1719 | 99.62 | 0.38 | 1.004 |
| 199-12 | 1.1494 | 1.1439 | 99.53 | 0.47 | 1.005 |
| 199-13 | 1.0198 | 1.0144 | 99.48 | 0.52 | 1.005 |
| 199-14 | 1.1012 | 1.1047 | 100.31 | -0.31 | 0.997 |
| 199-15 | 1.141 | 1.1417 | 100.06 | -0.06 | 0.999 |
| 199-16 | 1.1264 | 1.125 | 99.88 | 0.12 | 1.001 |
| 199-17 | 1.1053 | 1.1117 | 100.57 | -0.57 | 0.994 |
| 199-18 | 1.1576 | 1.1544 | 99.73 | 0.27 | 1.003 |
| 199-19 | 1.1444 | 1.141 | 99.71 | 0.29 | 1.003 |
| average | | | 99.86 | 0.14 | 1.002 |
| confidence limit | | | 0.57 | 0.57 | 0.006 |
| SD | | | 1.19 | 1.19 | 0.012 |
| RSD % | | | 1.19 | 870.98 | 1.208 |

Method 9

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|-------|
| 199-1 | 1.0679 | 1.0625 | 99.50 | 0.50 | 1.005 |
| 199-2 | 1.0375 | 1.0345 | 99.71 | 0.29 | 1.003 |
| 199-3 | 1.013 | 1.0057 | 99.29 | 0.71 | 1.007 |
| 199-4 | 0.9963 | 0.9909 | 99.46 | 0.54 | 1.005 |
| 199-5 | 1.0477 | 1.0418 | 99.44 | 0.56 | 1.006 |
| 199-6 | 1.0329 | 1.0278 | 99.51 | 0.49 | 1.005 |
| 199-7 | 1.0429 | 1.0408 | 99.80 | 0.20 | 1.002 |
| 199-8 | 1.0706 | 1.0658 | 99.56 | 0.44 | 1.005 |
| 199-9 | 1.0447 | 1.0426 | 99.80 | 0.20 | 1.002 |
| average | | | 99.56 | 0.44 | 1.004 |
| confidence limit | | | 0.13 | 0.13 | 0.001 |
| SD | | | 0.17 | 0.17 | 0.002 |
| RSD % | | | 0.18 | 40.00 | 0.177 |

Method 10

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|--------|
| 199-1 | 1.0133 | 1.0133 | 100.00 | 0.00 | 1.000 |
| 199-2 | 1.0062 | 1.0057 | 99.95 | 0.05 | 1.000 |
| 199-3 | 1.0256 | 1.0248 | 99.92 | 0.08 | 1.001 |
| 199-4 | 1.0121 | 1.0101 | 99.80 | 0.20 | 1.002 |
| 199-5 | 1.0208 | 1.0194 | 99.86 | 0.14 | 1.001 |
| 199-6 | 1.0301 | 1.0294 | 99.93 | 0.07 | 1.001 |
| 199-7 | 0.9998 | 0.9988 | 99.90 | 0.10 | 1.001 |
| 199-8 | 1.011 | 1.0099 | 99.89 | 0.11 | 1.001 |
| 199-9 | 1.004 | 1.0024 | 99.84 | 0.16 | 1.002 |
| 199-10 | 1.0062 | 1.0057 | 99.95 | 0.05 | 1.000 |
| average | | | 99.91 | 0.09 | 1.001 |
| confidence limit | | | 0.04 | 0.04 | 0.0004 |
| SD | | | 0.06 | 0.06 | 0.001 |
| RSD % | | | 0.06 | 61.70 | 0.059 |

Method 11

| JRC code | sample mass | residue mass | PAC | soluble | d |
|------------------|-------------|--------------|-------|---------|--------|
| | g | g | % | % | |
| 199-1 | 1.0624 | 1.0387 | 97.79 | 2.21 | 1.023 |
| 199-2 | 1.1102 | 1.0863 | 97.87 | 2.13 | 1.022 |
| 199-3 | 1.0455 | 1.0228 | 97.85 | 2.15 | 1.022 |
| 199-4 | 1.1353 | 1.1099 | 97.78 | 2.22 | 1.023 |
| 199-5 | 1.0223 | 0.9992 | 97.76 | 2.24 | 1.023 |
| 199-6 | 0.9119 | 0.8917 | 97.81 | 2.19 | 1.023 |
| 199-7 | 0.8517 | 0.8325 | 97.77 | 2.23 | 1.023 |
| 199-8 | 0.9301 | 0.9096 | 97.82 | 2.18 | 1.023 |
| 199-9 | 1.0053 | 0.984 | 97.90 | 2.10 | 1.022 |
| average | | | 97.82 | 2.18 | 1.023 |
| confidence limit | | | 0.04 | 0.04 | 0.0004 |
| SD | | | 0.05 | 0.05 | 0.001 |
| RSD % | | | 0.05 | 2.18 | 0.049 |

Method 13

| JRC code | sample mass | residue mass | insoluble | soluble |
|------------------|-------------|--------------|-----------|---------|
| | g | g | % | % |
| 199-1 | 1.053 | 0.4145 | 40.11 | 59.89 |
| 199-2 | 0.9973 | 0.3968 | 40.53 | 59.47 |
| 199-3 | 1.0389 | 0.41034 | 40.24 | 59.76 |
| 199-4 | 1.2188 | 0.4783 | 39.99 | 60.01 |
| 199-5 | 1.0133 | 0.4006 | 40.28 | 59.72 |
| 199-6 | 1.0329 | 0.4065 | 40.10 | 59.90 |
| 199-7 | 1.0126 | 0.4042 | 40.66 | 59.34 |
| 199-8 | 1.0413 | 0.4071 | 39.84 | 60.16 |
| average | | | 40.22 | 59.78 |
| confidence limit | | | 0.23 | 0.23 |
| SD | | | 0.27 | 0.27 |
| RSD % | | | 0.68 | 0.46 |

Method 14

| JRC code | sample mass | residue mass | insoluble | soluble |
|------------------|-------------|--------------|-----------|---------|
| | g | g | % | % |
| 199-1 | 1.0359 | 0.7 | 66.89 | 33.11 |
| 199-2 | 1.1229 | 0.7551 | 66.56 | 33.44 |
| 199-3 | 1.0899 | 0.7341 | 66.67 | 33.33 |
| 199-4 | 1.0249 | 0.6901 | 66.65 | 33.35 |
| 199-5 | 1.1063 | 0.7454 | 66.69 | 33.31 |
| 199-6 | 1.0965 | 0.7376 | 66.58 | 33.42 |
| 199-7 | 1.0297 | 0.6934 | 66.65 | 33.35 |
| 199-8 | 1.0207 | 0.6819 | 66.11 | 33.89 |
| average | | | 66.60 | 33.40 |
| confidence limit | | | 0.18 | 0.18 |
| SD | | | 0.22 | 0.22 |
| RSD % | | | 0.33 | 0.66 |

Method 15

| JRC code | sample mass | residue mass | insoluble | soluble |
|------------------|-------------|--------------|-----------|---------|
| | g | g | % | % |
| 199-1 | 1.0484 | 0.4082 | 39.68 | 60.32 |
| 199-2 | 0.9972 | 0.3913 | 39.98 | 60.02 |
| 199-3 | 1.1604 | 0.4336 | 38.10 | 61.90 |
| 199-4 | 1.1474 | 0.4525 | 40.18 | 59.82 |
| 199-5 | 1.0651 | 0.4144 | 39.65 | 60.35 |
| 199-6 | 1.1387 | 0.4787 | 42.80 | 57.20 |
| 199-7 | 1.1689 | 0.5033 | 43.82 | 56.18 |
| 199-8 | 1.2007 | 0.4619 | 39.21 | 60.79 |
| 199-9 | 1.2254 | 0.4778 | 39.73 | 60.27 |
| average | | | 40.35 | 59.65 |
| confidence limit | | | 1.38 | 1.38 |
| SD | | | 1.80 | 1.80 |
| RSD % | | | 4.46 | 3.02 |

Method 16

| JRC code | sample mass | residue mass | insoluble | soluble |
|------------------|-------------|--------------|-----------|---------|
| | g | g | % | % |
| 199-1 | 1.1414 | 0.7490 | 64.92 | 35.08 |
| 199-2 | 1.1199 | 0.7375 | 65.15 | 34.85 |
| 199-3 | 1.1946 | 0.7832 | 64.86 | 35.14 |
| 199-4 | 1.2122 | 0.7867 | 64.19 | 35.81 |
| 199-5 | 1.1229 | 0.7319 | 64.47 | 35.53 |
| 199-6 | 1.1241 | 0.7385 | 64.99 | 35.01 |
| 199-7 | 1.1334 | 0.7461 | 65.13 | 34.87 |
| 199-8 | 1.2088 | 0.7974 | 65.27 | 34.73 |
| 199-9 | 1.0901 | 0.7154 | 64.92 | 35.08 |
| 199-10 | 1.1170 | 0.7346 | 65.06 | 34.94 |
| 199-11 | 1.1259 | 0.7386 | 64.90 | 35.10 |
| 199-12 | 1.1094 | 0.7278 | 64.90 | 35.10 |
| 199-13 | 1.1338 | 0.7420 | 64.74 | 35.26 |
| 199-14 | 1.0351 | 0.6782 | 64.82 | 35.18 |
| 199-15 | 1.1628 | 0.7624 | 64.86 | 35.14 |
| 199-16 | 1.0895 | 0.7128 | 64.72 | 35.28 |
| 199-17 | 1.1087 | 0.7264 | 64.81 | 35.19 |
| 199-18 | 1.0774 | 0.7063 | 64.85 | 35.15 |
| 199-19 | 1.1229 | 0.7349 | 64.74 | 35.26 |
| 199-20 | 1.1552 | 0.7505 | 64.26 | 35.74 |
| 199-21 | 1.0829 | 0.7098 | 64.84 | 35.16 |
| 199-22 | 1.0483 | 0.6867 | 64.80 | 35.20 |
| 199-23 | 1.0191 | 0.6674 | 64.78 | 35.22 |
| 199-24 | 1.0405 | 0.6815 | 64.79 | 35.21 |
| 199-25 | 1.0162 | 0.6659 | 64.82 | 35.18 |
| average | | | 64.82 | 35.18 |
| confidence limit | | | 0.10 | 0.10 |
| SD | | | 0.24 | 0.24 |
| RSD % | | | 0.37 | 0.68 |

- Ventilated oven

Method 11

| JRC code | sample mass | residue mass | PAC | soluble | d |
|------------------|-------------|--------------|-------|---------|-------|
| | g | g | % | % | |
| 199-1 | 1.0049 | 0.9744 | 96.99 | 3.01 | 1.031 |
| 199-2 | 1.0328 | 1.0013 | 96.98 | 3.02 | 1.031 |
| 199-3 | 1.0367 | 1.0054 | 97.01 | 2.99 | 1.031 |
| 199-4 | 1.0196 | 0.9883 | 96.96 | 3.04 | 1.032 |
| 199-5 | 1.0117 | 0.9815 | 97.04 | 2.96 | 1.031 |
| 199-6 | 0.9934 | 0.9632 | 96.99 | 3.01 | 1.031 |
| 199-7 | 0.9973 | 0.9675 | 97.04 | 2.96 | 1.031 |
| 199-8 | 1.0178 | 0.9834 | 96.65 | 3.35 | 1.035 |
| 199-9 | 1.0084 | 0.9775 | 96.97 | 3.03 | 1.032 |
| 199-10 | 1.0106 | 0.9764 | 96.65 | 3.35 | 1.035 |
| average | | | 96.93 | 3.07 | 1.032 |
| confidence limit | | | 0.11 | 0.11 | 0.001 |
| SD | | | 0.15 | 0.15 | 0.002 |
| RSD % | | | 0.15 | 4.85 | 0.156 |

PAC 20 % (sample 233)

Method 1

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|-------|
| 233-1 | 1.1205 | 1.1179 | 99.77 | 0.23 | 1.002 |
| 233-2 | 1.0342 | 1.0320 | 99.79 | 0.21 | 1.002 |
| 233-3 | 1.0476 | 1.0460 | 99.85 | 0.15 | 1.002 |
| 233-4 | 1.0438 | 1.0430 | 99.92 | 0.08 | 1.001 |
| 233-5 | 1.0827 | 1.0796 | 99.72 | 0.28 | 1.003 |
| 233-6 | 1.0382 | 1.0401 | 100.18 | -0.18 | 0.998 |
| 233-7 | 1.1399 | 1.1411 | 100.10 | -0.10 | 0.999 |
| 233-8 | 1.0615 | 1.0567 | 99.55 | 0.45 | 1.005 |
| 233-9 | 1.0750 | 1.0723 | 99.75 | 0.25 | 1.003 |
| 233-10 | 1.1427 | 1.1408 | 99.84 | 0.16 | 1.002 |
| 233-11 | 1.0696 | 1.0671 | 99.77 | 0.23 | 1.002 |
| 233-12 | 1.0732 | 1.0708 | 99.78 | 0.22 | 1.002 |
| 233-13 | 1.0731 | 1.0727 | 99.96 | 0.04 | 1.000 |
| 233-14 | 1.1219 | 1.1250 | 100.27 | -0.27 | 0.997 |
| 233-15 | 0.9855 | 0.9814 | 99.59 | 0.41 | 1.004 |
| 233-16 | 1.0412 | 1.0402 | 99.90 | 0.10 | 1.001 |
| 233-17 | 1.1177 | 1.1136 | 99.64 | 0.36 | 1.004 |
| 233-18 | 0.9850 | 0.9820 | 99.70 | 0.30 | 1.003 |
| 233-19 | 1.1537 | 1.1494 | 99.63 | 0.37 | 1.004 |
| average | | | 99.83 | 0.17 | 1.002 |
| confidence limit | | | 0.09 | 0.09 | 0.001 |
| SD | | | 0.20 | 0.20 | 0.002 |
| RSD % | | | 0.20 | 113.15 | 0.198 |

Method 2

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|--------|
| 280-1 | 1.3362 | 1.3340 | 99.84 | 0.16 | 1.002 |
| 280-2 | 1.2788 | 1.2770 | 99.86 | 0.14 | 1.001 |
| 280-3 | 1.3206 | 1.3188 | 99.87 | 0.13 | 1.001 |
| 280-4 | 1.2948 | 1.2931 | 99.87 | 0.13 | 1.001 |
| 280-5 | 1.3070 | 1.3056 | 99.89 | 0.11 | 1.001 |
| 280-6 | 1.2574 | 1.2558 | 99.87 | 0.13 | 1.001 |
| 280-7 | 1.3057 | 1.3037 | 99.85 | 0.15 | 1.002 |
| 280-8 | 1.2885 | 1.2867 | 99.86 | 0.14 | 1.001 |
| 280-9 | 1.3203 | 1.3185 | 99.87 | 0.13 | 1.001 |
| 280-10 | 1.2802 | 1.2778 | 99.81 | 0.19 | 1.002 |
| 280-11 | 1.3161 | 1.3144 | 99.87 | 0.13 | 1.001 |
| 280-12 | 1.2568 | 1.2555 | 99.90 | 0.10 | 1.001 |
| 280-13 | 1.2681 | 1.2662 | 99.85 | 0.15 | 1.002 |
| 280-14 | 1.3302 | 1.3279 | 99.83 | 0.17 | 1.002 |
| 280-15 | 1.3001 | 1.2980 | 99.84 | 0.16 | 1.002 |
| 280-16 | 1.3002 | 1.2982 | 99.85 | 0.15 | 1.002 |
| 280-17 | 1.3140 | 1.3123 | 99.87 | 0.13 | 1.001 |
| 280-18 | 1.2716 | 1.2702 | 99.89 | 0.11 | 1.001 |
| 280-19 | 1.3370 | 1.3350 | 99.85 | 0.15 | 1.001 |
| 280-20 | 1.3273 | 1.3249 | 99.82 | 0.18 | 1.002 |
| average | | | 99.86 | 0.14 | 1.001 |
| confidence limit | | | 0.01 | 0.01 | 0.0001 |
| SD | | | 0.02 | 0.02 | 0.0002 |
| RSD % | | | 0.02 | 16.20 | 0.023 |

Method 3

| JRC code | sample mass | residue mass | insoluble | soluble |
|------------------|-------------|--------------|-----------|---------|
| | g | g | % | % |
| 233-1 | 1.0853 | 0.8977 | 82.27 | 17.73 |
| 233-2 | 1.1022 | 0.9105 | 82.16 | 17.84 |
| 233-3 | 1.1819 | 0.9767 | 82.19 | 17.81 |
| 233-4 | 1.1553 | 0.9535 | 82.08 | 17.92 |
| 233-5 | 1.1751 | 0.9704 | 82.13 | 17.87 |
| 233-6 | 1.1828 | 0.9754 | 82.01 | 17.99 |
| 233-7 | 1.1723 | 0.9679 | 82.11 | 17.89 |
| 233-8 | 1.1032 | 0.9116 | 82.18 | 17.82 |
| 233-9 | 1.2365 | 1.0269 | 82.61 | 17.39 |
| 233-10 | 1.1623 | 0.9652 | 82.60 | 17.40 |
| average | | | 82.23 | 17.77 |
| confidence limit | | | 0.15 | 0.10 |
| SD | | | 0.21 | 0.21 |
| RSD % | | | 0.25 | 1.16 |

Method 4

| JRC code | sample mass | residue mass | insoluble | soluble |
|------------------|-------------|--------------|-----------|---------|
| | g | g | % | % |
| 233-1 | 0.8765 | 0.8331 | 94.90 | 5.10 |
| 233-2 | 0.9991 | 0.9416 | 94.07 | 5.93 |
| 233-3 | 1.0588 | 1.0040 | 94.67 | 5.33 |
| 233-4 | 1.0185 | 0.9641 | 94.50 | 5.50 |
| 233-5 | 1.0712 | 1.0138 | 94.48 | 5.52 |
| 233-6 | 0.9277 | 0.8735 | 93.98 | 6.02 |
| 233-7 | 0.9117 | 0.8703 | 95.32 | 4.68 |
| 233-8 | 0.6375 | 0.6037 | 94.54 | 5.46 |
| 233-9 | 1.1050 | 1.0526 | 95.12 | 4.88 |
| 233-10 | 1.0238 | 0.9685 | 94.44 | 5.56 |
| average | | | 94.60 | 5.40 |
| confidence limit | | | 0.30 | 0.30 |
| SD | | | 0.42 | 0.42 |
| RSD % | | | 0.44 | 7.79 |

Method 5

| JRC code | sample mass | residue mass | PAC | soluble | d |
|------------------|-------------|--------------|--------|---------|-------|
| | g | g | % | % | |
| 233-1 | 1.1266 | 1.1246 | 99.82 | 0.18 | 1.002 |
| 233-2 | 1.0043 | 1.0037 | 99.94 | 0.06 | 1.001 |
| 233-3 | 1.1639 | 1.162 | 99.84 | 0.16 | 1.002 |
| 233-4 | 1.1527 | 1.1518 | 99.92 | 0.08 | 1.001 |
| 233-5 | 0.9977 | 1.0021 | 100.44 | -0.44 | 0.996 |
| 233-6 | 1.1102 | 1.1089 | 99.88 | 0.12 | 1.001 |
| 233-7 | 1.1402 | 1.1387 | 99.87 | 0.13 | 1.001 |
| 233-8 | 1.0718 | 1.0790 | 100.67 | -0.67 | 0.993 |
| 233-9 | 1.3688 | 1.3668 | 99.86 | 0.14 | 1.001 |
| 233-10 | 1.0482 | 1.0578 | 100.91 | -0.91 | 0.991 |
| 233-11 | 1.0051 | 1.0166 | 101.13 | -1.13 | 0.989 |
| 233-12 | 1.0977 | 1.0982 | 100.05 | -0.05 | 1.000 |
| 233-13 | 1.1259 | 1.1250 | 99.92 | 0.08 | 1.001 |
| 233-14 | 0.9967 | 1.0065 | 100.97 | -0.97 | 0.990 |
| 233-15 | 1.0622 | 1.0600 | 99.79 | 0.21 | 1.002 |
| 233-16 | 1.2002 | 1.1988 | 99.88 | 0.12 | 1.001 |
| 233-17 | 1.1545 | 1.1603 | 100.50 | -0.50 | 0.995 |
| 233-18 | 1.0908 | 1.1096 | 101.71 | -1.71 | 0.983 |
| 233-19 | 1.0735 | 1.0721 | 99.87 | 0.13 | 1.001 |
| 233-20 | 0.9736 | 0.9746 | 100.10 | -0.10 | 0.999 |
| average | | | 100.25 | -0.25 | 1.00 |
| confidence limit | | | 0.26 | 0.26 | 0.003 |
| SD | | | 0.55 | 0.55 | 0.005 |
| RSD % | | | 0.55 | -217.27 | 0.551 |

Method 6

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|-------|
| 233-1 | 1.0750 | 1.0722 | 99.74 | 0.26 | 1.003 |
| 233-2 | 1.0196 | 1.0177 | 99.82 | 0.18 | 1.002 |
| 233-3 | 1.0369 | 1.0373 | 100.04 | -0.04 | 1.000 |
| 233-4 | 1.0235 | 1.0195 | 99.61 | 0.39 | 1.004 |
| 233-5 | 1.0106 | 1.0126 | 100.20 | -0.20 | 0.998 |
| 233-6 | 1.0555 | 1.0552 | 99.97 | 0.03 | 1.000 |
| 233-7 | 1.0235 | 1.0211 | 99.77 | 0.23 | 1.002 |
| 233-8 | 1.0675 | 1.0670 | 99.95 | 0.05 | 1.000 |
| 233-9 | 1.0372 | 1.0347 | 99.76 | 0.24 | 1.002 |
| 233-10 | 1.0507 | 1.0487 | 99.81 | 0.19 | 1.002 |
| 233-11 | 1.0301 | 1.0273 | 99.73 | 0.27 | 1.003 |
| 233-12 | 1.0218 | 1.0200 | 99.83 | 0.17 | 1.002 |
| 233-13 | 1.0400 | 1.0369 | 99.70 | 0.30 | 1.003 |
| 233-14 | 1.0284 | 1.0298 | 100.13 | -0.13 | 0.999 |
| 233-15 | 1.0332 | 1.0282 | 99.52 | 0.48 | 1.005 |
| 233-16 | 1.0407 | 1.0380 | 99.74 | 0.26 | 1.003 |
| 233-17 | 1.0684 | 1.0653 | 99.71 | 0.29 | 1.003 |
| 233-18 | 1.0220 | 1.0220 | 100.00 | 0.00 | 1.000 |
| 233-19 | 1.0732 | 1.0731 | 99.99 | 0.01 | 1.000 |
| 233-20 | 1.0329 | 1.0299 | 99.71 | 0.29 | 1.003 |
| average | | | 99.84 | 0.16 | 1.002 |
| confidence limit | | | 0.08 | 0.08 | 0.001 |
| SD | | | 0.17 | 0.17 | 0.002 |
| RSD % | | | 0.17 | 107.36 | 0.177 |

Method 7

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|-------|
| 233-1 | 1.0542 | 1.0476 | 99.38 | 0.62 | 1.006 |
| 233-2 | 0.9976 | 0.9907 | 99.32 | 0.68 | 1.007 |
| 233-3 | 1.176 | 1.1696 | 99.46 | 0.54 | 1.005 |
| 233-4 | 1.1490 | 1.1414 | 99.35 | 0.65 | 1.007 |
| 233-5 | 1.0722 | 1.067 | 99.52 | 0.48 | 1.005 |
| 233-6 | 0.9402 | 0.9326 | 99.20 | 0.80 | 1.008 |
| 233-7 | 1.0286 | 1.0202 | 99.19 | 0.81 | 1.008 |
| 233-8 | 0.9250 | 0.9186 | 99.31 | 0.69 | 1.007 |
| 233-9 | 1.0294 | 1.0236 | 99.44 | 0.56 | 1.006 |
| 233-10 | 1.2063 | 1.1983 | 99.34 | 0.66 | 1.007 |
| 233-11 | 1.1271 | 1.1219 | 99.54 | 0.46 | 1.005 |
| 233-12 | 0.9628 | 0.9551 | 99.21 | 0.79 | 1.008 |
| 233-13 | 1.1155 | 1.1102 | 99.53 | 0.47 | 1.005 |
| 233-14 | 1.2035 | 1.1968 | 99.45 | 0.55 | 1.006 |
| 233-15 | 1.0572 | 1.0498 | 99.31 | 0.69 | 1.007 |
| 233-16 | 1.1463 | 1.1402 | 99.47 | 0.53 | 1.005 |
| 233-17 | 1.0396 | 1.0336 | 99.43 | 0.57 | 1.006 |
| 233-18 | 1.002 | 0.9963 | 99.44 | 0.56 | 1.006 |
| 233-19 | 0.9210 | 0.9144 | 99.29 | 0.71 | 1.007 |
| 233-20 | 1.1212 | 1.1156 | 99.51 | 0.49 | 1.005 |
| average | | | 99.38 | 0.62 | 1.006 |
| confidence limit | | | 0.05 | 0.05 | 0.001 |
| SD | | | 0.11 | 0.11 | 0.001 |
| RSD % | | | 0.11 | 18.07 | 0.113 |

Method 8

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|--------|
| 280-1 | 1.2915 | 1.2879 | 99.72 | 0.28 | 1.003 |
| 280-2 | 1.2577 | 1.2539 | 99.70 | 0.30 | 1.003 |
| 280-3 | 1.3515 | 1.3467 | 99.65 | 0.35 | 1.004 |
| 280-4 | 1.2673 | 1.2636 | 99.71 | 0.29 | 1.003 |
| 280-5 | 1.3120 | 1.3086 | 99.74 | 0.26 | 1.003 |
| 280-6 | 1.2487 | 1.2453 | 99.73 | 0.27 | 1.003 |
| 280-7 | 1.2528 | 1.2498 | 99.76 | 0.24 | 1.002 |
| 280-8 | 1.2936 | 1.2900 | 99.72 | 0.28 | 1.003 |
| 280-9 | 1.2892 | 1.2854 | 99.71 | 0.29 | 1.003 |
| 280-10 | 1.3414 | 1.3375 | 99.71 | 0.29 | 1.003 |
| 280-11 | 1.2416 | 1.2390 | 99.79 | 0.21 | 1.002 |
| 280-12 | 1.3607 | 1.3574 | 99.76 | 0.24 | 1.002 |
| 280-13 | 1.3107 | 1.3079 | 99.79 | 0.21 | 1.002 |
| 280-14 | 1.3062 | 1.3032 | 99.77 | 0.23 | 1.002 |
| 280-15 | 1.3278 | 1.3242 | 99.73 | 0.27 | 1.003 |
| 280-16 | 1.2769 | 1.2731 | 99.71 | 0.29 | 1.003 |
| 280-17 | 1.2978 | 1.2935 | 99.67 | 0.33 | 1.003 |
| 280-18 | 1.2831 | 1.2793 | 99.71 | 0.29 | 1.003 |
| 280-19 | 1.3582 | 1.3550 | 99.77 | 0.23 | 1.002 |
| 280-20 | 1.2959 | 1.2924 | 99.73 | 0.27 | 1.003 |
| average | | | 99.73 | 0.27 | 1.003 |
| confidence limit | | | 0.02 | 0.02 | 0.0002 |
| SD | | | 0.04 | 0.04 | 0.0004 |
| RSD % | | | 0.04 | 13.67 | 0.037 |

Method 9

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|-------|
| 233-1 | 1.0602 | 1.0574 | 99.74 | 0.26 | 1.003 |
| 233-2 | 1.0461 | 1.0433 | 99.73 | 0.27 | 1.003 |
| 233-3 | 1.0726 | 1.0675 | 99.53 | 0.47 | 1.005 |
| 233-4 | 1.2540 | 1.2520 | 99.84 | 0.16 | 1.002 |
| 233-5 | 1.0442 | 1.0432 | 99.91 | 0.09 | 1.001 |
| 233-6 | 1.0376 | 1.0363 | 99.88 | 0.12 | 1.001 |
| 233-7 | 1.0448 | 1.0441 | 99.93 | 0.07 | 1.001 |
| 233-8 | 1.0489 | 1.0459 | 99.72 | 0.28 | 1.003 |
| 233-9 | 1.0331 | 1.0302 | 99.72 | 0.28 | 1.003 |
| 233-10 | 1.0260 | 1.0230 | 99.71 | 0.29 | 1.003 |
| 233-11 | 1.0476 | 1.0525 | 100.46 | -0.46 | 0.995 |
| 233-12 | 1.0554 | 1.0572 | 100.17 | -0.17 | 0.998 |
| 233-13 | 1.0538 | 1.0544 | 100.06 | -0.06 | 0.999 |
| 233-14 | 1.0664 | 1.0641 | 99.79 | 0.21 | 1.002 |
| 233-15 | 1.0342 | 1.0339 | 99.97 | 0.03 | 1.000 |
| 233-16 | 1.0666 | 1.0672 | 100.06 | -0.06 | 0.999 |
| 233-17 | 1.0398 | 1.0418 | 100.19 | -0.19 | 0.998 |
| 233-18 | 1.0540 | 1.0538 | 99.98 | 0.02 | 1.000 |
| 233-19 | 1.0460 | 1.0432 | 99.73 | 0.27 | 1.003 |
| average | | | 99.90 | 0.10 | 1.001 |
| confidence limit | | | 0.11 | 0.11 | 0.001 |
| SD | | | 0.22 | 0.22 | 0.002 |
| RSD % | | | 0.22 | 222.02 | 0.222 |

Method 10

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|-------|
| 233-1 | 1.0170 | 1.0076 | 99.08 | 0.92 | 1.009 |
| 233-2 | 1.0329 | 1.0449 | 101.15 | -1.15 | 0.989 |
| 233-3 | 1.0067 | 1.0118 | 100.50 | -0.50 | 0.995 |
| 233-4 | 1.0362 | 1.0334 | 99.73 | 0.27 | 1.003 |
| 233-5 | 1.0034 | 1.0230 | 101.93 | -1.93 | 0.981 |
| 233-6 | 1.0136 | 1.0126 | 99.90 | 0.10 | 1.001 |
| 233-7 | 1.0082 | 1.0066 | 99.84 | 0.16 | 1.002 |
| 233-8 | 1.0588 | 1.0716 | 101.20 | -1.20 | 0.988 |
| 233-9 | 1.0538 | 1.0710 | 101.62 | -1.62 | 0.984 |
| 233-10 | 1.0429 | 1.0521 | 100.87 | -0.87 | 0.991 |
| 233-11 | 1.0526 | 1.0548 | 100.21 | -0.21 | 0.998 |
| 233-12 | 1.0456 | 1.0534 | 100.74 | -0.74 | 0.993 |
| 233-13 | 1.0246 | 1.0262 | 100.15 | -0.15 | 0.998 |
| 233-14 | 1.0005 | 1.0040 | 100.35 | -0.35 | 0.997 |
| 233-15 | 1.0095 | 1.0076 | 99.81 | 0.19 | 1.002 |
| 233-16 | 1.0055 | 1.0087 | 100.32 | -0.32 | 0.997 |
| 233-17 | 0.9974 | 0.9998 | 100.24 | -0.24 | 0.998 |
| 233-18 | 1.0139 | 1.0117 | 99.79 | 0.21 | 1.002 |
| 233-19 | 0.9950 | 0.9925 | 99.75 | 0.25 | 1.003 |
| 233-20 | 0.9436 | 0.9455 | 100.20 | -0.20 | 0.998 |
| average | | | 100.37 | -0.37 | 0.996 |
| confidence limit | | | 0.33 | 0.33 | 0.003 |
| SD | | | 0.70 | 0.70 | 0.007 |
| RSD % | | | 0.70 | -190.62 | 0.705 |

Method 11

| JRC code | sample mass g | residue mass g | PAC % | soluble % | d |
|------------------|------------------|-------------------|----------|--------------|--------|
| 280-1 | 1.2600 | 1.2526 | 99.42 | 0.58 | 1.006 |
| 280-2 | 1.2436 | 1.2365 | 99.43 | 0.57 | 1.006 |
| 280-3 | 1.4551 | 1.4453 | 99.33 | 0.67 | 1.007 |
| 280-4 | 1.3490 | 1.3403 | 99.36 | 0.64 | 1.006 |
| 280-5 | 1.3001 | 1.2918 | 99.37 | 0.63 | 1.006 |
| 280-6 | 1.3167 | 1.3089 | 99.41 | 0.59 | 1.006 |
| 280-7 | 1.2560 | 1.2480 | 99.37 | 0.63 | 1.006 |
| 280-8 | 1.3444 | 1.3368 | 99.44 | 0.56 | 1.006 |
| 280-9 | 1.1550 | 1.1474 | 99.35 | 0.65 | 1.007 |
| 280-10 | 1.2414 | 1.2343 | 99.43 | 0.57 | 1.006 |
| 280-11 | 1.3404 | 1.3317 | 99.36 | 0.64 | 1.007 |
| 280-12 | 1.2655 | 1.2592 | 99.51 | 0.49 | 1.005 |
| 280-13 | 1.2478 | 1.2408 | 99.44 | 0.56 | 1.006 |
| 280-14 | 1.3654 | 1.3571 | 99.40 | 0.60 | 1.006 |
| 280-15 | 1.4032 | 1.3946 | 99.39 | 0.61 | 1.006 |
| 280-16 | 1.2686 | 1.2614 | 99.44 | 0.56 | 1.006 |
| 280-17 | 1.3098 | 1.3015 | 99.37 | 0.63 | 1.006 |
| 280-18 | 1.1754 | 1.1680 | 99.38 | 0.62 | 1.006 |
| 280-19 | 1.2743 | 1.2665 | 99.39 | 0.61 | 1.006 |
| 280-20 | 1.3619 | 1.3531 | 99.36 | 0.64 | 1.007 |
| average | | | 99.40 | 0.60 | 1.006 |
| confidence limit | | | 0.02 | 0.02 | 0.0002 |
| SD | | | 0.04 | 0.04 | 0.0004 |
| RSD % | | | 0.04 | 7.10 | 0.043 |

Method 14

| JRC code | sample mass | residue mass | PAC | soluble | d |
|------------------|-------------|--------------|-------|---------|-------|
| | g | g | % | % | |
| 233-1 | 1.0502 | 1.0450 | 99.51 | 0.49 | 1.005 |
| 233-2 | 1.0181 | 1.0118 | 99.39 | 0.61 | 1.006 |
| 233-3 | 1.0542 | 1.0431 | 98.96 | 1.04 | 1.011 |
| 233-4 | 1.1314 | 1.1220 | 99.18 | 0.82 | 1.008 |
| 233-5 | 0.9022 | 0.8954 | 99.25 | 0.75 | 1.008 |
| 233-6 | 0.9869 | 0.9801 | 99.32 | 0.68 | 1.007 |
| 233-7 | 1.0571 | 1.0505 | 99.38 | 0.62 | 1.006 |
| 233-8 | 1.0225 | 1.0214 | 99.89 | 0.11 | 1.001 |
| 233-9 | 1.0267 | 1.0204 | 99.39 | 0.61 | 1.006 |
| 233-10 | 1.0281 | 1.0227 | 99.48 | 0.52 | 1.005 |
| 233-11 | 1.0449 | 1.0387 | 99.41 | 0.59 | 1.006 |
| 233-12 | 1.0124 | 1.0056 | 99.33 | 0.67 | 1.007 |
| 233-13 | 1.0421 | 1.0357 | 99.39 | 0.61 | 1.006 |
| 233-14 | 1.0645 | 1.0543 | 99.05 | 0.95 | 1.010 |
| 233-15 | 1.1128 | 1.1041 | 99.23 | 0.77 | 1.008 |
| 233-16 | 0.9866 | 0.9783 | 99.17 | 0.83 | 1.008 |
| 233-17 | 1.0626 | 1.0536 | 99.16 | 0.84 | 1.009 |
| 233-18 | 1.0038 | 0.9960 | 99.23 | 0.77 | 1.008 |
| 233-19 | 0.8853 | 0.8768 | 99.05 | 0.95 | 1.010 |
| 233-20 | 1.1553 | 1.1464 | 99.24 | 0.76 | 1.008 |
| average | | | 99.30 | 0.70 | 1.01 |
| confidence limit | | | 0.10 | 0.10 | 0.001 |
| SD | | | 0.20 | 0.20 | 0.002 |
| RSD % | | | 0.20 | 29.06 | 0.206 |

Method 16

| JRC code | sample mass | residue mass | insoluble | soluble |
|------------------|-------------|--------------|-----------|---------|
| | g | g | % | % |
| 233-1 | 1.0752 | 0.8779 | 81.18 | 18.82 |
| 233-2 | 1.0141 | 0.8303 | 81.41 | 18.59 |
| 233-3 | 1.0056 | 0.8201 | 81.08 | 18.92 |
| 233-4 | 1.0411 | 0.8494 | 81.12 | 18.88 |
| 233-5 | 0.9986 | 0.8143 | 81.07 | 18.93 |
| 233-6 | 0.9822 | 0.8014 | 81.12 | 18.88 |
| 233-7 | 1.0237 | 0.8352 | 81.12 | 18.88 |
| 233-8 | 1.0526 | 0.8590 | 81.14 | 18.86 |
| 233-9 | 1.0445 | 0.8522 | 81.12 | 18.88 |
| 233-10 | 1.0273 | 0.8382 | 81.12 | 18.88 |
| average | | | 81.15 | 18.85 |
| confidence limit | | | 0.07 | 0.05 |
| SD | | | 0.10 | 0.10 |
| RSD % | | | 0.12 | 0.51 |

PAC 40 % (sample 266)**method 11**

| JRC code | sample mass | residue mass | insoluble | soluble |
|------------------|-------------|--------------|-----------|---------|
| | g | g | % | % |
| 266-1 | 0.9931 | 0.6597 | 66.07 | 33.93 |
| 266-2 | 1.0022 | 0.6674 | 66.24 | 33.76 |
| 266-3 | 1.0371 | 0.6810 | 65.29 | 34.71 |
| 266-4 | 0.9873 | 0.6394 | 64.36 | 35.64 |
| 266-5 | 0.9892 | 0.6525 | 65.59 | 34.41 |
| average | | | 65.51 | 34.49 |
| confidence limit | | | 0.92 | 0.92 |
| SD | | | 0.74 | 0.74 |
| RSD % | | | 1.14 | 2.16 |

PAC 40 % (sample 281)

method 11

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 281-1 | 1.0585 | 0.9252 | 88.38 | 11.62 |
| 281-2 | 1.1600 | 0.9424 | 82.20 | 17.80 |
| 281-3 | 1.2256 | 0.9320 | 76.98 | 23.02 |
| average | | | 82.52 | 17.48 |
| confidence limit | | | 14.18 | 14.18 |
| SD | | | 5.71 | 5.71 |
| RSD % | | | 6.92 | 32.66 |

Quantification of PA6 in PAC

Elemental analysis

PAC 5 %– 40 % (samples 195 – 199, 233)

| JRC code | nitrogen % | carbon % | hydrogen % |
|------------------|---------------|-------------|---------------|
| 195-1 | 0.608 | 84.100 | 14.701 |
| 195-2 | 1.091 | 83.902 | 14.728 |
| average | 0.850 | 84.001 | 14.715 |
| confidence limit | 3.069 | 1.258 | 0.172 |
| SD | 0.342 | 0.140 | 0.019 |
| RSD % | 40.204 | 0.167 | 0.130 |

| JRC code | nitrogen % | carbon % | hydrogen % |
|------------------|---------------|-------------|---------------|
| 196-1 | 1.288 | 83.095 | 14.250 |
| 196-2 | 1.272 | 83.013 | 14.325 |
| average | 1.280 | 83.054 | 14.288 |
| confidence limit | 0.102 | 0.521 | 0.476 |
| SD | 0.011 | 0.058 | 0.053 |
| RSD % | 0.884 | 0.070 | 0.371 |

| JRC code | nitrogen % | carbon % | hydrogen % |
|------------------|---------------|-------------|---------------|
| 197-1 | 2.371 | 81.020 | 13.939 |
| 197-2 | 2.364 | 80.801 | 13.880 |
| average | 2.368 | 80.911 | 13.910 |
| confidence limit | 0.044 | 1.391 | 0.375 |
| SD | 0.005 | 0.155 | 0.042 |
| RSD % | 0.209 | 0.191 | 0.300 |

| JRC code | nitrogen % | carbon % | hydrogen % |
|------------------|---------------|-------------|---------------|
| 198-1 | 3.402 | 78.746 | 13.426 |
| 198-2 | 3.393 | 78.697 | 13.431 |
| average | 3.398 | 78.722 | 13.429 |
| confidence limit | 0.057 | 0.311 | 0.032 |
| SD | 0.006 | 0.035 | 0.004 |
| RSD % | 0.187 | 0.044 | 0.026 |

| JRC code | nitrogen % | carbon % | hydrogen % |
|------------------|---------------|-------------|---------------|
| 199-1 | 4.367 | 77.103 | 13.197 |
| 199-2 | 4.369 | 77.115 | 13.182 |
| average | 4.368 | 77.109 | 13.190 |
| confidence limit | 0.013 | 0.076 | 0.095 |
| SD | 0.001 | 0.008 | 0.011 |
| RSD % | 0.032 | 0.011 | 0.080 |

| JRC code | nitrogen % | carbon % | hydrogen % |
|------------------|---------------|-------------|---------------|
| 233-1 | 2.368 | 80.624 | 13.872 |
| 233-2 | 2.373 | 80.593 | 13.819 |
| average | 2.371 | 80.609 | 13.846 |
| confidence limit | 0.032 | 0.197 | 0.337 |
| SD | 0.004 | 0.022 | 0.037 |
| RSD % | 0.149 | 0.027 | 0.271 |

polyamide (sample 193)

| JRC code | nitrogen % | carbon % | hydrogen % |
|------------------|---------------|-------------|---------------|
| 193-1 | 11.943 | 62.265 | 9.970 |
| 193-2 | 11.945 | 62.292 | 9.984 |
| average | 11.944 | 62.279 | 9.977 |
| confidence limit | 0.013 | 0.172 | 0.089 |
| SD | 0.001 | 0.019 | 0.010 |
| RSD % | 0.012 | 0.031 | 0.099 |

Hydrolysis method

PAC 5 %– 40 % (samples 195 - 199, 233)

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|----------|------------------|-------------------|----------------|--------------|
| 195-1 | 1.0140 | 0.9858 | 97.13 | 2.87 |
| 195-2 | 1.0324 | 1.0036 | 97.12 | 2.88 |
| 195-3 | 1.0129 | 0.9731 | 95.95 | 4.05 |
| 195-4 | 1.0135 | 0.9840 | 97.00 | 3.00 |
| 195-5 | 1.0103 | 0.9769 | 96.59 | 3.41 |
| | | average | 96.76 | 3.24 |
| | | confidence limit | 0.62 | 0.62 |
| | | SD | 0.50 | 0.50 |
| | | RSD % | 0.52 | 15.52 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|----------|------------------|-------------------|----------------|--------------|
| 196-1 | 1.1893 | 1.0971 | 92.02 | 7.98 |
| 196-2 | 1.0504 | 0.9710 | 92.22 | 7.78 |
| 196-3 | 1.1120 | 1.0269 | 92.12 | 7.88 |
| 196-4 | 1.0871 | 1.0046 | 92.19 | 7.81 |
| 196-5 | 1.1479 | 1.0539 | 91.57 | 8.43 |
| | | average | 92.03 | 7.97 |
| | | confidence limit | 0.33 | 0.33 |
| | | SD | 0.26 | 0.26 |
| | | RSD % | 0.29 | 3.31 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|----------|------------------|-------------------|----------------|--------------|
| 197-1 | 1.1014 | 0.9073 | 81.92 | 18.08 |
| 197-2 | 1.0614 | 0.8761 | 82.09 | 17.91 |
| 197-3 | 1.0829 | 0.8890 | 81.63 | 18.37 |
| 197-4 | 1.0962 | 0.8970 | 81.36 | 18.64 |
| | | average | 81.75 | 18.25 |
| | | confidence limit | 0.51 | 0.51 |
| | | SD | 0.32 | 0.32 |
| | | RSD % | 0.39 | 1.76 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|----------|------------------|-------------------|----------------|--------------|
| 198-1 | 1.0907 | 0.8093 | 73.60 | 26.40 |
| 198-2 | 1.0007 | 0.7515 | 74.51 | 25.49 |
| 198-3 | 1.0738 | 0.8030 | 74.19 | 25.81 |
| 198-4 | 0.9630 | 0.7269 | 74.90 | 25.10 |
| 198-5 | 0.9836 | 0.7392 | 74.57 | 25.43 |
| | | average | 74.35 | 25.65 |
| | | confidence limit | 0.61 | 0.61 |
| | | SD | 0.49 | 0.49 |
| | | RSD % | 0.66 | 1.92 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 199-1 | 1.0138 | 0.6590 | 64.29 | 35.71 |
| 199-2 | 1.0158 | 0.6577 | 64.03 | 35.97 |
| 199-3 | 0.9983 | 0.6414 | 63.53 | 36.47 |
| 199-4 | 1.0383 | 0.6701 | 63.82 | 36.18 |
| 199-5 | 1.0203 | 0.6608 | 64.05 | 35.95 |
| average | | | 63.95 | 36.05 |
| confidence limit | | | 0.35 | 0.35 |
| SD | | | 0.29 | 0.29 |
| RSD % | | | 0.45 | 0.79 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 233-1 | 1.0300 | 0.8406 | 81.14 | 18.86 |
| 233-2 | 1.0307 | 0.8455 | 81.57 | 18.43 |
| 233-3 | 1.0335 | 0.8444 | 81.23 | 18.77 |
| 233-4 | 1.0601 | 0.8657 | 81.19 | 18.81 |
| average | | | 81.28 | 18.72 |
| confidence limit | | | 0.31 | 0.31 |
| SD | | | 0.19 | 0.19 |
| RSD % | | | 0.24 | 1.04 |

Method 16 of Directive 96/73/EC

PAC 5 %– 40 % (samples 195 – 199, 233)

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 195-1 | 1.0997 | 1.0550 | 95.81 | 4.19 |
| 195-2 | 1.1465 | 1.1000 | 95.82 | 4.18 |
| 195-3 | 1.0507 | 1.0081 | 95.82 | 4.18 |
| 195-4 | 1.0191 | 0.9766 | 95.70 | 4.30 |
| 195-5 | 1.1037 | 1.0582 | 95.75 | 4.25 |
| 195-6 | 1.0529 | 1.0098 | 95.78 | 4.22 |
| 195-7 | 1.0367 | 0.9942 | 95.78 | 4.22 |
| 195-8 | 1.0145 | 0.9736 | 95.85 | 4.15 |
| 195-9 | 1.0177 | 0.9769 | 95.87 | 4.13 |
| 195-10 | 1.0034 | 0.9630 | 95.85 | 4.15 |
| 195-11 | 1.2244 | 1.1746 | 95.81 | 4.19 |
| 195-12 | 1.1043 | 1.0594 | 95.81 | 4.19 |
| 195-13 | 1.0329 | 0.9908 | 95.80 | 4.20 |
| 195-14 | 1.0355 | 0.9929 | 95.76 | 4.24 |
| 195-15 | 1.3166 | 1.2629 | 95.80 | 4.20 |
| 195-16 | 1.2527 | 1.2016 | 95.80 | 4.20 |
| 195-17 | 1.2959 | 1.2432 | 95.81 | 4.19 |
| 195-18 | 1.2123 | 1.1626 | 95.78 | 4.22 |
| 195-19 | 1.0118 | 0.9702 | 95.76 | 4.24 |
| 195-20 | 1.1973 | 1.1485 | 95.80 | 4.20 |
| average | | | 95.80 | 4.20 |
| confidence limit | | | 0.02 | 0.02 |
| SD | | | 0.04 | 0.04 |
| RSD % | | | 0.04 | 0.89 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 196-1 | 1.1896 | 1.0863 | 91.07 | 8.93 |
| 196-2 | 1.1124 | 1.0154 | 91.03 | 8.97 |
| 196-3 | 1.0414 | 0.9505 | 91.02 | 8.98 |
| 196-4 | 1.1320 | 1.0331 | 91.01 | 8.99 |
| 196-5 | 1.0997 | 1.0042 | 91.07 | 8.93 |
| 196-6 | 1.0291 | 0.9391 | 91.00 | 9.00 |
| 196-7 | 1.0413 | 0.9502 | 91.00 | 9.00 |
| 196-8 | 1.1628 | 1.0613 | 91.02 | 8.98 |
| 196-9 | 0.9849 | 0.8991 | 91.04 | 8.96 |
| 196-10 | 1.0764 | 0.9830 | 91.07 | 8.93 |
| 196-11 | 1.1791 | 1.0772 | 91.11 | 8.89 |
| 196-12 | 1.0434 | 0.9523 | 91.02 | 8.98 |
| 196-13 | 1.0871 | 0.9937 | 91.16 | 8.84 |
| 196-14 | 1.0579 | 0.9666 | 91.12 | 8.88 |
| 196-15 | 1.0772 | 0.9840 | 91.10 | 8.90 |
| 196-16 | 1.0764 | 0.9829 | 91.06 | 8.94 |
| 196-17 | 1.1220 | 1.0242 | 91.03 | 8.97 |
| 196-18 | 1.0661 | 0.9740 | 91.11 | 8.89 |
| 196-19 | 1.1686 | 1.0672 | 91.07 | 8.93 |
| average | | | 91.06 | 8.94 |
| confidence limit | | | 0.02 | 0.02 |
| SD | | | 0.05 | 0.05 |
| RSD % | | | 0.05 | 0.51 |

| JRC code | sample mass | residue mass | insoluble | soluble |
|------------------|-------------|--------------|-----------|---------|
| | g | g | % | % |
| 197-1 | 1.13 | 0.93 | 81.51 | 18.49 |
| 197-2 | 1.11 | 0.90 | 80.70 | 19.30 |
| 197-3 | 1.13 | 0.93 | 81.44 | 18.56 |
| 197-4 | 1.22 | 1.00 | 81.31 | 18.69 |
| 197-5 | 1.11 | 0.90 | 80.77 | 19.23 |
| 197-6 | 1.12 | 0.92 | 81.48 | 18.52 |
| 197-7 | 1.22 | 1.00 | 81.31 | 18.69 |
| 197-8 | 1.15 | 0.93 | 80.77 | 19.23 |
| 197-9 | 1.18 | 0.96 | 81.33 | 18.67 |
| 197-10 | 1.16 | 0.94 | 81.14 | 18.86 |
| 197-11 | 1.06 | 0.86 | 81.34 | 18.66 |
| 197-12 | 1.00 | 0.82 | 81.27 | 18.73 |
| 197-13 | 1.05 | 0.86 | 81.36 | 18.64 |
| 197-14 | 1.02 | 0.83 | 81.29 | 18.71 |
| 197-15 | 1.03 | 0.84 | 81.29 | 18.71 |
| 197-16 | 1.00 | 0.81 | 81.14 | 18.86 |
| 197-17 | 1.02 | 0.83 | 81.20 | 18.80 |
| 197-18 | 1.03 | 0.84 | 81.25 | 18.75 |
| 197-19 | 1.00 | 0.82 | 81.21 | 18.79 |
| 197-20 | 1.02 | 0.83 | 81.23 | 18.77 |
| average | | | 81.22 | 18.78 |
| confidence limit | | | 0.11 | 0.11 |
| SD | | | 0.22 | 0.22 |
| RSD % | | | 0.28 | 1.20 |

| JRC code | sample mass | residue mass | insoluble | soluble |
|------------------|-------------|--------------|-----------|---------|
| | g | g | % | % |
| 198-1 | 1.1734 | 0.8581 | 72.51 | 27.49 |
| 198-2 | 1.1752 | 0.8596 | 72.53 | 27.47 |
| 198-3 | 1.2382 | 0.9057 | 72.53 | 27.47 |
| 198-4 | 1.1973 | 0.8744 | 72.41 | 27.59 |
| 198-5 | 1.1727 | 0.8578 | 72.53 | 27.47 |
| 198-6 | 1.2141 | 0.8875 | 72.48 | 27.52 |
| 198-7 | 1.1911 | 0.8692 | 72.36 | 27.64 |
| 198-8 | 1.2349 | 0.9017 | 72.40 | 27.60 |
| 198-9 | 1.1756 | 0.8582 | 72.38 | 27.62 |
| 198-10 | 1.2645 | 0.9226 | 72.34 | 27.66 |
| 198-11 | 1.0265 | 0.7504 | 72.49 | 27.51 |
| 198-12 | 1.0410 | 0.7600 | 72.39 | 27.61 |
| 198-13 | 1.0300 | 0.7509 | 72.28 | 27.72 |
| 198-14 | 1.0264 | 0.7493 | 72.39 | 27.61 |
| 198-15 | 1.0322 | 0.7534 | 72.37 | 27.63 |
| 198-16 | 1.0398 | 0.7582 | 72.30 | 27.70 |
| 198-17 | 1.0380 | 0.7574 | 72.35 | 27.65 |
| 198-18 | 1.0381 | 0.7569 | 72.29 | 27.71 |
| 198-19 | 1.0365 | 0.7545 | 72.17 | 27.83 |
| 198-20 | 1.0328 | 0.7537 | 72.36 | 27.64 |
| average | | | 72.39 | 27.61 |
| confidence limit | | | 0.05 | 0.05 |
| SD | | | 0.10 | 0.10 |
| RSD % | | | 0.13 | 0.35 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 199-1 | 1.1414 | 0.7490 | 64.92 | 35.08 |
| 199-2 | 1.1199 | 0.7375 | 65.15 | 34.85 |
| 199-3 | 1.1946 | 0.7832 | 64.86 | 35.14 |
| 199-4 | 1.2122 | 0.7867 | 64.19 | 35.81 |
| 199-5 | 1.1229 | 0.7319 | 64.47 | 35.53 |
| 199-6 | 1.1241 | 0.7385 | 64.99 | 35.01 |
| 199-7 | 1.1334 | 0.7461 | 65.13 | 34.87 |
| 199-8 | 1.2088 | 0.7974 | 65.27 | 34.73 |
| 199-9 | 1.0901 | 0.7154 | 64.92 | 35.08 |
| 199-10 | 1.1170 | 0.7346 | 65.06 | 34.94 |
| 199-11 | 1.1259 | 0.7386 | 64.90 | 35.10 |
| 199-12 | 1.1094 | 0.7278 | 64.90 | 35.10 |
| 199-13 | 1.1338 | 0.7420 | 64.74 | 35.26 |
| 199-14 | 1.0351 | 0.6782 | 64.82 | 35.18 |
| 199-15 | 1.1628 | 0.7624 | 64.86 | 35.14 |
| 199-16 | 1.0895 | 0.7128 | 64.72 | 35.28 |
| 199-17 | 1.1087 | 0.7264 | 64.81 | 35.19 |
| 199-18 | 1.0774 | 0.7063 | 64.85 | 35.15 |
| 199-19 | 1.1229 | 0.7349 | 64.74 | 35.26 |
| 199-20 | 1.1552 | 0.7505 | 64.26 | 35.74 |
| 199-21 | 1.0829 | 0.7098 | 64.84 | 35.16 |
| 199-22 | 1.0483 | 0.6867 | 64.80 | 35.20 |
| 199-23 | 1.0191 | 0.6674 | 64.78 | 35.22 |
| 199-24 | 1.0405 | 0.6815 | 64.79 | 35.21 |
| 199-25 | 1.0162 | 0.6659 | 64.82 | 35.18 |
| average | | | 64.82 | 35.18 |
| confidence limit | | | 0.10 | 0.10 |
| SD | | | 0.24 | 0.24 |
| RSD % | | | 0.37 | 0.68 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 233-1 | 1.0752 | 0.8779 | 81.18 | 18.82 |
| 233-2 | 1.0141 | 0.8303 | 81.41 | 18.59 |
| 233-3 | 1.0056 | 0.8201 | 81.08 | 18.92 |
| 233-4 | 1.0411 | 0.8494 | 81.12 | 18.88 |
| 233-5 | 0.9986 | 0.8143 | 81.07 | 18.93 |
| average | | | 81.17 | 18.83 |
| confidence limit | | | 0.17 | 0.17 |
| SD | | | 0.14 | 0.14 |
| RSD % | | | 0.17 | 0.74 |

- Influence of sample size**

0.500 g, 100 ml

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 199-1 | 0.5212 | 0.3415 | 64.82 | 35.18 |
| 199-2 | 0.5092 | 0.3317 | 64.43 | 35.57 |
| 199-3 | 0.5175 | 0.3383 | 64.67 | 35.33 |
| average | | | 64.64 | 35.36 |
| confidence limit | | | 0.48 | 0.48 |
| SD | | | 0.19 | 0.19 |
| RSD % | | | 0.30 | 0.55 |

0.250 g, 50 ml

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 199-1 | 0.2715 | 0.1774 | 64.63 | 35.37 |
| 199-2 | 0.2753 | 0.1791 | 64.35 | 35.65 |
| 199-3 | 0.2709 | 0.1765 | 64.44 | 35.56 |
| average | | | 64.48 | 35.52 |
| confidence limit | | | 0.36 | 0.36 |
| SD | | | 0.15 | 0.15 |
| RSD % | | | 0.23 | 0.41 |

0.200 g, 40 ml

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 199-1 | 0.2073 | 0.1350 | 64.41 | 35.59 |
| 199-2 | 0.2081 | 0.1355 | 64.40 | 35.60 |
| 199-3 | 0.2056 | 0.1339 | 64.42 | 35.58 |
| average | | | 64.41 | 35.59 |
| confidence limit | | | 0.02 | 0.02 |
| SD | | | 0.01 | 0.01 |
| RSD % | | | 0.01 | 0.02 |

0.150 g, 30 ml

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 199-1 | 0.1533 | 0.0976 | 62.94 | 37.06 |
| 199-2 | 0.1501 | 0.0967 | 63.71 | 36.29 |
| 199-3 | 0.1497 | 0.0966 | 63.81 | 36.19 |
| average | | | 63.49 | 36.51 |
| confidence limit | | | 1.18 | 1.18 |
| SD | | | 0.47 | 0.47 |
| RSD % | | | 0.75 | 1.30 |

0.100 g, 20 ml

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 199-1 | 0.1056 | 0.0684 | 64.06 | 35.94 |
| 199-2 | 0.1149 | 0.0744 | 64.04 | 35.96 |
| 199-3 | 0.1161 | 0.0751 | 63.97 | 36.03 |
| average | | | 64.02 | 35.98 |
| confidence limit | | | 0.11 | 0.11 |
| SD | | | 0.05 | 0.05 |
| RSD % | | | 0.07 | 0.13 |

0.100 g, 50 ml

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 199-1 | 0.1205 | 0.0774 | 63.52 | 36.48 |
| 199-2 | 0.1250 | 0.0805 | 63.68 | 36.32 |
| 199-3 | 0.1234 | 0.0795 | 63.71 | 36.29 |
| 199-4 | 0.1173 | 0.0755 | 63.65 | 36.35 |
| 199-5 | 0.1229 | 0.0790 | 63.56 | 36.44 |
| 199-6 | 0.1207 | 0.0775 | 63.49 | 36.51 |
| 199-7 | 0.1230 | 0.0790 | 63.51 | 36.49 |
| 199-8 | 0.1163 | 0.0749 | 63.69 | 36.31 |
| 199-9 | 0.1161 | 0.0748 | 63.71 | 36.29 |
| average | | | 63.61 | 36.39 |
| confidence limit | | | 0.07 | 0.07 |
| SD | | | 0.09 | 0.09 |
| RSD % | | | 0.15 | 0.25 |

0.250 g, 50 ml, light glassware

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 199-1 | 0.2504 | 0.1640 | 64.79 | 35.21 |
| 199-2 | 0.2505 | 0.1644 | 64.92 | 35.08 |
| 199-3 | 0.2491 | 0.1633 | 64.85 | 35.15 |
| 199-4 | 0.2456 | 0.1610 | 64.85 | 35.15 |
| 199-5 | 0.2472 | 0.1618 | 64.75 | 35.25 |
| 199-6 | 0.2574 | 0.1688 | 64.87 | 35.13 |
| 199-7 | 0.2546 | 0.1666 | 64.73 | 35.27 |
| 199-8 | 0.2447 | 0.1603 | 64.80 | 35.20 |
| 199-9 | 0.2497 | 0.1636 | 64.81 | 35.19 |
| average | | | 64.82 | 35.18 |
| confidence limit | | | 0.05 | 0.05 |
| SD | | | 0.06 | 0.06 |
| RSD % | | | 0.09 | 0.17 |

0.100 g, 50 ml, light glassware

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 199-1 | 0.1047 | 0.0685 | 64.72 | 35.28 |
| 199-2 | 0.1038 | 0.0678 | 64.61 | 35.39 |
| 199-3 | 0.1038 | 0.0678 | 64.61 | 35.39 |
| 199-4 | 0.1023 | 0.0670 | 64.79 | 35.21 |
| 199-5 | 0.1013 | 0.0662 | 64.64 | 35.36 |
| 199-6 | 0.1026 | 0.0670 | 64.59 | 35.41 |
| 199-7 | 0.1039 | 0.0679 | 64.64 | 35.36 |
| 199-8 | 0.1044 | 0.0681 | 64.52 | 35.48 |
| 199-9 | 0.1029 | 0.0672 | 64.60 | 35.40 |
| 199-10 | 0.1012 | 0.0661 | 64.61 | 35.39 |
| average | | | 64.63 | 35.37 |
| confidence limit | | | 0.05 | 0.05 |
| SD | | | 0.07 | 0.07 |
| RSD % | | | 0.11 | 0.21 |

- Combination with densitometry**

0.150 g, 50 ml, light glassware

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 255*-1 | 0.1515 | 0.1110 | 72.65 | 27.35 |
| 255*-2 | 0.1510 | 0.1101 | 72.30 | 27.70 |
| 255*-3 | 0.1518 | 0.1109 | 72.44 | 27.56 |
| 255*-4 | 0.1538 | 0.1125 | 72.53 | 27.47 |
| 255*-5 | 0.1498 | 0.1095 | 72.48 | 27.52 |
| average | | | 72.48 | 27.52 |
| confidence limit | | | 0.16 | 0.16 |
| SD | | | 0.13 | 0.13 |
| RSD % | | | 0.18 | 0.48 |

Chemical methods using formic acid solutions

PAC 5 %– 40 % (samples 195 - 199)

- Method B (98-100 % HCOOH, 3h, RT)

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 195-1 | 1.0821 | 1.0556 | 97.48 | 2.52 |
| 195-2 | 1.0866 | 1.0578 | 97.27 | 2.73 |
| 195-3 | 1.0750 | 1.0463 | 97.25 | 2.75 |
| 195-4 | 1.0406 | 1.0273 | 98.68 | 1.32 |
| 195-5 | 1.0654 | 1.0465 | 98.17 | 1.83 |
| 195-6 | 1.0633 | 1.0406 | 97.80 | 2.20 |
| 195-7 | 1.0757 | 1.0548 | 98.00 | 2.00 |
| 195-8 | 1.0741 | 1.0519 | 97.87 | 2.13 |
| average | | | 97.81 | 2.19 |
| confidence limit | | | 0.41 | 0.41 |
| SD | | | 0.49 | 0.49 |
| RSD % | | | 0.50 | 22.21 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 196-1 | 1.0340 | 0.9455 | 91.19 | 8.81 |
| 196-2 | 1.0460 | 0.9524 | 90.80 | 9.20 |
| 196-3 | 1.0558 | 0.9669 | 91.34 | 8.66 |
| average | | | 91.11 | 8.89 |
| confidence limit | | | 0.70 | 0.70 |
| SD | | | 0.28 | 0.28 |
| RSD % | | | 0.31 | 3.16 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 197-1 | 1.0967 | 0.9034 | 81.92 | 18.08 |
| 197-2 | 1.0544 | 0.8693 | 81.99 | 18.01 |
| 197-3 | 1.0201 | 0.8344 | 81.33 | 18.67 |
| 197-4 | 1.0494 | 0.8612 | 81.60 | 18.40 |
| 197-5 | 1.0556 | 0.8683 | 81.80 | 18.20 |
| average | | | 81.73 | 18.27 |
| confidence limit | | | 0.33 | 0.33 |
| SD | | | 0.27 | 0.27 |
| RSD % | | | 0.33 | 1.46 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 198-1 | 1.0447 | 0.7728 | 73.37 | 26.63 |
| 198-2 | 1.0424 | 0.7631 | 72.59 | 27.41 |
| 198-3 | 1.0454 | 0.7683 | 72.88 | 27.12 |
| 198-4 | 1.0076 | 0.7391 | 72.74 | 27.26 |
| 198-5 | 1.0047 | 0.7335 | 72.39 | 27.61 |
| average | | | 72.80 | 27.20 |
| confidence limit | | | 0.46 | 0.46 |
| SD | | | 0.37 | 0.37 |
| RSD % | | | 0.51 | 1.36 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 199-1 | 1.0504 | 0.6940 | 65.37 | 34.63 |
| 199-2 | 1.0148 | 0.6694 | 65.26 | 34.74 |
| average | | | 65.32 | 34.68 |
| confidence limit | | | 0.68 | 0.68 |
| SD | | | 0.08 | 0.08 |
| RSD % | | | 0.12 | 0.22 |

• Method C (98-100 % HCOOH, 15 min, RT)

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 195-1 | 1.0387 | 1.0029 | 96.45 | 3.55 |
| 195-2 | 1.0315 | 1.0214 | 98.99 | 1.01 |
| average | | | 97.72 | 2.28 |
| confidence limit | | | 16.15 | 16.15 |
| SD | | | 1.80 | 1.80 |
| RSD % | | | 1.84 | 78.81 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 196-1 | 1.0558 | 1.0059 | 95.13 | 4.87 |
| 196-2 | 1.0242 | 0.9720 | 94.75 | 5.25 |
| 196-3 | 1.0115 | 0.9374 | 92.46 | 7.54 |
| 196-4 | 1.0635 | 1.0006 | 93.91 | 6.09 |
| 196-5 | 1.0583 | 1.0171 | 95.99 | 4.01 |
| 196-6 | 1.0251 | 0.9873 | 96.20 | 3.80 |
| average | | | 94.74 | 5.26 |
| confidence limit | | | 1.46 | 1.46 |
| SD | | | 1.40 | 1.40 |
| RSD % | | | 1.47 | 26.53 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 197-1 | 1.0162 | 0.8446 | 82.67 | 17.33 |
| 197-2 | 1.0322 | 0.8573 | 82.61 | 17.39 |
| 197-3 | 1.0509 | 0.8688 | 82.22 | 17.78 |
| 197-4 | 1.1493 | 0.9482 | 82.05 | 17.95 |
| 197-5 | 1.0673 | 0.8797 | 81.97 | 18.03 |
| average | | | 82.31 | 17.69 |
| confidence limit | | | 0.40 | 0.40 |
| SD | | | 0.32 | 0.32 |
| RSD % | | | 0.39 | 1.82 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 198-1 | 1.0451 | 0.7704 | 73.11 | 26.89 |
| 198-2 | 1.0404 | 0.7667 | 73.09 | 26.91 |
| 198-3 | 1.0835 | 0.7989 | 73.13 | 26.87 |
| average | | | 73.11 | 26.89 |
| confidence limit | | | 0.05 | 0.05 |
| SD | | | 0.02 | 0.02 |
| RSD % | | | 0.03 | 0.08 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 199-1 | 1.0338 | 0.6854 | 65.60 | 34.40 |
| 199-2 | 1.0189 | 0.6659 | 64.65 | 35.35 |
| 199-3 | 1.0280 | 0.6792 | 65.37 | 34.63 |
| 199-4 | 1.0341 | 0.6849 | 65.53 | 34.47 |
| 199-5 | 1.0247 | 0.6780 | 65.47 | 34.53 |
| average | | | 65.32 | 34.68 |
| confidence limit | | | 0.48 | 0.48 |
| SD | | | 0.39 | 0.39 |
| RSD % | | | 0.59 | 1.12 |

- **Method D (80 % HCOOH, 7h, RT)**

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 199-1 | 1.0003 | 0.6778 | 67.08 | 32.92 |
| 199-2 | 1.1303 | 0.7634 | 66.85 | 33.15 |
| 199-3 | 1.0904 | 0.7356 | 66.78 | 33.22 |
| average | | | 66.90 | 33.10 |
| confidence limit | | | 0.39 | 0.39 |
| SD | | | 0.16 | 0.16 |
| RSD % | | | 0.23 | 0.47 |

- **Method E (80 % HCOOH, 1h, RT)**

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 199-1 | 1.1527 | 0.7791 | 66.90 | 33.10 |
| 199-2 | 1.1116 | 0.7487 | 66.67 | 33.33 |
| 199-3 | 1.0627 | 0.7192 | 66.99 | 33.01 |
| average | | | 66.85 | 33.15 |
| confidence limit | | | 0.42 | 0.42 |
| SD | | | 0.17 | 0.17 |
| RSD % | | | 0.25 | 0.51 |

- **Method F (80 % HCOOH, 15 min, RT) = method 4 of Dir. 96/73/EC**

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 195-1 | 1.1895 | 1.1883 | 99.90 | 0.10 |
| 195-2 | 1.0478 | 1.0457 | 99.79 | 0.21 |
| 195-3 | 1.0329 | 1.0308 | 99.79 | 0.21 |
| 195-4 | 1.1165 | 1.1139 | 99.76 | 0.24 |
| 195-5 | 1.0750 | 1.0723 | 99.74 | 0.26 |
| 195-6 | 1.1390 | 1.1381 | 99.92 | 0.08 |
| 195-7 | 1.0099 | 1.0065 | 99.65 | 0.35 |
| 195-8 | 1.1443 | 1.1397 | 99.59 | 0.41 |
| 195-9 | 1.0327 | 1.0281 | 99.54 | 0.46 |
| 195-10 | 1.1690 | 1.1661 | 99.74 | 0.26 |
| average | | | 99.74 | 0.26 |
| confidence limit | | | 0.09 | 0.09 |
| SD | | | 0.12 | 0.12 |
| RSD % | | | 0.12 | 47.18 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 196-1 | 1.0841 | 1.0812 | 99.72 | 0.28 |
| 196-2 | 1.1229 | 1.1190 | 99.64 | 0.36 |
| 196-3 | 1.0925 | 1.0858 | 99.37 | 0.63 |
| 196-4 | 1.0669 | 1.0637 | 99.69 | 0.31 |
| 196-5 | 1.0419 | 1.0375 | 99.56 | 0.44 |
| 196-6 | 1.0780 | 1.0742 | 99.64 | 0.36 |
| 196-7 | 1.0191 | 1.0134 | 99.42 | 0.58 |
| 196-8 | 1.0679 | 1.0643 | 99.65 | 0.35 |
| 196-9 | 1.1671 | 1.1641 | 99.73 | 0.27 |
| average | | | 99.60 | 0.40 |
| confidence limit | | | 0.10 | 0.10 |
| SD | | | 0.13 | 0.13 |
| RSD % | | | 0.13 | 32.68 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 197-1 | 1.0177 | 1.0034 | 98.55 | 1.45 |
| 197-2 | 1.0104 | 1.0005 | 98.99 | 1.01 |
| 197-3 | 1.0048 | 0.9978 | 99.28 | 0.72 |
| 197-4 | 1.0169 | 1.0050 | 98.79 | 1.21 |
| 197-5 | 1.0438 | 1.0295 | 98.59 | 1.41 |
| 197-6 | 1.0497 | 1.0363 | 98.68 | 1.32 |
| 197-7 | 1.0164 | 1.0074 | 99.09 | 0.91 |
| 197-8 | 1.0083 | 0.9910 | 98.23 | 1.77 |
| 197-9 | 1.0120 | 0.9988 | 98.66 | 1.34 |
| average | | | 98.76 | 1.24 |
| confidence limit | | | 0.24 | 0.24 |
| SD | | | 0.32 | 0.32 |
| RSD % | | | 0.32 | 25.59 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 198-1 | 1.0469 | 0.8586 | 81.55 | 18.45 |
| 198-2 | 1.0050 | 0.8234 | 81.47 | 18.53 |
| 198-3 | 1.0452 | 0.8473 | 80.58 | 19.42 |
| 198-4 | 1.1101 | 0.8971 | 80.33 | 19.67 |
| 198-5 | 1.2036 | 0.9672 | 79.86 | 20.14 |
| 198-6 | 1.1931 | 0.9975 | 83.18 | 16.82 |
| 198-7 | 1.1996 | 1.0009 | 83.00 | 17.00 |
| 198-8 | 1.1645 | 0.9600 | 81.98 | 18.02 |
| 198-9 | 1.1230 | 0.9161 | 81.10 | 18.90 |
| 198-10 | 1.0261 | 0.8372 | 81.12 | 18.88 |
| average | | | 81.42 | 18.58 |
| confidence limit | | | 0.77 | 0.77 |
| SD | | | 1.08 | 1.08 |
| RSD % | | | 1.32 | 5.79 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 199-1 | 1.079 | 0.7298 | 66.95 | 33.05 |
| 199-2 | 1.0825 | 0.7293 | 66.69 | 33.31 |
| 199-3 | 1.0691 | 0.7191 | 66.57 | 33.43 |
| 199-4 | 1.0637 | 0.7158 | 66.61 | 33.39 |
| 199-5 | 1.0511 | 0.7103 | 66.89 | 33.11 |
| 199-6 | 1.0244 | 0.6944 | 67.10 | 32.90 |
| 199-7 | 1.0361 | 0.7049 | 67.35 | 32.65 |
| 199-8 | 0.9972 | 0.6781 | 67.32 | 32.68 |
| 199-9 | 1.0566 | 0.7131 | 66.80 | 33.20 |
| 199-10 | 1.0779 | 0.7313 | 67.16 | 32.84 |
| 199-11 | 1.0283 | 0.6968 | 67.08 | 32.92 |
| 199-12 | 1.2898 | 0.8762 | 67.25 | 32.75 |
| 199-13 | 1.102 | 0.7438 | 66.81 | 33.19 |
| 199-14 | 1.1711 | 0.7947 | 67.18 | 32.82 |
| average | | | 66.98 | 33.02 |
| confidence limit | | | 0.15 | 0.15 |
| SD | | | 0.26 | 0.26 |
| RSD % | | | 0.39 | 0.79 |

Method 13 of Directive 96/73/EC

PAC 5 % – 40 % (samples 195 - 199)

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 195-1 | 1.0162 | 0.0505 | 5.12 | 94.88 |
| 195-2 | 1.0053 | 0.0484 | 4.96 | 95.04 |
| 195-3 | 0.9999 | 0.0485 | 5.00 | 95.00 |
| 195-4 | 1.0187 | 0.0539 | 5.45 | 94.55 |
| 195-5 | 1.0550 | 0.0516 | 5.04 | 94.96 |
| average | | | 5.11 | 94.89 |
| confidence limit | | | 0.25 | 0.25 |
| SD | | | 0.20 | 0.20 |
| RSD % | | | 3.86 | 0.21 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 196-1 | 1.0309 | 0.1110 | 11.07 | 88.93 |
| 196-2 | 1.0167 | 0.1108 | 11.20 | 88.80 |
| 196-3 | 1.0243 | 0.1157 | 11.61 | 88.39 |
| 196-4 | 1.0061 | 0.1133 | 11.58 | 88.42 |
| 196-5 | 1.0079 | 0.1078 | 11.00 | 89.00 |
| average | | | 11.29 | 88.71 |
| confidence limit | | | 0.35 | 0.35 |
| SD | | | 0.29 | 0.29 |
| RSD % | | | 2.53 | 0.32 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 197-1 | 1.0523 | 0.2093 | 20.39 | 79.61 |
| 197-2 | 1.0219 | 0.1945 | 19.52 | 80.48 |
| 197-3 | 1.0340 | 0.2060 | 20.42 | 79.58 |
| 197-4 | 1.0219 | 0.1946 | 19.53 | 80.47 |
| 197-5 | 1.0125 | 0.2009 | 20.34 | 79.66 |
| average | | | 20.04 | 79.96 |
| confidence limit | | | 0.59 | 0.59 |
| SD | | | 0.47 | 0.47 |
| RSD % | | | 2.36 | 0.59 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 198-1 | 1.0103 | 0.2948 | 29.83 | 70.17 |
| 198-2 | 1.0106 | 0.2984 | 30.18 | 69.82 |
| 198-3 | 1.0290 | 0.3037 | 30.16 | 69.84 |
| 198-4 | 1.0292 | 0.3018 | 29.97 | 70.03 |
| 198-5 | 1.0449 | 0.3047 | 29.81 | 70.19 |
| average | | | 29.99 | 70.01 |
| confidence limit | | | 0.22 | 0.22 |
| SD | | | 0.18 | 0.18 |
| RSD % | | | 0.59 | 0.25 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 199-1 | 1.053 | 0.4145 | 40.11 | 59.89 |
| 199-2 | 0.9973 | 0.3968 | 40.53 | 59.47 |
| 199-3 | 1.0389 | 0.41034 | 40.24 | 59.76 |
| 199-4 | 1.2188 | 0.4783 | 39.99 | 60.01 |
| 199-5 | 1.0133 | 0.4006 | 40.28 | 59.72 |
| 199-6 | 1.0329 | 0.4065 | 40.10 | 59.90 |
| 199-7 | 1.0126 | 0.4042 | 40.66 | 59.34 |
| 199-8 | 1.0413 | 0.4071 | 39.84 | 60.16 |
| average | | | 40.22 | 59.78 |
| confidence limit | | | 0.23 | 0.23 |
| SD | | | 0.27 | 0.27 |
| RSD % | | | 0.68 | 0.46 |

Manual separation

Binary mixtures PA6/PAC (samples 201, 203, 205, 206)

| JRC code | PAC mass g | PA6 mass g | sample mass g | PAC % | PA6 % |
|------------------|---------------|---------------|------------------|----------|----------|
| 201-1 | 0.6712 | 0.7456 | 1.4168 | 46.23 | 53.77 |
| 201-2 | 0.5990 | 0.6574 | 1.2564 | 46.53 | 53.47 |
| 201-3 | 0.5208 | 0.5916 | 1.1124 | 45.68 | 54.32 |
| 201-4 | 0.5819 | 0.6557 | 1.2376 | 45.88 | 54.12 |
| 201-5 | 0.5471 | 0.6169 | 1.1640 | 45.86 | 54.14 |
| 201-6 | 0.5551 | 0.6313 | 1.1864 | 45.65 | 54.35 |
| 201-7 | 0.5599 | 0.6320 | 1.1919 | 45.83 | 54.17 |
| 201-8 | 0.5678 | 0.6145 | 1.1823 | 46.88 | 53.12 |
| 201-9 | 0.5833 | 0.6562 | 1.2395 | 45.92 | 54.08 |
| 201-10 | 0.5993 | 0.6768 | 1.2761 | 45.82 | 54.18 |
| average | | | | 46.03 | 53.97 |
| confidence limit | | | | 0.29 | 0.29 |
| SD | | | | 0.40 | 0.40 |
| RSD % | | | | 0.87 | 0.74 |

| JRC code | PAC mass g | PA6 mass g | sample mass g | PAC % | PA6 % |
|------------------|---------------|---------------|------------------|----------|----------|
| 203-1 | 0.5432 | 0.5983 | 1.1415 | 46.44 | 53.56 |
| 203-2 | 0.5787 | 0.6511 | 1.2298 | 45.91 | 54.09 |
| 203-3 | 0.5828 | 0.6264 | 1.2092 | 47.05 | 52.95 |
| 203-4 | 0.6100 | 0.6626 | 1.2726 | 46.79 | 53.21 |
| 203-5 | 0.6116 | 0.6546 | 1.2662 | 47.16 | 52.84 |
| 203-6 | 0.5275 | 0.6005 | 1.1280 | 45.62 | 54.38 |
| 203-7 | 0.5748 | 0.6343 | 1.2091 | 46.39 | 53.61 |
| 203-8 | 0.5737 | 0.6539 | 1.2276 | 45.59 | 54.41 |
| 203-9 | 0.4955 | 0.5609 | 1.0564 | 45.76 | 54.24 |
| 203-10 | 0.5712 | 0.6162 | 1.1874 | 46.96 | 53.04 |
| average | | | | 46.37 | 53.63 |
| confidence limit | | | | 0.44 | 0.44 |
| SD | | | | 0.61 | 0.61 |
| RSD % | | | | 1.32 | 1.14 |

| JRC code | PAC mass g | PA6 mass g | sample mass g | PAC % | PA6 % |
|------------------|---------------|---------------|------------------|----------|----------|
| 205-1 | 0.5175 | 0.5598 | 1.0773 | 46.89 | 53.11 |
| 205-2 | 0.5858 | 0.6226 | 1.2084 | 47.33 | 52.67 |
| 205-3 | 0.5565 | 0.582 | 1.1385 | 47.73 | 52.27 |
| 205-4 | 0.5997 | 0.6373 | 1.2370 | 47.33 | 52.67 |
| 205-5 | 0.5482 | 0.5786 | 1.1268 | 47.50 | 52.50 |
| 205-6 | 0.5061 | 0.5593 | 1.0654 | 46.36 | 53.64 |
| 205-7 | 0.6276 | 0.6864 | 1.3140 | 46.62 | 53.38 |
| 205-8 | 0.5715 | 0.6193 | 1.1908 | 46.85 | 53.15 |
| 205-9 | 0.5325 | 0.6023 | 1.1348 | 45.78 | 54.22 |
| 205-10 | 0.5211 | 0.5915 | 1.1126 | 45.69 | 54.31 |
| average | | | | 46.81 | 53.19 |
| confidence limit | | | | 0.50 | 0.50 |
| SD | | | | 0.70 | 0.70 |
| RSD % | | | | 1.50 | 1.32 |

| JRC code | PAC mass g | PA6 mass g | sample mass g | PAC % | PA6 % |
|------------------|---------------|---------------|------------------|----------|----------|
| 206-1 | 0.5341 | 0.5765 | 1.1106 | 46.95 | 53.05 |
| 206-2 | 0.5683 | 0.6409 | 1.2092 | 45.86 | 54.14 |
| 206-3 | 0.5467 | 0.6018 | 1.1485 | 46.46 | 53.54 |
| 206-4 | 0.6076 | 0.6384 | 1.2460 | 47.62 | 52.38 |
| 206-5 | 0.5077 | 0.5429 | 1.0506 | 47.18 | 52.82 |
| 206-6 | 0.5827 | 0.6403 | 1.2230 | 46.50 | 53.50 |
| 206-7 | 0.4620 | 0.5165 | 0.9785 | 46.07 | 53.93 |
| 206-8 | 0.4467 | 0.5171 | 0.9638 | 45.21 | 54.79 |
| 206-9 | 0.4304 | 0.4757 | 0.9061 | 46.36 | 53.64 |
| average | | | | 46.47 | 53.53 |
| confidence limit | | | | 0.56 | 0.56 |
| SD | | | | 0.72 | 0.72 |
| RSD % | | | | 1.56 | 1.35 |

Binary mixtures PP/PAC (samples 208, 210, 212, 213)

| JRC code | PAC mass g | PP mass g | sample mass g | PAC % | PP % |
|------------------|---------------|--------------|------------------|----------|---------|
| 208-1 | 0.6028 | 0.6061 | 1.2089 | 49.37 | 50.63 |
| 208-2 | 0.5939 | 0.6121 | 1.2060 | 48.76 | 51.24 |
| 208-3 | 0.5437 | 0.5482 | 1.0919 | 49.30 | 50.70 |
| 208-4 | 0.5417 | 0.545 | 1.0867 | 49.36 | 50.64 |
| 208-5 | 0.5994 | 0.6013 | 1.2007 | 49.43 | 50.57 |
| 208-6 | 0.509 | 0.5138 | 1.0228 | 49.28 | 50.72 |
| 208-7 | 0.6024 | 0.5921 | 1.1945 | 49.94 | 50.06 |
| 208-8 | 0.6194 | 0.5915 | 1.2109 | 50.66 | 49.34 |
| 208-9 | 0.4866 | 0.4782 | 0.9648 | 49.95 | 50.05 |
| 208-10 | 0.5418 | 0.5546 | 1.0964 | 48.93 | 51.07 |
| average | | | | 49.50 | 50.50 |
| confidence limit | | | | 0.40 | 0.40 |
| SD | | | | 0.55 | 0.55 |
| RSD % | | | | 1.12 | 1.10 |

| JRC code | PAC mass g | PP mass g | sample mass g | PAC % | PP % |
|------------------|---------------|--------------|------------------|----------|---------|
| 210-1 | 0.5822 | 0.561 | 1.1432 | 50.44 | 49.56 |
| 210-2 | 0.5703 | 0.569 | 1.1393 | 49.57 | 50.43 |
| 210-3 | 0.5597 | 0.5621 | 1.1218 | 49.40 | 50.60 |
| 210-4 | 0.5737 | 0.5701 | 1.1438 | 49.67 | 50.33 |
| 210-5 | 0.5638 | 0.5658 | 1.1296 | 49.42 | 50.58 |
| 210-6 | 0.5594 | 0.5525 | 1.1119 | 49.82 | 50.18 |
| 210-7 | 0.5772 | 0.5718 | 1.1490 | 49.74 | 50.26 |
| 210-8 | 0.5804 | 0.5565 | 1.1369 | 50.56 | 49.44 |
| 210-9 | 0.5542 | 0.5621 | 1.1163 | 49.16 | 50.84 |
| 210-10 | 0.5965 | 0.5951 | 1.1916 | 49.57 | 50.43 |
| average | | | | 49.73 | 50.27 |
| confidence limit | | | | 0.32 | 0.32 |
| SD | | | | 0.45 | 0.45 |
| RSD % | | | | 0.90 | 0.89 |

| JRC code | PAC mass g | PP mass g | sample mass g | PAC % | PP % |
|------------------|---------------|--------------|------------------|----------|---------|
| 212-1 | 0.5510 | 0.5431 | 1.0941 | 49.87 | 50.13 |
| 212-2 | 0.5854 | 0.5617 | 1.1471 | 50.54 | 49.46 |
| 212-3 | 0.5475 | 0.5514 | 1.0989 | 49.33 | 50.67 |
| 212-4 | 0.5777 | 0.5503 | 1.128 | 50.72 | 49.28 |
| 212-5 | 0.5123 | 0.4816 | 0.9939 | 51.05 | 48.95 |
| 212-6 | 0.5341 | 0.5342 | 1.0683 | 49.51 | 50.49 |
| 212-7 | 0.5636 | 0.5678 | 1.1314 | 49.32 | 50.68 |
| 212-8 | 0.5745 | 0.5763 | 1.1508 | 49.43 | 50.57 |
| 212-9 | 0.5620 | 0.5650 | 1.127 | 49.38 | 50.62 |
| 212-10 | 0.5442 | 0.5428 | 1.087 | 49.57 | 50.43 |
| average | | | | 49.87 | 50.13 |
| confidence limit | | | | 0.47 | 0.47 |
| SD | | | | 0.65 | 0.65 |
| RSD % | | | | 1.31 | 1.30 |

| JRC code | PAC mass g | PP mass g | sample mass g | PAC % | PP % |
|------------------|---------------|--------------|------------------|----------|---------|
| 213-1 | 0.6866 | 0.6437 | 1.3303 | 51.12 | 48.88 |
| 213-2 | 0.6946 | 0.6700 | 1.3646 | 50.41 | 49.59 |
| 213-3 | 0.7065 | 0.7123 | 1.4188 | 49.31 | 50.69 |
| 213-4 | 0.6622 | 0.6295 | 1.2917 | 50.78 | 49.22 |
| 213-5 | 0.8036 | 0.7798 | 1.5834 | 50.26 | 49.74 |
| 213-6 | 0.6291 | 0.6281 | 1.2572 | 49.55 | 50.45 |
| 213-7 | 0.6964 | 0.6608 | 1.3572 | 50.82 | 49.18 |
| 213-8 | 0.7253 | 0.6673 | 1.3926 | 51.59 | 48.41 |
| 213-9 | 0.6956 | 0.6667 | 1.3623 | 50.57 | 49.43 |
| 213-10 | 0.6962 | 0.6789 | 1.3751 | 50.14 | 49.86 |
| average | | | | 50.45 | 49.55 |
| confidence limit | | | | 0.49 | 0.49 |
| SD | | | | 0.69 | 0.69 |
| RSD % | | | | 1.37 | 1.39 |

Carpet samples PA6/PAC (samples 234 - 239)

| JRC code | PAC mass g | PA6 mass g | sample mass g | PAC % | PA6 % |
|------------------|---------------|---------------|------------------|----------|----------|
| 234-1 | 0.5638 | 0.5977 | 1.1615 | 47.39 | 52.61 |
| 234-2 | 0.5618 | 0.5878 | 1.1496 | 47.72 | 52.28 |
| 234-3 | 0.5490 | 0.5824 | 1.1314 | 47.38 | 52.62 |
| 234-4 | 0.5758 | 0.6081 | 1.1839 | 47.49 | 52.51 |
| 234-5 | 0.6303 | 0.6425 | 1.2728 | 48.37 | 51.63 |
| 234-6 | 0.5554 | 0.5561 | 1.1115 | 48.82 | 51.18 |
| 234-7 | 0.5611 | 0.5974 | 1.1585 | 47.29 | 52.71 |
| 234-8 | 0.5530 | 0.5852 | 1.1382 | 47.44 | 52.56 |
| 234-9 | 0.5683 | 0.5883 | 1.1566 | 47.99 | 52.01 |
| 234-10 | 0.5691 | 0.5993 | 1.1684 | 47.56 | 52.44 |
| average | | | | 47.74 | 52.26 |
| confidence limit | | | | 0.36 | 0.36 |
| SD | | | | 0.50 | 0.50 |
| RSD % | | | | 1.05 | 0.96 |

| JRC code | PAC mass g | PA6 mass g | sample mass g | PAC % | PA6 % |
|----------|---------------|---------------|------------------|----------|----------|
| 235-1 | 0.5560 | 0.5969 | 1.1529 | 47.08 | 52.92 |
| 235-2 | 0.5544 | 0.5925 | 1.1469 | 47.19 | 52.81 |
| 235-3 | 0.5223 | 0.5845 | 1.1068 | 46.05 | 53.95 |
| 235-4 | 0.5435 | 0.6076 | 1.1511 | 46.07 | 53.93 |
| 235-5 | 0.5440 | 0.6078 | 1.1518 | 46.09 | 53.91 |
| 235-6 | 0.5355 | 0.5806 | 1.1161 | 46.83 | 53.17 |
| 235-7 | 0.5478 | 0.6006 | 1.1484 | 46.56 | 53.44 |
| 235-8 | 0.5490 | 0.5992 | 1.1482 | 46.67 | 53.33 |
| 235-9 | 0.5558 | 0.6091 | 1.1649 | 46.57 | 53.43 |
| 235-10 | 0.5517 | 0.6126 | 1.1643 | 46.24 | 53.76 |

| | | |
|------------------|-------|-------|
| average | 46.53 | 53.47 |
| confidence limit | 0.30 | 0.30 |
| SD | 0.42 | 0.42 |
| RSD % | 0.90 | 0.78 |

| JRC code | PAC mass g | PA6 mass g | sample mass g | PAC % | PA6 % |
|----------|---------------|---------------|------------------|----------|----------|
| 236-1 | 0.5638 | 0.6215 | 1.1853 | 46.42 | 53.58 |
| 236-2 | 0.5342 | 0.5839 | 1.1181 | 46.63 | 53.37 |
| 236-3 | 0.5573 | 0.5995 | 1.1568 | 47.03 | 52.97 |
| 236-4 | 0.5414 | 0.5940 | 1.1354 | 46.54 | 53.46 |
| 236-5 | 0.4992 | 0.5551 | 1.0543 | 46.20 | 53.80 |
| 236-6 | 0.5715 | 0.6322 | 1.2037 | 46.33 | 53.67 |
| 236-7 | 0.5135 | 0.5925 | 1.1060 | 45.29 | 54.71 |
| 236-8 | 0.5383 | 0.5953 | 1.1336 | 46.34 | 53.66 |
| 236-9 | 0.5336 | 0.6004 | 1.1340 | 45.91 | 54.09 |
| 236-10 | 0.5510 | 0.5990 | 1.1500 | 46.77 | 53.23 |

| | | |
|------------------|-------|-------|
| average | 46.35 | 53.65 |
| confidence limit | 0.35 | 0.35 |
| SD | 0.48 | 0.48 |
| RSD % | 1.04 | 0.90 |

| JRC code | PAC mass g | PA6 mass g | sample mass g | PAC % | PA6 % |
|----------|---------------|---------------|------------------|----------|----------|
| 237-1 | 0.5723 | 0.6118 | 1.1841 | 47.19 | 52.81 |
| 237-2 | 0.5305 | 0.5786 | 1.1091 | 46.69 | 53.31 |
| 237-3 | 0.5068 | 0.5785 | 1.0853 | 45.55 | 54.45 |
| 237-4 | 0.5640 | 0.6067 | 1.1707 | 47.03 | 52.97 |
| 237-5 | 0.5484 | 0.6031 | 1.1515 | 46.48 | 53.52 |
| 237-6 | 0.5310 | 0.5923 | 1.1233 | 46.13 | 53.87 |
| 237-7 | 0.5383 | 0.5891 | 1.1274 | 46.60 | 53.40 |
| 237-8 | 0.5374 | 0.5867 | 1.1241 | 46.66 | 53.34 |
| 237-9 | 0.5517 | 0.5816 | 1.1333 | 47.53 | 52.47 |
| 237-10 | 0.5410 | 0.5886 | 1.1296 | 46.75 | 53.25 |

| | | |
|------------------|-------|-------|
| average | 46.66 | 53.34 |
| confidence limit | 0.39 | 0.39 |
| SD | 0.55 | 0.55 |
| RSD % | 1.18 | 1.03 |

| JRC code | PAC mass g | PA6 mass g | sample mass g | PAC % | PA6 % |
|------------------|---------------|---------------|------------------|----------|----------|
| 238-1 | 0.5439 | 0.5928 | 1.1367 | 46.70 | 53.30 |
| 238-2 | 0.5527 | 0.5960 | 1.1487 | 46.97 | 53.03 |
| 238-3 | 0.5390 | 0.5992 | 1.1382 | 46.21 | 53.79 |
| 238-4 | 0.5237 | 0.5836 | 1.1073 | 46.15 | 53.85 |
| 238-5 | 0.5187 | 0.5904 | 1.1091 | 45.63 | 54.37 |
| 238-6 | 0.5170 | 0.5900 | 1.1070 | 45.56 | 54.44 |
| 238-7 | 0.5548 | 0.5953 | 1.1501 | 47.09 | 52.91 |
| 238-8 | 0.5320 | 0.5794 | 1.1114 | 46.72 | 53.28 |
| 238-9 | 0.5558 | 0.5892 | 1.1450 | 47.39 | 52.61 |
| 238-10 | 0.5493 | 0.5930 | 1.1423 | 46.94 | 53.06 |
| average | | | | 46.54 | 53.46 |
| confidence limit | | | | 0.45 | 0.45 |
| SD | | | | 0.62 | 0.62 |
| RSD % | | | | 1.34 | 1.17 |

| JRC code | PAC mass g | PA6 mass g | sample mass g | PAC % | PA6 % |
|------------------|---------------|---------------|------------------|----------|----------|
| 239-1 | 0.5523 | 0.5843 | 1.1366 | 47.45 | 52.55 |
| 239-2 | 0.5467 | 0.5823 | 1.129 | 47.28 | 52.72 |
| 239-3 | 0.5163 | 0.5791 | 1.0954 | 45.99 | 54.01 |
| 239-4 | 0.5305 | 0.584 | 1.1145 | 46.45 | 53.55 |
| 239-5 | 0.551 | 0.5909 | 1.1419 | 47.11 | 52.89 |
| 239-6 | 0.5177 | 0.5804 | 1.0981 | 46.00 | 54.00 |
| 239-7 | 0.5465 | 0.5980 | 1.1445 | 46.60 | 53.40 |
| 239-8 | 0.5563 | 0.5954 | 1.1517 | 47.16 | 52.84 |
| 239-9 | 0.533 | 0.607 | 1.14 | 45.61 | 54.39 |
| 239-10 | 0.5057 | 0.5815 | 1.0872 | 45.37 | 54.63 |
| average | | | | 46.50 | 53.50 |
| confidence limit | | | | 0.53 | 0.53 |
| SD | | | | 0.74 | 0.74 |
| RSD % | | | | 1.58 | 1.38 |

Carpet samples PP/PAC (samples 246 - 254)

| JRC code | PAC mass g | PP mass g | sample mass g | PAC % | PP % |
|------------------|---------------|--------------|------------------|----------|---------|
| 246-1 | 0.5634 | 0.4173 | 0.9807 | 56.97 | 43.03 |
| 246-2 | 0.5420 | 0.4127 | 0.9547 | 56.29 | 43.71 |
| 246-3 | 0.5456 | 0.4175 | 0.9631 | 56.17 | 43.83 |
| 246-4 | 0.5564 | 0.4225 | 0.9789 | 56.36 | 43.64 |
| 246-5 | 0.5576 | 0.4086 | 0.9662 | 57.23 | 42.77 |
| 246-6 | 0.5511 | 0.4112 | 0.9623 | 56.79 | 43.21 |
| 246-7 | 0.5667 | 0.4079 | 0.9746 | 57.67 | 42.33 |
| 246-8 | 0.5432 | 0.4169 | 0.9601 | 56.10 | 43.90 |
| 246-9 | 0.5557 | 0.4185 | 0.9742 | 56.56 | 43.44 |
| 246-10 | 0.5578 | 0.4245 | 0.9823 | 56.30 | 43.70 |
| average | | | | 56.64 | 43.36 |
| confidence limit | | | | 0.37 | 0.37 |
| SD | | | | 0.51 | 0.51 |
| RSD % | | | | 0.91 | 1.19 |

| JRC code | PAC mass g | PP mass g | sample mass g | PAC % | PP % |
|------------------|---------------|--------------|------------------|----------|---------|
| 247-1 | 0.5442 | 0.4004 | 0.9446 | 57.13 | 42.87 |
| 247-2 | 0.5521 | 0.4147 | 0.9668 | 56.62 | 43.38 |
| 247-3 | 0.5504 | 0.4018 | 0.9522 | 57.32 | 42.68 |
| 247-4 | 0.5626 | 0.4043 | 0.9669 | 57.71 | 42.29 |
| 247-5 | 0.5707 | 0.4129 | 0.9836 | 57.54 | 42.46 |
| 247-6 | 0.5277 | 0.3903 | 0.9180 | 57.00 | 43.00 |
| 247-7 | 0.5296 | 0.4017 | 0.9313 | 56.39 | 43.61 |
| 247-8 | 0.5488 | 0.4258 | 0.9746 | 55.83 | 44.17 |
| 247-9 | 0.4896 | 0.3755 | 0.8651 | 56.11 | 43.89 |
| 247-10 | 0.6319 | 0.4542 | 1.0861 | 57.70 | 42.30 |
| average | | | | 56.94 | 43.06 |
| confidence limit | | | | 0.48 | 0.48 |
| SD | | | | 0.67 | 0.67 |
| RSD % | | | | 1.18 | 1.56 |

| JRC code | PAC mass g | PP mass g | sample mass g | PAC % | PP % |
|------------------|---------------|--------------|------------------|----------|---------|
| 248-1 | 0.5459 | 0.4055 | 0.9514 | 56.90 | 43.10 |
| 248-2 | 0.5449 | 0.4072 | 0.9521 | 56.75 | 43.25 |
| 248-3 | 0.5434 | 0.413 | 0.9564 | 56.34 | 43.66 |
| 248-4 | 0.5102 | 0.3879 | 0.8981 | 56.33 | 43.67 |
| 248-5 | 0.5701 | 0.4273 | 0.9974 | 56.68 | 43.32 |
| 248-6 | 0.5269 | 0.4002 | 0.9271 | 56.35 | 43.65 |
| 248-7 | 0.5239 | 0.3991 | 0.9230 | 56.28 | 43.72 |
| 248-8 | 0.5534 | 0.4121 | 0.9655 | 56.84 | 43.16 |
| 248-9 | 0.5355 | 0.4026 | 0.9381 | 56.60 | 43.40 |
| 248-10 | 0.532 | 0.4055 | 0.9375 | 56.26 | 43.74 |
| average | | | | 56.53 | 43.47 |
| confidence limit | | | | 0.18 | 0.18 |
| SD | | | | 0.25 | 0.25 |
| RSD % | | | | 0.44 | 0.57 |

| JRC code | PAC mass g | PP mass g | sample mass g | PAC % | PP % |
|------------------|---------------|--------------|------------------|----------|---------|
| 249-1 | 0.5416 | 0.4018 | 0.9434 | 56.93 | 43.07 |
| 249-2 | 0.5391 | 0.4200 | 0.9591 | 55.73 | 44.27 |
| 249-3 | 0.5260 | 0.4012 | 0.9272 | 56.25 | 43.75 |
| 249-4 | 0.5565 | 0.4101 | 0.9666 | 57.09 | 42.91 |
| 249-5 | 0.5407 | 0.3996 | 0.9403 | 57.02 | 42.98 |
| 249-6 | 0.5174 | 0.3950 | 0.9124 | 56.23 | 43.77 |
| 249-7 | 0.5280 | 0.4030 | 0.9310 | 56.23 | 43.77 |
| 249-8 | 0.5165 | 0.3996 | 0.9161 | 55.90 | 44.10 |
| 249-9 | 0.5090 | 0.3900 | 0.8990 | 56.14 | 43.86 |
| 249-10 | 0.5222 | 0.4001 | 0.9223 | 56.14 | 43.86 |
| average | | | | 56.36 | 43.64 |
| confidence limit | | | | 0.34 | 0.34 |
| SD | | | | 0.48 | 0.48 |
| RSD % | | | | 0.85 | 1.10 |

| JRC code | PAC mass g | PP mass g | sample mass g | PAC % | PP % |
|------------------|---------------|--------------|------------------|----------|---------|
| 250-1 | 0.5145 | 0.3748 | 0.8893 | 57.38 | 42.62 |
| 250-2 | 0.5454 | 0.4150 | 0.9604 | 56.31 | 43.69 |
| 250-3 | 0.5401 | 0.4115 | 0.9516 | 56.28 | 43.72 |
| 250-4 | 0.4894 | 0.3796 | 0.8690 | 55.83 | 44.17 |
| 250-5 | 0.5319 | 0.3999 | 0.9318 | 56.60 | 43.40 |
| 250-6 | 0.5144 | 0.3874 | 0.9018 | 56.56 | 43.44 |
| 250-7 | 0.5226 | 0.4009 | 0.9235 | 56.11 | 43.89 |
| 250-8 | 0.5229 | 0.4018 | 0.9247 | 56.07 | 43.93 |
| 250-9 | 0.5258 | 0.4105 | 0.9363 | 55.67 | 44.33 |
| 250-10 | 0.5145 | 0.4037 | 0.9182 | 55.55 | 44.45 |
| average | | | | 56.24 | 43.76 |
| confidence limit | | | | 0.38 | 0.38 |
| SD | | | | 0.53 | 0.53 |
| RSD % | | | | 0.94 | 1.21 |

| JRC code | PAC mass g | PP mass g | sample mass g | PAC % | PP % |
|------------------|---------------|--------------|------------------|----------|---------|
| 251-1 | 0.5153 | 0.4113 | 0.9266 | 55.13 | 44.87 |
| 251-2 | 0.5113 | 0.4050 | 0.9163 | 55.32 | 44.68 |
| 251-3 | 0.5152 | 0.4116 | 0.9268 | 55.10 | 44.90 |
| 251-4 | 0.5011 | 0.3974 | 0.8985 | 55.29 | 44.71 |
| 251-5 | 0.5587 | 0.4118 | 0.9705 | 57.09 | 42.91 |
| 251-6 | 0.5421 | 0.3985 | 0.9406 | 57.15 | 42.85 |
| 251-7 | 0.5187 | 0.3966 | 0.9153 | 56.19 | 43.81 |
| 251-8 | 0.5074 | 0.3917 | 0.8991 | 55.95 | 44.05 |
| 251-9 | 0.5148 | 0.4166 | 0.9314 | 54.79 | 45.21 |
| 251-10 | 0.4992 | 0.3974 | 0.8966 | 55.19 | 44.81 |
| average | | | | 55.72 | 44.28 |
| confidence limit | | | | 0.60 | 0.60 |
| SD | | | | 0.85 | 0.85 |
| RSD % | | | | 1.52 | 1.91 |

| JRC code | PAC mass g | PP mass g | sample mass g | PAC % | PP % |
|------------------|---------------|--------------|------------------|----------|---------|
| 252-1 | 0.6028 | 0.4624 | 1.0652 | 56.11 | 43.89 |
| 252-2 | 0.6489 | 0.4867 | 1.1356 | 56.66 | 43.34 |
| 252-3 | 0.6612 | 0.4993 | 1.1605 | 56.49 | 43.51 |
| 252-4 | 0.6562 | 0.4965 | 1.1527 | 56.45 | 43.55 |
| 252-5 | 0.6568 | 0.499 | 1.1558 | 56.34 | 43.66 |
| 252-6 | 0.6571 | 0.4962 | 1.1533 | 56.49 | 43.51 |
| 252-7 | 0.6587 | 0.4985 | 1.1572 | 56.44 | 43.56 |
| 252-8 | 0.6402 | 0.487 | 1.1272 | 56.31 | 43.69 |
| average | | | | 56.41 | 43.59 |
| confidence limit | | | | 0.14 | 0.14 |
| SD | | | | 0.16 | 0.16 |
| RSD % | | | | 0.29 | 0.37 |

| JRC code | PAC mass g | PP mass g | sample mass g | PAC % | PP % |
|------------------|---------------|--------------|------------------|----------|---------|
| 253-1 | 0.6027 | 0.4585 | 1.0612 | 56.31 | 43.69 |
| 253-2 | 0.6098 | 0.4560 | 1.0658 | 56.73 | 43.27 |
| 253-3 | 0.6541 | 0.4927 | 1.1468 | 56.56 | 43.44 |
| 253-4 | 0.6498 | 0.4982 | 1.1480 | 56.12 | 43.88 |
| 253-5 | 0.6576 | 0.4864 | 1.1440 | 57.00 | 43.00 |
| 253-6 | 0.6478 | 0.5036 | 1.1514 | 55.78 | 44.22 |
| 253-7 | 0.6545 | 0.4963 | 1.1508 | 56.39 | 43.61 |
| 253-8 | 0.6546 | 0.4951 | 1.1497 | 56.46 | 43.54 |
| average | | | | 56.42 | 43.58 |
| confidence limit | | | | 0.31 | 0.31 |
| SD | | | | 0.37 | 0.37 |
| RSD % | | | | 0.66 | 0.85 |

| JRC code | PAC mass g | PP mass g | sample mass g | PAC % | PP % |
|------------------|---------------|--------------|------------------|----------|---------|
| 254-1 | 0.6044 | 0.4611 | 1.0655 | 56.24 | 43.76 |
| 254-2 | 0.5574 | 0.4263 | 0.9837 | 56.18 | 43.82 |
| 254-3 | 0.6523 | 0.4992 | 1.1515 | 56.17 | 43.83 |
| 254-4 | 0.6006 | 0.4562 | 1.0568 | 56.35 | 43.65 |
| 254-5 | 0.5994 | 0.4607 | 1.0601 | 56.06 | 43.94 |
| 254-6 | 0.6504 | 0.4972 | 1.1476 | 56.19 | 43.81 |
| 254-7 | 0.6028 | 0.4639 | 1.0667 | 56.03 | 43.97 |
| 254-8 | 0.6541 | 0.5047 | 1.1588 | 55.96 | 44.04 |
| average | | | | 56.15 | 43.85 |
| confidence limit | | | | 0.10 | 0.10 |
| SD | | | | 0.13 | 0.13 |
| RSD % | | | | 0.22 | 0.29 |

Quantification of binary mixtures and carpet samples

Method 11 of Directive 96/73/EC

Binary mixtures PA6/PAC (samples 200 – 206)

| JRC code | sample mass g | residue mass g | PAC % | PA6 % |
|------------------|------------------|-------------------|----------|----------|
| 200-1 | 1.0072 | 0.4769 | 46.68 | 53.32 |
| 200-2 | 1.0639 | 0.5108 | 47.35 | 52.65 |
| 200-3 | 1.0715 | 0.5135 | 47.26 | 52.74 |
| 200-4 | 1.0286 | 0.4903 | 47.00 | 53.00 |
| 200-5 | 1.0442 | 0.4989 | 47.11 | 52.89 |
| 200-6 | 1.0559 | 0.4979 | 46.48 | 53.52 |
| 200-7 | 1.0610 | 0.5017 | 46.61 | 53.39 |
| 200-8 | 1.0557 | 0.5008 | 46.77 | 53.23 |
| 200-9 | 1.0780 | 0.5095 | 46.59 | 53.41 |
| average | | | 46.87 | 53.13 |
| confidence limit | | | 0.24 | 0.24 |
| SD | | | 0.31 | 0.31 |
| RSD % | | | 0.67 | 0.59 |

| JRC code | sample mass g | residue mass g | PAC % | PA6 % |
|------------------|------------------|-------------------|----------|----------|
| 201-1 | 1.0615 | 0.4968 | 46.13 | 53.87 |
| 201-2 | 1.0050 | 0.4645 | 45.54 | 54.46 |
| 201-3 | 1.1129 | 0.5281 | 46.78 | 53.22 |
| 201-4 | 1.0125 | 0.4689 | 45.63 | 54.37 |
| 201-5 | 1.0646 | 0.4979 | 46.09 | 53.91 |
| 201-6 | 1.0737 | 0.5091 | 46.74 | 53.26 |
| 201-7 | 1.0735 | 0.5009 | 45.98 | 54.02 |
| 201-8 | 1.0462 | 0.4891 | 46.07 | 53.93 |
| 201-9 | 1.0731 | 0.5014 | 46.05 | 53.95 |
| 201-10 | 1.0299 | 0.4865 | 46.56 | 53.44 |
| average | | | 46.16 | 53.84 |
| confidence limit | | | 0.30 | 0.30 |
| SD | | | 0.42 | 0.42 |
| RSD % | | | 0.92 | 0.79 |

| JRC code | sample mass g | residue mass g | PAC % | PA6 % |
|------------------|------------------|-------------------|----------|----------|
| 202-1 | 1.0675 | 0.5219 | 48.23 | 51.77 |
| 202-2 | 1.0434 | 0.5109 | 48.31 | 51.69 |
| 202-3 | 0.9979 | 0.4777 | 47.20 | 52.80 |
| 202-4 | 1.0219 | 0.4977 | 48.04 | 51.96 |
| 202-5 | 1.0002 | 0.4904 | 48.37 | 51.63 |
| 202-6 | 1.0384 | 0.4994 | 47.43 | 52.57 |
| 202-7 | 1.0361 | 0.5006 | 47.65 | 52.35 |
| 202-8 | 1.0754 | 0.5199 | 47.68 | 52.32 |
| 202-9 | 1.0583 | 0.5050 | 47.05 | 52.95 |
| 202-10 | 1.0387 | 0.5034 | 47.80 | 52.20 |
| average | | | 47.78 | 52.22 |
| confidence limit | | | 0.33 | 0.33 |
| SD | | | 0.46 | 0.46 |
| RSD % | | | 0.97 | 0.88 |

| JRC code | sample mass g | residue mass g | PAC % | PA6 % |
|------------------|------------------|-------------------|----------|----------|
| 203-1 | 1.0639 | 0.5122 | 47.48 | 52.52 |
| 203-2 | 1.0194 | 0.4877 | 47.17 | 52.83 |
| 203-3 | 1.0054 | 0.4846 | 47.53 | 52.47 |
| 203-4 | 1.0057 | 0.4834 | 47.40 | 52.60 |
| 203-5 | 1.2997 | 0.6163 | 46.75 | 53.25 |
| 203-6 | 1.0196 | 0.4898 | 47.37 | 52.63 |
| 203-7 | 1.0192 | 0.4889 | 47.30 | 52.70 |
| 203-8 | 1.0034 | 0.4780 | 46.97 | 53.03 |
| 203-9 | 1.0270 | 0.4874 | 46.79 | 53.21 |
| 203-10 | 1.0700 | 0.5070 | 46.71 | 53.29 |
| average | | | 47.15 | 52.85 |
| confidence limit | | | 0.23 | 0.23 |
| SD | | | 0.32 | 0.32 |
| RSD % | | | 0.67 | 0.60 |

| JRC code | sample mass g | residue mass g | PAC % | PA6 % |
|------------------|------------------|-------------------|----------|----------|
| 204-1 | 1.0088 | 0.4877 | 47.68 | 52.32 |
| 204-2 | 1.0761 | 0.5055 | 46.30 | 53.70 |
| 204-3 | 1.0439 | 0.4985 | 47.08 | 52.92 |
| 204-4 | 1.1052 | 0.5294 | 47.23 | 52.77 |
| 204-5 | 1.0796 | 0.4997 | 45.61 | 54.39 |
| 204-6 | 1.0290 | 0.4975 | 47.68 | 52.32 |
| 204-7 | 1.0769 | 0.5112 | 46.80 | 53.20 |
| 204-8 | 1.0161 | 0.4834 | 46.90 | 53.10 |
| 204-9 | 1.0700 | 0.5194 | 47.88 | 52.12 |
| 204-10 | 1.0271 | 0.5178 | 49.77 | 50.23 |
| average | | | 47.29 | 52.71 |
| confidence limit | | | 0.79 | 0.79 |
| SD | | | 1.11 | 1.11 |
| RSD % | | | 2.34 | 2.10 |

| JRC code | sample mass g | residue mass g | PAC % | PA6 % |
|------------------|------------------|-------------------|----------|----------|
| 205-1 | 1.0080 | 0.4807 | 47.02 | 52.98 |
| 205-2 | 1.0202 | 0.4906 | 47.42 | 52.58 |
| 205-3 | 1.0192 | 0.4855 | 46.97 | 53.03 |
| 205-4 | 1.0240 | 0.4937 | 47.55 | 52.45 |
| 205-5 | 1.0053 | 0.4753 | 46.61 | 53.39 |
| 205-6 | 1.0088 | 0.4843 | 47.34 | 52.66 |
| 205-7 | 1.0314 | 0.5009 | 47.90 | 52.10 |
| 205-8 | 1.0165 | 0.4888 | 47.42 | 52.58 |
| 205-9 | 1.0735 | 0.5161 | 47.41 | 52.59 |
| 205-10 | 1.0584 | 0.5060 | 47.14 | 52.86 |
| average | | | 47.28 | 52.72 |
| confidence limit | | | 0.26 | 0.26 |
| SD | | | 0.36 | 0.36 |
| RSD % | | | 0.76 | 0.68 |

| JRC code | sample mass g | residue mass g | PAC % | PA6 % |
|------------------|------------------|-------------------|----------|----------|
| 206-1 | 1.0180 | 0.4843 | 46.90 | 53.10 |
| 206-2 | 1.0302 | 0.4943 | 47.31 | 52.69 |
| 206-3 | 1.0061 | 0.4849 | 47.53 | 52.47 |
| 206-4 | 1.0254 | 0.5042 | 48.51 | 51.49 |
| 206-5 | 1.0664 | 0.5103 | 47.18 | 52.82 |
| 206-6 | 1.0280 | 0.4675 | 44.79 | 55.21 |
| 206-7 | 1.0361 | 0.4920 | 46.81 | 53.19 |
| 206-8 | 1.0325 | 0.5149 | 49.22 | 50.78 |
| 206-9 | 1.0150 | 0.4530 | 43.94 | 56.06 |
| average | | | 46.91 | 53.09 |
| confidence limit | | | 1.27 | 1.27 |
| SD | | | 1.65 | 1.65 |
| RSD % | | | 3.52 | 3.11 |

Carpet samples PA6/PAC (samples 234 – 239)

| JRC code | sample mass g | residue mass g | PAC % | PA6 % |
|------------------|------------------|-------------------|----------|----------|
| 234-1 | 1.1592 | 0.5578 | 47.45 | 52.55 |
| 234-2 | 1.1489 | 0.5563 | 47.76 | 52.24 |
| 234-3 | 1.1291 | 0.5432 | 47.44 | 52.56 |
| 234-4 | 1.1807 | 0.5699 | 47.60 | 52.40 |
| 234-5 | 1.2700 | 0.6236 | 48.44 | 51.56 |
| average | | | 47.74 | 52.26 |
| confidence limit | | | 0.51 | 0.51 |
| SD | | | 0.41 | 0.41 |
| RSD % | | | 0.87 | 0.79 |

| JRC code | sample mass g | residue mass g | PAC % | PA6 % |
|------------------|------------------|-------------------|----------|----------|
| 235-1 | 1.1518 | 0.5523 | 47.28 | 52.72 |
| 235-2 | 1.1446 | 0.5506 | 47.44 | 52.56 |
| 235-3 | 1.1060 | 0.5226 | 46.58 | 53.42 |
| 235-4 | 1.1496 | 0.5402 | 46.32 | 53.68 |
| 235-5 | 1.1493 | 0.5410 | 46.40 | 53.60 |
| average | | | 46.80 | 53.20 |
| confidence limit | | | 0.65 | 0.65 |
| SD | | | 0.52 | 0.52 |
| RSD % | | | 1.11 | 0.98 |

| JRC code | sample mass g | residue mass g | PAC % | PA6 % |
|------------------|------------------|-------------------|----------|----------|
| 236-1 | 1.1836 | 0.5394 | 44.89 | 55.11 |
| 236-2 | 1.1168 | 0.5362 | 47.35 | 52.65 |
| 236-3 | 1.1556 | 0.5563 | 47.47 | 52.53 |
| 236-4 | 1.1327 | 0.5633 | 49.08 | 50.92 |
| 236-5 | 1.0520 | 0.4985 | 46.71 | 53.29 |
| average | | | 47.10 | 52.90 |
| confidence limit | | | 1.88 | 1.88 |
| SD | | | 1.51 | 1.51 |
| RSD % | | | 3.21 | 2.86 |

| JRC code | sample mass g | residue mass g | PAC % | PA6 % |
|------------------|------------------|-------------------|----------|----------|
| 237-1 | 1.1437 | 0.5458 | 47.05 | 52.95 |
| 237-2 | 1.1307 | 0.5455 | 47.58 | 52.42 |
| 237-3 | 1.1425 | 0.5479 | 47.29 | 52.71 |
| 237-4 | 1.1279 | 0.5437 | 47.54 | 52.46 |
| average | | | 47.37 | 52.63 |
| confidence limit | | | 0.39 | 0.39 |
| SD | | | 0.24 | 0.24 |
| RSD % | | | 0.52 | 0.46 |

| JRC code | sample mass g | residue mass g | PAC % | PA6 % |
|------------------|------------------|-------------------|----------|----------|
| 238-1 | 1.0066 | 0.4838 | 47.40 | 52.60 |
| 238-2 | 1.0014 | 0.4830 | 47.57 | 52.43 |
| 238-3 | 0.9955 | 0.4664 | 46.18 | 53.82 |
| 238-4 | 0.9944 | 0.4681 | 46.40 | 53.60 |
| 238-5 | 1.0007 | 0.4659 | 45.88 | 54.12 |
| average | | | 46.68 | 53.32 |
| confidence limit | | | 0.94 | 0.94 |
| SD | | | 0.75 | 0.75 |
| RSD % | | | 1.62 | 1.41 |

| JRC code | sample mass g | residue mass g | PAC % | PA6 % |
|------------------|------------------|-------------------|----------|----------|
| 239-1 | 1.1212 | 0.5388 | 47.39 | 52.61 |
| 239-2 | 1.1194 | 0.5243 | 46.16 | 53.84 |
| 239-3 | 1.1184 | 0.5341 | 47.09 | 52.91 |
| 239-4 | 1.1201 | 0.5305 | 46.69 | 53.31 |
| 239-5 | 1.0964 | 0.5174 | 46.52 | 53.48 |
| average | | | 46.77 | 53.23 |
| confidence limit | | | 0.60 | 0.60 |
| SD | | | 0.48 | 0.48 |
| RSD % | | | 1.03 | 0.90 |

Method 16 of Directive 96/73/EC

Binary mixtures PP/PAC (samples 207 – 213)

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 207-1 | 1.0226 | 0.9799 | 95.70 | 4.30 |
| 207-2 | 1.0476 | 1.0032 | 95.63 | 4.37 |
| 207-3 | 1.0616 | 1.0155 | 95.53 | 4.47 |
| 207-4 | 1.0345 | 0.9861 | 95.18 | 4.82 |
| 207-5 | 1.0275 | 0.9814 | 95.38 | 4.62 |
| 207-6 | 1.0488 | 1.0049 | 95.69 | 4.31 |
| 207-7 | 1.0378 | 0.9883 | 95.09 | 4.91 |
| 207-8 | 1.0582 | 1.0124 | 95.54 | 4.46 |
| 207-9 | 1.0349 | 0.9872 | 95.25 | 4.75 |
| average | | | 95.44 | 4.56 |
| confidence limit | | | 0.17 | 0.17 |
| SD | | | 0.23 | 0.23 |
| RSD % | | | 0.24 | 4.99 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 209-1 | 1.0748 | 0.9750 | 90.45 | 9.55 |
| 209-2 | 1.0479 | 0.9517 | 90.56 | 9.44 |
| 209-3 | 1.0590 | 0.9580 | 90.19 | 9.81 |
| 209-4 | 1.0455 | 0.9489 | 90.50 | 9.50 |
| 209-5 | 1.1326 | 1.0291 | 90.60 | 9.40 |
| 209-6 | 1.0156 | 0.9207 | 90.39 | 9.61 |
| 209-7 | 1.0727 | 0.9746 | 90.59 | 9.41 |
| 209-8 | 1.0629 | 0.9650 | 90.53 | 9.47 |
| 209-9 | 1.0699 | 0.9701 | 90.41 | 9.59 |
| 209-10 | 1.0338 | 0.9398 | 90.65 | 9.35 |
| average | | | 90.49 | 9.51 |
| confidence limit | | | 0.10 | 0.10 |
| SD | | | 0.13 | 0.13 |
| RSD % | | | 0.15 | 1.41 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 210-1 | 1.2170 | 1.1062 | 90.64 | 9.36 |
| 210-2 | 1.0864 | 0.9868 | 90.57 | 9.43 |
| 210-3 | 1.0984 | 0.9951 | 90.33 | 9.67 |
| 210-4 | 1.0345 | 0.9399 | 90.59 | 9.41 |
| 210-5 | 1.1826 | 1.0752 | 90.66 | 9.34 |
| 210-6 | 1.1581 | 1.0471 | 90.14 | 9.86 |
| 210-7 | 1.2215 | 1.1084 | 90.48 | 9.52 |
| 210-8 | 1.1806 | 1.0745 | 90.76 | 9.24 |
| 210-9 | 1.1190 | 1.0190 | 90.81 | 9.19 |
| 210-10 | 1.1692 | 1.0624 | 90.60 | 9.40 |
| average | | | 90.56 | 9.44 |
| confidence limit | | | 0.14 | 0.14 |
| SD | | | 0.20 | 0.20 |
| RSD % | | | 0.22 | 2.10 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 211-1 | 1.0533 | 0.9094 | 85.97 | 14.03 |
| 211-2 | 1.0485 | 0.9040 | 85.85 | 14.15 |
| 211-3 | 1.0402 | 0.8989 | 86.05 | 13.95 |
| 211-4 | 1.0520 | 0.9081 | 85.95 | 14.05 |
| 211-5 | 1.0741 | 0.9272 | 85.95 | 14.05 |
| 211-6 | 1.0428 | 0.9007 | 86.00 | 14.00 |
| 211-7 | 1.0388 | 0.8976 | 86.04 | 13.96 |
| 211-8 | 1.0107 | 0.8724 | 85.95 | 14.05 |
| 211-9 | 1.0335 | 0.8923 | 85.97 | 14.03 |
| average | | | 85.97 | 14.03 |
| confidence limit | | | 0.05 | 0.05 |
| SD | | | 0.06 | 0.06 |
| RSD % | | | 0.07 | 0.43 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 212-1 | 1.0267 | 0.8857 | 85.89 | 14.11 |
| 212-2 | 1.0421 | 0.8984 | 85.84 | 14.16 |
| 212-3 | 1.0272 | 0.8863 | 85.91 | 14.09 |
| 212-4 | 1.0449 | 0.9030 | 86.05 | 13.95 |
| 212-5 | 1.0248 | 0.8842 | 85.91 | 14.09 |
| 212-6 | 1.0372 | 0.8941 | 85.83 | 14.17 |
| 212-7 | 1.0552 | 0.9100 | 85.87 | 14.13 |
| 212-8 | 1.0391 | 0.8968 | 85.93 | 14.07 |
| 212-9 | 1.0774 | 0.9300 | 85.95 | 14.05 |
| average | | | 85.91 | 14.09 |
| confidence limit | | | 0.05 | 0.05 |
| SD | | | 0.07 | 0.07 |
| RSD % | | | 0.08 | 0.47 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 213-1 | 1.1067 | 0.9023 | 81.06 | 18.94 |
| 213-2 | 1.0285 | 0.8505 | 82.24 | 17.76 |
| 213-3 | 1.0740 | 0.8834 | 81.80 | 18.20 |
| 213-4 | 1.0938 | 0.8925 | 81.13 | 18.87 |
| 213-5 | 1.1229 | 0.9246 | 81.88 | 18.12 |
| 213-6 | 1.1317 | 0.9341 | 82.09 | 17.91 |
| 213-7 | 1.0636 | 0.8820 | 82.48 | 17.52 |
| 213-8 | 1.0942 | 0.9025 | 82.03 | 17.97 |
| 213-9 | 1.0766 | 0.8854 | 81.78 | 18.22 |
| 213-10 | 0.9977 | 0.8225 | 81.99 | 18.01 |
| average | | | 81.85 | 18.15 |
| confidence limit | | | 0.32 | 0.32 |
| SD | | | 0.45 | 0.45 |
| RSD % | | | 0.55 | 2.48 |

Carpet samples PP/PAC (samples 246 – 257)

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 246-1 | 0.9785 | 0.8245 | 83.85 | 16.15 |
| 246-2 | 0.9507 | 0.8029 | 84.04 | 15.96 |
| 246-3 | 0.9607 | 0.8102 | 83.92 | 16.08 |
| 246-4 | 0.9766 | 0.8249 | 84.05 | 15.95 |
| 246-5 | 0.9673 | 0.8145 | 83.79 | 16.21 |
| average | | | 83.93 | 16.07 |
| confidence limit | | | 0.15 | 0.15 |
| SD | | | 0.12 | 0.12 |
| RSD % | | | 0.14 | 0.74 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 246*-1 | 1.0650 | 0.7757 | 72.22 | 27.78 |
| 246*-2 | 1.0301 | 0.7518 | 72.37 | 27.63 |
| 246*-3 | 1.0206 | 0.7427 | 72.15 | 27.85 |
| 246*-4 | 1.0465 | 0.7617 | 72.17 | 27.83 |
| 246*-5 | 1.0521 | 0.7658 | 72.17 | 27.83 |
| average | | | 72.21 | 27.79 |
| confidence limit | | | 0.11 | 0.11 |
| SD | | | 0.09 | 0.09 |
| RSD % | | | 0.12 | 0.32 |

* PAC separated from carpet sample 246

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 247-1 | 0.9414 | 0.8419 | 89.13 | 10.87 |
| 247-2 | 0.9649 | 0.8620 | 89.04 | 10.96 |
| 247-3 | 0.9503 | 0.8493 | 89.07 | 10.93 |
| 247-4 | 0.9657 | 0.8622 | 88.98 | 11.02 |
| 247-5 | 0.9830 | 0.8787 | 89.09 | 10.91 |
| average | | | 89.06 | 10.94 |
| confidence limit | | | 0.07 | 0.07 |
| SD | | | 0.06 | 0.06 |
| RSD % | | | 0.06 | 0.53 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 247*-1 | 0.9894 | 0.8061 | 81.00 | 19.00 |
| 247*-2 | 1.1308 | 0.9236 | 81.21 | 18.79 |
| 247*-3 | 0.9993 | 0.8156 | 81.15 | 18.85 |
| 247*-4 | 0.9609 | 0.7847 | 81.19 | 18.81 |
| 247*-5 | 1.0522 | 0.8575 | 81.02 | 18.98 |
| average | | | 81.11 | 18.89 |
| confidence limit | | | 0.12 | 0.12 |
| SD | | | 0.10 | 0.10 |
| RSD % | | | 0.12 | 0.51 |

* PAC separated from carpet sample 247

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 248-1 | 0.9386 | 0.8930 | 95.00 | 5.00 |
| 248-2 | 0.8983 | 0.8545 | 94.98 | 5.02 |
| 248-3 | 0.9019 | 0.8580 | 94.99 | 5.01 |
| 248-4 | 0.9423 | 0.8958 | 94.92 | 5.08 |
| 248-5 | 0.9246 | 0.8775 | 94.75 | 5.25 |
| average | | | 94.93 | 5.07 |
| confidence limit | | | 0.13 | 0.13 |
| SD | | | 0.10 | 0.10 |
| RSD % | | | 0.11 | 2.00 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 248*-1 | 1.0771 | 0.9845 | 91.16 | 8.84 |
| 248*-2 | 1.0323 | 0.9442 | 91.22 | 8.78 |
| 248*-3 | 1.0878 | 0.9936 | 91.09 | 8.91 |
| 248*-4 | 1.0938 | 1.0004 | 91.22 | 8.78 |
| 248*-5 | 1.0872 | 0.9935 | 91.13 | 8.87 |
| average | | | 91.16 | 8.84 |
| confidence limit | | | 0.07 | 0.07 |
| SD | | | 0.05 | 0.05 |
| RSD % | | | 0.06 | 0.62 |

* PAC separated from carpet sample 248

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|----------|------------------|-------------------|----------------|--------------|
| 249-1 | 0.9397 | 0.7935 | 84.03 | 15.97 |
| 249-2 | 0.9231 | 0.7823 | 84.34 | 15.66 |
| 249-3 | 0.9298 | 0.7863 | 84.16 | 15.84 |
| 249-4 | 0.9590 | 0.8075 | 83.78 | 16.22 |
| 249-5 | 0.9377 | 0.7900 | 83.83 | 16.17 |
| | | average | 84.03 | 15.97 |
| | | confidence limit | 0.29 | 0.29 |
| | | SD | 0.23 | 0.23 |
| | | RSD % | 0.27 | 1.44 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|----------|------------------|-------------------|----------------|--------------|
| 249*-1 | 1.0585 | 0.7725 | 72.36 | 27.64 |
| 249*-2 | 1.0487 | 0.7659 | 72.42 | 27.58 |
| 249*-3 | 1.0482 | 0.7657 | 72.43 | 27.57 |
| 249*-4 | 1.0583 | 0.7730 | 72.43 | 27.57 |
| 249*-5 | 1.0601 | 0.7749 | 72.48 | 27.52 |
| | | average | 72.42 | 27.58 |
| | | confidence limit | 0.05 | 0.05 |
| | | SD | 0.04 | 0.04 |
| | | RSD % | 0.06 | 0.15 |

* PAC separated from carpet sample 249

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|----------|------------------|-------------------|----------------|--------------|
| 250-1 | 1.0510 | 0.9461 | 89.74 | 10.26 |
| 250-2 | 1.1446 | 1.0253 | 89.28 | 10.72 |
| 250-3 | 1.1050 | 0.9927 | 89.55 | 10.45 |
| 250-4 | 1.0802 | 0.9692 | 89.43 | 10.57 |
| 250-5 | 1.1322 | 1.0143 | 89.29 | 10.71 |
| | | average | 89.46 | 10.54 |
| | | confidence limit | 0.24 | 0.24 |
| | | SD | 0.19 | 0.19 |
| | | RSD % | 0.21 | 1.80 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|----------|------------------|-------------------|----------------|--------------|
| 250*-1 | 1.0339 | 0.8466 | 81.42 | 18.58 |
| 250*-2 | 1.0435 | 0.8546 | 81.43 | 18.57 |
| 250*-3 | 1.0364 | 0.8502 | 81.57 | 18.43 |
| 250*-4 | 1.0463 | 0.8569 | 81.43 | 18.57 |
| 250*-5 | 1.0471 | 0.8586 | 81.53 | 18.47 |
| | | average | 81.48 | 18.52 |
| | | confidence limit | 0.09 | 0.09 |
| | | SD | 0.07 | 0.07 |
| | | RSD % | 0.09 | 0.38 |

* PAC separated from carpet sample 250

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|----------|------------------|-------------------|----------------|--------------|
| 251-1 | 1.1459 | 1.0899 | 94.97 | 5.03 |
| 251-2 | 1.1015 | 1.0479 | 94.99 | 5.01 |
| 251-3 | 1.0929 | 1.0380 | 94.83 | 5.17 |
| 251-4 | 1.1059 | 1.0520 | 94.98 | 5.02 |
| 251-5 | 1.1068 | 1.0558 | 95.25 | 4.75 |
| | | average | 95.00 | 5.00 |
| | | confidence limit | 0.19 | 0.19 |
| | | SD | 0.15 | 0.15 |
| | | RSD % | 0.16 | 3.10 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 251*-1 | 1.0021 | 0.9161 | 91.17 | 8.83 |
| 251*-2 | 1.0067 | 0.9206 | 91.20 | 8.80 |
| 251*-3 | 1.0064 | 0.9189 | 91.06 | 8.94 |
| 251*-4 | 1.0199 | 0.9321 | 91.14 | 8.86 |
| 251*-5 | 1.0494 | 0.9591 | 91.15 | 8.85 |
| average | | | 91.14 | 8.86 |
| confidence limit | | | 0.07 | 0.07 |
| SD | | | 0.05 | 0.05 |
| RSD % | | | 0.06 | 0.61 |

* PAC separated from carpet sample 251

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 252-1 | 1.0652 | 0.8978 | 83.87 | 16.13 |
| 252-2 | 1.1356 | 0.9581 | 83.96 | 16.04 |
| average | | | 83.91 | 16.09 |
| confidence limit | | | 0.55 | 0.55 |
| SD | | | 0.06 | 0.06 |
| RSD % | | | 0.07 | 0.38 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 252*-1 | 1.3084 | 0.9531 | 72.23 | 27.77 |
| 252*-2 | 1.3105 | 0.9551 | 72.26 | 27.74 |
| 252*-3 | 1.2925 | 0.9415 | 72.22 | 27.78 |
| average | | | 72.24 | 27.76 |
| confidence limit | | | 0.05 | 0.05 |
| SD | | | 0.02 | 0.02 |
| RSD % | | | 0.03 | 0.08 |

* PAC separated from carpet sample 252

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 253-1 | 1.0612 | 0.9500 | 89.23 | 10.77 |
| 253-2 | 1.0658 | 0.9538 | 89.20 | 10.80 |
| average | | | 89.21 | 10.79 |
| confidence limit | | | 0.19 | 0.19 |
| SD | | | 0.02 | 0.02 |
| RSD % | | | 0.02 | 0.20 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 253*-1 | 1.3063 | 1.0684 | 81.32 | 18.68 |
| 253*-2 | 1.2984 | 1.0620 | 81.33 | 18.67 |
| 253*-3 | 1.2969 | 1.0605 | 81.30 | 18.70 |
| average | | | 81.32 | 18.68 |
| confidence limit | | | 0.03 | 0.03 |
| SD | | | 0.01 | 0.01 |
| RSD % | | | 0.01 | 0.06 |

* PAC separated from carpet sample 253

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|------------------|------------------|-------------------|----------------|--------------|
| 254-1 | 1.0655 | 1.0128 | 94.91 | 5.09 |
| 254-2 | 0.9837 | 0.9371 | 95.12 | 4.88 |
| average | | | 95.01 | 4.99 |
| confidence limit | | | 1.36 | 1.36 |
| SD | | | 0.15 | 0.15 |
| RSD % | | | 0.16 | 3.05 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|----------|------------------|-------------------|----------------|--------------|
| 254*-1 | 1.2447 | 1.1401 | 91.35 | 8.65 |
| 254*-2 | 1.3006 | 1.1924 | 91.44 | 8.56 |
| 254*-3 | 1.2007 | 1.0915 | 90.65 | 9.35 |
| | | average | 91.15 | 8.85 |
| | | confidence limit | 1.08 | 1.08 |
| | | SD | 0.44 | 0.44 |
| | | RSD % | 0.48 | 4.93 |

* PAC separated from carpet sample 254

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|----------|------------------|-------------------|----------------|--------------|
| 255-1 | 1.1146 | 0.9426 | 84.16 | 15.84 |
| 255-2 | 1.1133 | 0.9422 | 84.22 | 15.78 |
| 255-3 | 1.1551 | 0.9778 | 84.24 | 15.76 |
| 255-4 | 1.1532 | 0.9767 | 84.29 | 15.71 |
| 255-5 | 1.1090 | 0.9384 | 84.21 | 15.79 |
| 255-6 | 1.1176 | 0.9462 | 84.26 | 15.74 |
| | | average | 84.23 | 15.77 |
| | | confidence limit | 0.05 | 0.05 |
| | | SD | 0.04 | 0.04 |
| | | RSD % | 0.05 | 0.28 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|----------|------------------|-------------------|----------------|--------------|
| 256-1 | 1.1349 | 1.0161 | 89.24 | 10.76 |
| 256-2 | 1.1084 | 0.9931 | 89.30 | 10.70 |
| 256-3 | 1.1065 | 0.9918 | 89.34 | 10.66 |
| 256-4 | 1.1466 | 1.0281 | 89.37 | 10.63 |
| 256-5 | 1.0987 | 0.9856 | 89.42 | 10.58 |
| | | average | 89.33 | 10.67 |
| | | confidence limit | 0.08 | 0.08 |
| | | SD | 0.07 | 0.07 |
| | | RSD % | 0.08 | 0.64 |

| JRC code | sample mass g | residue mass g | insoluble % | soluble % |
|----------|------------------|-------------------|----------------|--------------|
| 257-1 | 1.0111 | 0.9609 | 94.89 | 5.11 |
| 257-2 | 1.0957 | 1.0412 | 94.88 | 5.12 |
| 257-3 | 1.0246 | 0.9729 | 94.80 | 5.20 |
| 257-4 | 1.0881 | 1.0340 | 94.88 | 5.12 |
| 257-5 | 1.1376 | 1.0809 | 94.87 | 5.13 |
| 257-6 | 1.0391 | 0.9865 | 94.79 | 5.21 |
| | | average | 94.85 | 5.15 |
| | | confidence limit | 0.05 | 0.05 |
| | | SD | 0.04 | 0.04 |
| | | RSD % | 0.05 | 0.84 |

EUR 24574 EN – Joint Research Centre – Institute for Health and Consumer Protection

Title: Fibre Labelling - Polypropylene/polyamide bicomponent - Aquafil

Author(s): P. Piccinini, R. Álvarez-Sarandes, M. de Sertorio, M. Trantallidi

Luxembourg: Publications Office of the European Union

2010 – 232 pp. – 21.0 x 29.7 cm

EUR – Scientific and Technical Research series – ISSN 1018-5593

ISBN 978-92-79-17456-8

doi:10.2788/36853

Abstract

In August 2007, the European Commission's Joint Research Centre (JRC) was entrusted by DG Enterprise to verify the validity and applicability of the testing methods, proposed by Aquafil S.p.A., for the identification and quantification of their new fibre (PAC). Developed for carpet applications, the fibre contains polyamide fibrils in polypropylene matrix (islands-in-the-sea).

Experimental results confirmed that identification of PAC can be achieved using Scanning Electronic Microscope (SEM) analysis, after dissolving the polyamide fibrils with formic acid. Additionally, Fourier Transform Infrared Spectroscopy (FT-IR) and Differential Scanning Calorimetry (DSC) can be used as techniques to differentiate PAC from binary mixtures made of polypropylene (PP) and polyamide (PA) fibres.

For quantification purposes, experiments showed that ventilated oven can be used, instead of the vacuum one proposed by the applicant, without damaging the fibre. The normal pre-treatment described in Directive 96/73/EC, was proved to be applicable to PAC and its correction factor *b* for mass loss during pre-treatment was established (0 %). The *agreed allowance* of the new fibre was measured (0.40 %) and the established value, adopted by the European network of national experts on Textile Labelling (ENNETL), was 1.00 %. The solubility properties of PAC were evaluated with all methods described in Directive 96/73/EC. The solubility behaviour of PA6 and PP was studied as well, in case the information is not included in the same Directive. The new fibre was insoluble in methods 1, 2, 5-11 and 14. The *d* correction factors were established on the basis of the experimental work carried out by the JRC and, in the case of methods 2, 8 and 11, confirmed through a collaborative trial at European level. The resulting values were: 1.00 for methods 1, 2, 5, 6, 8-10, 1.005 for method 11 and 1.01 for methods 7 and 14. PP was insoluble in methods 1, 3, 5-11, 14 and 16; the average *d* factor values were 1.00 in all cases. PA6 was insoluble in methods 5 and 10 and the average *d* factor values were 1.00 and 1.01, respectively. Experts agreed that only the correction factors *d* for PAC and PP shall be inserted in Directive 96/73/EC, as the ones for PA were measured only on PA6.

For the quantification of PA in PAC, the three methods proposed by the applicant (hydrolysis, DSC and FTIR) were examined by the JRC. Additionally, a series of chemical dissolution methods were investigated in order to find accurate and less time-consuming alternative methods for this quantification. PA in PAC was quantified *via* elemental analysis, on the basis of the nitrogen content of PAC samples, to obtain results that could be considered as reference values. Among the tested methods, method 16 of Directive 96/73/EC was proved to be the most accurate and non time-consuming. It was, therefore, proposed by the JRC and agreed by experts as the suitable method to quantify PA in PAC.

For the quantification of PAC in binary mixtures, manual separation is an adequate technique, whenever applicable. Several alternative methods were studied for mixtures with PP or PA and their accuracy evaluated by comparison of quantitative results to the reference values obtained *via* manual separation. Method 16 of Directive 96/73/EC was proved to be accurate for the quantification of binary mixtures PP/PAC; however, this quantification can only be achieved if the PA content of PAC is known or a quantity of PAC can be separated and analysed. Method 11 of Directive 96/73/EC was considered very accurate for the quantification of binary mixtures PA/PAC and was proposed by the JRC. As agreed during the 10th ENNETL meeting, a collaborative trial was organised by the JRC to validate method 11, in accordance with the rules laid down in ISO 5725 (1994). On the basis of successful results, experts agreed that the field of application of method 11 in Directive 96/73/EC shall be extended to the quantification of binary mixtures PA/PAC. Moreover, the modified washing procedure, needed to achieve a correct quantification of binary mixtures with high percentages of PA fibres, shall be added in the method's description together with the established precision of the analytical method, expressed as reproducibility limit (2 %).

Based on experimental results, discussions during the 9th, 10th and 11th ENNETL meetings and written consultation with national experts, the name and definition agreed and proposed for the new fibre were "polypropylene/polyamide bicomponent: a bicomponent fibre composed of between 10 % and 25 % by mass of polyamide fibrils embedded in polypropylene matrix".

How to obtain EU publications

Our priced publications are available from EU Bookshop (<http://bookshop.europa.eu>), where you can place an order with the sales agent of your choice.

The Publications Office has a worldwide network of sales agents. You can obtain their contact details by sending a fax to (352) 29 29-42758.

The mission of the JRC is to provide customer-driven scientific and technical support for the conception, development, implementation and monitoring of EU policies. As a service of the European Commission, the JRC functions as a reference centre of science and technology for the Union. Close to the policy-making process, it serves the common interest of the Member States, while being independent of special interests, whether private or national.

