

Proceedings of the EURL-FCM training workshop 2015 "Science collaborations behind safety in innovation for FCM"

*22 September 2015
Ispra*

C. Simoneau (ed)

2015



Proceedings of the EURL-FCM training workshop 2015 "Science collaborations behind safety in innovation for FCM"

This publication is a Technical report by the Joint Research Centre, the European Commission's in-house science service. It aims to provide evidence-based scientific support to the European policy-making process. The scientific output expressed does not imply a policy position of the European Commission. Neither the European Commission nor any person acting on behalf of the Commission is responsible for the use which might be made of this publication.

JRC Science Hub

<https://ec.europa.eu/jrc>

JRC98592

ISBN 978-92-79-53913-8 (PDF)

doi:10.2788/44507 (online)

© European Union, 2015

Reproduction is authorised provided the source is acknowledged.

All images © European Union 2015

How to cite: C. Simoneau (ed); Proceedings of the EURL-FCM training workshop 2015 "Science collaborations behind safety in innovation for FCM"; doi:10.2788/44507

Table of contents

Abstract	4
1. Introduction	5
2. Agenda.....	6
3. Presentations	7
A look back to advances from RTD for food contact – Dr Catherine Simoneau, European Commission Joint Research Centre, Ispra, Italy	7
Safemtech: Safety in Use and Emerging Technologies in Food Packaging Pathways (IAPP) 2010-2014 - Dr. Jesús Salafranca, University of Zaragoza Spain.....	17
SafeFoodPack Design: design of barrier and systems - Dr. Olivier Vitrac, INRA AgroParisTech, Paris France	35
Migration testing and modeling of nanoparticles from nano-polymer- composites. A collaboration with Plastic Europe, the European Carbon Black Association and from the European Silica producer association - Dr. Angela Stoermer, IVV Fraunhofer institute.....	85
SAFE bread TIN: lowering energy and contaminants in bread and rusk tins - Dr. Ronan Cariou, ONIRIS	103
Matrix exposure tool for public use - Dario Dainelli, EUPC / Matrix group	131
4. List of participants	147

Abstract

The JRC organised a workshop for the network of National Reference Laboratories to provide the latest state of the art look at "science behind innovation and safety for food contact materials".

Invited presentations were selected to represent relevant forward looking recent or on-going research projects at national or regional levels with a focus on collaborations across institutions and with industries. These included a short review on advances for food contact from RTD projects, a briefing on a Marie Curie Project dedicated to the safety in Use and emerging technologies in food packaging pathways (Safemtech) a National Project dedicated to the design of barrier and systems (SafeFoodPack Design), a Research project from a collaboration from professional Association and a national institute on migration testing and modelling of nanoparticles from nano-polymer-composites, a national project on lowering energy and contaminants in bread and rusk tins, an inter-industry project by professional associations on developing migration testing guidelines for non-harmonised areas, and a professional association funded FCM "matrix" exposure tool for public use.

The event promoted better access to information and fostered the use of state of the art progress in innovative applied research to open up practical ideas and networking contacts for future.

1. Introduction

Food availability, abundance and safety are paramount to feed the growing world population. Packaging protects food against microbiological /chemical contaminations, bioterrorism and product tampering, it is a physical support to information (ensuring traceability in the food chain), and is the key to achieve long lasting quality and shelf life of foods. Innovation is therefore a major driver. Yet, while new materials and technologies are constantly being developed, these must also be safe.

The JRC organised a workshop for the network of National Reference Laboratories to provide the latest state of the art look at science behind innovation and safety for food contact materials. Invited presentations were selected to represent relevant forward looking recent or on-going research projects at national or regional levels with a focus on collaborations across institutions and with industries. The event aimed to promote access to information and foster the use of state of the art progress in innovative applied research to open up practical ideas and networking contacts for future.

The presentations are reported in the next sections together with the agenda of the day.

2. Agenda

- 09:00-09:15 Arrival at the Joint Research Centre // Welcome // Welcome coffee //
- 09:20-09:50 A look back to advances from RTD for food contact
C. Simoneau, JRC
- 09:55-10:25 Safemtech: Safety in Use and Emerging Technologies in Food Packaging Pathways (IAPP) 2010-2014
Dr. Jesús Salafranca, University of Zaragoza Spain
- 10:30-11:00 Coffee break
- 11:00-11:30 SafeFoodPack Design: design of barrier and systems
Dr. Olivier Vitrac, INRA Agroparistech, Paris France
- 11:35-12:05 Migration testing and modeling of nanoparticles from nano-polymer-composites. A collaboration with Plastic Europe, the European Carbon Black Association and from the European Silica producer association
Dr. Angela Stoermer, IVV Fraunhofer institute, Freising, Germany
- 12:10-12:40 SAFE bread TIN: lowering energy and contaminants in bread and rusk tins
Dr. Ronan Cariou, ONIRIS, Nantes, France
- 12:40-13:00 Q&A
- 13:00-14:30 Lunch / Buffet
- 14:30-15:00 Migration testing guidelines- a professional association initiative for the non harmonised areas
Peter Oldring, Facet Industry group
- 15:05-15:35 Matrix exposure tool for public use
Dario Dainelli, EUPC / Matrix group
- 16:10-17:00 Q&A and end of meeting

A look back to advances from RTD for food contact – Dr Catherine Simoneau, European Commission Joint Research Centre, Ispra, Italy



Science behind Safety and innovation for FCM



www.jrc.ec.europa.eu

Catherine Simoneau
Institute for Health and Consumer Protection
Chemical Assessment and Testing Unit

Serving society
Stimulating innovation
Supporting legislation

A world of man made materials



Conventional :

- Plastics, including multilayers
- Regenerated cellulose, Paper and board,
- Glass and ceramics,
- Elastomers, Metals, Wood, textile, waxes etc.

FCM is a technologically driven sector



These bottles are 30% plant based (sugar cane)-
in operation since 2011 in DK
Source: <http://www.hevergedaily.com>



Biobased plastics for yoghurt: use 43% less fossil
resources compared to the polystyrene containers
Source: <http://www.sustainablebrands.com>



PET: FCM PET is recycled for food
and non food uses: In 2011 39% rPET
in the EU into fibres, 25% into pack
containers.

Source: <http://www.pet-core-europe.org/>

Sustainable: do more with less!

- Biobased: made from renewable sources
- Recycled: PET recycling including for FCM

Innovative materials??

Active materials:

acts on atmosphere inside package

- Antibacterial, antioxidant etc

*Antibacterial
bags and boxes*



Intelligent:

follow quality during shelf life

- indicators of temperature.
- Freshness/spoilage
- integrity /leakage

Including nano



*protect beer from
"UV burn"*



*Protecting juices
against light that
damages vitamins*



*nanoTitantium filter;
antibacterial, anti
odour (deo), trap
for dust particles*

A number of regulatory frameworks..



Functionality

- Handle & protect
- Advertise and inform (labelling)

Product Safety

- General Safety
- Liability



Food Safety

- Food law
- Food contact legislation
- Food Official Controls

Environment

- Waste
- Sustainability




Importance of the consumer's voice

Package



INTERACTION



Foods



ACCEPTABILITY OF PACKED FOOD
By the consumer



Success in innovation means safety by design...

ASPECTS OF FOOD SAFETY

- Ensure chemical safety
- Provide for regulatory compliance



Innovations means science behind

- http://cordis.europa.eu/home_en.html
 - Large EU investments in research via Framework programmes
 - FP 5 
 - FP6 
 - FP7 
 - Horizon 2020 
 - Other RTD tools – Cost, Marie Curie etc
 - National projects
- ⇒ Many research projects multipartners have led to innovative concepts, and some to anticipate developments for harmonised legislative options....

Examples of FP7 projects

NANOPACK- ICT 216176	Nano packaging technology for interconnect and heat dissipation (2007-2010)
FACET-KBBE 211686	Flavours, additives and food contact material exposure task (2008-2012)
NAFISPACK-KBBE 212544	Natural antimicrobials for innovative and safe packaging (2008-2011)
PERFOOD-KBBE – 227525	PERFluorinated Organics in Our Diet"Perfluorinated Organic Compounds in the Foodchain: a Risk Analysis to Support Government Policy"
FLEXPARENEW-NMP 207810	Design and development of an innovative ecoefficient low-substrate flexible paper packaging from renewable resources to replace petroleum based barrier films
REBIOFOAM-NMP 214425	Development of a flexible and energy-efficient pressurised microwave heating process to produce 3D-shaped renewable bio-polymer foams for a novel generation of transportation packaging
NANOPACK-PEOPLE 223832	Multifunctional nanomaterials for intelligent food packaging applications (2008-2012)
SAFETECHNOPACK-REGIONAL 202772	Improving the scientific and technological research capacity of food institute on safety and technology of food packaging (2008-2011)
COBAPACK-SME 231106	Development of a new recyclable long life co-injected high barrier packaging for food applications, with broad design possibilities and reduced manufacturing costs (SME)
RPET-FC-SME 232055	Environmentally friendly food packaging tray with lower carbon footprint (2009-2011)
HORTIBIOPACK-SME	Development of innovative biodegradable packaging system to improve shelf life, quality and safety of high-value sensitive horticultural fresh produce (2009-2011)
FRESHFILM-SME 232217	New active recyclable packaging with natural antioxidising for the extension of the fresh food shelf live (2009-2011)
BREW-PACK-SME 232216	Multi-layer biopolymer films demonstrating selective gas barrier and functional properties suitable for high performance food packaging, derived from integrated bio-refining of sustainable biomass (2009-2011)
BIOSURF-SME 232172	Development and implementation of a contact biocide polymer for its application as antimicrobial and anti-deposit surfaces in the food industry (2009-2011)

Example of FP6 projects

SAFE FOOD	through a New Integrated Risk Analysis Approach for Foods
MIGROSURE	migration of chemicals from packaging toward foods.
PERFORCE	Activity New and Emerging Science and Technology
HIGHQ RTE-FOOD 23140	Innovative non-thermal processing technologies to improve the quality and safety of ready-to-eat (RTE) meals
NOVELQ-FOOD 15710	Novel Processing Methods for the Production and Distribution of High-Quality and Safe Foods (2006-2011)
ANTIOXIPACK-FP6-MOBILITY 24183	The design of active packaging for food applications with oxygen scavenging or antioxidant capacity (2005-2007)
MICRO-GMAP-FP6-MOBILITY 42609	Multipurpose tuneable microwave plasma source of germicidal modified atmospheric packaging for food industries (2006-2009)
SUSTAINPACK-FP6-NMP 500311	Innovation and Sustainable Development in the Fibre Based Packaging Value Chain (2004-2008)
POLYCOAT-FP6-NMP 505635	Economical exploitation of polymer coated steel sheet in large-scale production of new can types by the European can industry (2004-2006)
PICUS-FP6-SME 17684	Development of a 100 % Biodegradable Plastic Fiber to Manufacture Twines to Stake Creeping Plants and Nets for Packaging Agricultural Products (2005-2007)
MIGRESIVES-FP6-SME 30309	Research programme on migration from adhesives in food packaging materials in support of European legislation and standardisation (2007-2010)
WHEYLAYER-FP6-SME 218340	Whey protein-coated plastic films to replace expensive polymers and increase recyclability (2008-2011)
ONLINE TRACEABILITY-FP6-SME- 32947	Online quality control and traceability for the food processing industry
FOOD PRO - FP6-SME 508374	Ohmic heating for food processing (FOOD PRO) (2004-2006)
SAFEFILL - FP6-SME 32685	Safe aseptic flexible efficient filling of liquids (2006-2008)

Joint
Research
Centre


RTD projects in anticipation of legislation

FP5 EU TRD "Recyclability":

- Research on recycling of PET plastics (what contaminants can be eliminated or brought by recycling)
⇒ RTD technical guidance
⇒ Peer reviewed publications => acceptance
- Led to a legislation on recycling
- EFSA process for authorisation

Active packaging

- Several research projects (actipack, nafispack etc)
- Many publications with sound data
- Confidence on which to develop a harmonised legislation
- Now also EFSA process for authorisation



Bio materials, Paper and board, adhesives, nanomaterials

Joint
Research
Centre

What has science data given to compliance?

Cannot test on every food: development of "simulants"

Liquids simulating different types of foods (acidic, alcoholic, fatty, dry)- e.g. oil for fatty foods

- ⇒ new inception of Tenax as simulant for dry foods was based on > 10 years research in both academia and in EU projects
- ⇒ Change of milk simulant from 10% to 50% also based on large kinetics within EU project (migrosure, FACET)
- ⇒ Extensions from packaging to kitchenware (at the crossroads of legal principles, pragmatic science and consumer behaviour)




Sound data to support compliance testing

Need to simulate the shelf life

- Exposure of the material to time/ temperature (worst) conditions (with simulants)
- **Faster! modelling**
 - ⇒ development of diffusion modelling also the results of **SMT project 1997-2000**
 - ⇒ Taken into peer referred publications
 - ⇒ Acceptance for regulatory purposes and authorisation
 - ⇒ Taken into practical guide → now in note for guidance
 - ⇒ Recognised for PE, PP, PS, PET, PA
 - ⇒ Now also for more complex systems multilayers, real foods
- **Better: mimic long storage conditions**
 - ⇒ now the use of an Arrhenius equation into legislation

Migration – predictable..

- ▶ D_p - diffusion coefficient
- ▶ $K_{p,F}$ - partition coefficient



$$\frac{\partial c}{\partial t} = D \left(\frac{\partial^2 c}{\partial x^2} + \frac{\partial^2 c}{\partial y^2} + \frac{\partial^2 c}{\partial z^2} \right) + \left(v_1 \frac{\partial c}{\partial x} + v_2 \frac{\partial c}{\partial y} + v_3 \frac{\partial c}{\partial z} \right) + k_1 c^2 + k_2 c$$

$$\frac{\partial c}{\partial t} = D \cdot \frac{\partial^2 c}{\partial x^2}$$

$$t_2 = t_1 \cdot \exp \left(\frac{E_a}{R} \right) \cdot \left(\frac{1}{T_1} - \frac{1}{T_2} \right)$$

Estimation of exposure

Predicting migration

Estimate EU consumer exposure to
Food Contact Material
Substances


RTD project FACET 2008-2012 and
its sustainability



A path towards better exposure assessment

FP6 Food migrosure + FP7 FACET: a new exposure tool

- Research on kinetics of migration from plastics into real food
- Research on assessment of additives flavourings and food contact materials
- Now a software output (JRC entity towards sustainability)
- Tested in an EFSA assessment



FACET can estimate

- *exposure to existing substances in FCMs at varying levels of sophistication*
- *exposure for substances in foods measured in surveillance surveys*
- *exposure to (new or existing) substances from new packaging*
- *exposure to new substances **and NIAS***



Ensuring safety in innovation based on "science with a purpose"



*Thank you
for your
attention!*

Joint
Research
Centre

Page left blank intentionally

Safemtech: Safety in Use and Emerging Technologies in Food Packaging Pathways (IAPP) 2010-2014 - Dr. Jesús Salafranca, University of Zaragoza Spain



 **GOGLIO**



 **Universidad
Zaragoza**

Dr. Jesús Salafranca

**SAFEMTECH: Safety in Use and Emerging Technologies
in Food Packaging Pathways (IAPP) 2010-2014**

***EURL-FCM training workshop "Science collaborations
behind safety in innovation and policy developments"***

ISPRA – Italy

September 22nd, 2015



UNIZAR & GOGLIO

2



instituto de investigación
en ingeniería de Aragón
Universidad de Zaragoza



Head: **Prof. Dr. Cristina Nerín**

Head: **Dr. Osvaldo Bosetti**

experience

- Analytical chemistry
- Food Packaging Interactions
- Diffusion and migration of adhesives in food packaging
- Packaging materials & materials science & technology
- Active food packaging
- Microbiological performance
- Intelligent food packaging
- Chemical sensors



- Food packaging production
- Design of packaging
- Packaging materials & materials science & technology
- Adhesive formulations
- Printing inks
- Engineering
- Production of laminates

multidisciplinary



Universidad
Zaragoza



SAFEMTECH PROJECT

3

"Safety in Use and Emerging Technologies in Food Packaging"
Marie Curie Industry-Academia Partnerships and Pathways (IAPP)

Objective 1:

Study of
ADHESIVE
FORMULATIONS
and
improvement
of their SAFETY
in use in food
packaging

Development of
analytical procedures

Objective 2:


Development
of ACTIVE and
INTELLIGENT
packaging



Universidad
Zaragoza


OBJECTIVES / WORK PACKAGES

4



MANAGEMENT STRUCTURE

5





DELIVERABLES

6

Deliverables	Initial
D 1.1	Migrants identified from actual adhesives
D 1.2	Migration values from actual adhesives
D 2.1	Proposal of new compounds as components of the new formulations
D 2.2	Diffusion values for the new compounds
D 3.1	Prediction of migration by mathematical model
D 3.2	Comparison of data and validation of the model
D 3.3	Training of GOGLIO technicians about the model for migration prediction
D 4.2.1	Proposal of a new antioxidant active packaging
D 4.2.2	Proposal of a new technology for producing active packaging
D 4.3.1	Antioxidant efficiency of the active agents
D 4.3.2	Antioxidant efficiency of the active packaging materials
D 4.4.1	New active antioxidant materials for industrial use
D 4.4.2	New technology for producing new active materials
D 4.4.3	Proposal of international patent on the new active packaging developed and produced
D 5.1	New intelligent packaging



Universidad
Zaragoza



IDENTIFICATION OF NIAS

7

NIAS = Non Intentionally Added Substances

NIAS are all the compounds that could be

- formed during polymerization as by-products of curing reaction...
- or already present into raw material as by-product of their production...
- or degradation products.

For all these reasons, NIAS are unexpected

RISK ASSESSMENT OF NIAS

EUROPEAN LEGISLATION
(EU 10/2011)

NATIONAL LEGISLATION

TOXICITY REPORTS

NO TOXICITY DATA


Threshold of
Toxicological
Concern (TTC)
approach

CRAMER RULES

Class I (Low)
< 1.8 mg/person/day

Class II (Intermediate)
< 0.54 mg/person/day


Class III (High)
< 0.09 mg/person/day




Universidad
Zaragoza

THE BEGINNING: PAA's


8



- **Primary aromatic amines (PAA)** are products from residual isocyanates in polyurethane adhesives, the most used in multilayer plastic packaging materials not completely cured



- PAA can be generated from hydrolysis of polyurethanes when packaging materials are used in acidic medium under retorting conditions ($T > 121^\circ\text{C}$)



18 MULTILAYERS TESTED

UHPLC-Q-TOF/MS^E METHOD

9


Main capabilities

- Powerful analytical system
- Exact mass measurement
- Unique molecular structure assignation
- Very complete software MassLynx[®] with specific modules
- Innovative MS^E: exact mass from precursor ion and daughter fragments in the same run




UHPLC-Q-TOF-MS^E system

- ChemSpider® and SciFinder® databases




Pattern recognition (MarkerLynx XS®)

- Principal component analysis (PCA) discovered 3 sample groups
 - ✓ **Group A:** OPA + CPP
 - ✓ **Group B:** PE
 - ✓ **Group C:** PE/EVOH
- PCA differentiated between the kind of material rather than kind of adhesive
- In other words, the most important **NIAS** seemed to **come from the material itself, not from the adhesive**



RESULTS FROM NIAS DETERMINATION

12




- **MIGRANTS FROM ADHESIVES:** Triphenyl phosphate; 1,6-dioxacyclododecane-7,12-dione; unknown adipate
- **OTHER MIGRANTS:** **1,4-trioxacyclotridecane-8,13-dione** (*adhesive*); dodecane (*LDPE*); caprolactam (*OPA+CPP*); 2,4-di-tert-butylphenol (*LDPE, PE/EVOH, adhesives*); BHT (*LDPE, adhesives*)
- **All the laminates comply with EU legislation** (total PAA < 10 µg·kg⁻¹)

ACTIONS TAKEN WITH PROBLEMATIC MIGRANTS

13

LACTONES

- Found in most of polyurethane adhesives (side-reaction between adipic acid and ethylene glycol)
 - not possible to remove them from the adhesives
 - they migrate very efficiently
 - no experimental data of toxicity available (Cramer class III)
 - not listed in EU 10/2011 (max. migration 10 µg kg⁻¹ food)
- **SUCCESSFUL ACTIONS**
 - **Higher curing time and temperature**
 - **Higher thickness of LDPE**
 - **Incorporation of EVOH as internal layer (functional barrier)**



OTHERS

- Adhesion promoter **3-glycidoxypropyltrimethoxysilane**: FDA approved but not in Europe. **Removed from adhesive formulation and substituted** by 3-aminopropyltriethoxysilane (listed in EU 10/2011)
- One **MDI based adhesive** with high values of PAA has been **substituted by a new adhesive with aliphatic HDI** (risk of formation and migration of PAA completely avoided)

GAMMA IRRADIATION... WHY?

14

- **Gamma radiation** is one of the safest ways for microbiological decontamination of food packaging materials (aseptic filling)



CONS

- High penetration capacity (direct use in containers)
- Treatment at room temperature and atmospheric pressure
- Process parameters versatile
- No residues generation
- Immediate use of irradiated materials



- Possible undesirable changes in materials (chemical, physical, thermal, mechanical and permeability)
- Release of substances present in polymers or generated
- Migration processes

EXPERIMENTAL


15

- **Samples:** thermosealed flexible material bags filled with air / inert gas
- **Analytical technique:** HS-SPME-GC-MS
- **13 industrial multilayer packages representative** of the most usual applications: dry foods, sauces, ready-to-eat meals, hot-filling or aseptic-filling




Sample	Structure (from outer to inner layer)
1	PET ALU PA PE
2	PET ALU PA PP
3	PET ALU PET PE
4	PET ALU PET PP
5	PET PE
6	PET PETmz PE
7	PET PA PE + PP
8	PET coexPE-EVOH
9	PET ALU PE+PB
10	coexPE-EVOH PE
11	PE-ALU-PA-PE PE-PE PE
12	PE-PETmz-PE PE-PE PE
13	LLDPE-PETmz-LLDPE coexLLDPE-EVOH-LLDPE LLDPE






- **Antioxidants** (e.g. BHT) are present in unirradiated materials
- **Hydrocarbons** decrease slightly when irradiating
- **Oxidation compounds** (e.g. 2,6-di-tertbutyl-1,4-benzoquinone) appear as a consequence of gamma irradiation
- **1,3-di-tertbutylbenzene** is the most representative compound generated in irradiated samples

Air, non irradiated, recent




Nitrogen, non irradiated, recent




Very similar profiles

Air, 15 kGy, recent



Nitrogen, 15 kGy, recent




Oxidation (air)
Aromatics (> N₂)
Esters (N₂)




EFFECT OF IRRADIATION DOSE

18


Air, 15 kGy, recent




Air, 25 kGy, recent



N₂, 15 kGy, recent



N₂, 25 kGy, recent



Only small differences between 15 and 25 kGy




Universidad
Zaragoza




EFFECT OF LONG-TERM STORAGE

19


Air, non irradiated, 8 months




Nitrogen, non irradiated, 8 months



Air, 15 kGy, 8 months



Nitrogen, 15 kGy, 8 months



- **Profiles almost identical** between recent and 8-month storage samples
- **Generalized reduction (~45%)** of all the compounds
- **Fast initial release**, then slow reabsorption by the polymeric matrix (*equilibrium*)



Universidad
Zaragoza



QUANTITATIVE RESULTS (ng·dm⁻²)

20

Sample	acid	alcohol	aldehy.	alkane	alkene	aox	aromatic	cyclic	ester	ether	ketone	oxid.	Total
001	0*	63	0*	40	50	3	50	409	120	9	24	7	775
015	24	44	11	3	5	0*	1021	47	194	66	98	34	1547
032	24	54	15	2	4	0*	1040	48	216	93	124	38	1658
047	0*	61	3	47	49	2	43	408	115	7	29	7	771
063	2*	15	19	0*	4	0*	1033	23	174	87	47	1	1405
094	0*	155	14	195	356	0*	2	92	85	14	7	1	921
122	0*	92	1	147	209	0*	179	8	55	95	50	11	847
146	1*	113	1	190	106	0*	156	63	95	26	1	20	772
170	0*	131	10	302	216	0*	2	99	83	12	8	1	864
191	1*	77	1	128	333	0*	310	16	94	40	5	5	1010
230	0*	73	0*	50	129	4	44	71	66	5	15	6	463
...

- **None** of the **non-listed substances** and **NIAS** identified and quantified **surpassed the limit of 10 µg·kg⁻¹** (equivalent to 1670 ng·dm⁻²) established in Commission Regulation (EU) No 10/2011




Universidad
Zaragoza




SET-OFF MIGRATION

21

MULTILAYER MATERIAL




CONVENTIONAL MIGRATION



Universidad
Zaragoza

SET-OFF MIGRATION

22



SET-OFF MIGRANTS FROM INKS (UPLC-Q-TOF)

23

Migrants (RT _{mass})	Intens. (1-3)	Adduct	Molecular formula	Candidates	$\Delta mDa / \Delta ppm$	Remarks
4.93_299.1108	2	MNa ⁺	C ₁₂ H ₂₀ O ₇	Citric acid triethyl ester CAS: 77-93-0	0.3/1.0	Plastizicer in packaging ink
5.63_285.2909	2	MH ⁺	C ₁₇ H ₃₆ N ₂ O	Schercodine CAS: 3179-80-4	0.4/1.4	Emulsifier
5.92_271.1885	1	MNa ⁺	C ₁₃ H ₂₈ O ₄	Tripropyleneglycol monobutyl ether CAS: 55934-93-5	-0.2/-0.7	Packaging ink solvent
5.96_299.1835	2	MNa ⁺	C ₁₄ H ₂₈ O ₅	Triethylene glycol caprylate CAS: 28397-10-6	0.0/0.0	Surfactant: emulsify, lubricate
6.09_313.3217	2	MH ⁺	C ₁₉ H ₄₀ N ₂ O	Schercodine M/ Myristamidopropyl dimethylamine CAS: 45267-19-4	-0.4/-1.3	Non-ionic surfactants
6.39_343.2965	1	MH ⁺	C ₁₉ H ₃₈ N ₂ O ₃	Lauramidopropyl betaine CAS: 4292-10-8	-0.1/-0.3	Surfactant
6.98_425.2151	2	MNa ⁺	C ₂₀ H ₃₄ O ₈	Acetyl tributyl citrate CAS: 77-90-7	1.1/2.6	Plastizicer



SCIENTIFIC PUBLICATIONS

24

1. **D. Pezo, M. Fedeli, O. Bosetti, C. Nerín.** Aromatic amines from polyurethane adhesives in food packaging: The challenge of identification and pattern recognition using Quadrupole-Time of Flight-Mass Spectrometry^E. *Analytica Chimica Acta*, 756 (2012), 49–59.
2. **J.S. Félix, F. Isella, O. Bosetti, C. Nerín.** Analytical tools for identification of non-intentionally added substances (NIAS) coming from polyurethane adhesives in multilayer packaging materials and their migration into food simulants. *Analytical and Bioanalytical Chemistry* 403 (2012) 2869–2882.
3. **F. Isella, E. Canellas, O. Bosetti, C. Nerín.** Migration of non intentionally added substances from adhesives by UPLC–Q-TOF/MS and the role of EVOH to avoid migration in multilayer packaging materials. *Journal of Mass Spectrometry* 48 (2013) 430–437.



SCIENTIFIC PUBLICATIONS

25

4. **D. Carrizo, G. Gullo, O. Bosetti, C. Nerín.** Development of an active food packaging system with antioxidant properties based on green tea extract. *Food Additives & Contaminants: Part A* 31 (2014) 364–373.
5. **M. Aznar, C. Domeño, C. Nerín, O. Bosetti.** Set-off of non volatile compounds from printing inks in food packaging materials and the role of lacquers to avoid migration. *Dyes and Pigments* 114 (2015) 85–92.
6. **J. Salafranca, I. Clemente, F. Isella, C. Nerín, O. Bosetti.** Influence of oxygen and long term storage on the profile of volatile compounds released from polymeric multilayer food contact materials sterilized by gamma irradiation. *Analytica Chimica Acta* 878 (2015) 118–130.



7. Partition, diffusion and migration of 1,4,7-trioxocyclotridecane-8,13-dione, a non-intentionally added compound, from polyurethane adhesives in multilayer food packaging and the barrier effect of EVOH. *Packaging Technology and Science* (2015) *Under review*.
8. Development of an innovative multilayer antimicrobial packaging material for tomato sauce *Food Control* (2015) *Under review*.
9. Extension of shelf life of two fatty foods using an active antioxidant multilayer packaging system containing green tea extract. *Food Control* (2015) *Under review*.
10. Set-off of volatile compounds in multilayer food packaging and specific migration (2015) *In preparation*.
11. Migration from printing inks in multilayer packaging materials by GC-MS analysis and pattern recognition with chemometrics. (2015) *In preparation*.



Several scientific presentations were done during the Project to disseminate the results of SAFEMTECH. Relevant information is available in the website (<http://www.safemtech.eu/>)



- **SPECIFIC SEMINAR** "Adhesives: how could they affect food packaging safety?" organized in Varese (Italy) during the second year of the project. 9 talks were presented, with 138 attendees from the industry outside the Project.



- **CLOSING CONFERENCE** organized in Zaragoza (Spain) at the end of the project. 10 talks were given, with more than 60 attendees present, most of them from the industrial sector.



- Recently, two conferences to disseminate the success and results of SAFEMTECH project were given in **HISPACK 2015**:
 - **O. Bosetti**: "TRADEIT Brokerage Event of Packaging"
 - **C. Nerín**: "Migración de adhesivos y su aplicación a film multicapa: proyecto SAFEMTECH"



DISSEMINATION ACTIVITIES

28



- D. Pezo, M. Fedeli, O. Bosetti, C. Nerín "Determinación de aminas alifáticas y aromáticas e identificación de otros migrantes de films multicapas para alimentos por Q-TOF MASAS[^]E". 13^{as} Jornadas de Análisis Instrumental. November 2011, Barcelona, Spain.



- J.S. Félix, F. Isella, O. Bosetti, C. Nerín "Analytical tools for identification of non intentionally added substances (NIAS) coming from polyurethane adhesives in multilayer packaging materials and their migration into food simulants". 5th International Symposium on Recent Advanced in Food Analysis (RAFA). November 2011, Prague, Czech Republic.



- A. Maccagnan, D. Carrizo, J. Félix, O. Bosetti, C. Nerín "Multi-analysis of 1,4,7-trioxocyclotridecane-8,13-dione in polyurethane adhesive used in multilayer food packaging". 26th Symposium on Packaging IAPRI. June 2013, Espoo, Finland.



- J. Salafranca, F. Isella, O. Bosetti, C. Nerín "Migration of volatile NIAS from food packaging multilayer materials". FIRST AWARD TO POSTER PRESENTATIONS. Swiss Food Science Meeting. June 2013, Neuchâtel, Switzerland.




Universidad
Zaragoza



DISSEMINATION ACTIVITIES

29



- C. Nerín, M. Aznar, P. Alfaro "UPLC-MS-QTOF as a tool for identifying non volatile NIAS from food packaging materials". Swiss Food Science Meeting. June 2013, Neuchâtel, Switzerland.



- C. Nerín "Natural antioxidants anchored on packaging to increase the shelf life. A different perspective". SLIM 2014, June 2014, Brunswick, USA.



- C. Nerín "The new challenges of food packaging materials". The 2nd International Conference of Packaging Technology and Science & The 2nd Asian Packaging Network Conference. October 2014, Wuxi, China.



- C. Nerín "Discover the latest innovations in active packaging to keep your cakes fresh longer". The cake freshness seminar organized by Puratos. March 2015, Brussels, Belgium.



Universidad
Zaragoza



PATENT: NEW ACTIVE PACKAGING

30

- New green tea-based antioxidant material developed and patented
- All the requirements fulfilled
- Production at industrial level by GOGLIO
- The material is already in the market

WO2014170426 (A1)
"MULTILAYER ASSEMBLY"

(12) INTERNATIONAL APPLICATION PUBLISHED UNDER THE PATENT COOPERATION TREATY (PCT)
(19) World Intellectual Property Organization
(43) International Publication Date: 23 October 2014 (23.10.2014)
(10) International Publication Number: WO 2014/170426 A1

WIPO PCT

(51) International Patent Classification:
B32B 27/02 (2006.01) B32B 27/10 (2006.01)
B32B 15/08 (2006.01) C09F 7/00 (2006.01)
B32B 27/08 (2006.01) B65D 81/00 (2006.01)
B32B 27/18 (2006.01) B65D 65/00 (2006.01)
B32B 29/00 (2006.01)

(21) International Application Number: PCT/EP2014/057882
(22) International Filing Date: 17 April 2014 (17.04.2014)
(25) Filing Language: English
(26) Publication Language: English
(30) Priority Date: 13/04/2013 17 April 2013 (17.04.2013) EP
M2013A000623 17 April 2013 (17.04.2013) IT
(71) Applicant: GOGLIO S.p.A. [IT/IT]; Via A. Solari 10, I-20144 Milan (MI) (IT).
(72) Inventors: BOSETTI, Ovidio; Via Castelli 43, I-21100 Varese VA (IT); FIDELL, Mauro; Via Montecassino 8, I-21049 Trinate VA (IT); NERIN DE LA PUERTA, M.C. Cristina; c/ Paseo de las Damas 5 - 2º A, I-50009 Zaragoza ES (ES); CARROZZA, Daniel; Campus Río Ebro, Edificio Torres Quevedo, Universidad de Zaragoza, c/ María de Lano 3, I-50018 Zaragoza ES (ES).
(74) Agents: PONTIROLI, Alessandro et al.; Piazza San Babila 5, I-20122 Milan MI (IT).

(81) Designated States (unless otherwise indicated, for every kind of national protection available): AE, AG, AL, AM, AO, AT, AU, AZ, BA, BB, BG, BH, BR, BW, BY, BZ, CA, CH, CL, CN, CO, CR, CU, CZ, DE, DK, DM, DO, DZ, EC, EG, ES, FI, GB, GD, GE, GH, GM, GT, HN, HR, HU, ID, IL, IN, JP, KE, KG, KN, KP, KR, KZ, LA, LC, LK, LR, LS, LT, LU, LV, MA, MD, ME, MG, MK, MN, MW, MX, MY, MZ, NA, NG, NI, NO, NZ, OM, PA, PE, PG, PH, PL, PT, QA, RO, RU, RW, SA, SC, SD, SE, SG, SK, SL, SM, ST, SV, SY, TH, TJ, TM, TN, TR, TT, TZ, UA, UG, US, UZ, VC, VN, ZA, ZM, ZW.

(84) Designated States (unless otherwise indicated, for every kind of regional protection available): ARIPO (BW, GH, GM, KE, LR, LS, MW, MZ, NA, RW, SD, SL, SZ, TZ, UG, ZM, ZW), Eurasian (AM, AZ, BY, KG, KZ, RU, TJ, TM), European (AL, AT, BE, BG, CH, CY, CZ, DE, DK, EE, ES, FI, FR, GB, GR, HU, IE, IT, LT, LU, LV, MC, MK, MT, NL, NO, PL, PT, RO, RS, SE, SI, SK, SM, TR), OAPI (BF, BJ, CF, CG, CI, CM, GA, GN, GQ, GW, KM, ML, MR, NE, SN, TD, TG).

Declarations under Rule 4.17:
— of inventorship (Rule 4.17(ii))
Published:
— with international search report (Art. 21(3))



31





instituto de investigación
en ingeniería de Aragón
Universidad de Zaragoza

32



Universidad
Zaragoza



Page left blank intentionally

**SafeFoodPack Design: design of barrier and systems - Dr. Olivier Vitrac,
INRA Agroparistech, Paris France**

JRC, Ispra, Italy
Sept 22, 2015



SAFEFOODPACK DESIGN design of barrier and systems

Olivier Vitrac (coordinator)

olivier.vitrac@agroparistech.fr

UMR 1145 Food Processing and Engineering
Group Interactions between Materials and Media in Contact
AgroParisTech, 91300 Massy, France
<http://modmol.agroparistech.fr>




olivier.vitrac@agroparistech.fr / UMR 1145 Food Processing and Engineering

.01
Sept 2015

KEY FIGURES

- ❖ Project funded by the French National Research Agency (ANR)
- ❖ Reference: ANR_ALIA_009
- ❖ Jan 1st 2011 – Dec 31th 2014
- ❖ 11 partners
- ❖ Budget: 2.8 M€
- ❖ Grant: 790 k€
- ❖ 3 PhDs
- ❖ 3 Post-docs
- ❖ 1 engineer
- ❖ 3 Masters



SAFEFOODPACK DESIGN

.02
Sept 2015

LIST OF TASKS

Task 0 – Project management (INRA)

Task 1 – Deformulation of food packaging materials (LNE, SCL 33, ANIA, JCEP)

Task 2 – Application of FMECA approaches (LNE, INRA, ANIA, France Emballage, JCEP, Storsack)

Task 3 – Inference of expert rules (INRA, LNE)

Task 4 – Scaling D with solute geometry, T-Tg (INRA, UL)

Task 5 – Feeding large databases of K (UB, INRA)

Task 6 – Plasticization due to gas/aroma/lipid sorption (UL, UB, INRA)

Task 7 – Simulation engines (INRA)

Task 8 – Dissemination (CASIMIR, all)




SAFEFOODPACK DESIGN

olivier.vitrac@agroparistech.fr
Sept 2015




.03
Sept 2015

GENERAL GOAL = PREVENTING MIGRATION



.04
Sept 2015

- ❖ _00 ID OF THE PROJECT
- ❖ _01 CONTEXT
- ❖ _02 MIGRATION WITHOUT CONTACT
- ❖ _03 BLIND DEFORMULATION
- ❖ _04 MOLECULAR MODELING: D
- ❖ _05 MOLECULAR MODELING: K
- ❖ _06 PREVENTIVE APPROACHES
- ❖ _07 GENERAL RECOMMENDATIONS



_01



CONTEXT

WHY A NEW PROJECT?

WHY FOCUSING ON DESIGN?


HOW TO MANAGE THE COMPLEXITY OF THE SUPPLY CHAIN,
MANY MATERIALS?



olivier.vitrac@agroparistech.fr / UMR 1145 Food Processing and Engineering

.06
Sept 2015

WHAT IS MIGRATION ?




SAFEFOODPACK DESIGN

.07
Sept 2015

COUPLED MASS TRANSFER


between the food product and the packaging material



additive
food constituent


MIGRATION ISSUES

CROSSED MASS TRANSFER OF FOOD CONTACT MATERIALS AND FOOD CONSTITUENTS




HETEROGENEOUS EU REGULATIONS

Variable concepts



TOWARDS NEW CONCEPTS

PREVENTIVE APPROACHES OF FOOD SAFETY



17 groups of materials listed in Annex 1 of regulation 1935/2004/EC are still not covered by specific measures. They must be produced according to **Good Manufacturing Practices** (Regulation 2023/2006/EC) incl. 3 pillars: quality assurance system, quality control system, documentation.




UMR 1145 Food Processing and Engineering

CHAINED STEPS, COMBINED MATERIALS

Supply chain




CROSSED-MASS TRANSFER BETWEEN MATERIALS



Chain of responsibility along the supply chain


Material vs Information flux






TOWARDS NEW CONCEPTS

DEVELOPING COOPERATION BETWEEN STAKEHOLDERS



TOWARDS NEW CONCEPTS

DEVELOPING COOPERATION BETWEEN STAKEHOLDERS





MIGRATION MODELING

AUTHORIZED/RECOGNIZED IN EU, US, China

At each stage of manufacture, supporting documentation, substantiating the declaration of compliance, should be kept available for the enforcement authorities. Such demonstration of compliance July be based on migration testing. **As migration testing is complex, costly and time consuming it should be admissible that compliance can be demonstrated also by calculations, including modelling, other analysis, and scientific evidence or reasoning if these render results which are at least as severe as the migration testing.** Test results should be regarded as valid as long as formulations and processing conditions remain constant as part of a quality assurance system.

To screen for specific migration the migration potential can be calculated based on the residual content of the substance in the material or article applying generally recognised diffusion models based on scientific evidence that are constructed such as to overestimate real migration.



Sept, 2015


SAFEFOODPACK DESIGN

REGULATION 10/2011/EC

.018
Sept 2015

HOW TO OVERESTIMATE MIGRATION

MODELING CAN DEMONSTRATE COMPLIANCE



.019

ALL SOFTWARE ARE BUILT ON SIMILAR ASSUMPTIONS

http://modmol.agroparistech.fr/SFPP3/SFPP3_migratives/

SFPP3 client/server DIFFUSION_1DFV2n

My Information

My user: **demouser** (change user)
 My project: **common** (change project)
 My database: **common2013a.sfpp3.database.xml**
 My Application: **Diffusion_1DFV2n** (change application)
 INRA/SFPP3 - 2013-04-18 22:03:53

Archived simulations or templates

acetaldehyde_PET3
 Import properties from a previous result file in the current form
 (geometry) (formulation) (contact conditions) (transport prop.) (all)
 Import a concentration profile
 (Concentration profile)
 Clear all properties in the current form
 (form reset)
 Search migrants/data: ☒ Migrants (M,SML...) ☐ Transport Properties
 name/IUPAC:

Contact conditions

☒ L_FP 100 m³F·m⁻³P import
☐ V_F cm³
☐ A_F cm²
 rho_F 1 kg·m⁻³ or g·cm⁻³ import
 k_F 1 import
 Bi 1000000 import
 t 6 months import
☐ Temperature: set import

Layer selector

☒ Layer 1
 L_P 300 μm import
 rho_P 1 kg·m⁻³ or g·cm⁻³ import
 K_F/P 0.1 import T
 D_P 1e-015 m²s⁻¹ import T
 Conc. 50 ppm import

Help

Acetaldehyde

Name: Acetaldehyde (Acetic aldehyde; Ethanal; Ethyl aldehyde; CH₃CHO; Acetaldehyd; Aldehyde acetique; Aldeide acetica; NCI-C563...)
CAS: 75-07-0
REF: 10060
InChIKey: IKGUXGNUTLKF-UHFFFAOYSA-N
Formula: C₂H₄O
M: 44.053 g/mol
SML: 6 ppm
EFSA: Group TDI = 0.1 mg/kg b.w. (calculated as acetaldehyde (including 10060 and 23920))
 Toxicity profiles similar to methaldehyde. A 2-year oral rat study and a 3-generation oral rat study including teratogenicity with methaldehyde. The reports on nasal carcinogenicity after inhalation were considered without relevance for effects from oral intake of smaller doses. (adopted at 113rd SCF meeting)(17-18 September 1998)
http://europa.eu.int/comm/food/fs/sc/scf/out16_en.html
Fit Regulation: +Positive list

Save result as:
 Summary Launch simulation

Acceptable threshold or specific migration limit: 6 ppm


Free

SFPP3: a framework to deploy migration simulation and decision tools
 SAFE FOOD PACKAGING PORTAL ©INRA/Olivier Vitrac

020
Sept 2015

New trends: OPEN-SOURCE codes

<https://github.com/ovitrac/FMECAengine>




021
Sept 2015

Probabilistic (equilibrium)




Probabilistic/deterministic

Probabilistic (out of equilibrium)









Free energy perturbation

$$\exp\left(-\frac{F_1 - F_0}{k_B T}\right) = \left\langle \exp\left(-\frac{U_1 - U_0}{k_B T}\right) \right\rangle$$



SCALE

FULLY COUPLED = combining variability and uncertainty



SCALE

_02



MIGRATION WITHOUT CONTACT

VOLATILE AND NON VOLATILE SUBSTANCES
HOW TO PREDICT AND CONTROL THEM ?



olivier.vitrac@agroparistech.fr / UMR 1145 Food Processing and Engineering

.024
Sept 2015

MATBIM 2015, SAROGOSA, SPAIN



ANOTHER EXAMPLE


CONTAMINATION VIA PERMEATION



SAFEFOODPAC

.025
Sept 2015

OUT INTERPRETATION OF GERMAN SURVEY IN 2010,2011




Biedermann et al. (2013)

UMR 1145 Food Processing and Engineering

26


CONTAMINATION TROUGH THE GAS PHASE

EXAMPLE OF DRY FOOD packed within a 50 μm thick BOPP and exposed to a cardboard material formulated with 15 surrogates



PREDICTIONS vs EXPERIMENTS

Nguyen et al. 2014, submitted to I&EC, FAC



TWO EXTREME CASES

Type 1 : desorption in gaseous phase
(exponential without delay)




$$\frac{C_{i,P_4}^{t=0} - C_{i,P_4}(t)}{C_{i,P_4}^{t=0} - C_{i,P_4}^{eq}} = \frac{p_i^{vsat}(T) V_i \gamma_{i,P_4}^v(T) h_e}{(1 - \varepsilon_{P_4}) RT l_{P_4}} (1 + K_{P_4/F} L_{P_4/F}) t$$

$$\frac{dm_{i,F}(t)}{dt} \Big|_{t \rightarrow 0} \propto p_i^{vsat}(T)$$


$$\frac{m_{i,F}^{eq}}{m_{i,P_4}^{t=0}} = \left(1 + \sum_{j=1}^4 \frac{1}{K_{i,F/P_j}} \frac{l_{P_j}}{l_F} \right)^{-1}$$

Type 2 : diffusion through the PP layer



UMR 1145 Food Processing and En

ISO-MIGRATION: TIME x TEMPERATURE x M
ISO-TIME: CONTAMINATION x TEMPERATURE x M




22 INRA
SCIENCE & IMPACT

SAFEFOODPACK DESIGN
 Example: benzyl butyl phthalate ($M = 313$ g·mol⁻¹)

.030
Sept 2015

FMECAengine can manage volatiles



INRA
SCIENCE & IMPACT

Nguyen P-M et al., AIChE J. 2013, 59 (4), 1183

"FMECAengine" open-source project <https://github.com/ovitrac/FMECAengine>

UMR 1145 Food Processing and Engineering

.031

_03



BLIND DEFORMULATION


HOW TO IDENTIFY RAPIDLY UNKNOWN POSSIBLE MIGRANTS?
 APPLICABLE TO NIAS, MIGRANTS FROM ARBITRARY MATERIALS
 WHAT ARE THE COMMON MIGRANTS?



olivier.vitrac@agroparistech.fr / UMR 1145 Food Processing and Engineering

.032
 Sept 2015

GENERAL GOALS




033




SFPDRMNSpec

<https://github.com/ovitrac/SFPDnmrspec>



.034
Sept 2015


SFPDnmrspec v 0.1 (opensource)




.035
Sept 2015

REAL POLYOLEFINES



a) Mixture S3



— reference concentration
 $\triangle \nabla$ upper and lower concentration bounds
 \diamond predicted concentration
 $+ \times$ upper and lower concentration bounds



b) Mixture S5




SAFEFOODPACK DESIGN

.036
Sept 2015




REAL POLYESTERS



Present	Class	Likely substances	ρ
	C12	a: Irganox 1010	0.85
x	C12	b: Irganox 1076	0.84
x	C12	c: Irganox PS802	0.82
	C12	d: Irganox PS800	0.81
x	C06	e: Chimassorb 81	0.75
x	C06	f: hexadecanol*	0.63

— reference concentration
 $\triangle \nabla$ upper and lower concentration bounds
 \diamond predicted concentration
 $+ \times$ upper and lower concentration bounds



SAFEFOODPACK DESIGN

olivier.vitrac@agroparistech.fr
Sept 2015



Figure 9. Predicted concentrations for extract S6 (two scenarios) according to the insertion scenarios set by Schulze's rule. Asterisk (*) notes that data for this substance was based on the ¹H NMR spectrum of 1-hexadecanol, as calculated with ChemNMR from ChemBioDraw Ultra 14 Suite.⁵⁷

037
pt2015



```


1 <?xml version="1.0"?>
2 <!-- SafeFoodPack Design Project (ANR-10-ALIA-009)Authors: Mai Nguyen, Cedric Lythaud, Olivier Vitrac
3 Contact: olivier.vitrac@agroparistech.fr
4 10-Nov-2014 16:40:56
5 LP_MOL11 -->
6 <root xml:tb_version="2.01" id="1" type="struct" size="1 1">
7   <dmpr id="1" type="struct" size="1 1">
8     <PS id="1" type="struct" size="1 1">
9       <formula id="1" type="char" size="1 4">C8H8</formula>
10      <fw id="1" type="double" size="1 1">104.15</fw>
11      <normvalue id="1" type="double" size="1 1">14517314957899.68</normvalue>
12      <gates id="1" type="double" size="10 4">6.8 6.2 1.67 1.15 7.24 2.14 1.51 1.23 0.8100000000000001 -0.14 7.225 6.8 2.1
13    </PS>
14    <PE id="1" type="struct" size="1 1">
15      <formula id="1" type="char" size="1 4">C2H4</formula>
16      <fw id="1" type="double" size="1 1">28</fw>
17      <normvalue id="1" type="double" size="1 1">112590106321399.8</normvalue>
18      <gates id="1" type="double" size="6 4">1.12 0.78 7.22 2.11 1.51 -0.12 1.39 0.94 7.32 2.15 1.63 0.12 0.01 0.01 0.01
19    </PE>
20    <PP id="1" type="struct" size="1 1">
21      <formula id="1" type="char" size="1 4">C3H6</formula>
22      <fw id="1" type="double" size="1 1">42.08</fw>
23      <normvalue id="1" type="double" size="1 1">142859934253081.4</normvalue>
24      <gates id="1" type="double" size="5 4">1.18 0.76 7.21 1.48 -0.11 1.32 0.9300000000000001 7.32 1.63 0.11 0.01 0.01 0.
25    </PP>
26    <ITX id="1" type="struct" size="1 1">
27      <formula id="1" type="char" size="1 8">C16H14O5</formula>
28      <fw id="1" type="double" size="1 1">254.35</fw>
29      <normvalue id="1" type="double" size="1 1">1210127206888148</normvalue>
30      <gates id="1" type="double" size="10 4">7.4 3 1.29 8.4700000000000001 7.23 3.42 1.5 1.37 1.23 -0.06 7.75 3.15 1.37 8.
31    </ITX>
32    <BP4 id="1" type="struct" size="1 1">
33      <formula id="1" type="char" size="1 7">C19H14O</formula>
34      <fw id="1" type="double" size="1 1">258.31</fw>
35      <normvalue id="1" type="double" size="1 1">56419466590739.2</normvalue>

```

DEFORMULATION OF 100 REAL PACKAGING MATERIALS

SUMMARY

- ❖ **>110 samples collected**, 97 samples extracted
- ❖ **Fast blind deformulation** (NMR, FTIR, Raman, direct infusion in MS) via generalized correlations (weighted, regularized, sparse solutions)
- ❖ **PIPELINES to NMR and MS libraries**
- ❖ **Libraries of fingerprints**: calibrated spectra (+400 NMR, +90 FTIR) and chromatograms (GC-MS: 250 substances, HPLC-UV: retention times of ~100 substances)
- ❖ **All data have been integrated within an EXPERT SYSTEM**, which can be interrogated using “natural language”
- ❖ **Automatic PIPELINES to simulation engines**




Tables generated automatically with:
Engine: C:\Data\Olivier\INRA\Projets\SafeFoodPack_design\instruments\deformulation_report_template_SFPO.m
User@host: Olivier@LIP_MDL11
Date: 21-Sep-2015

Page 2/7

engineering

DEFORMULATION OF 100 REAL PACKAGING MATERIALS

EXAMPLE



EXPERT SYSTEM

OVERVIEW

SAFEFOODPACK DESIGN

olivier.vitrac@agroparistech.fr
Sept 2015

INRA
SCIENCE & IMPACT

FOOD	DESIGN	CATEGORY	POLYMER	SUBSTANCE	FOOD STORAGE
milk	bag with gusset	flexible	PS	Technological function	frozen
ham	compartment alized tray	rigid	PA	chemical function	chilled
babyfood	doy pack	reheatable	PVDC	IUPAC	hot filled
Biscuit	Heatable pot	printed	acrylic adhesive	CAS	Microwave heating
mustard	Gourd	storage before use	aluminum	M range	Sterilized
	Etc.	Etc.	nitro ink	Etc.	

.041
Sept 2015

OVERVIEW

PACKAGING CLASSIFICATION

OVERVIEW

SAFEFOODPACK DESIGN

CATÉGORIES D'EMBALLAGES

Tableau à utiliser pour la question Q11 si le corps principal de votre emballage est en plastique

MERCI DE REPORTER LE CODE DU QUESTIONNAIRE INITIAL

Type	Exemple	Description	Code
Brique			
"Gourde" / day pack			

SAFEFOODPACK DESIGN

CATÉGORIES D'EMBALLAGES FLEXIBLES

Tableau à utiliser pour la question Q11 si le corps principal de votre emballage est en plastique flexible

MERCI DE REPORTER LE CODE DE L'EMBALLAGE DU QUESTIONNAIRE INITIAL

Type	Exemple	Description	Code
VFFS : Vertical Form-Fill-Seal		vertical	
VFFS avec soufflets		vertical, peut être debout, soufflet scellés	
HFFS : Horizontal Form-Fill-Seal		horizontal	

SAFEFOODPACK DESIGN

COMPOSANTS EN CONTACT AVEC L'ALIMENT

Tableau à utiliser pour la question Q19 pour décrire le système de fermeture de votre emballage

REPORTER LE CODE DU COMPOSANT DANS LE QUESTIONNAIRE INITIAL

Exemple	Description	Code
		C1

SAFEFOODPACK DESIGN

COMPOSANTS NE RENTRANT PAS EN CONTACT AVEC L'ALIMENT

Tableau à utiliser pour la question Q27 pour décrire le suremballage

MERCI DE REPORTER LE CODE DU SUREMBALLAGE DANS LE QUESTIONNAIRE INITIAL

Type	Exemple	Description	Code
Surbouchage		peut aussi être collée à l'emballage	C9
Étiquette collée ou auto-adhésive			C10
Étiquette scellée par chevauchement			C11

SAFEFOODPACK DESIGN

CATÉGORIES D'EMBALLAGES NON PLASTIQUES

Tableau à utiliser pour la question Q11 si le corps principal de votre emballage n'est pas en plastique

MERCI DE REPORTER LE CODE DE L'EMBALLAGE DANS LE QUESTIONNAIRE INITIAL

Type	Exemple	Description	Code
Carton			A1

SAFEFOODPACK DESIGN

Emballage sous vide

F8

SAFEFOODPACK DESIGN

Enveloppe non scellée

peut avoir un point de colle

F9


olivier.vitrac@agroparistech.fr
Sept 2015

INRA
SCIENCE & IMPACT

042
sept 2015



EXAMPLES

WHICH MATERIAL TO BE USED TO STORE MILK IN “GOURD”



WHICH MATERIAL MAY CONTAIN THIS SUBSTANCE?







WHAT IS THIS 112-85-6 ?

```
>> load chemspider 112-85-6
```


CHEMSPIDER reuses cached data for '112-85-6' (date=21-sept.-2015 21:03:02)

ans =

```

CSID: 7923
InChI: 'InChI=1S/C22H44O2/c1-2-3-4-5-6-7-8-9-10-11-12-13-14-15-16-17-18-19-20-21-22/h1,23,24'
InChIKey: 'UKMSUNONTOPIOI-UHFFFAOYSA-N'
SMILES: 'CCCCCCCCCCCCCCCCCCCC(=O)O'
Name: 'Docosanoic acid'
CAS: ['112-85-6' '16529-65-0' '22302-43-8' '505-18-8']
Synonyms: {1x68 call}
QuickMass: {1x1 struct}
quickproperties: {1x1 struct}
Properties: {1x1 struct}
UserProperties: {8x1 struct}
EPI: {1x1 struct}
Thumbnail: 'C:\Data\Olivier\INRA\Codes\MS\cache.ChemSpider'
Structure: 'C:\Data\Olivier\INRA\Codes\MS\cache.ChemSpider'
url: 'http://www.chemspider.com/RecordView.aspx?id=112856'
urlstructure: 'http://www.chemspider.com/ImagesHandler.ashx?id=112856'
links: {1x1 struct}


```



VOLATILE MIGRANTS FROM PS STORED BEFORE USE AS STACKS?

```
substance: (substance:@volatiles)
AND (polymer:PS)
AND (storagebeforeuse:stack)
```

```
L1,CAS110-98-5,CAS10303-64-7,CAS111-41-1,CAS107-88-0,CAS111-87-5,CAS115-77-5,CAS120-47-8,CAS120-86-9,CAS122-95-2,CAS123-62-6,CAS124-48-5,CAS125-28-5,CAS126-68-0,CAS127-08-7,CAS128-64-7,CAS129-00-0,CAS129-08-1,CAS129-10-1,CAS129-11-2,CAS129-12-3,CAS129-13-4,CAS129-14-5,CAS129-15-6,CAS129-16-7,CAS129-17-8,CAS129-18-9,CAS129-19-0,CAS129-20-1,CAS129-21-2,CAS129-22-3,CAS129-23-4,CAS129-24-5,CAS129-25-6,CAS129-26-7,CAS129-27-8,CAS129-28-9,CAS129-29-0,CAS129-30-1,CAS129-31-2,CAS129-32-3,CAS129-33-4,CAS129-34-5,CAS129-35-6,CAS129-36-7,CAS129-37-8,CAS129-38-9,CAS129-39-0,CAS129-40-1,CAS129-41-2,CAS129-42-3,CAS129-43-4,CAS129-44-5,CAS129-45-6,CAS129-46-7,CAS129-47-8,CAS129-48-9,CAS129-49-0,CAS129-50-1,CAS129-51-2,CAS129-52-3,CAS129-53-4,CAS129-54-5,CAS129-55-6,CAS129-56-7,CAS129-57-8,CAS129-58-9,CAS129-59-0,CAS129-60-1,CAS129-61-2,CAS129-62-3,CAS129-63-4,CAS129-64-5,CAS129-65-6,CAS129-66-7,CAS129-67-8,CAS129-68-9,CAS129-69-0,CAS129-70-1,CAS129-71-2,CAS129-72-3,CAS129-73-4,CAS129-74-5,CAS129-75-6,CAS129-76-7,CAS129-77-8,CAS129-78-9,CAS129-79-0,CAS129-80-1,CAS129-81-2,CAS129-82-3,CAS129-83-4,CAS129-84-5,CAS129-85-6,CAS129-86-7,CAS129-87-8,CAS129-88-9,CAS129-89-0,CAS129-90-1,CAS129-91-2,CAS129-92-3,CAS129-93-4,CAS129-94-5,CAS129-95-6,CAS129-96-7,CAS129-97-8,CAS129-98-9,CAS129-99-0
```



CAS112-85-6	Docosanoic acid
CAS129-47-8	4-(2-Aminoethyl)aniline
CAS12738-64-6	+D-Fructofuranosyl +D-glucopyranoside

EXAMPLES OF PIPES

- ROUGH ESTIMATES OF A AIR/POLYMER PARTITION COEFFICIENTS

```
>> FMECAKairP acetophenone
```


```
LOAD CHEMSPIDER      extraction of ChemSpiderID=7132 ('acetophenone') completed in 10.26 s
```

LOAD_CHEMISPIDER: updated cache

```
7132.mat      21-sept.-2015 21:37:19      77.6 kBytes  C:\Data\Olivier\INRA\Codes\MS\cache.ChemSpider
CHEMSPIDER reuses cached data for 'acetophenone' (date=21-sept.-2015 21:37:19)
```

ans =

9.1995e-06



```
>> FMECAKairP ethylbenzene
```


```
LOAD_CHEMSPIDER      extraction of ChemSpiderID=7219 ('ethylbenzene') completed in 11.9 s
```

LOAD_CHEMISPIDER: updated cache

```
7219.mat      21-sept.-2015 21:42:34      107.1 kBytes  C:\Data\Olivier\INRA\Codes\MS\cache.ChemSpider
CHEMSPIDER reuses cached data for 'ethylbenzene' (date=21-sept.-2015 21:42:34)
```

ans =

2.2485e-04



```
>> FMECAKairP 'benzoic acid'
```


```
LOAD CHEMSPIDER      extraction of ChemSpiderID=238 ('benzoic acid') completed in 5.746 s
```

LOAD_CHEMISPIDER: updated cache

```
238.mat      21-sept.-2015 21:45:01      41.2 kBytes  C:\Data\Olivier\INRA\Codes\MS\cache.ChemSpider
CHEMSPIDER reuses cached data for 'benzoic acid' (date=21-sept.-2015 21:45:01)
```

ans =

1.3674e-08



_04



MOLECULAR MODELING


PREDICTING DIFFUSION COEFFICIENTS



olivier.vitrac@agroparistech.fr / UMR 1145 Food Processing and Engineering

.046
Sept 2015

NESTED MODELING HIERARCHY



SAFEFOODPACK DESIGN

.047
Sept 2015

Systems Analysis at the Molecular Scale

HERSCHEL RABITZ

Problems involving physiochemical phenomena on both the microscopic and macroscopic scales often raise similar sets of generic issues and questions. The complexity of these problems is beginning to make inoperative the traditional intuition-based approaches to their analysis and solution. The common characteristics of large, multi-variable, complex molecular systems call for a new, more systematic approach to guide theoretical and experimental efforts. With mathematical modeling becoming an essential ingredient in the studies, it is argued that molecular systems analysis and especially the systematic tools of sensitivity analysis can play an increasingly important role in understanding and finding solutions to complex, chemically based problems.





Fig. 1. Flow chart illustrating the hierarchical connection between microscopic and macroscopic variables in chemical dynamics and kinetics. Sensitivity analysis techniques may be developed to specifically probe the parametric and functional interconnections between the levels of the flow chart. The double-headed arrows connecting elements in the flow chart imply that both forward and inverse questions may be explored.



Science 13 October 1989:
Vol. 246 no. 4927 pp. 221-226

USING MOLECULAR MODELING AS A COMPUTATIONAL MICROSCOPE




INRA
SCIENCE & IMPACT

.049
22 104 / 2015

SCALING D WITH SOLUTE SIZE

STIFF DIFFUSANTS




From: A. R. Berens, Pure Appl. Chem., 1981, 53, 365

.050
Sept 2015

FLEXIBLE DIFFUSANTS


Local and temporary trapping of additive between polymer segments

Additive translation controlled by the relaxation of polymer itself and by the rate of creation of free volumes.



The relative free volume required for the translation of large additives is smaller as displacements of atoms/patterns are more likely not to be correlated together.


51



Solute geometry captured

by one single parameter $\xi = \frac{V_s^*}{V_m^*}$

Ratio of critical molar volume of solvent jumping unit to critical molar volume of polymer jumping unit




$$\frac{D(\xi, T)}{D(\xi_0, T)} = f\left(\frac{M}{M_0}\right) = g(\exp[-(\xi - \xi_0)])$$

Eur. Polym. J. Vol. 34, pp. 797, 1998
Macromolecules, Vol. 27, pp. 4684, 1994

From Vrentas et al. (1977, 1996, 1998) theory, trace diffusion coefficient ratio can be expressed as:

$$T > T_g \quad \frac{D(\xi, T)}{D(\xi_0, T)} = \exp\left(-\frac{E^*(\xi) - E^*(\xi_0)}{RT}\right) \exp\left(-\frac{(\xi - \xi_0)}{K_{12}(\gamma_2 \tilde{V}_2^* (K_{22} + T - T_g))}\right)$$



52



$$\alpha = \left. \frac{\partial \ln D}{\partial \ln M} \right|_{M_0, T, T_g} \gg 1$$

53

SCALING EXPONENTS FOR HOMOLEGIOUS SERIES OF SUBSTANCES




$$\alpha(T - T_g) = 1 + \frac{K_\alpha}{T - T_g + K_\beta}$$

Formal equivalences between FVT and scaling laws

Rubber polymers: $T > T_g$


	Scaling law (Eq. (19))	Free-volume theory (Eq. (22))
Relative diffusant effects	$\ln \left(\frac{M}{M_0} \right)$	$0.24(\xi - \xi_0)$
Scaling exponent $\alpha(T, T_g)$	$1 + \frac{K_\alpha}{T - T_g + K_\beta}$	$0.24 \frac{\gamma}{K_{12}} \frac{\hat{V}_p^*}{K_{22} + T - T_g}$ K_{12}, K_{22} are polymer free-volume parameters.
Relative activation energy $Ea(M, T) - Ea(M_0, T) =$ $Ea(\xi, T) - Ea(\xi_0, T) =$ $\frac{\partial \ln \frac{D(M, T)}{D(M_0, T)}}{\partial 1/T} =$	$K_\alpha \frac{RT^2}{(T - T_g + K_\beta)^2} \ln \frac{M}{M_0}$	$\frac{E^*(\xi) - E^*(\xi_0)}{\gamma \bar{V}_p^*} + (\xi - \xi_0) \frac{\gamma \bar{V}_p^*}{K_{12}} \frac{RT^2}{(K_{22} + T - T_g)^2}$

SCALING EXPONENTS FOR VARIOUS POLYMERS



SCALING ACTIVATION ENERGY VARIOUS DIFFUSANTS IN VARIOUS POLYMERS

$$E_a(M) \approx E_a(M_0) + \ln(M/M_0)$$




OVERESTIMATING D VALUES

PIRINGER EQUATION

$$\ln \bar{D}_{(M,T)} = A'_P - 0.1351M^{2/3} + 0.003M - \frac{\tau + 10454}{RT}$$

SAFETY MARGIN

Polymer	A' _P	τ (K)
LDPE,LLDPE	11	0
HDPE	14	1565
PP (homo and random)	13	1565
PP (rubber)	11	0
PS	0	0
HIPS	1	0
PET	6	1565
PBT	6	1565
PEN	5	1565
PA	2	0
PVC	0	0



Crit. Rev. Food Sci. Nut. 2015 (Fang & Vitrac)
<http://www.tandfonline.com/doi/full/10.1080/10408398.2013.849654>


Piringer

.058
 21/04/2015

ROBUSTNESS OF THE PIRINGER EQUATION

RUBBER POLYMERS (T > T_g)

- T_g ~ 0°C (PP)
- T_g ~ 50°C (PA)



Crit. Rev. Food Sci. Nut.
 2015 (Fang & Vitrac)
<http://www.tandfonline.com/doi/full/10.1080/10408398.2013.849654>



.059
 Sept 2015

05



MOLECULAR MODELING



PARTITION AND ACTIVITY COEFFICIENTS

HEAT OF SORPTION/DESORPTION



BEYOND PARTITION COEFFICIENTS

Sorption hysteresis of n-hexane in PS at 298 K



J. Polym. Sci. Part B: Polymer Physics, 1014, 52(19), 1252–1258

.061
Sept2015

EFFECT OF PARTITION COEFFICIENT ON MIGRATION



50 times for chemical affinity for P

50 times for chemical affinity for F

$K_{i,F/P} =$

1/50



50



$$K_{i,F/P} = \frac{C_{i,F}^{eq}}{C_{i,P}^{eq}} = \frac{1}{1 - \text{crystallinity}} \frac{\gamma_{i,P}^v}{\gamma_{i,F}^v}$$


.062
Sept 2015

MANY METHODS AVAILABLE

Class	Models
Group contribution	UNQUAC, UNIFAC, NRTL
Associative model 	SAFT, PRISM Optimized for polar and liquid phase (De Anda et al Pol. Eng. & Sci., 2011)
Molecular modelling at atomistic scale 	Explicit representation of <u>entangled chains</u> <u>Representation of polymer chains without entanglement</u>


.063
Sept 2015

OFF-LATTICE FLORY-HUGGINS FORMULATION OF EXCESS CHEMICAL POTENTIALS IN BINARY BLEND-VOID SYSTEMS



Chemical potential (definition of J. Williard Gibbs)

$$\mu_{i,k} = \left(\frac{\partial G_{i+k}}{\partial n_i} \right)_{P,T,i \neq j} = \mu_i^0 + RT \ln a_i = \mu_i^0 + RT \ln \phi_i + RT \ln \gamma_{i,k}^v = \mu_i^0 + \mu_i^{id} + \mu_{i,k}^{excess}$$





Flory expression at infinite dilution in $k=P$ or in $k=F$

$$\frac{\{\mu_{i,k}^{excess}\}_{k=P,F}}{k_B \cdot T} = \ln \gamma_{i,k}^v = \left(1 - \frac{1}{r_k} \right) \cdot \phi_k + \chi_{i,k} \cdot \phi_k^2 \approx \left(1 - \frac{1}{r_k} \right) + \chi_{i,k}$$

$$2k_B T \chi_{i,k} = \langle h_{i+k} \rangle_T + \langle h_{k+i} \rangle_T - \langle h_{k+k} \rangle_T - \langle h_{i+i} \rangle_T$$


64


 Bawendi et al., *J. Chem Phys.* 1986; 1987; 1988
 Gillet et al., *I&EC*, 2009; 2010; Vitrac and Gillet, *Int. J. Chem. Reactor Eng.* 2010
SAFE FOOD PACK DESIGN
 olivier.vitrac@agroparistech.fr
 Sept 2015


$$\ln(\gamma_{i,k}^v) = \left(1 - \frac{1}{r_k} \right) \phi_k + \chi_{i,k} \phi_k^2$$

$k = P, F$


FLORY HUGGINS APPROXIMATION AT ATOMISTIC SCALE



IDEALIZED POLYMER CHAINS ($k = P$)

$$2k_B T \chi_{i,k} = \langle h_{i+k} \rangle_T + \langle h_{k+i} \rangle_T - \langle h_{k+k} \rangle_T - \langle h_{i+i} \rangle_T$$

EXCESS ENTHALPIES ARE CALCULATED FROM SIMPLE A MIXING RULE OF PAIR CONTACT ENERGIES




$$\langle h_{A+B} \rangle_T = \langle \epsilon_{A+B} z_{A+B} \rangle_T \approx \langle \epsilon_{A+B} \rangle_T \langle z_{A+B} \rangle$$


.065
Sept 2015

DETAILS OF THE ENERGY SAMPLING PROCEDURE

Pair contact energies



$$\langle \epsilon_{A+B} \rangle_T = \frac{\int_{-\infty}^{+\infty} \epsilon pr(\epsilon) \exp\left(-\frac{\epsilon}{RT}\right) d\epsilon}{\int_{-\infty}^{+\infty} pr(\epsilon) \exp\left(-\frac{\epsilon}{RT}\right) d\epsilon}$$



Excess enthalpies

Homopolymers

$$\chi_{i,P}^{(n_{i,P}^{\min})} = \frac{\langle h_{i,P}^{n_{i,P}^{\min}} \rangle_T + \langle h_{P+i}^{n_{i,P}^{\min}} \rangle_T - \langle h_{P+P}^{n_{i,P}^{\min}} \rangle_T - \langle h_{i+i} \rangle_T}{2RT}$$


$$n_{i,P}^{\min} = \underset{n_P}{\operatorname{argmin}} \left(\chi_{i,P}^{(n_P)} \right)$$

$$\langle h_{j+k} \rangle_T = \langle \epsilon_{j+k} \rangle_T \langle z_{j+k} \rangle + \beta_{jk}$$

In liquids (denoted F ou L)

$$\chi_{i,F} = \frac{\langle h_{i+F} \rangle_T + \langle h_{F+i} \rangle_T - \langle h_{F+F} \rangle_T - \langle h_{i+i} \rangle_T}{2RT}$$


$$\text{For water: } \langle h_{F+F} \rangle_T = 4 \langle \epsilon_{A+B} \rangle_T \langle z_{A+B} \rangle$$



.066
21/04/2015


FIRST COMPARISONS BETWEEN DIRECT CALCULATIONS AND EXPERIMENTS (no fit) – 45 SOLUTES

Polyethylene in contact with




Alkanes	Alcohols	Volatiles	Plastics additives
decane	decanol	camphor	BHT
undecane	undecanol	diphenyl oxide	chimassorb 81
dodecane	dodecanol	diphenylmethane	Erucamide
tridecane	tridecanol	d-limonene	Irganox 1076
tetradecane	tetradecanol	dl-menthol	Irganox 1035
pentadecane	pentadecanol	eugenol	Irganox 245
hexadecane	hexadecanol	isoamyl acetate	Irgafos 168
heptadecane	heptadecanol	linalyl acetate	Irganox 3114
octadecane	octadecanol	phenylethyl alcohol	Irganox ps802
nonadecane	nonadecanol		stearic acid
eicosane	eicosanol		Tinuvin 326
docosane			
tetracosane			
octacosane			

METHANOL-POLYETHYLENE PARTITIONING




68

EXTENSION TO COPOLYMERS (ethylene vinyl acetate)



Mean field approximation (Flory-Huggins ternary : $i + \text{PE} + \text{PVAc}$)

$$\chi_{i,EVA}^{(wVA)} = \chi_{i,PVAc} \phi_{VA}^{(wVA)} + \chi_{i,PE} (1 - \phi_{VA}^{(wVA)}) - \chi_{PVAc,PE} \phi_{VA}^{(wVA)} (1 - \phi_{VA}^{(wVA)})$$



Microscopic approach (binary : $i + \text{copolymer}$) : sampling of all possible isomers



MACROSCOPIC VS MICROSCOPIC MIXING ENERGIES

Polymer Blends

$$\begin{aligned} \diamond \Delta \mu_i^{ex} &= \frac{1}{RT} \frac{\partial \Delta_{mix} G}{\partial N_i} \big|_{\{N_k\}_{k=1..v}, T, P} - \ln(\phi_i) \\ &= \sum_{k=1..v} \left(1 - \frac{r_i}{r_k}\right) \phi_k + r_i \sum_{j=1..v} \chi_{ij} \phi_j^2 \\ &\quad + r_i \sum_{\substack{j=1..v \\ k=1..v \\ j < k}} (\chi_{ij} + \chi_{ik} - \chi_{jk}) \phi_j \phi_k \end{aligned}$$

❖ For binary systems:

$$\chi_P = \frac{1}{2} (\chi_{i1} + \chi_{i2} - \chi_{12})$$

Random copolymers, block polymers

$$\begin{aligned} \diamond \chi_P &= \sum_{k=1..v} \frac{p_{ii} p_{ik} h_{ik} + p_{ii} p_{ki} h_{ki} - p_{ii} p_{ik} h_{ii} - p_{ii} p_{ki} h_{kk}}{(p_{ii} + p_{ii}) k_B T} \\ &\quad - \sum_{\substack{j=1..v \\ k=1..v \\ j < k}} p_{ij} p_{ik} \chi_{jk} \\ &= \sum_{k=1..v} p_{ik} \chi_{i,k} - \sum_{\substack{j=1..v \\ k=1..v \\ j < k}} p_{ij} p_{ik} \chi_{jk} \end{aligned}$$

$$\diamond p_{ik} = p_{ki} = \phi_k$$



SAFEFOODPACK DESIGN

.070
16/03/2015


19 TESTED SOLUTES

Name	CAS number	Structure	Name	CAS number	Structure	Name	CAS number	Structure
1-Naphthol	1321-67-1		4-Nitrophenol	100-02-7		Benzonitrile	100-47-0	
2-Naphthol	135-19-3		2-Nitrotoluene	1321-12-6		Benzophenone	119-61-9	
2-Nitroaniline	29757-24-2		3-Nitrotoluene	1321-12-6		Benzyl alcohol	100-51-6	
3-Nitroaniline	99-09-2		4-Nitrotoluene	99-99-0		Nicotine	54-11-5	
4-Nitroaniline	100-01-6		Acetophenone	98-86-2		Nitrobenzene	98-95-3	
2-Nitrophenol	88-75-5		Benzoic acid	65-85-0		Pyridine	110-86-1	
3-Nitrophenol	554-84-7							

Reference data (group of Prausnitz): *J Appl Polym Sci* 2002, 85:2041–2052; *AIChE J* 2002, 48:1284-1291


71

VALUES OF χ FOR 19 SOLUTES IN HOMO-PVAC




COMPARISON BETWEEN THE MICROSCOPIC AND MEAN FIELD APPROXIMATION

Effect of acetylation rate on χ



Configurations of minimal energies : $n = 5$
(acetylation rate w/w = 0.82)




○ Microscopic calculations

— mean field approximation

MOLECULAR RESULTS INTEGRATED WITHIN A “SMALL” SOFTWARE

Databases of results
calculated at molecular scale




Small “real-time” software

$i =$

74

Which polymer? Which migrant? Which food simulant?

$i =$




For 200 tabulated activity coefficients, one partition coefficient costs less than 1.5 € (with tax credit)

75

TOWARDS SIMPLE RULES

Vitrac, O. and G. Gillet (2010). "An Off-Lattice Flory-Huggins Approach of the Partitioning of Bulky Solutes between Polymers and Interacting Liquids." *International Journal of Chemical Reactor Engineering* 8.

- 1: Decane
- 2: Undecane
- 3: Dodecane
- 4: Tridecane
- 5: Tetradecane
- 6: Pentadecane
- 7: Hexadecane
- 8: Heptadecane
- 9: Octadecane
- 10: Nonadecane
- 11: Eicosane
- 12: Docosane
- 13: Tetracosane
- 14: Octacosane
- 15: Decanol
- 16: Undecanol
- 17: Dodecanol
- 18: Tridecanol
- 19: Tetradecanol
- 20: Pentadecanol
- 21: Hexadecanol
- 22: Heptadecanol
- 23: Octadecanol
- 24: Nonadecanol
- 25: Eicosanol
- 26: Camphor
- 27: Diphenyl oxide
- 28: Diphenylmethane
- 29: D-limonene
- 30: DL-menthol
- 31: Eugenol
- 32: Isoamyl acetate
- 33: Linalyl acetate
- 34: Phenylethyl alcohol
- 35: BHT
- 36: Chimassorb 81
- 37: Erucamide
- 38: Irgafos 168
- 39: Irganox 1035
- 40: Irganox 1076
- 41: Irganox 245
- 42: Irganox 3114
- 43: Irganox PS802
- 44: Stearic acid
- 45: Tinuvin 326



76

_06



**PREVENTIVE APPROACHES OF THE
CONTAMINATION**


FMECA APPROACHES



olivier.vitrac@agroparistech.fr / UMR 1145 Food Processing and Engineering

.077
Sept 2015

NESTED MODELING HIERARCHY




PREVENTIVE APPROACHES INSPIRED FROM AERONAUTICS INDUSTRY



Application to food packaging




Projet « Conception raisonnée d'emballages sûrs »




.080

Failure Mode Effects Criticality Analysis

LOGICAL STEPS




- ❖ List of components and functions
- ❖ Failure = migration mode tree
- ❖ **Severity** = $f(C_F)$
 - Dimensionless scale
 - Normalized by toxicological data
 - Substance and material independent
 - Linear to C_F for acceptable C_F values and non-linear beyond
- ❖ **Criticality ranking**
 - by component
 - by substance
 - by process or storage step
 - Comparative designs
- ❖ Ensuring **detectability** via calculations and simulation




Nguyen *et al.* 2013, AICHE J.

.081
Sept 2015



ALL STEPS MUST BE INCLUDED IN THE ANALYSIS

As soon they cause a redistribution of packaging constituents through the different materials (even without food contact).




ALL STEPS MUST BE INCLUDED IN THE ANALYSIS

Mass transfer in the gas phase cannot be neglected during curing, long-term storage and oven heating



MICROWAVE HEATING



TRANSFER IN VAPOR PHASE
+STEAM EXTRACTION




UMR 1145 Food Processing and Engineering

84

.084

CHAINED STEPS


1: Setoff → 2: HotFilling → 3: Storage → 4: OvenHeating_{x 10⁻⁴}



.085
Sept2015

ASSESSING THE SEVERITY OF A SINGLE STEP

CASE OF "SETOFF" STEP



Full methodology described in *AIChE J.* 2013, **59**(4), 1183-1212





$$\text{Severity}(\hat{C}_F(\text{step } i)) = f \left[\max \left\{ \underbrace{C_{F_M} | 1 \rightarrow 2 \rightarrow \dots \rightarrow M - C_{F_M} | 1 \rightarrow 2 \rightarrow \dots \rightarrow M/i}_{\text{comparison with step } i \text{ removed}}, C_{F_i} | i \right\} \right]$$

.086
Sept 2015

COMPARING THE SEVERITY OF A SEVERAL STEPS, PACKAGING DESIGNS, SUBSTANCES...

CASE OF "SETOFF" STEP



Full methodology described in *AIChE J.* 2013, **59**(4), 1183-1212

.087
Sept 2015


FOOD SURVEY FOR NON-EXPERTS IN FCM

id	parent	geometry	polymer	food	foodsimulant	foodtexture	step	temperature	comment
LDPEYogurtBottle		smallbottle	LDPE	yogurt	ethanol50	liquid	storage	chilled	pot of yogurt
HDPEOilCap		cap	HDPE	oil	fatty	liquid	storage	ambient	oil bottle cap
PPDrinkGoblet		gobletPP	PP	holdrink	ethanol50,fatty	liquid	consumption	not	coffee goblet
PPButterContainer		container	PP	butter	fatty	semisolid	storage	chilled	butter container
PPCreamPot		container	PP	cream	fatty	semisolid	storage	chilled	pot of cream
PPDrinkStraw		straw	PP	yogurt	ethanol50	liquid	consumption	ambient	straw
PSYogurtPot		pot	PS	yogurt	ethanol50	semisolid	storage	chilled	pot of yogurt
PSDrinkGoblet		gobletPS	PS	holdrink	ethanol50,fatty	liquid	consumption	not	coffee goblet
PVCSauceLid		gasket	pPVC	sauce	fatty	liquid	process	sterilization	cover gasket
PVCSauceLid2	PVCSauceLid		pPVC	sauce	fatty	liquid	storage	ambient	


- ❖ 9 packaged food products purchased on the French market in 2011
- ❖ Geometry and materials were determined

id	parent	geometry	polymer	food	foodsimulant	foodtexture	step	temperature	comment
PSYogurtPot		pot	PS	yogurt	ethanol50	semisolid	storage	chilled	pot of yogurt

- ❖ Simulation scenarios were automatically generated via an expert system



- ❖ Example of inference: distribution of D values



UMR 1145 Food Processing and Engineering

.088

olivier.vitrac@agroparistech.fr
Sept 2015

SAFEFOODPACK DESIGN



_07

GENERAL RECOMMENDATIONS

Training, education and cooperation programs




olivier.vitrac@agroparistech.fr / UMR 1145 Food Processing and Engineering

.089
Sept 2015




HUMAN RISK




HOW TO REDUCE THE RISK OF CONTAMINATION



DEVELOPING THE COOPERATION BETWEEN STAKEHOLDERS





WEBINARS/ONLINE TRAINING

<http://modmol.agroparistech.fr/SFPD/training/>

<http://rmt-propackfood.actia-asso.eu/>

FORMATION A LA SECURITE ALIMENTAIRE DES EMBALLAGES ET MATERIAUX AU CONTACT DES ALIMENTS

Liste des modules disponibles

MODULE 1 : LES BASES DE LA CONCEPTION D'UN EMBALLAGE SÛR

I. Présentation du projet SafeFoodPack Design

II. Les outils, moyens et ressources

III. Les facteurs d'influence

- 1) Définition de la migration
- 2) Les matériaux
- 3) Les lois de transfert et les facteurs d'influence

IV. La réglementation

- 1) Le contexte réglementaire
- 2) Les responsabilités
- 3) Les matériaux plastiques
- 4) Les matériaux plastiques recyclés
- 5) Les dérivés apocryphes
- 6) La pellicule de cellulose régénérée
- 7) La céramique
- 8) Les matériaux et emballages actifs et intelligents
- 9) La réglementation française

V. Toxicologie

- 1) L'évaluation des risques
- 2) La gestion des risques
- 3) Les stratégies

MODULE 2 : APPROFONDISSEMENT ET ÉTUDES DE CAS

MODULE 3 : DÉMONSTRATION DES OUTILS

MODULE 4 : APPLICATION DES OUTILS

Contacts :

- Jacques Thébaud - Directeur de CASIMIR: jthebaud@casimir.org
- Olivier Vitrac - Chargé de Recherche INRA - coordinateur du projet SafeFoodPack Design: olivier.vitrac@agroparistech.fr
- Audrey Goujon - Chargée de mission emballage: audrey.goujon@agroparistech.fr

MODULE 2 : Approfondissement et études de cas

ÉTUDE DE CAS : Le sandwich

Question 1

Cherchez les synonymes, les n° CAS, la Masse molaire et la SML des substances. (Accédez aux propriétés de l'emballage en cliquant **ici** ou dans la rubrique « Aide »)

Archivées simulations ou templates

Select a simulation result or a template
Report properties from a previous result file to this report form
Import a cooperation profile
Clear all properties in the current form
[Link used] Search properties by: **PT** **cas** **de** **the** **1** **PT** **transfert** **kinetique**

Selectionner « migranda »

Insérer le nom de la substance recherchée

Grâce au nom et au n° CAS vous pourrez ensuite vérifier dans la réglementation si les substances figurent dans la liste positive.

MODE PLEIN ÉCRAN

cliquez sur le bouton en bas à droite pour voir la présentation en plein écran

QUITTER LE MODE PLEIN ÉCRAN

cliquez sur le bouton en haut à gauche pour quitter le mode plein écran

ACCÉDER À L'AIDE

Pour aller plus loin

- Question 1
- Question 2
- Question 3
- Question 4
- Question 5
- Question 6
- Question 7
- Question 8
- Question 9
- Question 10

Les autres chapitres

Les autres modules

Les liens utiles

Contacts :

- Jacques Thébaud - Directeur de CASIMIR: jthebaud@casimir.org
- Olivier Vitrac - Chargé de Recherche INRA - coordinateur du projet SafeFoodPack Design: olivier.vitrac@agroparistech.fr
- Audrey Goujon - Chargée de mission emballage: audrey.goujon@agroparistech.fr

095

UMR 1145 Food Processing and Engineering



PROPACK FOOD

EMBALLAGE ALIMENTAIRE

PROCÉDÉ D'EMBALLAGE

PROPACK FOOD TRAINING

Accueil Guides Etudes de cas Cours Documentations Partenaires Contacts

ETUDE DE CAS ALIMENTARITÉ

Introduction

- Le lait en bouteille
- Le sandwich emballé
- Les haricots verts en conserve
- Le plat cuisiné réchauffable
- L'eau en bouteille
- Le quatre-temps emballé
- Défaillance organoleptique avant la mise en contact
- Défaillance organoleptique sur un produit après conditionnement

INTRODUCTION

Propack Food Training a conçu pour un public aussi bien d'industriels que d'étudiants des études représentatives des cas les plus fréquemment rencontrés dans le domaine des interactions entre le produit alimentaire contenu et l'emballage contenant.

Ces exemples illustrent des couples produit/matériaux suffisamment différents et représentatifs de cas réels. Ils ont pour objectif de dérouler une démarche didactique permettant de se poser les bonnes questions et ainsi de répondre en particulier aux exigences réglementaires ou aux modifications sensorielles provenant de l'emballage.

Ces mêmes études de cas sont reprises dans la partie « Guide alimentarité ACTIA » sous forme de logigrammes.

Un grand nombre d'informations présentes dans les différents chapitres du site Propack Food Training (guides, cours, documentation) peut être consulté afin de dérouler les études de cas.

Cours











VOUS VOULEZ CONCEVOIR UN EMBALLAGE POUR UN ALIMENT :

- QUEL(S) POLYMER(S) UTILISER ? -



Introduction

Logigramme général d'aptitude au contact alimentaire

Vous voulez modifier un élément de design

Les voies de contamination

Vous voulez modifier un élément de process

Vous avez 2 propositions d'emballage pour un aliment

Vous voulez concevoir un emballage pour un aliment

Réglementation des matériaux au contact des aliments

MAIN STEPS TO REVIEW

FMECA « brique de lait infantile »					
Phase	Formulation	Design	Process	Informations	Mécanismes
	Formulation	design	Process	Informations	Mécanismes décrits
Inventaire	<ul style="list-style-type: none"> monomères (plastiques, colles) catalyseurs antioxydants lubrifiants biocides (carton, encre) huiles minérales (carton) solvants photoinitiateurs autres résidus (NIAS) 	<p>Deux composants :</p> <ul style="list-style-type: none"> corps de la brique (4 matériaux, 5 couches) bouchon (1 matériau) <p>Six matériaux</p> <ul style="list-style-type: none"> LDPE, PP (bouchon) feuille d'aluminium carton (origine) « colles » « encre » 	<ul style="list-style-type: none"> production, stockage, assemblage des matériaux assemblage et stockage des composants impression des films stockage des emballages vides conditionnement aseptique stockage et distribution des briques de lait utilisation finale de la brique: réfrigérée, ambiante, réchauffée? mode de consommation (boire au goulot) 	<ul style="list-style-type: none"> identité et nature des matériaux au sein des assemblages éléments de formulation des matériaux (substances réglementées spécifiquement ou non) conditions utilisées pour tester le risque de contamination conditions de préparation, conditionnement, stockage, consommation de l'aliment emballé communication des éléments de modification de la formulation du design, du process et de l'utilisation finale 	<ul style="list-style-type: none"> diffusion à travers des couches décalque contamination croisée avec d'autres matériaux ou avec l'ambiance de stockage
	<p>Fortement concentrée</p> <ul style="list-style-type: none"> antioxydants, lubrifiants, biocides huiles minérales, photoinitiateurs monomères, catalyseurs, solvants autres résidus 	<p>Matériau barrière</p> <ul style="list-style-type: none"> feuille d'aluminium <p>Matériaux réservoir de contaminants de faibles masses</p> <ul style="list-style-type: none"> encre colle <p>Matériaux réservoir de contaminants de fortes masses</p> <ul style="list-style-type: none"> PP, LDPE carton 	<p>Etapes associées à des temps longs</p> <ul style="list-style-type: none"> stockage des matériaux stockage des composants stockage des produits finis <p>Etapes associées à des températures élevées</p> <ul style="list-style-type: none"> conditionnement aseptique <p>Etapes pouvant induire à des contaminations croisées</p> <ul style="list-style-type: none"> stockage impression collage / assemblage 	<ul style="list-style-type: none"> information non-documentée ou manquante information accessible information documentée qui accompagne le composant ou le matériau information vérifiable et/ou auditable fréquence de mise à jour des informations : régulière, à l'occasion de changement, uniquement à la conception ou à l'achat,... 	<ul style="list-style-type: none"> transferts qui peuvent être évalués rapidement par le calcul : en provenance ou au travers LDPE, PP transferts qui requièrent des essais expérimentaux simples : décalque transferts qui requièrent une expertise approfondie : contamination croisée, vieillissement



Dr. Olivier Vitrac lectures and workshops

Date: July 1, 2015

Location: School of Packaging, MSU

LECTURES ABOUT

"PREDICTION OF MASS TRANSFER IN POLYMERS"

by OLIVIER VITRAC, Ph.D.

INRA, FRANCE

<http://www.canr.msu.edu/events/vitrac>

http://www.packaging.msu.edu/industry_testing_services/downloadable_presentations

When	Presentation	Where
29th June (Monday) 10:00am- 11:00am	Diffusion coefficients of organic solutes in polymers: new perspectives of prediction	Conference Center, Room 100, School of Packaging
30th June (Tuesday) 2:00pm- 3:00pm	An atomistic Flory-Huggins formulation for the tailored prediction of activity and partition coefficients	The Ternes Outreach Center, Room 120, School of Packaging Registration required
1st July (Wednesday) 2:00pm- 4:00pm	Workshop: Prediction of the migration: beyond conventional estimates*	The Ternes Outreach Center, Room 120, School of Packaging Registration required

UMR 1145 Food Processing and Engineering

Migration testing and modeling of nanoparticles from nano-polymer-composites. A collaboration with Plastic Europe, the European Carbon Black Association and from the European Silica producer association - Dr. Angela Stoermer, IVV Fraunhofer institute

Fraunhofer IVV



<http://www.ivv.fraunhofer.de>

Migration testing and modeling of nanoparticles from nano-polymer composites

Angela Störmer, Johannes Bott &
Roland Franz
Fraunhofer IVV, Freising, Germany

EURL-FCM training workshop "Science
collaborations behind safety in innovation
and policy developments

22nd September 2015, Ispra

 **Fraunhofer**
IVV



Agenda

- Overview and summary of experimental model studies on the migration potential of ‚nano additives‘ from food contact plastics
- Migration modeling for nanoparticles from plastics – some calculations and visualisations of their migratability
- A view into an EFSA Opinion
- Conclusions



Overview experimental model studies

We did a series of experimental studies (migration tests and other) using **LDPE polymer** (high diffusion properties, worst case matrix) containing ‘nano additives’ at various concentrations:

- **Nano-sized titanium nitride, TiN**
(listed in PIM – 20 ppm in PET)
- **Nano silver**
(has been used in numerous studies)
- **Carbon black**
(listed in PIM – 2.5% in polymer)
- **Synthetic amorphous silica (hydrophilic and silanated)**
(listed in PIM – no restriction)
- **Laponite**
(a very small nanoclay, still in hands, finished shortly)





Model system:

Nano titanium nitride (TiN) in LDPE

Bott J, Störmer A and Franz R., A model study into the migration potential of nanoparticles from plastics nanocomposites for food contact. Food Packaging and Shelf Life 2(2) 73-80 (2014). DOI: 10.1016/j.fpsl.2014.08.001.




Titanium nitride (TiN) in PET bottles for water and soft drinks – a very consumer relevant example

Technical function:

'Reheat additive' -
improves the thermal properties,
increase of production lots



Preforms
for PET bottles



Migration potential of NPs in food contact plastics



Model system: nano TiN in LDPE

Inhouse production of 3 different LDPE films (d = 60 µm) with TiN levels of

....0 ppm (blank), 100 ppm, 500 ppm, 1000 ppm

...using a masterbatch of nano TiN (20 nm) in LDPE



Fraunhofer
IVV


Migration potential of NPs in food contact plastics




Model system: nano TiN in LDPE

TEM images of the LDPE film with nano TiN at levels of

100 ppm in LDPE



1000 ppm in LDPE



Fraunhofer
IVV

Migration potential of NPs in food contact plastics



Model system: nano TiN in LDPE

Results migration test **10 d @ 60°C** (Ti determined by ICP-MS)

Test film (LDPE)	Food simulant	Ti migration [µg/dm²]	Ti migration [µg/kg]
100, 500, 1000 ppm	3% acetic acid	n.d. ≤ 0.040	≤ 0.24
100, 500, 1000 ppm	iso-octane	n.d. ≤ 0.017	≤ 0.11
100, 500, 1000 ppm	95% ethanol	n.d. ≤ 0.018	≤ 0.11
100, 500, 1000 ppm	0.2 % Novachem	n.d. ≤ 0.016	≤ 0.09



Migration potential of NPs in food contact plastics



Model system:

Nano silver in LDPE

Bott J, Störmer A, and Franz R, 2014. A comprehensive study into the migration potential of nano silver particles from food contact polyolefins. In: Chemistry of Food and Food Contact Materials: From production to plate. Benvenuto M A, Ahuja S, Duncan T V, Noonan G, Roberts-Kirchhoff E. Eds: ACS Symposium Series 1159, American Chemical Society, Washington DC, US. doi:10.1021/bk-2014-1159.ch005.



Migration potential of NPs in food contact plastics



Model system: nano silver in LDPE

Inhouse production of 3 different LDPE films (100 μm) with nano silver at levels of

....0 ppm (blank), 50 ppm, 185 ppm and 250 ppm

...using a commercial masterbatch of nano Ag in LDPE



Fraunhofer
IVV


Migration potential of NPs in food contact plastics



Model system: nano silver in LDPE

TEM images of the worst-case test material:

LDPE film (100 μm) with nano-silver at 250 ppm



Fraunhofer
IVV


Migration potential of NPs in food contact plastics



Model system: nano silver in LDPE

Silver migration from nano Ag LDPE films after 10 days @ 60°C

Comparison:
3% acetic acid
versus all
other simulants
(total silver
measured by
ICP-MS)



Fraunhofer
IVV


Migration potential of NPs in food contact plastics



Model system: nano silver in LDPE

Question: Is Ag as determined by ICP-MS nano Silver?

Test: AF4 analysis 1 ppm nano silver: silver rapidly dissolves to ions



Ag nanoparticles in 3 % acetic acid (orange, red) and water (blue, green) at RT.

In water 80 % of initial particles still present after 24 h.

Fraunhofer
IVV



Model system:

Carbon Black in LDPE and PS

Bott J., Stoermer A. and Franz R.: Investigation into the migration of nanoparticles from plastic packaging materials containing carbon black into foodstuffs. Food Additiv. Contam. Vol. 31 (10), 1769–1782 (2014). DOI: 10.1080/19440049.2014.952786.



Summary of all studies experimental results:

In **ALL** cases, migration studies even when using exaggerated contact conditions of food simulants with the test films, no analytical (ICP-MS, AF4) observation of migrated nanoparticles was obtained.

The achieved detection limits were dependent on the type of nano additive and ranged from 0.02 µg/dm² - 0.5 µg/dm² (0.12 µg/kg - 0.5 µg/kg food) and were in two other cases at 5 ppb and 130 ppb.





Migration modeling of nano particles from food contact plastics

Intention:

.... to support and substantiate our experimental results and other findings

.... to explore into the concentration range not accessible to analytical determinations




Migration modeling of nanoparticles

'Conventional' migration from FCM plastics can be modeled today ...

...when mass transport follows Fickian Law

$$\frac{\partial c}{\partial t} = D_p \frac{\partial^2 c}{\partial x^2}$$



Key-Parameter: Diffusion coefficient D_p & partition constant $K_{P/F}$

Migration potential of NPs in food contact plastics



Migration modeling of NPs for PET

JOURNAL OF Applied Polymer SCIENCE

A New Method for the Prediction of Diffusion Coefficients in Poly(ethylene terephthalate)

Frank Welle

Fraunhofer Institute for Process Engineering and Packaging IVV, Giggenhauser Straße 35, Freising 85354, Germany
Correspondence to: F. Welle (E-mail: welle@ivv.fraunhofer.de)

$$D_p = b \left(\frac{V}{c} \right)^{\frac{1}{d} - \frac{a}{T}}$$

Parameter	Value
a	$1.93 \cdot 10^{-3} \text{ K}^{-1}$
b	$2.37 \cdot 10^{-6} \text{ cm}^2 \text{ s}^{-1}$
c	11.1 Å^3
d	$1.50 \cdot 10^{-4} \text{ K}^{-1}$

Fraunhofer
IVV

Migration potential of NPs in food contact plastics



Migration modelling of nanoparticles - PET

$$D_p = f(\text{molecular volume})$$

JOURNAL OF Applied Polymer SCIENCE

A New Method for the Prediction of Diffusion Coefficients in Poly(ethylene terephthalate)

Frank Welle
Fraunhofer Institute for Process Engineering and Packaging IVV, Giggenhauser Straße 35, Freising 85354, Germany
Correspondence to: F. Welle (E-mail: welle@ivv.fraunhofer.de)




Figure 3. Correlation of the experimentally determined activation energy of diffusion E_A with the calculated volume of the migrants, red and green lines: variance of 20% on the molecular volume V . [Color figure can be




Figure 5. Correlation of literature of the diffusion coefficients in PET at 35°C and 40°C (Table 3 in Ref. 18) with the calculated molecular volume, black line: predicted diffusion coefficients from eq. (9), green and red line: variance of $\pm 20\%$ of the molecular volume V . [Color figure can be


Fraunhofer
IVV

Migration potential of NPs in food contact plastics



Migration modeling for PET - diffusion coefficients at 40°C

**Activation energy increases dramatically with d !
Diffusion coefficients become absurdly low!
=> No Migration**



d [nm]	V [nm³]	E _a [kJ/mol]	D _{PET} [cm²/s]
0,5	0,1	98,3	7,726E-13
1	0,5	213,6	1,9026E-20
2	4,2	328,8	4,737E-28
3	14,1	396,3	1,6834E-32
4	33,5	444,1	1,1731E-35
5	65,4	481,2	4,1752E-38
6	113,1	511,5	4,1686E-40
7	179,6	537,1	8,4808E-42
8	268,1	559,4	2,905E-43
9	381,7	578,9	1,4814E-44
10	523,6	596,5	1,034E-45
15	1767,1	663,9	3,6743E-50
20	4188,8	711,7	2,5605E-53
30	14137,2	779,1	9,099E-58
40	33510,3	827,0	6,3408E-61
50	65449,8	864,1	2,2568E-63

Migration potential of NPs in food contact plastics



Model study & migration modeling of nanoparticles

FOOD PACKAGING AND SHELF LIFE 2 (2014) 73–80

Available online at www.sciencedirect.com

ScienceDirect

journal homepage: <http://www.elsevier.com/locate/fpsl>

Recently published

CrossMark

A model study into the migration potential of nanoparticles from plastics nanocomposites for food contact

J. Bott*, A. Störmer, R. Franz

Fraunhofer Institute for Process Engineering and Packaging IVV, Giggenhauser Straße 35, 85354 Freising, Germany

Migration potential of NPs in food contact plastics



Migration modelling of nanoparticles - Polyolefines

For PO's a correlation between molecular volume and activation energy respectively diffusion coefficient as established for PET is not available.

⇒ Need of a different approach

IDEA:

- Surrogate Nanoparticles with worst case character: spheres consisting of a material with low molecular weight (m.w.) and assuming a low density
- Calculate m.w. as a function of diameter
- Calculate D_p as function of m.w. using the PIRINGER's equation (so-called 'exact equation')



Migration potential of NPs in food contact plastics



Migration modelling of nanoparticles - polyolefines


Edited by
Otto G. Piring and Albert L. Baner

WILEY-VCH

Plastic Packaging

$$D_{p,i} = D_u \exp(w_{i,e} - w_{p,e} \cdot 0.14(14j+2)^{2/3} - w_{j,e}^{2/3} T_{m,p} R/RT) \quad (6.28)$$

with $i = (M_{r,i} - 2)/14$
 $w_{i,e} = (1 + 2\pi/i)^{i/e}$, $j = (i^{1/3})$, $w_{j,e} = (1 + 2\pi/j)^{j/e}$, $p = (M_{r,p}/14)^{1/3}$, $w_{p,e} = (1 + 2\pi/p)^{p/e}$



PIRINGER equation (6.28):
 so-called 'exact' equation
 for Polyethylene < T_{mp}

$D_{p,i} = f(T, m.w._{Migrant}, m.w._{Polymer}, T(m.p.)_{Polymer})$




Migration potential of NPs in food contact plastics



Migration modeling of nano particles:

Example: 1000 ppm of NP (TiN)
in LDPE (d = 3 mm)
Contact: 10 days @ 40°C




Fraunhofer
IVV

Can nano particles migrate from FC plastics into foods?




Migration (10d@40°C) modeling of NPs (1000 ppm in LDPE)




Fraunhofer
IVV

Can nano particles migrate from FC plastics into foods?

Migration modelling - concentration profile: LDPE




Can nano particles migrate from FC plastics into foods?



Migration potential of NPs in food contact plastics



EFSA opinion on an additive (impact modifier in PVC) in nanoform



European Food Safety Authority

EFSA Journal 2014;12(4):3635

SCIENTIFIC OPINION

Scientific Opinion on the safety assessment of the substances (butadiene, ethyl acrylate, methyl methacrylate, styrene) copolymer either not crosslinked or crosslinked with divinylbenzene or 1,3-butanediol dimethacrylate, in nanoform, for use in food contact materials¹

EFSA Panel on Food Contact Materials, Enzymes, Flavourings and Processing Aids (CEF)^{2,3}

European Food Safety Authority (EFSA), Parma, Italy



Migration potential of NPs in food contact plastics



EFSA opinion on an additive (impact modifier in PVC) in nanoform

“Recognized migration modelling, as currently settled, is not directly applicable to nanoparticle migration estimation. For this reason, the applicant applied additional conservative assumptions to estimate migration of the nanoparticles from the nanocomposite material, in particular the assumption that all particles had a size less than 10 nm. The estimated migration was 1×10^{-6} mg/kg food.

Real migration, if any, is expected to be even lower and therefore consumer exposure would be very low, if any (Bott et al., 2014).

Consequently, **the Panel considered that the intended use of these nanoparticulate substances does not give rise to exposure of the consumer via food** and therefore would not be of toxicological concern if used only in rigid PVC individually or in combination up to a total of 10 % w/w and for the food contact applications described.”

Bott J, Störmer A, and Franz R, 2014. A comprehensive study into the migration potential of nano silver particles from food contact polyolefins. In: Chemistry of Food and Food Contact Materials: From production to plate. Benvenuto M A, Ahuja S, Duncan T V, Noonan G, Roberts-Kirchhoff E. Eds: ACS Symposium Series 1159, American Chemical Society, Washington DC, US. doi:10.1021/bk-2014-1159.ch005.





Conclusions

- Our migration studies did not show any evidence that NPs would migrate from the LDPE host polymer into food simulants even under very severe test conditions.
- Migration modeling indicates that NP larger than 3 - 4 nm in diameter cannot migrate (following Fick's law of diffusion) at all from LDPE and therefore not from any plastics FCM. For PET, the cut-off value would be below 1 nm. However, usual primary NPs are already larger. And, due to aggregation and agglomeration of NP such small single NP do not occur in FCM.



Conclusions

- Experimental results and theoretical considerations (migration modeling) strongly underpin the assumption that NPs are immobilised when fully incorporated in FCM plastics (no direct contact).

From this exposure of the consumer via ingestion can be excluded.

- Whether mechanical stress or strong interactions with foods (swelling) of the polymer surface may cause physical release should be considered in the particular case and be checked.





Thank you!

This work was supported by

- [PlasticsEurope](#)
- the Bavarian State Ministry of Environment and Public Health within the project 'LENA' on Nanotechnology related Food Safety coordinated by the Bavarian Authority for Public Health and Food Safety (LGL)
- [International Carbon Black Association ICBA](#)
- [Association of Synthetic Amorphous Silica Producers ASASP](#)

which is greatly acknowledged!


Many thanks also to Johannes Bott, our Ph.D. student who has done the experimental work including test sample preparations.

Page left blank intentionally

SAFE bread TIN: lowering energy and contaminants in bread and rusk tins - Dr. Ronan Cariou, ONIRIS



EURL-FCM training workshop "Science collaboration behind safety in innovation and policy developments"
22nd September 2015 | Ispra, Italy



Laboratoire d'Étude des Résidus et Contaminants dans les Aliments (LABERCA)
USC INRA 1329, Oniris, LUNAM Université
CS50707, 44307 Nantes Cedex 3, France - www.laberca.org

SAFE BREAD TIN

LOWERING ENERGY AND CONTAMINANTS IN BREAD AND RUSK TINS

Ronan CARIOU, PhD

Bruno VEYRAND, Gaud DERVILLY-PINEL,
Bruno LE BIZEC, Alain LE BAIL

Outline

1. Oniris

2. SAFE bread TIN project

3. LABERCA



Ronan CARIOU | EURL-FCM training workshop | 22nd September 2015 | Ispra, Italy

2/17

Oniris

Nantes Atlantic College of Veterinary Medicine, Food Science and Engineering

- Merging of Veterinarian and Agriculture Engineer schools



<http://www.oniris-nantes.fr/en/>



<http://www.laberca.org/>



<http://www.gepea.fr/>

- Process Engineering for Environment and Food
- Joint Research Unit between Oniris and École des Mines of Nantes (UMR CNRS 6144)



Ronan CARIOU | EURL-FCM training workshop | 22nd September 2015 | Ispra, Italy

3/17

Lowering energy and contaminants in bread and rusk tins



~1 060 000 €



Sustainable food systems call



Baking modelling

Coord.: Pf Alain LE BAIL

Baking modelling

Steering committee

C. Simoneau

SME
Industrial coatingIndustrial bread
manufacturerChemical analyses
(migrants)Rheology
Chemical analyses (Maillard)


Polymer science

Technology transfer center
Optical technologiesRonan CARIOU | EURL-FCM training workshop | 22nd September 2015 | Ispra, Italy

4/17

Lowering energy and contaminants in bread and rusk tins

- => Ageing of anti stick coating
- Bread depanning / stickiness
 - Chemical risk (neoformed, exogenous)
 - Non destructive sensors: detection of end of life
 - Innovative pan coating and process

Ronan CARIOU | EURL-FCM training workshop | 22nd September 2015 | Ispra, Italy

5/17

Establishment of the material and methods


- Reference baking test (recipe, geometry, etc.)

Industrial bread
manufacturer


- Pan index based on protocols for coating properties (tribology tests / surface scrapping, wettability, hardness, roughness, surface morphology, spectroscopy)



- Analysis of PFAS migrants




PFOS



PFOA




- Analysis of neoformed




Hydroxymethylfurfural



Furan



Acrylamide




Carboxymethyllysine



Ronan CARIOU | EURL-FCM training workshop | 22nd September 2015 | Ispra, Italy

6/17

- Automatic baking machine at pilot scale – accelerated ageing of pans



Miniaturized pans



Ronan CARIOU | EURL-FCM training workshop | 22nd September 2015 | Ispra, Italy

7/17



Baking process



- Heat transfer models needed to predict


Crust formation as fct of time-temperature

Relationship between coating structure and baking



- Baking studies

Bread properties



- Partial vacuum baking

Lower temperature

↳ Energy ↳ Migration ↳ Maillard




Ronan CARIU | EURL-FCM training workshop | 22nd September 2015 | Ispra, Italy

8/17

Crust pan interface

- Characterisation of coating ageing

Tribology, imaging, functionality



- Chemistry of the crust



- Prototype pans



Ronan CARIU | EURL-FCM training workshop | 22nd September 2015 | Ispra, Italy

9/17

Task 4: accelerated ageing at pilot scale (2000 cycles)

- Kinetic study (every 200 cycles)

Analysis of PFAS



Analysis of neoformed compounds



Analysis of coating (multispectral)



Crust evolution



Task 5: accelerated ageing at industrial scale (12 months)

Similar to Task 4, adjustments

Industrial bread manufacturer



Ronan CARIOU | EURL-FCM training workshop | 22nd September 2015 | Ispra, Italy

10/17

Task 6: Finalized solutions

- Coating and operation guide
- Equipment for ageing evaluation
- Equipment for crust assessment
- Guide for good practices for FCM undergoing thermal cycling



Task 7: Dissemination

- Various targets (industry, authorities, academic)

FINAL CONFERENCE – SATIN PROJECT

**NON STICK COATING IN THE BAKING INDUSTRY
TECHNOLOGICAL, CHEMICAL and REGULATORY ISSUES**

PARIS - 28-29 JUIN 2016

<http://satin-baking.fr/>



Ronan CARIOU | EURL-FCM training workshop | 22nd September 2015 | Ispra, Italy

11/17

Disclaimer




Pf Alain LE BAIL

alain.lebail@oniris-nantes.fr

Chemical nature of coating


- Resin by LC-HRMS
- Ethoxylate pattern

Ronan CARIOU | EURL-FCM training workshop | 22nd September 2015 | Ispra, Italy

12/17

LABERCA

~50 collaborators

Ronan CARIOU | EURL-FCM training workshop | 22nd September 2015 | Ispra, Italy

13/17



UPLC-MS/MS (x 1)



HPLC (x 2)



GC-MS (x 3)



LC-HRMSⁿ (x 3)



GC-MS/MS (x 2)



LC-MS/MS (x 2)



UPLC-IM-HRMS (x 1)



GC-HRMS (x 3)




GC-C-IRMS (x 3)



Ronan CARIOU | EURL-FCM training workshop | 22nd September 2015 | Ispra, Italy

14/17



*National Reference Laboratory (NRL)



Ronan CARIOU | EURL-FCM training workshop | 22nd September 2015 | Ispra, Italy

15/17


LABERCA

- Uninterrupted participation to EU projects (FP4 → FP7, ...H2020)

- National Research projects (ANR, ANSES, ANSM, PNRPE...)

- Support for public policies (ANSES, InVS...)

- Regional support for agribusiness sector



Ronan CARIU | EURL-FCM training workshop | 22nd September 2015 | Ispra, Italy

16/17

Acknowledgements



Financial support

The French National Research Agency



<http://www.laberca.org>
<http://www.saraf-educ.org>



ronan.cariou@oniris-nantes.fr

17/17

Page left blank intentionally

Why some migration conditions for plastics are not appropriate for other FCMs.

Peter Oldring

Representing numerous associations
directly or indirectly involved in FCMs

NRLs 22nd September 2015 JRC

Associations & Bodies participating in Initiative

▪ ACE	Beverage cartons
▪ APEAL	Steel for packaging
▪ CEFIC-FCA	Suppliers of food contact additives
▪ CEPE	Can coating manufacturers
▪ CEPI	Paper industry
▪ EAA	Aluminium
▪ EEA	Porcelain enamelled articles
▪ EMPAC	Rigid metal packaging
▪ ETRMA	Rubbers
▪ EuPIA	Printing inks
▪ EWF	Wax federation
▪ FEC	Housewares, all materials, non-stick for this work
▪ FEFCO	Corrugated packaging
▪ FEICA	Adhesives and sealants
▪ FPE	Multi-material flexible packaging
▪ GAE	Glass Alliance Europe
▪ CELIEGE	Cork
▪ CES Silicones Europe	Silicone elastomers
▪ INSTITUTE NEHRING	Test house
▪ JRC – as observers	

2

DISCLAIMER

- I am not an analyst.
- I cannot do analytical chemistry.
- However, I have to understand and work with – make decisions etc., – analytical data, in order to determine the safety of my company's products.
- The work is embryonic and associations are still joining and the final format will certainly be different to that initially envisaged, but as of yet we do not know how different.

3

The Issue - 1

- In the Plastics Regulation (10/2011) and supporting documentation, i.e. Migration Guidelines, some of the simulants, times and temperatures are inappropriate for non-harmonised FCMs (Food Contact Materials).
- However in the absence of harmonised regulations the conditions used in the Plastics Regulation are often applied to non-plastics.
- National Regulations for non-harmonised FCMs are tending to adopt the conditions in 10/2011 – example proposed coating regulations for both Netherlands and Belgium, although different in detail.

4

The Issue - 2

- Obtaining higher levels of migrants under inappropriate conditions may result in misinterpreting the results, particularly if the simulant, time and temperatures specified in 10/2011 cause deterioration or physico-chemical change of the substrate leading to an overestimation of migration compared to that in foodstuffs.

5

Industry response - 1

- Members of associations have formed a task to offer testing better adapted to the specificity of various materials/ sectors.
- JRC was requested to have an advisory capacity as they were responsible for leading the drafting of the technical guidelines for plastics (reg. 10/2011) and have currently a brief to look at non harmonised FCM
- Each sector is assessing the applicability or not of the plastics 10/2011 migration testing guidelines for their own sector.

6

Industry response - 2

- In some cases they are applicable for other FCM but in some cases they are not
- Gaps or lack of feasibility of implementations are identified and expertise collected and shared to offer technical solutions for improved compliance testing.
- Test proposals are based on technical / scientifically demonstrated justification.
- The Task Force are developing their own compliance guidelines with separate chapters for each non-harmonized FCM:

7

Industry response - 3

- Chapters
 - Introduction
 - FCM specific chapters
 - FPE
 - Adhesives
 - Light metal packaging
 - Paper & Board
 - Silicones
 - Rubbers & TPE
 - Coatings not covered elsewhere
 - Further sub-divided: work in progress

8

Industry response - 4

- Can – EMPAC / CEPE
- Heatseal – EuPIA / FEICA / FPE
- Coldseal - EuPIA / FEICA / FPE
- Coatings on plastic film CEPE (part)
- Non-stick – FEC / CEPE / CEFIC
- Coatings on Paper and board – CEPI / CITPA
- Heavy duty – CEPE
- Polymeric Coatings on glass – CEPE?
- Coatings on metal foil – FPE / CEPE
- Passivation coatings on metals - APEAL
- SOL-GEL Non-stick coatings – FEC
- Others

9

Industry response - 5

- Each FCM sector applies the common format for Material Specific Guidelines for Conformity Testing
- Scope
 - Uses
- Definitions
- Material Specific Properties to be considered when testing this class of FCM
 - Brief outline as to why plastic testing guidelines may be inappropriate

10

Industry response – 6

- Test Procedures
- Evaluation of test results
- Annexes
 - Annex 1: Reasons why plastic guidelines are not suitable for this class of FCM.
 - Annex 2: References
- The amount of detail in each sector's chapters will vary considerably, e.g. silicones are relatively specific to bake ware, whereas adhesives cover the majority of adhesives with different issues for different adhesives.

11

Industry response - 7

- During meetings, different FCM sectors found that other sectors had similar problems with some simulants, times or temperatures.
- There is still debate as to whether to tackle the subject substrate by substrate or material by material e.g. baking paper as paper or as fluoro-polymers, silicones etc.
- Some examples of the issues and proposed solutions follow.

12

Issues with 3% Acetic Acid for Overall Migration

13


3% Acetic Acid – 1

- A general issue common to many FCM sectors is the use of 3% acetic acid for overall migration (OM).
- OM is NOT a measure of safety, but of inertness.
- Acetic acid corrodes aluminium, either as a coated substrate or foil layer in a multi-layer FCM.

14

3% Acetic Acid - 2

- Two quite distinct processes are happening during the test
 - True **Migration** – a physical transfer of substances from the **organic** lacquer into the food simulant
 - **Corrosion** – a chemical reaction between acetic acid and the aluminium foil/substrate causing the formation of aluminium acetate and the release of aluminium ions into the food simulant



3% Acetic Acid – 3

- High test results can be obtained, because when the simulant is evaporated to dryness and the residue weighed, the residue is largely aluminium acetate salts
- This increases the weight of the residue, for example:
 - Aluminium molecular weight = 27
 - Aluminium triacetate molecular weight = 204
- Hence up to 87% of the measured result is due to the simulant, not to the aluminium (ions) released.

16

3% Acetic Acid – 4

- For FPE the overall migration from coated aluminium foil is their biggest issue.
- Coatings for rigid metal packaging also have a major issue with 3% acetic acid.
- The use of citric acid has been proposed, but this has the drawback that in practice it is not volatile enough for a gravimetric determination of overall migration by evaporation.

17

3% acetic acid – 5

- Proposals being investigated for FPE and coated rigid metal packaging include:
 - 3% acetic acid being used for the extraction, BUT only the chloroform soluble organic material is weighed.
 - ❖ Extract in 3% acetic acid, then mix chloroform with the extract, separate the phases and then evaporate the chloroform soluble part to dryness before weighing. Need to confirm that all of the organic material is extracted.
 - For can coatings the use of stainless steel panels and silver foil is being investigated in order to validate chloroform approach.

18

Issues with Olive Oil and Silicone Elastomers

19

Silicone Elastomers - 1

- Silicones are exempted from (EU) N° 10/2011 given that elastomers have different physico-chemical properties compared to plastics
- Problems for silicone elastomers arise mainly with compliance testing for baking moulds

Silicone Elastomers - 2

- Olive / vegetable oils contain components penetrating into the silicone elastomer matrix, which results in an overestimation of migration compared to real food. The same applies to its substitutes iso-octane and 95% ethanol.
- Absorbed oil must be removed by soxhlet extraction with a non-polar solvent, which may in turn cause additional extraction of components from the silicone, thereby skewing the results further from reality.

Silicone Elastomers - 3

- A proposed solution is to use Tenax which does not penetrate the silicone elastomer matrix.
- Tenax was an accepted substitute under Directive 97/48/EC but its use as a substitute under 10/2011, lacks clarity.
- Tenax also overestimates migration compared to normal bake ware (e.g. muffins, marble cake) but if the reduction factor of 5 is applied, the results are comparable to standard bake ware.

Silicone Elastomers - 4

- The most important criteria to determine suitability of silicone moulds for food contact is the limit for volatile substances (0.5%) as mandatory according to Recommendation XV of the BfR and the French legislation.
- In appropriately post-cured materials meeting the limit for volatiles <0.5% the majority of migrants consist of cyclic siloxanes with $M_w > 1000 \text{ Da}$ which according to present knowledge, are not expected to endanger human health.

Issues with 50% Ethanol

24

50% Ethanol - 1

- Some polyester based coatings show delamination and swell when tested under severe time/temperature conditions (e.g. 2 h 130 °C) with simulant D1 (50 % ethanol)
- The same polymeric coatings do not show any physical changes when they are in contact with milk products under equivalent sterilisation conditions.
- Overall migration tests and most specific migration tests cannot be carried out in milk products instead of simulants.

50% Ethanol - 2

- Proposal: Compliance of coatings which are not resistant to 50 % ethanol can be demonstrated by
 - decreasing testing time and/or temperature to a level where no physical changes of the coating film occur
 - or
 - migration testing with simulant A (10 % ethanol) and D2 (vegetable oil) rather than 50 % ethanol

Relationship between simulant results
and those in foodstuffs

Can Coating – example of food – 1

- A coating for metal packaging was needed for a range of foodstuffs with varying oily characteristics, from vegetables in oil to water/oil emulsions.
- Rather than use various simulants, including oil, 95% ethanol was used, as a worst case simulant to cover the range.
- 95% ethanol was an alternative to oil in Directive 97/48/EC, and although not in 10/2011, it is in revised Warenwet which would apply to coatings on rigid metal packaging.
- Customer also requested 95% ethanol.

28

Can Coating – example of food – 2

- The standard test protocol for 95% ethanol was 4 hrs @ 60° C (for sterilisation at 120 - 130° C), followed by 10 days at 40° C.
- Under the new conditions of 10/2011 and the Warenwet, the storage temperature is now 10 days @ 60° C, if these 'rules' are applied to non-plastics, which is common practice.
- Test results using 95% ethanol gave cause for further investigation.

29

Can Coating – example of food – 3

- The results of extraction of a monomer into 95% ethanol, 10 days @ 60°C, were compared to the levels in an aqueous / oily emulsion (D1 simulant in 10/2011) which was in packaging surrounded only by that coating.
- For comparison extraction into acetonitrile and hexane/acetone (1/1) (both 24 hrs @ ambient), gave values between 9 and 16 µg/6 dm².

30

Can Coating – example of food - 4

- The foodstuff was industrially processed and stored for 6 – 12+ months.
- 4 different batches of coating and packaging were used.
- The surface area to volume ratios (S/V) of the packaging was double the EU assumption of 1kg/6 dm² - given as corrected concentration using actual S/V ratios.

31

Can Coating – example of food - 5

- Foodstuff industrially filled and processed < LOD of 70 µg/kg.
- Results of extraction into 95% ethanol.

package sample	storage conditions	conc. (µg/6 dm ²)	corrected conc. µg/kg
1	1 day at 60°C	105	210
	10 days at 60°C	370	740
2	1 day at 60°C	128	256
	10 days at 60°C	386	772
3	1 day at 60°C	133	266
	10 days at 60°C	394	788
4	1 day at 60°C	139	278
	10 days at 60°C	318	636

32

Can Coating – example of food - 6

- Clearly, the results in 95% ethanol are completely different to that in food.
- Whilst hydrolysis maybe occurring in 95% ethanol, it is not in the presence of the foodstuff.
- Reaching a conclusion about the safety of the coating using the extraction data would give rise to arguably unnecessary concerns about the safety of the coating.

33

Acknowledgements

- All members of this task force for their inputs.
- In particular, for this presentation, Christa Burger, John Dixon, Beate Ganster, Catherine Simoneau, Richard Whitaker, Ulrich Nehring, Michelle Callow.

THANK YOU FOR YOUR ATTENTION




Exposure Matrix

packaging use data

Dario Dainelli, 22 September 2015

Background



Industry Exposure Projects

Matrix:

- Now available on-line:
www.matrixcalculation.eu
- Client-server, no need for downloading
- User friendly, trouble-free

FACET

What is www.matrixcalculation.eu ?

www.matrixcalculation.eu is a web-based tool for calculation of exposure to substances migrating from Food Contact Materials and Articles;

To be used in the exercise of Risk Assessment required by Article 19 of Reg. EU N0. 10/2011, in particular in relation to NIAS (Non Intentionally Added Substances) and NLS (Non-Listed Substances);

Represents a practical approach to enable risk management decided in a tiered way.



To be reminded:

Risk = Occurrence x Exposure

Exposure [$\mu\text{g}/\text{person}/\text{day}$] = Migration [$\mu\text{g}/\text{dm}^2$] x Surface [$\text{dm}^2/\text{person}/\text{day}$]

Surface distribution table

	Packaging mat.1	Packaging mat.2	Packaging mat. 3	Packaging mat. m
Food 1	D_{11}	D_{12}	D_{13}	D_{1m}
Food 2	D_{21}	D_{22}	D_{23}	D_{2m}
Food 3	D_{31}	D_{32}	D_{33}	D_{3m}
Food n	D_{n1}	D_{n2}	D_{n3}	D_{nm}

One more step

Tolerable Exposure Limit (TEL): if Exposure < TEL then Migration is trivial enough to avoid further assessment

Migration @ TEL = Level Of Interest (LOI), i.e. the level of migration below which no assessment is needed, but above which a risk assessment shall be done.

$$\text{LOI } [\mu\text{g}/\text{dm}^2] = \text{TEL } [\mu\text{g}/\text{person}/\text{day}] / S [\text{dm}^2/\text{person}/\text{day}]$$

May be set based on Cramer class, or may take other values depending on the level of risk that one wants to evaluate

Background of www.matrixcalculation.eu

The tool builds on the equation $\text{Exposure} = \text{Migration} \times \text{Surface}$

The term “Migration” is either an experimental value or a calculated one (worst-case or migration modelling)


The term “Surface” represents the 50%ile of Packaging/Food D-curves, for 5 countries (FR, DE, IT, UK, ES).

Each Surface table (for each Country) consists of 51 food classes and 77 packaging materials

sub basket	1 aluminium foil	2 paper	3 RCF (regenerated cellulose film)	4 Other mono-substrate plastic	5 Other monosubstrate non-plastic	6 VLDPE or LDPE and blends with LDPE	7 LDPE	8 acid+ester copolymers (E-VA, EMA, EAA, FBA)	9 other PE based blends	10 HDPE	11 multilayer PE	12 OPP	13 metallized OPP	14 other Pp	15 PA	16 PC	17 PET (CPET and APET)	18 non-expanded PS	19 expanded PS (EPS)	20 plasticized (soft) PVC and PVDC	21 non-plasticized (rigid) PVC and PVDC	22 APET/PE	23 plastic/APET/PE	24 OPE/PE
01. Alcoholic Beverages	0	0	0	0	0.982	0	0	0	0	0	0	0	0	0	0	0	0.002	0	0	0	0	0	0	0
02. Non-alcoholic beverages	0.005	0	0	0	0.29	0	0.001	0	0.031	0	0	0	0	0.004	0	0	1.839	0	0	0	0	0	0	0
03. Concentrates of juices	0	0	0	0	0.009	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
04. Liquid coffee or tea	0	0	0	0.041	0.02	0	0	0	0.001	0	0	0	0	0	0	0	0.129	0	0	0	0	0	0	0
05. Dry beverage powders	0	0.133	0	0	0.017	0	0	0	0.008	0	0	0	0	0.09	0	0	0.012	0	0	0	0	0	0	0
06. Breakfast cereals and bars	0	0	0	0.067	0	0	0.002	0	0	0	0	0.007	0	0.001	0	0	0	0	0	0	0	0	0	0.019
07. Cereal flour	0	0.2	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
08. Dough	0	0.006	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0.015	0.009	0
09. Bread	0	0.166	0	0	0	0.05	0.101	0.05	0.001	0.05	0.252	0	0.101	0	0	0	0	0	0	0	0	0	0	0.002
10. Dry rice and pasta	0	0.086	0	0	0	0	0.075	0	0.004	0	0.028	0	0	0	0	0	0	0	0	0	0	0	0	0.054
11. Fresh pasta	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0.001	0.002	0	0	0	0.022	0	0
12. Sweet biscuits	0	0.114	0	0	0.003	0	0	0	0	0	0.179	0.091	0.012	0	0	0	0.069	0.001	0	0	0.006	0	0	0
13. Savoury/salty biscuits	0	0	0	0	0	0	0	0	0	0	0.032	0.003	0	0	0	0	0	0	0	0	0	0	0	0.005
14. Potato crisps and potato snacks	0	0.012	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
15. Roasted and/or salted nuts	0	0	0	0	0.005	0	0	0	0	0	0.001	0	0	0	0	0	0.001	0	0	0	0	0	0	0.011
16. Sugar	0	0.118	0	0	0	0	0.002	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
17. Sugar confectionery	0	0.005	0.004	0.001	0	0	0	0	0	0	0.005	0.001	0.005	0	0	0	0	0	0	0.001	0	0	0	0.001

Proposed model for Risk Assessment

Risk characterization						
Very harmful	3	3	6	9		
Harmful	2	2	4	6		
No or slightly harmful	1	1	2	3		
		1	2	3		
		Low	Medium	High		
		Risk identification				



Steps for exposure assessment and risk assessment on a FCM

1. Decide conditions and simulant(s)
2. Migration test / analysis → chromatogram
3. ALTERNATIVELY: determine worst-case migration
4. Option: determine a LOI
5. Identify the substances for which Exposure needs to be calculated (exclude those in positive list, optionally exclude those below LOI)
6. Run www.matrixcalculation.eu and determine exposure
7. Use exposure in a Risk Assessment exercise

Deep dive into Matrix

- Overview
- Definition of food groups.
- Packaging description.
- Surface/volume ratio.
- Packaging use data for Germany.
- Packaging use data for UK, France, Italy, Spain.

Overview

- packaging use data for **DE, UK, FR, IT, ES** = 300 mio consumers
- intention to cover the entire diet (excluding dietary supplements)
- packaging use: consumer retail market
→ primary packaging, pre-packed foods
 - excludes over-the-counter sales and vending
 - DE: data purchased from the *Gesellschaft für Verpackungs-Marktforschung* (GVM)
 - UK/FR/IT/ES: data purchased from *EuroMonitor* (EM)
- covers all packaging materials, but most refined only for plastics 12

Definition of food groups

- 51 food groups
 - starting point = Re. 10/2011
 - some modifications to better reflect different packaging technologies used
e.g. distinction dry / liquid / refrigerated / frozen / preserve.
- GVM and EM in-house data uses their own food descriptions
 - these were mapped against the 51 food groups defined
 - some differences between GVM and EM mapping
 - document on mapping individual food items against in-house food groups is available from both institutes

13

1. alcoholic beverages including wines, beers and liquors	27. frozen fruits or frozen fruit pastes
2. non-alcoholic non-dairy beverages including waters, juices and soft drinks	28. fresh fish and seafood
3. concentrates of juices and soft drinks; syrups for dilution	29. processed fish and seafood products, excluding preserves and frozen
4. liquid coffee or tea preparations	30. fresh meat including poultry and game; fresh raw sausage
5. dry coffee, tea, cocoa powder, dry beverage powders	31. processed meat products, excluding preserves and frozen
6. cereals; cereal flakes or bars; breakfast cereals and muesli; pop-corn; seeds	32. preserves of fish, seafood, meat or preserves of processed fish, seafood, meat products
7. cereal flour and meal (including self-raising), starches	33. frozen meat, fish or seafood, unprocessed (frozen processed are in 47)
8. dough	34. eggs and processed (liquid, powdered or dried) egg fractions
9. bread including pizza bottoms, blinis, toasted bread etc.	35. liquid milk, flavoured milk drinks, milk concentrate, cream
10. dry rice and pasta without seasoning, including plain dried noodles	36. dried milk powder
11. fresh (uncooked) refrigerated pasta without seasoning	37. dairy products and preparations with or without fruit (fromage frais is in 38)
12. sweet biscuits, cakes, pancakes, pastry, including chocolate-coated	38. cheese
13. savoury/salty biscuits, crackers, crispbreads	39. ice-cream and frozen yoghurt
14. potato crisps, potato snacks, tortilla chips	40. fats and oils of animal or vegetable origin, including butter and margarine
15. roasted and/or salted nuts, and snack mixtures mainly composed of these	41. liquid oily sauces (mayonnaise, vinaigrette, salad dressings etc.)
16. sugar	42. liquid non-oily sauces (soy based sauces, pasta sauces, liquid stocks, etc.)
17. sugar confectionery	43. liquid soups (frozen are in group 47)
18. sugar-based syrups not for dilution; honey	44. herbs, spices, salt; powders for soups, sauces and desserts; stock cubes
19. chocolate spreads and syrups; peanut butter	45. vinegar, mustard, ketchup and other condiments
20. chocolate and chocolate confectionery	46. yeast and raising agents
21. fresh vegetables, green salads and lettuce, potatoes	47. prepared meals and meal components, frozen
22. vegetable preserves	48. prepared meals and meal components, refrigerated
23. frozen vegetables	49. prepared meals and meal components, dehydrated, including dried potato, vegetable
24. fresh fruit, whole or cut	50. prepared meals and meal components, preserves
25. dried fruit, nuts (excluding roasted and salted nuts), and mixtures of the two	51. infant formula and baby food
26. fruit preserves	

Definition of food groups

- GVM data
 - 348 in-house subsectors
 - these were aggregated to 62 subsectors
 - data reported in 51 sectors with 62 subsectors
- EM data
 - 156 in-house subsectors
 - data reported in 51 sectors with 156 subsectors

COUNTRY	SECTOR	SUBSECTOR
	Beverages	Bier
		Wine
		Fruit Juice
		...

Packaging description

A. Mono-substrate packaging materials

1. aluminium foil
2. paper
3. RCF (regenerated cellulose film)
4. other mono-substrate
 - 4.1. other mono-substrate plastic
 - 4.2. other mono-substrate non-plastic
5. monolayer PE
 - 5.1. VLDPE or LLDPE and blends with LDPE
 - 5.2. LDPE (density > 0.9)
 - 5.3. Acid + ester copolymers (EVA, EMA, EAA, EBA)
 - 5.4. HDPE
 - 5.5. Other PE based blends
6. multilayer PE
7. Polypropylene
 - 7.1. OPP
 - 7.2. metallized OPP
 - 7.3. other PP
8. PA
9. PC
10. PET (CPET & APET)
11. PS
 - 11.1. non-expanded PS
 - 11.2. EPS
12. PVC (& PVDC)
 - 12.1. plasticized (soft)
 - 12.2. non-plasticized (rigid)

B. Multi-substrate plastic packaging materials

- | | | |
|--------------------|----|----------------------------|
| 13. APET/PE | or | plastic/APET/PE |
| OPET/PE | or | plastic/OPET/PE |
| metallized-OPET/PE | or | plastic/metallized-OPET/PE |
| 14. PVC/PE | or | plastic/PVC/PE |

- | | | |
|---------------------------------|----|-----------------------------|
| 15. PA/PE | or | plastic/PA/PE |
| OPA/PE | or | plastic/OPA/PE |
| metallized-OPA/PE | or | plastic/metallized-OPA/PE |
| 16. OPP/PE | or | plastic/OPP/PE |
| PP/PE | or | plastic/other polyolefin/PE |
| 17. other plastic/PE | | |
| 18. OPP/OPP | or | plastic/OPP |
| OPP/metallized-OPP | or | plastic/metallized-OPP |
| PE/PP | or | other plastic/PE/PP |
| other plastic/PP | | |
| 19. plastic/PET | | |
| 20. PE/ionomer | | |
| other plastic/ionomer | | |
| 21. other plastic/other plastic | | |

C. Multi-substrate multi-material flexible packaging materials

- | | | |
|--|----|---|
| 22. aluminium/paper | or | aluminium/plastic/paper |
| plastic/aluminium/paper | or | plastic/aluminium/plastic/paper |
| 23. aluminium/paper/plastic | or | aluminium/plastic/paper/plastic |
| plastic/aluminium/paper/plastic | or | plastic/aluminium/plastic/paper/plastic |
| 24. aluminium/PE | or | aluminium/plastic/PE |
| plastic/aluminium/PE | or | plastic/aluminium/plastic/PE |
| 25. aluminium/plastic (non-PE) | or | plastic/aluminium/plastic (non-PE) |
| 26. paper/aluminium/plastic | or | paper/plastic/aluminium/plastic |
| plastic/paper/aluminium/plastic | or | plastic/paper/plastic/aluminium/plastic |
| 27. plastic/aluminium | | |
| paper/aluminium | or | paper/plastic/aluminium |
| plastic/paper/aluminium | or | plastic/paper/plastic/aluminium |
| 28. paper/plastic | or | plastic/paper/plastic |
| 29. other combination of non-plastic(s) and plastic(s) | | |

Packaging description

- food contact side is to the right
- classification based on “substrate” e.g. a film
the substrate itself may be mono-layer or multi-layer (co-extrusion).
- no split according to presence/absence of inks /coatings / adhesives.
- polymer types are generic unless otherwise indicated, for example:
 - in group 5 the “PE” is split according to copolymers;
 - in groups 6, 13-29 “PE” includes blends, co-extrusions and copolymers;
 - use of “other PE”, “other PP”, “other plastic”.

Packaging description

- 29 material groups defined with 77 subgroups
 - GVM and EM generated new data i.e. the split of their in-house data according to the required packaging descriptions
 - EM data reported at subgroup level
 - GVM data reporting
 - groups / subgroups maintained for plastics
 - 8 groups / 26 subgroups defined for plastic/non-plastic multilayers were aggregated back to 4 groups
 - 4 groups defined for non-plastic materials were aggregated back to 2 groups

18

Packaging description

- Multi-component packaging e.g. tray with lid, bottle with cap:
 - GVM distinguishes between
 - main pack
 - caps or other side materials
 - EM distinguishes between
 - main pack
 - side material (e.g. a lidding film on a tray)
 - cap (e.g. on a bottle or jar)
 - separator (e.g. insert between slides of ham)
 - EM data includes in-house classification of pack types.

19

I. Metal

1. Metal food can
2. Metal beverage can
3. Metal aerosol can
4. Metal tins
5. Aluminium container/tray
6. Collapsible metal tubes
7. Other metal
8. Kegs

II. Rigid plastic

1. Rigid plastic PET bottles
2. Rigid plastic HDPE bottles
3. Other plastic bottles
4. Rigid plastic jars
5. Other rigid plastic containers
6. Thin wall plastic containers
7. Rigid speciality cosmetics containers
8. Squeezable plastic tubes
9. Plastic trays
 - 9.a. Ready meal trays
 - 9.b. Other plastic trays

III. Glass

1. Glass bottles
2. Glass jars

IV. Liquid cartons

1. Gable-top liquid carton
2. Brick-shape liquid carton
3. Other shaped liquid cartons

V. Paper-based containers

1. Folding cartons
2. Composite containers/ tubes
3. Board tubs
4. Bag-in-box

VI. Flexible packaging

1. Stand-up pouches
 - 1.a. Plastic pouches
 - 1.b. Aluminium/plastic pouches
2. Flexible plastic
3. Aluminium foil
4. Flexible paper
5. Flexible aluminium/plastic
6. Flexible aluminium/paper
7. Flexible paper/plastic
8. Blister and strip packs

VII. Other packaging

20

Surface/volume ratio

- GVM in-house data includes S/V ratio from sample purchases
 - surface / food volume for most rigid packaging
 - surface / food weight for most flexible packaging
 - aggregated S/V calculated by most-frequent-value method
 - packaging area calculated from aggregated quantity of food packed and aggregated S/V

21

Surface/volume ratio

- EM in-house data does not include S/V ratio
 - primary data reported includes pack size (i.e. food content) and number of packs per pack size
 - we proposed a theoretical model to calculate S/V ratio based on pack size and on three geometric shapes:
 - “brick” shape, with 10% headspace
 - “bar” shape, with 25% headspace
 - “flat” shape with a volume-dependent ‘aspect ratio’ and with 50% headspace
 - EM assigned pack shape and calculated S/V and packaging area at the individual pack item level (*note: discuss bundle wrap*)

22

GVM packaging use data for DE

- primary in-house data from 2003
- data reported for 61 food descriptions against 54 packaging descriptions, each data point split between main/side
- types of data reported:
 - volume of food at aggregated food group level
 - surface/volume ratio
 - calculated packaging area
 - split between rigid and flexible packaging

23

EM packaging use data for UK/FR/IT/ES

- primary in-house data from 2005
- data reported for 156 food descriptions against 77 packaging descriptions
 - each data point split between main/side
 - additionally split per EM pack type
 - additionally split per pack size
 - → **8000 lines of data**
- types of data reported:
 - number of sales units for each pack size
 - volume of food for each pack size
 - calculated S/V ratio and packaging area

24

Conclusions

Access to raw data available if requested

Possible trainings if needed, organized by Associations

Presentation to DG Santé not done yet, but proposed

Already used by industry


Recommended to use to all stakeholders, including Control labs.

25

Back-up

26

OPP monolayer



TR	peak identification	qual	SEMIQUANTITATIVE EVALUATION ug/dm ²
12.22	BHT	98	45
13.86	Cyclohexadecane	91	11
14.16	Di propyl phthalate (internal standard)	94	12,5
14.83	7,9-Di-tert-butyl-1-oxaspiro(4,5)deca-6,9-diene-2,8-dione	98	13
15.51	Sebacic acid, dibutyl ester	91	84
16.14	Tributyl acetylacrylate	91	145
19.70	Erucamide	87	15

Identify the substances in positive list

- BHT (#315) : has an SML : 3 mg/kg, conc : 45 $\mu\text{g}/\text{dm}^2 \Rightarrow 45 \times 6 \mu\text{g}/\text{kg}^* \Rightarrow 0,27 \text{ mg}/\text{kg}$
- Sebacic acid dibutylester (#242) & tributyl acetyl citrate (#138), group SML (32) : 60 mg/kg $\Rightarrow 84 + 145 \mu\text{g}/\text{dm}^2 = 229 \mu\text{g}/\text{dm}^2 \Rightarrow 229 \times 6 \mu\text{g}/\text{kg} = 1,37 \text{ mg}/\text{kg}$
- Erucamide (#271) : has no SML (permitted additive to plastics used in food packaging) \Rightarrow max allowed migration: 60 mg/kg (art 11.2 of 10/2011) $\Rightarrow 15 \mu\text{g}/\text{dm}^2 \Rightarrow 0,09 \text{ mg}/\text{kg}$

Substances to be further assessed:

Cyclohexadecane (CAS 295-65-8),

7,9-di-tert-butyl-1-oxaspiro(4,5)deca-6,9-diene-2,8-dione (CAS 82304-66-3)

1. Use of QSAR to determine the Cramer Class:
 1. Cyclohexadecane (CAS 295-65-8) : Cramer class I – TTC of 1800 $\mu\text{g}/\text{person.day}$
 2. 7,9-di-tert-butyl-1-oxaspiro(4,5)deca-6,9-diene-2,8-dione (CAS 82304-66-3): Cramer class III - TTC of 90 $\mu\text{g}/\text{person.day}$
2. Use of www.matrixcalculation.eu to calculate exposure and benchmark with TTC (EXAMPLE)

Page intentionally left blank

4. List of participants



EUROPEAN COMMISSION
JOINT RESEARCH CENTRE

EURL FCM PLENARY MEETING AND TRAINING WORKSHOP
Participants Details - 21/09/2015 to 22/09/2015

TOTAL PARTICIPANTS: 29

BRADLEY EMMA

FERA

Sand Hutton

YO41 1LZ YORK

tel: +44 1904 462604

fax: +44 1904 462133

E-mail: emma.bradley@fera.co.uk

BUSTOS JUANA

CENTRO NACIONAL ALIMENTACION (CNA)-
Spanish Agency for Consumer Affairs, Food
Safety and Nutrition

Carretera Pozuelo-Majadahonda km 5

28220 MAJADAHONDA -MADRID (Spain)

tel: 0913380607

E-mail: JBustos@msssi.es

CARIOU RONAN

Oniris

Route de Gâchet

44307 NANTES (France)

tel: +33 2 40 68 78 80

E-mail: ronan.cariou@oniris-nantes.fr

CEDERBERG TOMMY LICHT

National Food Institute, Technical University of
Denmark

Mørkhøj Bygade 19

DK-2860 SØBORG (Denmark)

tel: +45 35 88 40 00

fax: + 45 35 88 40 01

E-mail: tlce@food.dtu.dk

CEPURNIEKS GUNTIS

Institute of Food Safety, Animal Health and
Environment "BIOR"

Lejupe 3

LV-1076 RIGA (Latvia)

E-mail: guntis.cepurnieks@bior.gov.lv

DAINELLI DARIO

European plastics Converters

ave de Cortenbergh 71

1000 BRUSSELS

E-mail: dario.dainelli@sealedair.com

DOMÁNY GÁBOR

Hungarina Food Chain Safety Office

Mester utca 81

H-1095 BUDAPEST (Hungary)

tel: +36-1-456-3010

fax: +36-1-215-6858

E-mail: domanyg@neh.gov.hu

EKROTH SUSANNE

National Food Agency

PO Box 622

SE-751 26 UPPSALA

tel: +46 733 54 53 47

fax: +46 18 10 58 48

E-mail: suek@slv.se



EUROPEAN COMMISSION
JOINT RESEARCH CENTRE

EURL FCM PLENARY MEETING AND TRAINING WORKSHOP
Participants Details - 21/09/2015 to 22/09/2015

HANUSOVA KRISTYNA

National Institute of Public Health, NRL for FCM
Šrobárova 48
100 42 PRAGUE (Czech Republic)
tel: +420267082317
E-mail: kristyna.hanusova@szu.cz

KAPPENSTEIN OLIVER

Federal Institute for Risk Assessment
BERLIN (Germany)
tel: 030184123428
E-mail: oliver.kappenstein@bfr.bund.de

KEEGAN JOHN

Public Analyst's Laboratory
Sir Patrick Dun's
D02 P667 DUBLIN (Ireland)
tel: +35316612022
fax: +35316628532
E-mail: John.Keegan@hse.ie

MERILÄINEN ARJA

Finnish Customs Laboratory
Tekniikantie 13
FI-02150 ESPOO (Finland)
tel: +358 40 3323249
E-mail: arja.merilainen@tulli.fi

MILANA MARIA ROSARIA

Istituto Superiore di Sanità
Viale Regina Elena 299
00161 ROMA (Italy)
tel: 0039 0649902608
fax: 0039 0649387068
E-mail: mariarosaria.milana@iss.it

OKHOLM BOLETTE

The Danish Veterinary and Food Administration
Soenderskovvej 5
8520 LYSTRUP (Denmark)
tel: +45 7227 6900
E-mail: book@fvst.dk

OLDRING PETER

Valspar
37, worcester Rd
OX7 5YF CHIPPING NORTON, OXON (United Kingdom)
tel: +44 7770 654178
E-mail: peter.olding@valspareurope.com

PARASKEVA VATYLIOTOU EVGENIA

State General Laboratory, Cyprus
44 Kimonos street
1451 NICOSIA (Cyprus)
tel: 0035722809172
fax: 0035722316434
E-mail: evatyliotou@sgl.moh.gov.cy

PAWLICKA MARZENA

National Institute of Hygiene
Chocimska 24
00-791 WARSAW
tel: +48 22 54 21 282
fax: +48 22 54 21 392
E-mail: mpawlicka@pzh.gov.pl

POLZ MARKUS

AGES
Spargelfeldstrasse 191
A-1226 VIENNA (Austria)
tel: +43 (0) 50555-35350
fax: +43 (0) 50555-35379
E-mail: markus.polz@ages.at



EUROPEAN COMMISSION
JOINT RESEARCH CENTRE

EURL FCM PLENARY MEETING AND TRAINING WORKSHOP
Participants Details - 21/09/2015 to 22/09/2015

SALAFRANCA JESUS
UNIVERSITY OF ZARAGOZA
C/ MARIA DE LUNA, 3 (EINA, TORRES QUEVEDO
BLDG.)
E-50018 ZARAGOZA (Spain)
tel: +34 976 762 628
E-mail: fjsl@unizar.es

SAUVEGRAIN PATRICK
LNE
Avenue Roger Hennequin
78125 TRAPPES
tel: +33130691293
fax: +33130691234
E-mail: patrick.sauvegrain@lne.fr

SCHUMMER CLAUDE
Laboratoire National de Sante - ALI
1, rue Louis Rech
3555 DUDELANGE (Luxembourg)
tel: +352 28100637
fax: +352 28100622
E-mail: claudeschummer@lne.etat.lu

SCHUPP BASTIAAN

E-mail: Bastiaan.SCHUPP@ec.europa.eu

STOERMER ANGELA
Fraunhofer IVV
Giggenhauser Str. 35
85354 FREISING
tel: +49(0)8161/491-720
fax: +49(0)8161/491-777
E-mail: angela.stoermer@ivv.fraunhofer.de

SVILPA GINTAUTAS
Public Health Surveillance Laboratory
Zolyno str. 36
LT - 10210 VILNIUS (Lithuania)
tel: +370 5 210 5492
fax: +370 5 210 4848
E-mail: gintautas.svilpa@nvspl.lt

SYĚOVÁ MILADA
European Commission (not JRC)
Zdravotni-cka 3
05952 POPRAD (Slovak Republic)
tel: 00421910912938
E-mail: pp.sycova@uvzsr.sk

TAMMEARU KRISTI
Health Board
Kotka 2
11315 TALLINN (Estonia)
E-mail: kristi.tammearu@terviseamet.ee

TOGKALIDOU TIMOKLEIA
General Chemical State Laboratory, Athens, Greece,
B' Division of Athens, B' Department
An. Tsocha 16
11521 ATHENS (Greece)
tel: 0302106479312

VANHOECK ELS
Scientific institute of public health
J. wytsmansstraat 14
B-1050 ELSENE
tel: +32 2 642 51 72



EUROPEAN COMMISSION
JOINT RESEARCH CENTRE

EURL FCM PLENARY MEETING AND TRAINING WORKSHOP
Participants Details - 21/09/2015 to 22/09/2015

fax: 0302106469755

E-mail: els.vanhoeck@wiv-isp.be

E-mail: timokleia@hotmail.com

VITRAC OLIMER

Institut National de la Recherche Agronomique

1 rue des Olympiades

91300 MASSY

tel: +33 1 69 93 50 63

fax: +33 1 69 93 51 85

E-mail: olivier.vitrac@agroparistech.fr

Europe Direct is a service to help you find answers to your questions about the European Union
Free phone number (*): 00 800 6 7 8 9 10 11
(*) Certain mobile telephone operators do not allow access to 00 800 numbers or these calls may be billed.

A great deal of additional information on the European Union is available on the Internet.
It can be accessed through the Europa server <http://europa.eu>

How to obtain EU publications

Our publications are available from EU Bookshop (<http://bookshop.europa.eu>),
where you can place an order with the sales agent of your choice.

The Publications Office has a worldwide network of sales agents.
You can obtain their contact details by sending a fax to (352) 29 29-42758.

JRC Mission

As the Commission's in-house science service, the Joint Research Centre's mission is to provide EU policies with independent, evidence-based scientific and technical support throughout the whole policy cycle.

Working in close cooperation with policy Directorates-General, the JRC addresses key societal challenges while stimulating innovation through developing new methods, tools and standards, and sharing its know-how with the Member States, the scientific community and international partners.

*Serving society
Stimulating innovation
Supporting legislation*

